


COMPACT DISC STEREO SYSTEM

KENWOOD

RXD-C2/L

SERVICE MANUAL

(UD-202 main unit)

Free service manuals
Gratis schema'sDigitized © 1994-10 PRINTED IN KOREA
B51-4991-00(K) 2706

www.freeservicemanuals.info




Photo is RXD-C2 M type.

*Refer to parts list on page 59.

PRECAUTIONS FOR REPAIR

- For the operation of the cassette mechanism, see Service Manual (B51-4869-00) of RXD-C3/C3L.

RXD-C2/L

CONTENTS/ACCESSORIES

SYSTEM CONFIGURATION	2	AJUSTES	
ACCESSORIES	2	CD sección	21
RECEIVER UNIT	4	CASSETTE DECK sección	23
CD PLAYER/ CASSETTE DECK UNIT	5	TUNER sección	25
REMOTE CONTROL UNIT	6	WIRING DIAGRAM	27
DISASSEMBLY FOR REPAIR	7	PC BOARD(Component Side View)	29
BLOCK DIAGRAM	9	SCHEMATIC DIAGRAM	35
CIRCUIT DESCRIPTION	11	EXPLODED VIEW(CD MECHANISM)	55
ADJUSTMENT		EXPLODED VIEW	
CD section	20	(CASSETTE DECK MECHANISM)	56
CASSETTE DECK section	22	EXPLODED VIEW(MAIN UNIT)	57
TUNER section	24	PARTS LIST	59
		SPECIFICATIONS	BACK COVER





System configuration

SYSTEM NAME	MAIN UNIT	SPEAKER
UD-202	RXD-C2/L	LS-C2

System carton box

Destination	Parts No.
M (Singapore mode)	H60-0284-04
M (Chinese made)	H60-0285-04
X (Singapore made)	H60-0286-04
Y	H60-0287-04

Accessories

AM loop antenna assy(1) (T90-0195-05)	FM indoor antenna(1) (T90-0182-15)	Antenna adaptor(1) (For U.K. and Europe) (T90-0198-05)	Remote control unit(1) (A70-1004-05) : RC-C2
			
	AC plug adaptor(1) (Except for the U.S.A., Canada, Mexico, Europe, U.K. and Australia) (E03-0115-05)	Batteries(R6/AA)(2)	Battery cover : (A09-0170-08)
Loop antenna stand (J19-3645-05)			
	For the unit with a European AC plug in areas other than Europe.		


Beware of condensation

When water vapor comes into contact with the surface of a cold material, condensation is produced. If condensation occurs, correct operation may not be possible, or the unit may not function correctly. This is not a malfunction, however, and the unit should be dried-out. (To do this, turn the POWER switch ON and leave the unit as it is for several hours.)

Be especially careful in the following conditions:

- When the unit is brought from a cold place to a warm place, and there is a large temperature difference.
- When a heater starts operating.
- When the unit is brought from an air-conditioned place to a place of high temperature with high humidity.
- When there is a large difference between the internal temperature of the unit and the ambient temperature, or in conditions where condensation occurs easily.

RXD-C2/L



Lock terminal board
(E20-0476-05)

Slide switch
(S62-0034-05)

Slide switch
(S31-2322-05)

Variable resistor
(R31-0002-05)

Phono jack
(E63-0115-15)

AC power cord*
(E30-)

Lock terminal board
(E70-0045-05)



Power cord bushing
(J42-0083-05)

Photo is RXD-C2 M type.

*Refer to parts list on page 59.

RXD-C2/L

RECEIVER UNIT

**1 POWER key**

Press to turn the power of the system ON/OFF.

2 DEMO key

Press to start demonstration.

3 Remote control light sensor**4 ACTIVE N.B. key****5 VOLUME CONTROL knob****6 ENTER key****7 LONG PLAY mode key**

Press to let the sound play for long hours.

8 ONE TOUCH EDIT key

Press for simplified CD recording.

9 PHONES jack

Insert headphones into this jack.

10 DIRECTION switch key**11 DUBBING keys (HIGH, NOR.)**

Press for tape dubbing.

12 Deck switch keys (A/B)

Press to select the deck to be operated.

13 DOLBY NR key**14 REC/ARM key****15 Input selector keys**

CD: Functions as the play/pause key.

TAPE: Functions as the play key. Pressing during playback changes the tape transport direction.

TUNER: Functions as the BAND key.

AUX: Press to play the AUX input source.

16 Skip (P.CALL) keys

CD: Function as the skip keys.

TAPE: Function as the skip key. to search the beginning of music programs.

TUNER: Function as the P.CALL keys.

When power is OFF: Used to adjust the clock or timer operation.

17 Stop (AUTO) key

CD, TAPE: Functions as the stop key.

TUNER: Functions as the AUTO key.

When power is OFF:

Activates the clock adjustment mode.

18 Fast winding (TUNING) keys

CD, TAPE: Function as the fast forward/backward keys.

TUNER: Function as the TUNING keys.


When power is OFF:

Used to set the timer.

19 MIC jack**20 MIC MIXING control knob**

RXD-C2/L

CD PLAYER/ CASSETTE DECK UNIT



1 Disc tray

2 OPEN/CLOSE key

3 PRESENCE key


Press for presence play.

4 EQUALIZER key

Press to select a graphic equalizer pattern.


5 REPEAT key

Press to play CD track(s) repeatedly.



Digitized by

www.freeservicemanuals.info



1 Deck A cassette holder


2 Deck B cassette holder

3 Deck A eject key

4 Deck B eject key

RXD-C2/L


REMOTE CONTROL UNIT




DISASSEMBLY FOR REPAIR

1. How to Remove Clamper


1. Remove the cabinet.
2. Remove both-sides-catchers of clamper ass'y and slide it backwards.
3. Lift the clamper ass'y.

**2. How to Remove Tray**


1. Turn power switch off after tray is open.
2. Remove screw (1).
3. Lift the tray (2).
4. Slide the tray frontwards and remove it (3).

**3. How to Mount Tray**


1. Slide slider fully rightwards and pull out tray gear frontwards (1).
2. Insert tray gear in slit of tray (2).
3. Set tray-back-groove to boss of slider (3).
4. Fix tray with screw (4).


**4. How to Replace Pickup**

1. Remove clamper ass'y and set tray-open.
2. Move pickup at center position of its all travel (1).
3. Turn rod stopper (2) and lift pickup ass'y (3).

**5. How to Open Tray when Tray Not Come Out**

1. Insert screw driver to left-side hole of mechanism ass'y.
2. Push slider rightwards.






RXD-C2/L

CIRCUIT DESCRIPTION

Microprocessor periphery block diagram




RXD-C2/L

CIRCUIT DESCRIPTION

CD microprocessor : μ PD78012BGC-652(X29 : IC204)

1. Pin connection diagram



N.C : PULL DOWN

RXD-C2/L

CIRCUIT DESCRIPTION

2. Pin description

Pin No.	Name	I/O	Description
1	MLCK	O	Signal processing IC clock
2	MDATA	O	Signal processing IC data
3	MLD	O	Signal processing IC latch
4	CDPW	O	Signal processing IC power regulation
5	ICRST	O	Signal processing IC reset
6	SSEL	O	Signal processing IC SSEL regulation
7	DMUTE	O	Digital mute
8	N.C	O	
9	Vss		
10	A/B	O	Deck regulation A/B switch
11	R/P	O	Deck regulation RECORD/PLAY
12	N/H	O	Deck regulation NORMAL/HIGH
13	NR	O	Deck regulation NOISE REDUCTION
14	ASEL	O	Deck regulation A SELECT
15	BSEL	O	Deck regulation B SELECT
16	RMUTE	O	Deck regulation REC MUTE
17	LMUTE	O	Deck regulation LINE MUTE
18	N.C	I	
19	N.C	I	
20	CLOSESW	I	Mechanism close switch
21	OPENSW	I	Mechanism open switch
22	N.C	I	Mechanism stop switch
23	N.C	I	Mechanism position switch
24	Vss		GND
25	SLTSW	I	Mechanism start limit switch
26	N.C	O	
27	CLOSEM	O	Close motor forward
28	OPENM	O	Open motor rewind
29	N.C	O	
30	N.C	O	
31	N.C	O	
32	DCOFF	O	DC servo ON/OFF control
33	N.C	O	
34	N.C	O	
35	RESET		Reset
36	UD202SW	I	UD202/UD302 choice H : UD202 L : UD302
37	SREQ	I	Microprocessor communications SREQ
38	SRDY	I	Microprocessor communications SRDY
39	BLKCK	I	Q Data synchronization clock
40	Vdd		+5V

RXD-C2/L

CIRCUIT DESCRIPTION

Pin No.	Name	I/O	Description
41	X2	O	Clock(8.38MHz)
42	X1	I	Clock
43	IC		GND
44	XT2		No use
45	DSP. DISC SW	I	Connect Vss H : DISC display
46	AVss		A/D GND
47	N.C	O	
48	N.C	O	
49	RESY	I	Spindle servo lock signal
50	CRC	I	Q data CRC check signal
51	TLOCK	I	Tracking lock signal
52	FLOCK	I	Focus lock signal
53	STAT	I	Signal processing IC status signal
54	SENSE	I	Signal processing IC sensing signal
55	AVdd		A/D power supply
56	AVref		A/D reference
57	RXDT	I	Microprocessor communications reception data
58	TXDT	O	Microprocessor communications transmission data
59	TRCLK	O	Microprocessor communications clock
60	MREQ	O	Microprocessor communications MREQ
61	N.C	O	
62	SUBQ	I	Q data
63	N.C	O	
64	SQCK	O	Q data clock

3. Test mode

1. CD test mode input method

While depressing the CD key, plug the power cord into an AC power outlet.

2. Operations after entering test mode

- When test mode is entered
 - a. The tray opens
- When the CD(PLAY) key is pressed while the tray is open
 - a. The tray closes
 - b. Tracks N01, 2, 32 play
 - c. STOP

3. How to clear test mode

- Turn off the power.
- Press the tray open/close key.

4. Description of keys


No	Key	Operation	Display
1	STOP	STOP operation Displays the automatic adjustment results The value of the F/T balance adjustment (in 256 increments) is converted to 1-9. NG : 1,9 The F/T gain is a multiple NG : F ≤ 2 , or ≥ 11 NG : T 0 or ≥ 7	Changes T NO :01→ T NO:00 Time display section 8 8 : 8 8 F T F T Balance Gain In NG, blinks
2	CD▶	PLAY operation PLAY tracks No,1, 2, 32	TNO : 05
3	REPEAT	Tracking off Sled off	TNO : 03
4	FF	PLAY track No.32	TNO : 02

RXD-C2/L

CIRCUIT DESCRIPTION

Receiver/Deck Microprocessor : M38197MA-088FP(X25 : IC1)

1. Pin connection diagram



RXD-C2/L

CIRCUIT DESCRIPTION

2. Key Matrix

	KEY RETURN 0 (44)	KEY RETURN 1 (43)	KEY RETURN 2 (42)	KEY RETURN 3 (41)
KS0(66)	POWER ON/STANDBY	—	DEMO	—
KS1(65)		REC/ARM	HIGH	NORMAL
KS2(64)	A/B	DIRECTION	DOLBY NR	ONE TOUCH EDIT
KS3(63)	PACK(A)	CrO ₂ (A)	PLAY(A)	F • REC • INH
KS4(62)	DSW 0	DSW 1	DSW 2	—
KS5(61)	—	—	—	CD • REPEAT
KS6(60)	DISC • SKIP	OPEN/CLOSE	LONG • PLAY	—
KS7(59)	PACK(B)	CrO ₂ (B)	PLAY(B)	R • REC • INH
KS8(58)	PRESENCE	EQUALIZER	ENTER	ACTIVE N.B
KS9(57)		■	◀◀	▶▶
KS10(56)	AUX	TAPE	TUNER	CD
KS11(55)	TEST	—	—	—

() is Pin No.

3. Pin description

Pin No.	Name	I/O	Description
1	A/D1(60Hz)	I	Spectrum analyzer 60 Hz analog input
2	A/D2(400Hz)	I	Spectrum analyzer 400 Hz analog input
3	A/D(2.7kHz)	I	Spectrum analyzer 2.7 kHz analog input
4	A/D4(16kHz)	I	Spectrum analyzer 16kHz analog input
5	A.MOTOR	O	A deck capstan motor regulation H: ON
6	A.SOL	O	A deck solenoid regulation H: ON
7	B.MOTOR	O	B deck capstan motor regulation H: ON
8	B.SOL	O	B deck solenoid regulation H: ON
9	$\overline{\text{SD}}$	I	Tuner SD input L: Tuned H: Not tuned
10	$\overline{\text{STEREO}}$	I	Tuner stereo input L: Stereo H: Mono
11	SELST	O	Selector IC (TC9614N) strobe output
12	DTMUTE	O	Selector IC (TC9614N) data mute
13	$\overline{\text{CD-RESET}}$	O	CD microprocessor reset signal output L: Reset
14	S-REQ	O	Slave transmission request signal output H: Request (For receiver ↔ microprocessor communications)
15	SRDY	O	Transmission signal possible signal output (For receiver ↔ microprocessor communications)
16	TRCLK	I	Communications clock input (For receiver ↔ microprocessor communications)
17	RVDT	O	Slave serial data output (For receiver ↔ microprocessor communications)
18	TXDT	I	Master serial data input (For receiver ↔ microprocessor communications)
19	$\overline{\text{SDA}}$	O	Surround IC (μPC1853) DATA output
20	CLOCK	O	Surround IC (μPC1853), Expander IC (M66310FP), PLL IC (LC7218), Selector IC (TC9164N) Clock output (common-use)

RXD-C2/L

CIRCUIT DESCRIPTION

Pin No.	Name	I/O	Description
21	DATA	O	Expander IC (M66310FP), PLL IC (LC7218), Selector IC (TC9164N) DATA output (common-use)
22	PLLCE	O	PLL IC (LC7218) CE output H: Enable L: Disable
23	PLLDO	I	PLL IC (LC7218) IF COUNT input
24	M66ST	O	Expander IC (M66310FP)strobe output
25	BIAS	O	Bias oscillation regulation H: Oscillation
26	DPSS(MS OUT)	I	DPSS (search) sensitivity input L: Detect between tracks H: Detect presence of tracks
27	B-PH	I	B deck photo sensor input
28	A-PH	I	A deck photo sensor input
29	M-REQ	I	Master transmission request signal output H: Request (For receiver ↔ microprocessor communications)
30	CE	O	Backup detection L: Backup H: Normal
31	PROTECT	I	Protection detection H: Protect ON L: Normal
32	REMOCON	I	Remote controller input
33	ENCODER B	I	Rotary encoder input B
34	ENCODER A	I	Rotary encoder input A
35	RESET	I	Reset signal input L: Reset
36	XCIN	I	Clock-use clock signal input 32kHz quartz crystal connected
37	XCOUT	O	Clock-use clock signal output 32kHz quartz crystal connected
38	XIN	I	Main clock input 8.38 MHz ceramic oscillator connected
39	XOUT	O	Main clock output 8.38 MHz ceramic oscillator connected
40	Vss		GND connector Connect to GND
41	KR3	I	Key return signal input 3
42	KR2	I	Key return signal input 2
43	KR1	I	Key return signal input 1
44	KR0	I	Key return signal input 0
45	MUTE	O	Mute regulation L: Mute ON H: Mute OFF
46	POWER	O	Power regulation H: Power ON L: Power OFF
47	G1	O	FL G1 grid drive connector
48	G2	O	FL G2 grid drive connector
49	G3	O	FL G3 grid drive connector
50	G4	O	FL G4 grid drive connector
51	G5	O	FL G5 grid drive connector
52	G6	O	FL G6 grid drive connector
53	G7	O	FL G7 grid drive connector
54	G8	O	FL G8 grid drive connector
55	S12	O	FL S12 segment drive connector and key scan signal output 11
56	S13	O	FL S13 segment drive connector and key scan signal output 10
57	S14	O	FL S14 segment drive connector and key scan signal output 9
58	S15	O	FL S15 segment drive connector and key scan signal output 8
59	S16	O	FL S16 segment drive connector and key scan signal output 7 (B deck common)
60	S17	O	FL S17 segment drive connector and key scan signal output 6
61	S18	O	FL S18 segment drive connector and key scan signal output 5
62	S19	O	FL S19 segment drive connector and key scan signal output 4 (Tuner dispatch)
63	S20	O	FL S20 segment drive connector and key scan signal output 3 (A deck common)

RXD-C2/L

CIRCUIT DESCRIPTION

Pin No.	Name	I/O	Description
64	S21	O	FL S21 segment drive connector and key scan signal output 2
65	S22	O	FL S22 segment drive connector and key scan signal output 1
66	S42	O	FL S42 segment drive connector and key scan signal output 0
67	S41	O	FL S41 segment drive connector
68	S40	O	FL S40 segment drive connector
69	S39	O	FL S39 segment drive connector
70	S38	O	FL S38 segment drive connector
71	S37	O	FL S37 segment drive connector
72	S36	O	FL S36 segment drive connector
73	S35	O	FL S35 segment drive connector
74	S34	O	FL S34 segment drive connector
75	S33	O	FL S33 segment drive connector
76	S32	O	FL S32 segment drive connector
77	S31	O	FL S31 segment drive connector
78	S30	O	FL S30 segment drive connector
79	S29	O	FL S29 segment drive connector
80	S28	O	FL S28 segment drive connector
81	S27	O	FL S27 segment drive connector
82	S26	O	FL S26 segment drive connector
83	S25	O	FL S25 segment drive connector
84	S24	O	FL S24 segment drive connector
85	S23	O	FL S23 segment drive connector
86	S11	O	FL S11 segment drive connector
87	S10	O	FL S10 segment drive connector
88	S9	O	FL S9 segment drive connector
89	S8	O	FL S8 segment drive connector
90	S7	O	FL S7 segment drive connector
91	VDD		Power supply input (+5V)
92	S6	O	FL S6 segment drive connector
93	S5	O	FL S5 segment drive connector
94	S4	O	FL S4 segment drive connector
95	S3	O	FL S3 segment drive connector
96	S2	O	FL S2 segment drive connector
97	S1	O	FL S1 segment drive connector
98	VEE	I	Pull-down power supply input (for FL) Connected to -30V
99	AVss	I	Analog power supply input Connected to GND
100	VREF	I	A/D converter reference voltage input Connected to +5V

CIRCUIT DESCRIPTION

4. Conditions by Description

Destination Type	Diode switches(DSW)			Band	Receiving frequency range	Interchannel space	Intermediate frequency	PLL reference frequency	PLL(X29 : IC2 LA7218) output port							
	DSW2 D43	DSW1 D40	DSW0 D39						⑨	⑩	⑪	⑫	⑬	⑭	⑮	
K1(1700)	0	0	0	FM	87.5~108.0MHz	100kHz	+10.7MHz	25kHz	m	i	H	L	H	H	H	
				AM	530~1700kHz	10kHz	+450kHz	10kHz	m	i	H	H	L	H	H	
K2(1610)	0	0	1	FM	87.5~108.0MHz	100kHz	+10.7kHz	25kHz	m	i	H	L	H	H	H	
				AM	530~1610kHz	10kHz	+450kHz	10kHz	m	i	H	H	L	H	H	
E1	0	1	1	FM	87.5~108.0kHz	50kHz	+10.7kHz	25kHz	m	i	H	L	H	H	H	
				AM	531~1602kHz	9kHz	+450kHz	9kHz	m	i	H	H	L	H	H	
E2(LW)	1	0	0	FM	87.5~108.0MHz	50kHz	+10.7MHz	25kHz	m	i	H	L	H	H	H	
				MW	531~1602kHz	9kHz	+450kHz	9kHz	m	i	H	H	L	H	H	
				LW	153~279kHz	9kHz	+450kHz	9kHz	m	i	H	H	L	H	H	
M	0	X	1	Change K2/E1 by setting "DSW1" only. (DSW1= 0:K2 Type ; 1:E1 Type)												

* Diode switch(DSWx) : 0=Without diode(in the case of static, LOW input)
1=With diode(in the case of static, HIGH input)
X=Transistor switch(0=OFF/ 1=ON)

* Here the PLL reference frequency is the value set in PLL, the AM division ratio becomes the same as the PLL reference frequency, but the FM division ratio is twice the PLL frequency.

* When the diode switch destination is different from this chart, it becomes the K1 destination.

PLL port

m= H: AUTO STEREO
L: MONO

i= H: IF SIGNAL ON
L: IF SIGNAL OFF

5. Initialization(Reset)

Insert the AC plug into the outlet while holding down the ENTER key of main unit.

Initial stage

	State	
SYSTEM	POWER	OFF
CLOCK PROG.	CLOCK	STOP(AM0:00)
	PROG. Operation MODE	OFF
	PROG.1 : ON=AM0:00	OFF=AM0:00
	MOD=PLAY	SOC=TUNER(1ch)
AMP	PROG.2 : ON=AM0:00	OFF=AM0:00
	MOD=PLAY	SOC=TUNER(1ch)
	VOLUME	7SEG=7(μPC1853 VOLdata=10)
	SELECTOR	TUNER
TUNER	EQ.	OFF
	PRESENCE	OFF
	LONG PLAY	OFF
	ACTIVE N.B.	OFF
	MUTING	OFF
	BAND	FM
TAPE	Each last BAND	
	FM : P.ch= - - ch	FREQ=min(76.0 or 87.5MHz)
	AM(MW) : P.ch= - - ch	FREQ=min(530 or 531kHz)
	LW : P.ch= - - ch	FREQ=min(153kHz)
CD	P.CH Memory 1ch~20ch	: Test frequency (Refer to Test Frequency)
	Tuning MODE	AUTO (AUTO STEREO)
	A/B Selector	B
	A Deck Head position	For FWD
REPEAT	B Deck Head position	For FWD
	DOLBY NR	OFF
	DIRECTION	ENDLESS
	DISC Selector	DISC 1
REPEAT	REPEAT	OFF

6. Test Frequency(Maker's Memory Frequency)

Destination PRESET	K		E	
	WIDE BAND	NARROW BAND	With LW	Without LW
1	FM 98.0MHz	FM 98.0MHz	FM 98.0MHz	FM 98.0MHz
2	FM108.0MHz	FM108.0MHz	FM108.0MHz	FM108.0MHz
3	AM 630kHz	AM 630kHz	AM 630kHz	AM 630kHz
4	AM 990kHz	AM 990kHz	AM 990kHz	AM 990kHz
5	AM 1440kHz	AM 1440kHz	AM 1440kHz	AM 1440kHz
6	AM 1610kHz	AM 1610kHz	AM 1602kHz	AM 1602kHz
7	AM 1700kHz	FM 87.5MHz	LW 162kHz	FM 87.5MHz
8	FM 87.5MHz	FM 87.5MHz	LW 216kHz	FM 87.5MHz
9	FM 87.5MHz	FM 87.5MHz	LW 270kHz	FM 87.5MHz
10	FM 89.1MHz	FM 89.1MHz	FM 89.1MHz	FM 89.1MHz
11	FM 87.5MHz	FM 87.5MHz	LW 279kHz	FM 87.5MHz
12	FM 90.0MHz	FM 90.0MHz	FM 90.0MHz	FM 90.0MHz
13	FM106.0MHz	FM106.0MHz	FM106.0MHz	FM106.0MHz
14	AM 530kHz	AM 530kHz	MW 531kHz	AM 531kHz
15	FM 87.5MHz	FM 87.5MHz	LW 153kHz	FM 87.5MHz
16	FM 97.5MHz	FM 97.5MHz	FM 97.5MHz	FM 97.5MHz
17	FM 98.5MHz	FM 98.5MHz	FM 98.5MHz	FM 98.5MHz
18	FM 87.5MHz	FM 87.5MHz	FM 87.5MHz	FM 87.5MHz
19	FM 87.5MHz	FM 87.5MHz	FM 87.5MHz	FM 87.5MHz
20	FM 87.5MHz	FM 87.5MHz	FM 87.5MHz	FM 87.5MHz

RXD-C2/L


ADJUSTMENT

CD section


No.	ITEM	INPUT SETTING	OUTPUT SETTING	PLAYER SETTING	ALIGNMENT POINTS	ALIGN FOR	FIG.
Remove the clamper ass'y before step 1. And remount it after step 1.							
1	LASER POWER	—	Set the sensor section of the optical power meter on the pickup lens.	With pressing the P.MODE key, turn the power on to enter the test mode. Press the "CHECK" key to check that the display is "03".	—	On the power from 0.08 to 0.15mW, when the diffraction grating is correctly aligned with the RF level of 1.0Vp-p or more.	(a)
Cancel test mode and open the tray to load the disc.							
2	FOCUS ERROR	Test disc Type 4	Connect an oscilloscope as follows. CN207 Connect hot side to RF(No.①) Connect Ground to VREF(No.②)	Press the PLAY key.	FE BALANCE VR201	Adjust the waveform to better point.	(b)

(Note) Type 4 disc : SONY YDS-18 Test Disc or equivalent.

(a) Laser power



(b)



- RF signal in test mode(PLAY).
- Perform the tangential and focusing offset adjustment so that each of the center cross points are focused into one point on the display. The crossing points above and below the center shall also be displayed clearly.


AJUSTES

CD sección


No	ITEM	AJUSTES DE ENTRADA	AJUSTES DE SALIDA	AJUSTES DEL SINTONIZADOR	PUNTOS DE CALIBRACIÓN	CALIBRA R EN	FIG.
Quite la brazadera antes del paso 1 y vuelva a montarla después del 1.							
1	POTENCIA DEL LÁSER	—	Coloque la sección del sensor del medidor de potencia óptica en la lente del captor.	Active la alimentación eléctrica al tiempo que oprime la tecla P.MODE para acceder a la modalidad de prueba. Oprima la tecla "CHECK" para comprobar que la indicación es "03".	—	A una potencia de 0,08 a 0,15mV, la rejilla de difracción debe estar correctamente alineada, con un nivel de RF de 1,0Vp-p o más.	(a)
Cancelar la modalidad de prueba y abrir la bandeja para cargar el disco.							
2	ERROR DE ENFOQUE	Probar el disco tipo 4.	Conectar un osciloscopio como sigue.CN207 Conectar RD(No①) al lado con corriente Conectar VREF(No④) a masa.	Oprimir la tecla PLAY.	EQUILIBRIO FE VR201	Ajustar al punto donde la forma de onda es óptima.	(b)

(Nota) : Disco tipo 4 : Disco de prueba SONY YDS-18 o equivalente.

(a) Potencia del láser



(b)



- Señal RD en modo de prueba(reproducción).
- Realizar los ajustes de desviación tangencial y de enfoque de manera que cada una de las crucetas centrals se enfoquen en punto de la pantalla. Las crucetas que están encima debajo del centro deben también indicarse con claridad.

RXD-C2/L

ADJUSTMENT

Cassette Deck section

No.	ITEM	INPUT SETTING	OUTPUT SETTING	DECK SETTING	ALIGNMENT POINTS	ALIGN FOR	FIG
Unless otherwise specified, set the respective switches as follows: TAPE : NORMAL DOLBY : OFF INPUT : AUX							
I. Cassette mechanism section(Recording/ play head adjustment)							
1	Degaussing and cleaning	—	—	Power : off, Degaussing, cleaning, PLAY	Recording heads, Erase heads, Capstans, Pinch rollers	Degauss the recording/play heads by a heads eraser. Clean the recording/play heads, erase heads capstans and pinch rollers by a cotton swab soaked with alcohol.	
2	Recording/play head azimuth	SCC-1727, TCC-153, MTT-144, 10kHz, -10dBs	(B)	PLAY	Azimuth adjustment screw	Maximize the output and adjust so that the Lissajous figure nears a line slanted 45°	
II. Printed circuit board adjustment Note : First perform the double-speed adjustment.							
1	Tape speed (double)	SCC-1727, TCC-110, MTT-144, 3kHz,	(B)	After normal play, always short the base side of Q7 to GND to set to high speed.	A DECK : VR7 B DECK : VR1	Adjust so that the frequency is 6 kHz at the tape center.	
2	Tape speed (normal)	SCC-1727, TCC-110, MTT-111, 3kHz,	(B)		A DECK : VR8 B DECK : VR2	Adjust so that the frequency is 3 kHz at the tape center.	
III. Printed circuit board adjustment(X28-2620-00)							
1	Play back level	MTT-150 400Hz	(B)	PLAY	A DECK : VR9(L) VR10(R) B DECK : VR3(L) VR4(R)	Set pins No.1(L ch) and No.4(R ch) of CN401 to -0.5dBs. Or, set pins No.8(L ch) and No.49(R ch) of IC 401 to 775mV.	
2	Bias current		(B)		B DECK : VR5(L) VR6(R)	Record 1kHz and 10kHz reciprocally, and adjust so that they are identical in playback level.	
3	Bias oscillating frequency	Load the non recorded tapes on Deck A and B.	Connect the frequency counter between E.H(+) & GND on Deck B.	REC	B DECK: L3	After confirming BEAT CANCEL OFF, adjust so that the frequency counter shows 105kHz.	

AJUSTES

Cassette Deck sección

Orden	Ítem	Ajuste de entrada	Ajuste de salida	Ajuste de la platina	Puntos de ajuste	MÉtodo de ajuste	Fig.
A menos que se indique lo contrario, ajustar los interruptores respectivos de la manera siguiente: TAPE: NORMAL DOLBY: OFF INPUT: AUX							
I. Sección del mecanismo de la cassette (ajuste de la cabeza de grabación/reproducción)							
1	Desmagneti- zación y limpieza	—	—	Alimentación: apagado, desmagnetización, limpieza, reproducción	Cabezas de grabación, cabezas de borrado, ejes de arrastre, rodillos presores	Desmagnetizar las cabezas de grabación/reproducción con un borrador de cabezas. Limpiar las cabezas de grabación/ reproducción, cabezas de borrado, ejes de arrastre y rodillos presores con un bastoncillo de algodón humedecido en alcohol.	
2	Acimut de la cabeza de grabación/ reproducción	SCC-1727, TCC-153, MTT-144, 10kHz, -10dBs	(B)	REPRODUCCIÓN (PLAY)	Tornillo de ajuste del acimut	Maximizar la salida y ajustar de manera que la forma de Lissajous se aproxime a una línea inclinada 45°	
II. Ajuste de la tarjeta de circuito impreso Nota: Efectuar primero el ajuste de la velocidad doble.							
1	Velocidad de la cinta (doble)	SCC-1727, TCC-110, MTT-144, 3kHz	(B)	DespuÉS de la reproducción normal, cortocircuitar siempre la base de Q7 con masa (GND) para ajustarlo en alta velocidad.	PLATINA A: VR7 PLATINA B: VR1	Ajustar de manera que la frecuencia sea de 6 kHz en el centro de la cinta.	
2	Velocidad de la cinta (normal)	SCC-1727, TCC-110, MTT-111, 3kHz	(B)		PLATINA A: VR8 PLATINA B: VR2	Ajustar de manera que la frecuencia sea de 3 kHz en el centro de la cinta.	
III. Ajuste de la tarjeta de circuito impreso (X28-2620-00)							
1	Nivel de reproducción	MTT-150 400Hz	(B)	REPRODUCCI"IN (PLAY)	PLATINA A: VR9 (IZQ.) VR10 (DCH.) PLATINA B: VR3 (IZQ.) VR4 (DCH.)	Ajustar los contactos n°1 (canal izq.) y n° 4 (canal dch.) de CN401 en -0,5 dBs. O ajustar los contactos n° 8 (canal izq.) y n° 49 (canal dch.) de IC401 en 775 mV.	
2	Corriente de polarización		(B)		PLATINA B: VR5 (IZQ.) VR6 (DCH.)	Grabar 1 Mhz y 10 kHz recíprocamente, y ajustar de manera que sean idÉnticos en el nivel de reproducciÚn.	
3	FRECUENCIA DE OSCILACIÓN DE LA POLARIZACIÓN	Cargar las cintas sin grabar en las platinas A y B.	Conectar el contador de frecuencias entre E.H.(+) y masa de la platina B.	GRABACIÓN (REC)	PLATINA B: L3	Después de confirmar que la cancelación de batido (BEAT CANCEL) est- desactivada, ajustar de manera que el contador de frecuencias indique 105 kHz.	

RXD-C2/L

ADJUSTMENT

TUNER section

M.X.R, I Type (X29-249X)

No.	ITEM	INPUT SETTING	OUTPUT SETTING	TUNER SETTING	ALIGNMENT POINTS	ALIGN FOR	FIG.
FM SECTION		BAND : FM					
1	DISTORTION (STEREO)	(C) 98.0MHz 1kHz, ± 68.25 kHz dev Pilot : ± 7.5 kHz dev 60 dB μ (ANT input)	(B)	AUTO 98.0MHz	IFT (W02-)	Minimum distortion.	

E.T.G Type (X29-248X)

No.	ITEM	INPUT SETTING	OUTPUT SETTING	TUNER SETTING	ALIGNMENT POINTS	ALIGN FOR	FIG.
FM SECTION		BAND : FM					
1	DISCRIMINATOR	(A) 98.0MHz 1kHz, ± 75 kHz dev 60 dB μ (ANT input)	Connect a DC voltmeter between TP3 and TP4. (X05-)	AUTO or MONO 98.0MHz	L3 (X05-)	0V	(c)
2	DISTORTION (STEREO)	(C) 98.0MHz 1kHz, ± 68.25 kHz dev Pilot : ± 7.5 kHz dev 60 dB μ (ANT input)	(B)	AUTO 98.0MHz	IFT (W02-)	Minimum distortion.	
3	SEPARATION	(C) 98.0MHz 1kHz, ± 40 kHz dev Pilot : ± 6 kHz dev Selector : L or R 60 dB μ (ANT input)	(B)	AUTO 98.0MHz	VR3 (X29-)	Minimum crosstalk.	
4	TUNING LEVEL	(C) 98.0MHz 1kHz, ± 75 kHz dev 14dB μ (ANT input) 75 Ω 18dB μ (ANT input) 300 Ω	(B)	AUTO or MONO 98.0MHz	VR1 (X29-)	Adjust VR1 and stop at the point where FL201(TUNED) goes ON.	
AM SECTION		BAND : AM(MW)					
1	TUNING LEVEL	(D) 1008MHz 400Hz, 30% mod 26 dB μ (ANT input)	(B)	1008 kHz	VR2 (X29-)	Adjust VR2 and stop at the point where FL201(TUNED) goes ON.	

AJUSTES

TUNER sección

Tipo M.X.R, I (X29-249X)

No	ITEM	AJUSTES DE ENTRADA	AJUSTES DE SALIDA	AJUSTES DEL SINTONIZADOR	PUNTOS DE CALIBRACIÓN	CALIBRA R EN	FIG.
SECCIÓN DE FM		BANDA: FM					
1	DISTORSIÓN (ESTÉREO)	(C) 98,0 MHz 1 kHz, $\pm 68,25$ kHz desv. Piloto: $\pm 7,5$ kHz desv. 60 dB μ (entrada ANT)	(B)	AUTO 98,0 Mhz	IFT (W02-)	Distorsión mínima	


Tipo E.T.G(X29-248X)

No	ITEM	AJUSTES DE ENTRADA	AJUSTES DE SALIDA	AJUSTES DEL SINTONIZADOR	PUNTOS DE CALIBRACIÓN	CALIBRA R EN	FIG.
FM SECTION		BAND : FM					
1	DISCRIMINADOR	(A) 98,0 MHz 1 kHz, ± 75 kHz desv. 60 dB μ (entrada ANT)	Conectar un voltímetro de CC entre TP3 y TP4. (X05-)	AUTO o MONO 98,0 MHz	L3 (X05-)	0V	(c)
2	DISTORSIÓN (ESTÉREO)	(C) 98,0 MHz 1 kHz, $\pm 68,25$ kHz desv. Piloto: $\pm 7,5$ kHz desv. 60 dBm (entrada ANT)	(B)	AUTO 98,0 MHz	IFT (W02-)	Distorsión mínima	
3	SEPARACIÓN	(C) 98,0 MHz 1 kHz, ± 40 kHz desv. Piloto: ± 6 kHz desv. Selector: L o R 60 dBm (entrada ANT)	(B)	AUTO 98,0 MHz	VR3 (X29-)	Diafonía mínima	
4	NIVEL DE SINTONA	(A) 98,0 MHz 1 kHz, ± 75 kHz desv. 14 dB μ (entrada ANT) 75 Ω 14 dBm(entrada ANT) 300 Ω	(B)	AUTO o MONO 98,0 MHz	VR1 (X29-)	Ajustar VR1 y parar en el punto donde se activa FL201 (TUNED)	
SECCIÓN DE AM		BANDA: AM (OM)					
1	NIVEL DE SINTONA	(D) 1008 kHz 400 Hz, 30% mod. 26 dB μ (entrada ANT)	(B)	1008 kHz	VR2 (X29-)	Ajustar VR2 y parar en el punto donde se activa FL201 (TUNED)	

RXD-C2/L

ADJUSTMENT

(c)




REC output : for X29 L ch, connect CN401 pin 1 to GND;
for X29 R ch, connect CN401 pin 4 to GND.

Salida de REC : X29 canal izp., Conectar CN401
contactos nº 1 a masa.
X29 canal dch., Conectar CN401
contactos nº 4 a masa.


RXD-C2/L RXD-C2/L

WIRING DIAGRAM





PC BOARD(Component side view)

DISPLAY UNIT(X25-559X-XX)
RECORD/PLAYBACK UNIT(X28-2620-00)



FRONT







32

PC BOARD(Component side view)


MAIN UNIT- TUNER(X29-2532-70) : E, G, T TYPE



X29-2520-XX (Y, M, X TYPE) TUNER



X29-2532-70 (T, E, G TYPE) TUNER




CAUTION: For continued safety, replace safety critical components only with manufacturer's recommended parts (refer to parts list). Δ Indicates safety critical components. To reduce the risk of electric shock, leakage-current or resistance measurements shall be carried out (exposed parts are acceptably insulated from the supply circuit) before the appliance is returned to the custom-World of free manuals


DC voltages are as measured with a high impedance voltmeter. Values may vary slightly due to variations between individual instruments or/and units.

Les tensions c.c. doivent être mesurées avec un voltmètre à haute impédance. Les valeurs peuvent différer légèrement du fait des variations inhérentes aux appareils et aux instruments de mesure individuels.

Die angegebenen Gleichspannungswerte wurden mit einem hochohmigen Spannungsmesser gemessen. Dabei schwanken die Meßwerte aufgrund von Unterschieden zwischen einzelnen Instrumenten oder Geräten u. U. geringfügig.








CAUTION: For continued safety, replace safety critical components only with manufacturer's recommended parts (refer to parts list). ⚠ Indicates safety critical components. To reduce the risk of electric shock, leakage-current or resistance measurements shall be carried out (exposed parts are acceptably insulated from the supply circuit) before the appliance is returned to the customer.

RXD-C2/L
KENWOOD



RXD-C2/L

PARTS LIST

No.3

* New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnés dans le Parts No. ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

Ref. No. 参照番号	Address 位置	Parts No. 部品番号	Description 部品名 / 規格	Desti- nation 仕	Re- marks 備考
X2		L77-2111-05	CRYSTAL RESONATOR (32.768KHZ)		
R100		RS14KB30821J	FL-PR00F RS 820 J 2W		
W210		RS14KB3A221J	FL-PR00F RS 220 J 1W		
		R92-0670-05	CHIP R 0 OHM		
S1 -10		S40-1064-05	PUSH SWITCH		
S14		S40-1064-05	PUSH SWITCH		
S16		S40-1064-05	PUSH SWITCH		
S17		S40-1064-05	PUSH SWITCH		
S19 -30		S40-1064-05	PUSH SWITCH		
S32		S31-2322-05	SLIDE SWITCH		
		T99-0548-05	SPEED DETECTOR		
S31		HZ52-7N(B2)	ZENER DIODE		
D3		RD2-7ES(B2)	ZENER DIODE		
D3		HZ35-6N(B2)	ZENER DIODE		
D4		RD5-6ES(B2)	ZENER DIODE		
D4		HSS104A	DIODE		
D5		ISS131	DIODE		
D7		HSS104A	DIODE		
D7		ISS131	DIODE		
D8		MA111	DIODE		
D9 -18		HSS104A	DIODE		
D9 -18		ISS131	DIODE		
D20 -21		HSS104A	DIODE		
D20 -21		ISS131	DIODE		
D38 -39		MA111	DIODE		
D39 -41		MA111	DIODE		
D41		MA111	DIODE		
D42		HSS104A	DIODE		
D42		ISS131	DIODE		
D43		MA111	DIODE		
D44		HZ55-6N(B2)	ZENER DIODE		
D44		RD5-6ES(B2)	ZENER DIODE		
D51		MA111	DIODE		
D51 -59		MA111	DIODE		
ED1		F1F6QW5R	INDICATOR TUBE		
IC1		M38197MA-088FP	MOS-IC		
IC2		M66310FP	MOS-IC		
IC3		XR-1091ECP	IC(GE FILTER)		
IC4		BA10393F	IC		
IC5		S-80740AL	IC(VOLTAGE DETECTOR)		
Q1		2SC2412K	TRANSISTOR		
Q2		2SA1037K	TRANSISTOR		
Q3 -6		2SC2412K	TRANSISTOR		
Q7		DT124EU	DIGITAL TRANSISTOR		
Q8		2SA1037K	TRANSISTOR		
Q9 -16		DT124EU	DIGITAL TRANSISTOR		
Q17 ,18		DT124EU	DIGITAL TRANSISTOR		
A1		W02-1046-05	ELECTRIC CIRCUIT MODULE		
A1		W02-1174-05	ELECTRIC CIRCUIT MODULE		

RECORD/PLAYBACK UNIT(X28-2620-00)

No.2

* New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnés dans le Parts No. ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

Ref. No. 参照番号	Address 位置	Parts No. 部品番号	Description 部品名 / 規格	Desti- nation 仕	Re- marks 備考
-		H50-1362-04	ITEM CARTON CASE		
645	1H	J19-2808-05	HOLDER		
646	1F	J19-3645-05	ANTENNA STAND		
647	1H	J42-0083-05	POWER CORD BUSHING		
		J61-0035-05	WIRE BAND		
651	1G, 2G	K29-6026-03	KN0B (SELECTOR, EQ)		
652	2G	K29-6027-03	KN0B (OPERATION)		
653	1F, 1G	K29-6028-03	KN0B (POWER, FUNCTION)		
654	2G	K29-6029-02	KN0B (OPER, CL0, REP, ACTIVE, NB)		
655	2F	K29-6030-04	KN0B (EJECT)		
656	2F	K29-6031-04	KN0B (EJECT)		
657	2F	K29-6032-04	KN0B (VOLUME CONTROL)		
658	2F	K29-6033-04	KN0B (MIC MIXING)		
665	2H	L07-1831-05	POWER TRANSFORMER		
665	2H	L07-1834-05	POWER TRANSFORMER		
665	2H	L07-1835-05	POWER TRANSFORMER		
670	1A	T90-0182-15	LEAD WIRE ANTENNA		
671	1A	L00P ANTENNA	LOOP ANTENNA		
672	1A	T90-0195-05	ANTENNA ADAPTOR		

DISPLAY UNIT(X25-559X-XX)

D22 -25		B30-2462-05	LED(GRN)		
D26 -30		B30-2463-05	LED(TWIN VRPG 561)		
D31 -36		B30-2462-05	LED(GRN)		
C1		C90-3210-05	ELECTR0 22UF		
C2		CK73FB1H223K	CHIP C 0.022UF		
C3		CK73FSL1H102J	CHIP C 1000PF		
C4		C90-3210-05	ELECTR0 22UF		
C5		CK73FB1H223K	CHIP C 0.022UF		
C6		C90-3214-05	ELECTR0 100UF		
C9		CK73FB1H223K	CHIP C 0.022UF		
C15		CK73FB1H103K	CHIP C 0.010UF		
C20		C90-1827-05	ELECTR0 0.047UF		
C21		CK73FF1C105Z	CHIP C 1.0UF		
C22		CK73FB1H103K	CHIP C 0.010UF		
C23 ,24		C90-3253-05	ELECTR0 1UF		
C26		CK73FCH1H220J	CHIP C 22PF		
C27		CK73FCH1H180J	CHIP C 18PF		
C30		C90-3214-05	ELECTR0 100UF		
C32		C90-3214-05	ELECTR0 100UF		
C35		CK73FB1H223K	CHIP C 0.022UF		
C36		C90-3253-05	ELECTR0 1UF		
C41 ,42		CK73FCH1H221J	CHIP C 220PF		
C43		CK73FB1H102K	CHIP C 1000PF		
C44 -46		CK73FF1C105Z	CHIP C 1.0UF		
C47 ,48		CK73FB1E104K	CHIP C 0.100UF		
F1		F06-2021-05	FUSE (SEMK0) (250V T2AL)		
F6		F06-2021-05	FUSE (SEMK0) (250V T2AL)		
CN8 -11		J19-3719-03	HOLDER		
L1 ,2		J13-0075-05	FUSE CLIP		
X1		L40-1011-17	SMALL FIXED INDUCTOR(100UH, K)		
		L78-0605-05	RESONATOR (8.39MHZ)		

L:Scandinavia
Y:PX(Far East, Hawaii)
Y:AFES(Europe)

K:USA
T:England
X:Australia

P:Canada
E:Europe
M:Other Areas

R:Mexico
G:Germany
M:Other Areas

H: Chinese made

A: A DECK
B: B DECK

△ indicates safety critical components.

RXD-C2/L

PARTS LIST

* New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnés dans le Parts No. ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

No.5

Ref. No. 参照番号	Address 位置	New Parts 部品新	Parts No. 部品番号	Description 部品名 / 規格	Desti- nation 仕向備考
MAIN UNIT-TUNER(X29-2520-XX) : Y, M, X TYPE					
C1 , 2			CK73FB1H103K	CHIP C	0.010UF K
C4			CE04LW1A470M	ELECTRØ	47UF 10WV
C5			CK73FB1H103K	CHIP C	0.010UF K
C8			CK73FB1H103K	CHIP C	0.010UF K
C10			CK73FB1H102K	CHIP C	1000PF K
C11			CE04LW1H470M	ELECTRØ	4.7UF 50WV
C13			CE04LW1H101M	ELECTRØ	1.0UF 50WV
C14			CE04LW1H2R2M	ELECTRØ	2.2UF 50WV
C21 , 22			CQ95FNG1H163J	MYLAR	0.016UF J
C23			CE04LW1H010M	ELECTRØ	1.0UF 50WV
C24			CE04LW1H3R3M	ELECTRØ	3.3UF 50WV
C25			CE04LW1V100M	ELECTRØ	10UF 35WV
C27			CK73FB1E473K	CHIP C	0.047UF K
C28			CE04LW1V100M	ELECTRØ	10UF 35WV
C31			CE04LW1A470M	ELECTRØ	47UF 10WV
C32			CK73FB1H103K	CHIP C	0.010UF K
C33			CK73FCH1H270J	CHIP C	27PF J
C34			CK73FCH1H220J	CHIP C	22PF J
C35 -38			CK73FB1H471K	CHIP C	470PF K
C39			CE04LW1C470M	ELECTRØ	47UF 16WV
C40			CK73FB1H223K	CHIP C	0.022UF K
C41			CE04LW1H010M	ELECTRØ	1.0UF 50WV
C42 , 43			CK73FB1H103K	CHIP C	0.010UF K
C50			C91-0769-05	CERAMIC	0.01UF K
C51			CE04LW1H010M	ELECTRØ	1.0UF 50WV
C52			CE04LW1C470M	ELECTRØ	47UF 16WV
C57			CK73FCH1H220J	CHIP C	22PF J
C61			CK73FB1H103K	CHIP C	0.010UF K
C62			CE04LW1C101M	ELECTRØ	100UF 16WV
C65			CE04LW1H010M	ELECTRØ	1.0UF 50WV
C66			CK73FB1H103K	CHIP C	0.010UF K
C71			CE04LW1V100M	ELECTRØ	10UF 35WV
C72			CE04LW1C470M	ELECTRØ	47UF 16WV
C103-106			CE04LW1HR47M	ELECTRØ	0.47UF 50WV
C107			CK73FB1E473K	CHIP C	0.047UF K
C112			CK73FSL1H101J	CHIP C	100PF J
C114			CK73FB1H681K	CHIP C	680PF K
C116			CK73FSL1H101J	CHIP C	100PF J
C117			CK73FB1H681K	CHIP C	680PF K
C118			CK73FB1H103K	CHIP C	0.010UF K
C119			CK73FSL1H101J	CHIP C	100PF J
C121			CE04LW1C470M	ELECTRØ	47UF 16WV
C122			CE04LW1V330M	ELECTRØ	33UF 35WV
C135, 136			CQ93FNG1H682J	MYLAR	6800PF J
C182			CK73FSL1H150J	CHIP C	15PF J
J1			E20-0476-05	LOCK TERMINAL BOARD(4P)	
J2			F10-0953-04	SHIELDING PLATE	
CF1 , 2			L72-0531-05	CERAMIC FILTER	
CF3			L72-0574-05	CERAMIC FILTER	
L7			L30-0911-05	AM IFT	
L10			L40-1091-17	SMALL FIXED INDUCTØR	
L11			L40-1021-14	SMALL FIXED INDUCTØR(1.0MH, K)	
L12			L40-1091-17	SMALL FIXED INDUCTØR	

A : A DECK
B : B DECK

A indicates safety critical components.

* New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnés dans le Parts No. ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

No.4

Ref. No. 参照番号	Address 位置	New Parts 部品新	Parts No. 部品番号	Description 部品名 / 規格	Desti- nation 仕向備考
C13			CE04LW1V100M	ELECTRØ	10UF 35WV
C14			CQ93HP2A822J	MYLAR	2200PF J
C15 -18			CK45FSL1H221J	CERAMIC	220PF K
C19			CK45FB2H471K	CERAMIC	470PF K
C20			CE04LW1V470M	ELECTRØ	4.7UF 35WV
C21 , 22			CK45FB1H332K	CERAMIC	3300PF K
C23			CK45FSL1H032K	CERAMIC	0.010UF Z
C24			CK45FB1H102K	CERAMIC	1000PF K
C51 , 52			CK45FSL1H221J	CERAMIC	220PF K
C53 , 54			CK45FB1H471K	CERAMIC	470PF K
C55 , 56			CE04LW1V100M	ELECTRØ	10UF 35WV
C57 , 58			CK45FB1H391K	CERAMIC	390PF K
C59 , 60			CE04LW1C470M	ELECTRØ	47UF 16WV
C61 , 62			CQ92FM1H153J	MYLAR	0.015UF J
C63			CE04LW1V100M	ELECTRØ	10UF 35WV
C64			CK45FB1H102K	CERAMIC	1000PF K
J1 , 2			J11-0098-05	WIRE CLAMPER	
L1 , 2			L40-1035-20	SMALL FIXED INDUCTØR(10MH, J)	
L3			L32-0542-05	BIAS OSCILLATING COIL	
VR1			R12-3685-05	TRIMMING PØT. (10K)	
VR2			R12-3686-05	TRIMMING PØT. (22K)	
VR3 , 4			R12-0605-05	TRIMMING PØT. (220)	
VR5 , 6			R12-5086-05	TRIMMING PØT. (100K)	
VR7			R12-3685-05	TRIMMING PØT. (10K)	
VR8			R12-3686-05	TRIMMING PØT. (22K)	
VR9 , 10			R12-0606-05	TRIMMING PØT. (350)	
K1			S51-2089-05	MAGNETIC RELAY	
K1			S76-0018-05	MAGNETIC RELAY	
D7 -9			H5S104	D100E	
D7 -9			1SS133	D100E	
D54 , 55			H5S104	D100E	
D54 , 55			1SS133	D100E	
IC1 , 2			TA8125S	IC (2CH PRE AMP)	
Q1 , 2			2SC3246	TRANSISTØR	
Q3 , 4			2SC1845(F, E)	TRANSISTØR	
Q5			2SA992(F, E)	TRANSISTØR	
Q6			2SA1175(F, E)	TRANSISTØR	
Q6			2SA933S(Q, R)	TRANSISTØR	
Q7			2SC1740S(Q, R)	TRANSISTØR	
Q7			2SC2785(F, E)	TRANSISTØR	
Q8			DTIC124ES	DIGITAL TRANSISTØR	
Q8			UN4212	TRANSISTØR	
Q9 -12			2SC1740S(Q, R)	TRANSISTØR	
Q9 -12			2SC2785(F, E)	TRANSISTØR	
Q13 , 14			2SC3246	TRANSISTØR	
Q15			2SA1175(F, E)	TRANSISTØR	
Q15			2SA933S(Q, R)	TRANSISTØR	
Q16			2SC1740S(Q, R)	TRANSISTØR	
Q16			2SC2785(F, E)	TRANSISTØR	
Q17 -19			DTIC124ES	DIGITAL TRANSISTØR	
Q17 -19			UN4212	TRANSISTØR	

A : A DECK
B : B DECK

A indicates safety critical components.

RXD-C2/L

PARTS LIST

✖ New Parts

Parts without Parts No. are not supplied.
Les articles non mentionnés dans le Parts No. ne sont pas fournis.
Teile ohne Parts No. werden nicht geliefert.

No.6

Ref. No. 参照番号	Address 位置	Parts No. 部品番号	Description 部品名 / 規格	Desti- nation 仕向備考
L103 L106 X1 X2		L39-1328-05 L40-1091-17 L77-1122-05 L78-0295-05	COMBINATION COIL SMALL FIXED INDUCTOR CRYSTAL RESONATOR(7.2MHZ) RESONATOR (456KHZ)	
R11 R31 R42 R44 R111 R127,128		RS14KB3A820J RS14KB3D21J R014NB2E101J R014NB2E470J R014NB2E101J	FL-PR00F RS 82 J 1W FL-PR00F RS 220 J 2W RD 100 J 1/4W RD 47 J 1/4W RD 100 J 1/4W	
W164,165 W167 W169 W173-182 W184-188		E31-0001-00 E31-0001-00 E31-0001-00 E31-0001-00 E31-0001-00	JUMPER WIRE (RESISTOR TYPE) JUMPER WIRE (RESISTOR TYPE) JUMPER WIRE (RESISTOR TYPE) JUMPER WIRE (RESISTOR TYPE) JUMPER WIRE (RESISTOR TYPE)	
W191-193 W195-201		E31-0001-00 E31-0001-00	JUMPER WIRE (RESISTOR TYPE) JUMPER WIRE (RESISTOR TYPE)	YM
S101		S62-0034-05	SLIDE SWITCH	
D3 D3 D4 D4 D7 D8 D8 D11 D11,112		HZ55.1N(82) R05.1ES(82) HZ53.3N(82) R03.3ES(82) MA110 HSS104 1SS133 HZ58.2N(82) R08.2ES(82) MA110	ZENER DIODE ZENER DIODE ZENER DIODE ZENER DIODE DIODE DIODE ZENER DIODE ZENER DIODE DIODE	
IC1 IC2 IC12 Q1 Q2		LA1831A-KEN LC7218 NJM4550 2SC2714(R,0) 2SC1845(F,E)	ANALOGUE IC IC(PULL SYNTHESIZER) IC(OP AMP X2) TRANSISTOR TRANSISTOR	
Q3 Q3 Q7 Q11 Q102		2SC2458(Y,GR) 2SC311A(Q,R) 2SC2412K 2SD1757K 2SD863(E,F) 2SA1037K	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR	
Q104 Q107,108 Q109,110 Q111		2SA1037K 2SC2412K 2SD1757K 2SA1037K	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR	YM
A1		W02-1190-05	FM FRONT-END ASSY	
MAIN UNIT-TUNER(X29-2532-70) : E, G, T TYPE				
C1 C2 C4 C5 C6 C7		CK73FB1H103K CE04LW1C470M CK73FB1H223K CK73FB1E473K CE04LW1H383M	CHIP C 0.010UF K ELECTR0 47UF 16WV CHIP C 0.022UF K CHIP C 0.047UF K ELECTR0 3.3UF 50WV	
C8 C9 C10 C11 C12		CK73FB1H482K CK73FB1H103K CC73FCH1H530J CE04HW1E100M CE04LW1H010M	CHIP C 6800PF K CHIP C 0.010UF K CHIP C 33PF J NP-ELEC 10UF 25WV ELECTR0 1.0UF 50WV	



L:Scandinavia K:USA P:Canada R:Mexico
Y:PX(Far East, Hawaii) T:England E:Europe G:Germany
Y:AFES(Europe) X:Australia M:Other Areas

A : A DECK
B : B DECK

⚠ indicates safety critical components.

No.7

Ref. No. 参照番号	Address 位置	Parts No. 部品番号	Description 部品名 / 規格	Desti- nation 仕向備考
C13 C14 C21 C21 ,22 C23 C25		CE04LW1HR33M CE04LW1H010M CK73FB1H682K CE04LW1V100M CE04LW1V100M	ELECTR0 0.33UF 50WV ELECTR0 1.0UF 50WV CHIP C 6800PF K ELECTR0 10UF 35WV ELECTR0 10UF 35WV	
C27 C28 C31 C32 C33		CE04LW1V100M CK73FB1E473K CE04LW1A470M CK73FB1H103K CC73FCH1H270J	ELECTR0 10UF 35WV CHIP C 0.047UF K ELECTR0 47UF 10WV CHIP C 0.010UF K CHIP C 27PF J	
C34 C35 C39 C40 C41		CC73FCH1H220J CK73FB1H471K CE04LW1C470M CQ93FCH1H223J CE04HW1H2R2M	CHIP C 22PF J CHIP C 470PF K ELECTR0 47UF 16WV MYLAR 0.022UF J NP-ELEC 2.2UF 50WV	
C42 ,43 C47 ,48 C50 C51 C52		CK73FB1H103K CE04LW1H0R1M CK73FB1H103K CE04LW1H010M CE04LW1C470M	CHIP C 0.010UF K ELECTR0 0.1UF 50WV CHIP C 0.010UF K ELECTR0 1.0UF 50WV ELECTR0 47UF 16WV	
C57 C66 C66 C107 C151		CC73FCH1H220J CE04LW1H010M C91-0769-05 CK73FB1E473K CK73FB1E104K	CHIP C 22PF J ELECTR0 1.0UF 50WV CERAMIC 0.01UF K CHIP C 0.047UF K CHIP C 0.10UF K	
C182		CC73FSL1H150J	CHIP C 15PF J	
J1 J2 CF1 ,2 L1 ,2 L3 L3 L5 L7		E20-0321-05 F10-0963-04 L72-0636-05 L40-1091-17 L30-0498-05 L79-0125-05 L30-0911-05	LOCK TERMINAL BOARD SHIELDING PLATE CERAMIC FILTER SMALL FIXED INDUCTOR FM TET LC FILTER AM IFT	
L10 L103 L106 X1 X2		L40-1091-17 L39-1325-05 L40-1091-17 L77-1122-05 L78-0295-05	SMALL FIXED INDUCTOR COMBINATION COIL SMALL FIXED INDUCTOR CRYSTAL RESONATOR(7.2MHZ) RESONATOR (456KHZ)	
R11 R31 R42 R111 VR1		R014NB2E470J RS14KB3D21J R014NB2E101J R014NB2E470J R12-3686-05	RD 47 J 1/4W FL-PR00F RS 220 J 2W RD 100 J 1/4W RD 47 J 1/4W TRIMMING POT.(22K)	
VR2 VR3 W221 W500 W520		R12-3685-05 R12-1619-05 R92-0670-05 R92-0670-05 R92-0670-05	TRIMMING POT.(10K) TRIMMING POT.(4.7K) CHIP R 0 0HM CHIP R 0 0HM CHIP R 0 0HM	
W523 W524-526 W602-604 W606-609 W614		R92-0679-05 R92-0670-05 R92-0670-05 R92-0670-05 R92-0670-05	CHIP R 0 0HM CHIP R 0 0HM CHIP R 0 0HM CHIP R 0 0HM CHIP R 0 0HM	
W617-619		R92-0670-05	CHIP R 0 0HM	



L:Scandinavia K:USA P:Canada R:Mexico
Y:PX(Far East, Hawaii) T:England E:Europe G:Germany
Y:AFES(Europe) X:Australia M:Other Areas

A : A DECK
B : B DECK

⚠ indicates safety critical components.

RXD-C2/L

PARTS LIST

No.9

Ref. No. 参照番号	Address 位置	Parts No. 部品番号	Description 部品名 / 規格	Desti- nation 仕向	Re- marks 備考
C230, 231		CE04HW1HR33M	NP-ELEC		
C232		CK73FB1E104K	CHIP C		
C233		CE04LW1A101M	ELECTR0		
C244, 245		CE04LW1H2R2M	ELECTR0		
C246		CE04LW1A470M	ELECTR0		
C247		CE04LW0J331M	ELECTR0		
C248		CE04LW1A101M	ELECTR0		
C249		CK73FF1C105Z	CHIP C		
C250, 251		CK73FB1H103K	CHIP C		
C253		CK73FB1E104K	CHIP C		
C254		CK73FF1C105Z	CHIP C		
C255-260		CK73FSL1H221J	CHIP C		
C261		CE04HW1E100M	NP-ELEC		
C260, 291		CK73FB1H152K	CHIP C		
C292		CK73FSL1H102J	CHIP C		
C293		CE04LW1A101M	ELECTR0		
C294		CE04LW1A101M	ELECTR0		
C295		CE04LW1A101M	ELECTR0		
C296		CK73FCH1H220J	CHIP C		
C297		CE04LW1V4R7M	ELECTR0		
C401, 402		CK73FB1H682K	CHIP C		
C403, 404		CK73FB1H933K	CHIP C		
C405, 406		CK73FSL1H221J	CHIP C		
C407-410		CE04LW1H010M	ELECTR0		
C411, 412		C093FMC1H333J	MYLAR		
C413, 414		CE04LW1HR47M	ELECTR0		
C415, 416		CE04LW1H2R2M	ELECTR0		
C417, 418		CE04LW1H0R1M	ELECTR0		
C419, 420		CE04LW1V100M	ELECTR0		
C421, 422		CE04LW1H2R2M	ELECTR0		
C423, 424		CE04LW1HR47M	ELECTR0		
C425, 426		CE04LW1A101M	ELECTR0		
C427, 428		CE04LW1H2R2M	ELECTR0		
C429-432		CK73FB1H222K	CHIP C		
C501		CE04LW1H010M	ELECTR0		
C502		CK73FB1H103K	CHIP C		
C503		CE04LW1H0R1M	ELECTR0		
C504		CE04LW1C101M	ELECTR0		
C506		CE04LW1C220M	ELECTR0		
C507		CE04LW1V100M	ELECTR0		
C508		CE04LW1H2R2M	ELECTR0		
C601, 602		CK73FSL1H221J	CHIP C		
C605, 606		CE04LW1V100M	ELECTR0		
C607, 608		CK73FB1H471K	CHIP C		
C609, 610		CE04LW1H010M	ELECTR0		
C611, 612		CK73FB1H333K	CHIP C		
C615, 616		CE04LW1H0R1M	ELECTR0		
C617, 618		CE04LW1H220M	ELECTR0		
C619-622		CC45FSL1H331J	CERAMIC		
C623, 624		CC45FSL1H101J	CERAMIC		
C625, 626		CE04LW1A470M	ELECTR0		
C627-629		CE04LW1H470M	ELECTR0		
C630		CE04KW2A4R7M	ELECTR0		
C631-634		C093FMC1H104J	MYLAR		
C635, 636		CK45FF1H223Z	CERAMIC		

A : A DECK
B : B DECK

indicates safety critical components

indicates safety critical components

No.8

Ref. No. 参照番号	Address 位置	Parts No. 部品番号	Description 部品名 / 規格	Desti- nation 仕向	Re- marks 備考
W621-626		R92-0679-05	CHIP R		
W627		R92-0670-05	CHIP R		
W628		R92-0679-05	CHIP R		
W629		R92-0670-05	CHIP R		
W630, 631		R92-0679-05	CHIP R		
W632, 633		R92-0670-05	CHIP R		
W634		R92-0679-05	CHIP R		
D3		HZ55, 1N(82)	ZENER D100E		
D3		R05, 1ES(82)	ZENER D100E		
D4		HZ53, 3K(82)	ZENER D100E		
D4		R03, 3ES(82)	ZENER D100E		
D5		HSS104	D100E		
D5		ISS133	D100E		
D111, 112		HSS104	D100E		
D111, 112		ISS133	D100E		
IC1		LA1851N	IC(CAM, FM TUNER)		
IC2		LC7218	IC(PLL SYNTHESIZER)		
Q1		2SC2714(R, 0)	TRANSISTOR		
Q2		2SC1845(F, E)	TRANSISTOR		
Q3		2SC2412K	TRANSISTOR		
Q5		2SA1037K	TRANSISTOR		
Q7		2SC2412K	TRANSISTOR		
Q102, 103		2SA1037K	TRANSISTOR		
Q109, 110		2SD1757K	TRANSISTOR		
Q111		2SA1037K	TRANSISTOR		
Q113, 114		2SC2412K	TRANSISTOR		
Q116		2SC2412K	TRANSISTOR		
A1		W02-1166-15	FM FRONT-END ASSY		
MAIN UNIT-EXCEPT TUNER(X29-254X-XX)					
C201		CE04LW1V100M	ELECTR0		
C202		CE04LW1A470M	ELECTR0		
C203		CK73FCH1H180J	CHIP C		
C204		CK73FB1E104K	CHIP C		
C205		CE04HW1H010M	NP-ELEC		
C206		CE04LW0J471M	ELECTR0		
C207		CE04HW1H010M	NP-ELEC		
C208		CK73FSL1H101J	CHIP C		
C209		CK73FB1H273K	CHIP C		
C210		CK73FB1H661K	CHIP C		
C211		CK73FB1H222K	CHIP C		
C212		CK73FB1H331K	CHIP C		
C213		CK73FSL1H331J	CHIP C		
C214		CE04LW1H010M	ELECTR0		
C215		CK73FB1E104K	CHIP C		
C216		CK73FB1H332K	CHIP C		
C217, 218		CK73FB1E104K	CHIP C		
C219		CK73FB1H273K	CHIP C		
C220		CK73FB1H153K	CHIP C		
C221, 222		CE04LW1A101M	ELECTR0		
C223		CK73FB1C224K	CHIP C		
C224		CK73FB1E104K	CHIP C		
C225, 226		CK73FB1H472K	CHIP C		
C227		CK73FB1H102K	CHIP C		
C228, 229		CK73FB1H223K	CHIP C		

A : A DECK
B : B DECK

indicates safety critical components

indicates safety critical components

✕ New Parts

Parts without Parts No. are not supplied.
Les articles non mentionnés dans le Parts No. ne sont pas fournis.
Teile ohne Parts No. werden nicht geliefert.

✕ New Parts

Parts without Parts No. are not supplied.
Les articles non mentionnés dans le Parts No. ne sont pas fournis.
Teile ohne Parts No. werden nicht geliefert.

RXD-C2/L

PARTS LIST

No.11					
Ref. No.	Address	New Parts	Parts No.	Description	Re-nation
C714			CK73FF1C105Z	CHIP C	
C716			CE04LW1H010M	ELECTRØ	
C718			CE04LW1V470M	ELECTRØ	
C719			CK45FF1H103Z	CERAMIC	
C720			CE04LW1E222M	ELECTRØ	
C721			CE04LW1A101M	ELECTRØ	
C722			CK45FF1H103Z	CERAMIC	
C723			CE04LW1A470M	ELECTRØ	
C724, 725			CE04LW1C470M	ELECTRØ	
C726, 727			CC45FSL1H220J	CERAMIC	
C728, 729			CQ93FMG1H333J	MYLAR	
C755			CE04LW1C470M	ELECTRØ	
C800			CK45FF1H103Z	CERAMIC	
C801, 802			CK45FB1H102K	CERAMIC	
J601			E63-0115-15	PHONE JACK	
J602			E11-0220-05	MINIATURE PHONE JACK	
J603			E11-0209-05	PHONE JACK	
J604			E70-0045-05	LOCK TERMINAL BOARD	
F2, 3			F05-3121-05	FUSE (SEMKØ)	
F4			F05-1623-05	FUSE (SEMKØ)	
F5			F06-1022-05	FUSE (SEMKØ)	
CN603-606			J13-0075-05	FUSE CLIP	
CN613-616			J13-0075-05	FUSE CLIP	
J608			J11-0098-05	WIRE CLAMPER	
L201			L40-1001-17	SMALL FIXED INDUCTØR(100H,K)	
L202			L40-1091-17	SMALL FIXED INDUCTØR	
L401, 402			L79-1201-05	LC FILTER	
L403, 404			L40-1035-20	SMALL FIXED INDUCTØR(10MH,J)	
X201			L78-0299-05	RESONATØR (16.93M)	
X202			L78-0605-05	RESONATØR (8.38MHZ)	
R296			R014NB2E220J	RD	
R524			R014NB2E100J	RD	
R540			R014NB2E100J	RD	
R637-640			R014NB2E222J	RD	
R643			R014NB2E102J	RD	
R644			R014NB2E471J	RD	
R645, 646			R014NB2E47J	RD	
R647-650			R014NB2E102J	RD	
R715			R014NB2E47J	RD	
R720			R014NB2E010J	RD	
R733-736			RS14KB3AR22J	FL-PRØØF RS	
R742			R014CB2E220J	FL-PRØØF RD	
R800			R014AB2E1R0J	FL-PRØØF RD	
VR201			R12-3688-05	TRIMMING PØT.(47K 7e)	
VR601			R31-0028-05	VARIABLE RESISTØR	
VR602			R31-0002-05	VARIABLE RESISTØR	
K601			S51-2094-05	MAGNETIC RELAY	
D201-209			H1110	D100E	
D501			MS104	D100E	
D502			1SS133	D100E	
			HZSS-1N(B2)	ZENER D100E	

A : A DECK
B : B DECK

No.10					
Ref. No.	Address	New Parts	Parts No.	Description	Re-nation
C637-639			CK73FB1H222K	CHIP C	
C640, 641			CK73FB1H103K	CHIP C	
C642			CK73FB1H331K	CHIP C	
C643, 644			CK73FB1H103K	CHIP C	
C645			CE04LW1H010M	ELECTRØ	
C646			CK73FB1E104K	CHIP C	
C647			CE04LW1H010M	ELECTRØ	
C648			CE04LW1C470M	ELECTRØ	
C649			CE04LW1V100M	ELECTRØ	
C650			CE04LW1H010M	ELECTRØ	
C651			CK73FB1H103K	CHIP C	
C652			CC73FSL1H221J	CHIP C	
C653			CE04LW1A101M	ELECTRØ	
C654			CE04LW1H010M	ELECTRØ	
C655			CC73FCH1H220J	CHIP C	
C656			CE04LW1V477M	ELECTRØ	
C657			CC73FSL1H102J	CHIP C	
C658, 659			CE04LW1H010M	ELECTRØ	
C660			CK45FF1H103Z	CERAMIC	
C661, 662			CE04LW1V100M	ELECTRØ	
C663, 664			CE04LW1H3R3M	ELECTRØ	
C665, 666			CK73FB1H221K	CHIP C	
C667, 668			CE04LW1H220M	ELECTRØ	
C669, 670			CE04LW1HR47M	ELECTRØ	
C671			CC73FSL1H691J	CHIP C	
C672			CK73FB1E823K	CHIP C	
C673			CK73FB1E104K	CHIP C	
C674			CK73FB1H222K	CHIP C	
C675, 676			CK73FB1H423K	CHIP C	
C677			CK73FB1H102K	CHIP C	
C678			CK73FB1H682K	CHIP C	
C679			CK73FB1E563K	CHIP C	
C680			CK73FB1H682K	CHIP C	
C681			CK73FB1E563K	CHIP C	
C682			CK73FF1C105Z	CHIP C	
C685			CE04LW1H010M	ELECTRØ	
C686, 687			CK73FB1H222K	CHIP C	
C694			CE04HW1H2R2M	NP-ELEC	
C695, 696			CE04LW1A470M	ELECTRØ	
C697, 698			CK45FF1H103Z	CERAMIC	
C697, 698			CQ93FMG1H104J	MYLAR	
C699, 700			C90-1780-05	ELECTRØ	
C701			CK45FB1H102K	CERAMIC	
C702			CE04LW1E470M	ELECTRØ	
C703			CE04LW1C470M	ELECTRØ	
C704			CE04LW1C101M	ELECTRØ	
C705			CE04LW1V470M	ELECTRØ	
C706			CK45FB1H102K	CERAMIC	
C707			CE04LW1A470M	ELECTRØ	
C708			CE04LW1C470M	ELECTRØ	
C709			CC45FSL1H101J	CERAMIC	
C710			CE04LW1C222M	ELECTRØ	
C711			CE04LW1H101M	ELECTRØ	
C712			CE04LW1V100M	ELECTRØ	
C713			CK45FF1H223Z	CERAMIC	

A : A DECK
B : B DECK

* New Parts
Parts without Parts No. are not supplied.
Les articles non mentionnés dans le Parts No. ne sont pas fournis.
Teile ohne Parts No. werden nicht geliefert.

RXD-C2/L

PARTS LIST

* New Parts
Parts without Parts No. are not supplied.
Les articles non mentionnés dans le Parts No. ne sont pas fournis.
Teile ohne Parts No. werden nicht geliefert.

No.13

Ref. No. 参照番号	Address 位置	New 新	Parts No. 部品番号	Description 部品名 / 規格	Re- marks 備考
Q506			UN4112	TRANSISTOR	
Q507			DT124ES	DIGITAL TRANSISTOR	
Q508			UN4212	TRANSISTOR	
Q509			2SC2412K	TRANSISTOR	
Q601, 602			2SC2878(B)	TRANSISTOR	
Q603			2SA1048(Y,GR)	TRANSISTOR	
Q604			2SA1309A(Q,R)	TRANSISTOR	
Q604, 605			2SC1845(F,E)	TRANSISTOR	
Q606			2SC2003(L,K)	TRANSISTOR	
Q607			2SC2458(Y,GR)	TRANSISTOR	
Q608			2SC3311A(Q,R)	TRANSISTOR	
Q609			2SD2012	TRANSISTOR	
Q610			2SD2061	TRANSISTOR	
Q611			2SC2458(Y,GR)	TRANSISTOR	
Q612, 613			2SC3311A(Q,R)	TRANSISTOR	
Q612, 613			2SA1048(Y,GR)	TRANSISTOR	
Q614, 615			2SD2012	TRANSISTOR	
Q616, 617			2SD2061	TRANSISTOR	
Q618			2SC2458(Y,GR)	TRANSISTOR	
Q619-621			2SC3311A(Q,R)	TRANSISTOR	
Q622, 623			2SC2878(B)	TRANSISTOR	
CD MECHANISM ASSY(X92-2028-X1)					
101	3B	*	A10-2947-21	CHASSIS (MAIN)	
102	2B		A11-0735-03	SUB CHASSIS (FRAME)	
103	1A		A11-0737-02	SUB CHASSIS (CLAMPER)	
DM	1B		A11-0733-05	SUB CHASSIS ASSY (DISC MOTOR)	
111	1B		D10-2325-04	ROD	
112	2B		D10-3253-03	SLIDER	
113	3A		D13-0975-04	GEAR (INTERMEDIATE)	
114	3A		D13-0976-03	GEAR (CENTER)	
115	3A		D13-0977-03	GEAR (CARRIER)	
116	3A		D13-0978-03	GEAR (IDLER)	
117	2A		D13-0979-03	GEAR (MAIN)	
118	2A		D13-0980-02	LACK (GEAR)	
119	2B		D13-0894-05	GEAR (MOTOR)	
120	1B		D13-0895-05	GEAR (INTERMEDIATE)	
121	1B		D13-0896-05	GEAR (FEED)	
125	3B		D15-0328-04	MOTOR PULLEY	
126	3A		D15-0329-03	PULLEY	
127	3B		D16-0329-04	BELT	
131	2B		E35-0420-05	LEAD WIRE	
132	1B	*	E35-1013-15	WIRING HARNESS	
133	1B	*	E35-1014-05	WIRING HARNESS	
134	2B, 3B		E35-1015-05	WIRING HARNESS	
135	2B		C01-3464-04	COMPRESSION SPRING	

A : A DECK
B : B DECK
L:Scandinavia K:USA P:Canada R:Mexico
Y:PK(Far East, Hawaii) T:England E:Europe G:Germany
Y:AFES(Europe) X:Australia M:Other Areas indicates safety critical components.

* New Parts
Parts without Parts No. are not supplied.
Les articles non mentionnés dans le Parts No. ne sont pas fournis.
Teile ohne Parts No. werden nicht geliefert.

No.12

Ref. No. 参照番号	Address 位置	New 新	Parts No. 部品番号	Description 部品名 / 規格	Re- marks 備考
D502			R05.1ES(B2)	ZENER DIODE	
D601-604			MA110	DIODE	
D605			HZ510N(B2)	ZENER DIODE	
D606			RO10ES(B2)	ZENER DIODE	
D606-609			MA110	DIODE	
D610			HZ53.3N(B2)	ZENER DIODE	
D611, 612			R03.3ES(B2)	ZENER DIODE	
D611, 612			S5688B	DIODE	
D613			1SR139-100	DIODE	
D613			HZ58.2N(B2)	ZENER DIODE	
D613			R08.2ES(B2)	ZENER DIODE	
D614			D35BA20F03	DIODE	
D614			RBV-402LFA	DIODE	
D615, 616			HZ56.2N(B2)	ZENER DIODE	
D615, 616			R06.2ES(B2)	ZENER DIODE	
D621, 622			H5S104	DIODE	
D621, 622			1S5133	DIODE	
D623			S5688B	DIODE	
D623			1SR139-100	DIODE	
D625			HZ55.1N(B2)	ZENER DIODE	
D625			R05.1ES(B2)	ZENER DIODE	
D626, 627			H5S104	DIODE	
D626, 627			1S5133	DIODE	
D630			MA110	DIODE	
D631			KBP02NL-6127	DIODE	
D632			MA110	DIODE	
D633			KBP02NL-6127	DIODE	
D634			MA110	DIODE	
D635			S5688B	DIODE	
D635			1SR139-100	DIODE	
IC201			AN806SB	ANALOGUE IC	
IC202			BA6398FP	ANALOGUE IC	
IC203			MN662720RB	MOS-IC	
IC204			UPD78012BGC-652	MI-COM IC	
IC206			TA80409S	IC(MOTOR CONTROL)	
IC207			SM5875BM	MOS-IC	
IC401			HA12182NT	ANALOGUE IC	
IC601			NJU7313AM	ANALOGUE IC	
IC602			CXA1642M	ANALOGUE IC	
IC603, 604			NJM4565M	IC(OP AMP X2)	
IC605			UPC1853CT-02	ANALOGUE IC	
IC606			NJM4565D	IC(OP AMP X2)	
IC607			STK4142/2K	CUSTOM IC	
Q201			2SA1534A(R,S)	TRANSISTOR	
Q202			2SA954(L,K)	TRANSISTOR	
Q203			2SC2412K	TRANSISTOR	
Q204			DTA115EU	DIGITAL TRANSISTOR	
Q205			DT124EU	DIGITAL TRANSISTOR	
Q401, 402			DT124EU	DIGITAL TRANSISTOR	
Q403-406			2SD1757K	TRANSISTOR	
Q503			DTA124ES	DIGITAL TRANSISTOR	
Q503			UN4112	TRANSISTOR	
Q504			2SC2412K	TRANSISTOR	
Q505			2SC3940A(R,S)	TRANSISTOR	
Q506			DTA124ES	DIGITAL TRANSISTOR	

A : A DECK
B : B DECK
L:Scandinavia K:USA P:Canada R:Mexico
Y:PK(Far East, Hawaii) T:England E:Europe G:Germany
Y:AFES(Europe) X:Australia M:Other Areas indicates safety critical components.

RXD-C2/L

PARTS LIST

✕ New Parts
 Parts without Parts No. are not supplied.
 Les articles non mentionnés dans le Parts No. ne sont pas fournis.
 Teile ohne Parts No. werden nicht geliefert.

No.15

Ref. No. 参照番号	Address 位置	Parts No. 部品番号	Description 部品名 / 規格	Desti- nation 仕	Re- marks 備考
453	1C	G01-3717-08	INTER LOCK SP (L)		
454	2D	G01-3723-08	INTER LOCK SP (R)		
455	2C	G01-3718-08	RETURN SPR		
456	2C	G01-3719-08	FWD SPR		
457	2C	G01-3720-08	HEAD RETURN PLATE SP		
458	2D	G01-3721-08	BRAKE SP (R)		
459	1D	G01-3722-08	BRAKE SP (L)		
460	1D	G01-3724-08	CLUTCH ARM SPRING (B)		
461	1D	G01-3725-08	CLUTCH SP		
462	1D	G02-0913-08	PACK SPRING		
463	2C	G02-1043-08	AZIMUTH SPR		
465	2C	G11-2117-08	HEAD WIRE CLAMP		
466	1D	G11-2205-08	TUBE		
467	2D	G16-0791-08	REFLECT SEAL		
470	1E	J19-3652-08	CABLE HOLDER		
471	2C	J19-3709-08	HEAD BASE		
472	2C	J21-6135-08	HEAD RETURN PLATE		
473	2C	J21-6184-08	HEAD PLATE ASSY		
474	2C	J42-0183-08	REEL BUSH		
475	2D	J69-0086-08	FILAMENT TAPE		
AA		N19-1316-08	POLY WASHER		
AB		N19-1354-08	NYLON WASHER		
AC		N19-1355-08	NYLON WASHER		
AD		N19-1384-08	POLY WASHER		
AE		N19-1385-08	POLY WASHER		
AF		N19-1386-08	POLY WASHER		
AG		N19-1387-08	TEFRON WASHER		
AH		N19-1388-08	POLY WASHER		
AK		N09-2900-08	SCREW		
S		N09-1497-08	TAP TITE SCREW		
T		N09-2871-08	TAPPING SCREW		
V		N09-2876-08	HEAD SCREW		
W		N09-2901-08	BIND TAP TITE SCREW		
X		N09-3112-08	AZIMUTH SCREW		
Y		N19-1287-08	POLY WASHER		
Z		N19-1288-08	POLY WASHER		
480	1E,2E	S74-0033-08	REC SWITCH		
481	1E,2E	S74-0042-08	PLAY SWITCH		
484	1E	T94-0233-08	SOLENOID ASSY		
485	1E,2E	T95-0125-08	PHOTO INTERRUPTER		
MM	1E	T42-0687-08	MOTOR ASSY		
PH	2C	T31-0066-08	ROTATION HD MP10P-AB215		A
RPEH	1C	T31-0020-08	ROTATION HD YK56R-AA405		B

L:Scandinavia
 K:USA
 T:England
 X:Australia
 P:Canada
 E:Europe
 M:Other Areas
 R:Mexico
 G:Germany
 I:Other Areas
 A : A DECK
 B : B DECK
 indicates safety critical components

✕ New Parts
 Parts without Parts No. are not supplied.
 Les articles non mentionnés dans le Parts No. ne sont pas fournis.
 Teile ohne Parts No. werden nicht geliefert.

No.14

Ref. No. 参照番号	Address 位置	Parts No. 部品番号	Description 部品名 / 規格	Desti- nation 仕	Re- marks 備考
136	1B	G10-0146-04	NON-WOVEN FABRIC		
140	1B,2B	J02-1058-15	INSULATOR		
141	1A	J11-0180-03	CLAMPER		
142	2A	J99-0513-01	TRAY		
S1	3B	S33-2062-05	LEVER SWITCH (OPEN/CLOSE)		
S2	2B	S33-1022-05	LEVER SWITCH (SLT)		
155	1A	T50-1058-04	YÖKE		
156	1A	T99-0503-15	MAGNET		
FM	2B	T42-0566-05	DC MOTOR (FEED MOTOR)		
LM	3B	T42-0609-05	DC MOTOR (LOADING MOTOR)		
PU	1B	T75-0010-05	OPTICAL PICKUP HEAD		
J1		E20-0476-05	LOCK TERMINAL BOARD(4P)	YMX	
CASSETTE MECHANISM ASSY(A : D40-1343-X5, B : D40-1345-X5)					
401	2C	A10-3174-08	HEAD CHASSIS		
405	2E	D01-0175-08	FLYWHEEL (R) ASSY		
406	1D	D01-0176-08	FLYWHEEL (L) ASSY		
407	1C	D10-3468-08	INTER LOCK ARM (L) (A MECHA)		
408	2D	D10-3469-08	INTER LOCK ARM (R) (B MECHA)		
409	1E	D10-3470-08	SHIFT LEVER		
410	2E	D10-3471-08	HEAD CHANGE ARM		
411	1E	D10-3472-08	CAM GEAR		
412	1C	D10-3476-08	EJECT LEVER (L) (A MECHA)		
413	2E	D10-3477-08	EJECT LEVER (R) (B MECHA)		
414	2C	D10-3478-08	SELET LEVER		
415	1D	D10-3479-08	CHASSIS OS ASSY		
416	2C	D10-3480-08	C/R LEVER		
420	2C	D13-0981-08	ROTATION GEAR		
421	1C	D13-1616-08	REW GEAR		
422	1C,2D	D13-1617-08	REEL GEAR		
423	1D	D13-1618-08	IDLER GEAR		
424	2C	D13-1621-08	RETURN GEAR		
425	1E	D13-1622-08	TRIGGER ARM		
426	2D	D14-0367-08	PINCH ARM (R) ASSY		
427	2C	D14-0368-08	PINCH ARM (L) ASSY		
430	1D	D15-0369-08	IDLER PULLEY		
431	2E	D16-0375-08	DRIVE BELT		
432	2E	D16-0376-08	CLUTCH BELT		
433	1C,2C	D19-0270-18	REEL CAP (A)		
434	1D	D19-0287-08	CLUTCH ARM ASSY		
440	1E	E35-0396-08	1SP FLAT RIBBON WIRE		
441	2C	E35-0985-08	3P HEAD WIRE ASSY (A MECHA)		
441	2C	E35-0987-08	SP HEAD WIRE ASSY (B MECHA)		
442	1E	E35-0986-08	MOTOR WIRE		
445	1C,2D	G01-3709-08	B.T SPRING		
446	1D	G01-3710-08	SHIFT LEVER SP		
447	1E	G01-3711-08	TRIGGER ARM SP		
448	2E	G01-3712-08	HEAD CHANGE ARM SP		
449	1C,2E	G01-3713-08	EJECT SP		
450	2C	G01-3714-08	C/R LEVER SP		
451	2C	G01-3715-08	SELECT SP		
452	2C	G01-3716-08	SHIFT SP		

L:Scandinavia
 K:USA
 T:England
 X:Australia
 P:Canada
 E:Europe
 M:Other Areas
 R:Mexico
 G:Germany
 I:Other Areas
 A : A DECK
 B : B DECK
 indicates safety critical components

RXD-C2/L

SPECIFICATIONS

Amplifier section

Rated power output

(IHF'66) 1kHz, 10 % T.H.D. at 6 Ω 37 W + 37 W

Input sensitivity / Impedance

AUX 200 mV / 47 k Ω

MIC 3.5 mV / 47 k Ω

Total harmonic distortion

..... 0.2 % (1 kHz, 1/2 rated power, 6 Ω)

Signal to noise ratio

AUX 80 dB (IHF'66)

FM Tuner section

Tuning frequency range 87.5 MHz ~ 108 MHz

Sensitivity (IHF) 13.2 dBf (1.2 μ V at 75 Ω)

AM Tuner section

Tuning frequency range

9 kHz step 531 kHz ~ 1,602 kHz

10 kHz step 530 kHz ~ 1,610 kHz

Usable sensitivity 12 μ V / (500 μ V / m)

Cassette deck section

Track 4-track, 2-channel stereo

Recording system AC bias system
(Frequency: 105 kHz)

Heads

A deck Playback head 1

B deck Playback / recording head 1

Erasing head 1

Motors

A deck 1

B deck 1

Fast winding time Approx. 120 seconds
(C-60 tape)

Wow and flutter 0.15 % (W.R.M.S.)

KENWOOD follows a policy of continuous advancements in development.

For this reason specifications may be changed without notice.

Note:

Component and circuitry are subject to modification to insure best operation under differing local conditions. This manual is based on the general market (M) standard, and provides information on regional circuit modification through use of alternate schematic diagrams, and information on regional component variations through use of parts list.

CD player section

Laser Semiconductor laser

Playing rotation 200 rpm ~ 500 rpm (CLV)

Wow & Flutter Unmeasurable Limit

General


Power consumption 110 W

Dimensions W : 270 mm

H : 305 mm

D : 337 mm

Weight (net) 6.8 kg



Free service manuals
Gratis schema's

Digitized by

www.freeservicemanuals.info

KENWOOD CORPORATION

14-6, Dogenzaka 1-chome, Shibuya-ku, Tokyo, 150 Japan

KENWOOD SERVICE CORPORATION

P.O. BOX 22745, 2201 East Dominguez St., Long Beach, CA 90801-5745, U.S.A.

KENWOOD ELECTRONICS CANADA INC.

6070 Kestrel Road, Mississauga, Ontario, Canada L5T 1S8

KENWOOD ELECTRONICS LATIN AMERICA S.A.

P.O. BOX 55-2791, Piso 6 Plaza Chase, Cl. 47 y Aquilino de la Guardia, Panama, Republic de Panama

TRIO-KENWOOD U.K. LIMITED

Kenwood House, Dwight Road, Watford, Herts, WD1 8EB, United Kingdom

KENWOOD ELECTRONICS BENELUX N.V.

Mechelsesteenweg 418 B-1930 Zaventem, Belgium

KENWOOD ELECTRONICS DEUTSCHLAND GMBH

Rembrücker Str. 15, 63150 Heusenstamm, Germany

TRIO-KENWOOD FRANCE S.A.

13 Boulevard Ney, 75018 Paris, France

KENWOOD ELECTRONICS ITALIA S.p.A.

Via G. Sirtori, 7/9 20129 Milano, Italy

KENWOOD ESPANA S.A.

Bolivia, 239-08020 Barcelona, Spain

KENWOOD ELECTRONICS AUSTRALIA PTY. LTD. (A.C.N. 001 499 074)

P.O. BOX 504, 8 Figtree Drive, Australia Centre, Homebush, N.S.W. 2140, Australia

KENWOOD & LEE ELECTRONICS, LTD.

Unit 3712-3724, Level 37 Tower 1, Metroplaza, 223 Hing Fong Road,

Kwai Fong N.T. Hong Kong

KENWOOD ELECTRONICS SINGAPORE PTE LTD

No. 1 Genting Lane # 07-00, KENWOOD Building, Singapore, 1334

KENWOOD ELECTRONICS (MALAYSIA) SDN BHD

10 th Floor, Block B, Wisma Semantan, No. 12, Jalan Gelenggang, Bukit Damansara,

50490 Kuala Lumpur, Malaysia