


# Service Manual

74 MX710/01B/07B/60B

Mini compo



## TABLE OF CONTENTS

|                                         |    |                                                |     |
|-----------------------------------------|----|------------------------------------------------|-----|
| MARANTZ DESIGN & SERVICE .....          | 1  | CD VOLTAGE TABLE .....                         | 50  |
| SPECIFICATION .....                     | 2  | CONNECTION DIAGRAM .....                       | 52  |
| SYSTEM CONNECTION .....                 | 2  |                                                |     |
| CONTROLS .....                          | 3  | TAPE DECK/AMPLIFIER UNIT                       |     |
| OPERATING THE RESET SWITCH .....        | 4  | DECK ADJUSTMENT .....                          | 54  |
| PARTS LIST(ACCESSORIES & REMOCON) ..... | 5  | EXPLODED VIEW(CABINET & CHASSIS) .....         | 56  |
|                                         |    | PARTS LIST .....                               | 57  |
| CD/TUNER UNIT                           |    | EXPLODED VIEW(TAPE MECHANISM) .....            | 64  |
| TUNER ADJUSTMENT .....                  | 6  | PARTS LIST(TAPE MECHANISM) .....               | 65  |
| LASER BEAM SAFETY PRECAUTION .....      | 8  | IC BLOCK DIAGRAM .....                         | 66  |
| CD MECHANISM REMOVAL .....              | 9  | LCD BLOCK DIAGRAM .....                        | 71  |
| CD SERVICE MODE .....                   | 13 | SCHEMATIC DIAGRAM(FRONT) .....                 | 72  |
| CD ADJUSTMENT .....                     | 16 | SCHEMATIC DIAGRAM(TAPE DECK MECHANISM) .....   | 73  |
| EXPLODED VIEW(CABINET & CHASSIS) .....  | 18 | SCHEMATIC DIAGRAM(TAPE DECK AMP) 01B-07B ..... | 74  |
| PARTS LIST .....                        | 19 | WIRING DIAGRAM(TAPE DECK AMP) 01B-07B .....    | 76  |
| EXPLODED VIEW(CD MECHANISM) .....       | 22 | SCHEMATIC DIAGRAM(TAPE DECK AMP) 60B .....     | 78  |
| IC BLOCK DIAGRAM .....                  | 24 | WIRING DIAGRAM(TAPE DECK AMP) 60B .....        | 80  |
| LCD BLOCK DIAGRAM .....                 | 30 | SCHEMATIC DIAGRAM(PRE-AMP) .....               | 82  |
| BLOCK DIAGRAM(CD MAIN) .....            | 31 | WIRING DIAGRAM(PRE-AMP) 01B .....              | 84  |
| SCHEMATIC DIAGRAM(FRONT) .....          | 32 | WIRING DIAGRAM(PRE-AMP) 07B .....              | 86  |
| SCHEMATIC DIAGRAM(CD) .....             | 34 | WIRING DIAGRAM(PRE-AMP) 60B .....              | 88  |
| WIRING DIAGRAM(CD) .....                | 36 | SCHEMATIC DIAGRAM(SYSCON & MAIN AMP) 01B ..... | 90  |
| SCHEMATIC DIAGRAM(TUNER) 01B .....      | 38 | WIRING DIAGRAM(MAIN AMP) 01B .....             | 92  |
| WIRING DIAGRAM(TUNER & FRONT) 01B ..... | 40 | SCHEMATIC DIAGRAM(SYSCON & MAIN AMP) 07B ..... | 94  |
| SCHEMATIC DIAGRAM(TUNER) 07B .....      | 42 | WIRING DIAGRAM(MAIN AMP) 07B .....             | 96  |
| WIRING DIAGRAM(TUNER & FRONT) 07B ..... | 44 | SCHEMATIC DIAGRAM(SYSCON & MAIN AMP) 60B ..... | 98  |
| SCHEMATIC DIAGRAM(TUNER) 60B .....      | 46 | WIRING DIAGRAM(MAIN AMP) 60B .....             | 100 |
| WIRING DIAGRAM(TUNER & FRONT) 60B ..... | 48 | CONNECTION DIAGRAM .....                       | 102 |

## MARANTZ DESIGN AND SERVICE

### MARANTZ DESIGN AND SERVICE

Using superior design and selected high grade components, MARANTZ company has created the ultimate in stereo sound.

Only **original MARANTZ parts** can insure that your MARANTZ product will continue to perform to the specifications for which it is famous.

Parts for your MARANTZ equipment are generally available to our National Marantz Subsidiary or Agent.

### ORDERING PARTS:

Parts can be ordered either by mail or by telex. In both cases, correct part number has to be specified. The following information must be supplied to eliminate delays in processing your order:

1. Complete address
2. Complete part numbers and quantities required
3. Description of parts
4. Model number for which part is required
5. Way of shipment
6. Signature: any order form or telex must be signed otherwise such part order will be considered as null and void.

### PARTS ORDERING

Parts may be ordered at the following addresses:

**AUSTRIA**  
HORNYPHON  
Vertriebsgesellschaft GmbH  
Wienerbergstrasse 1  
A 1101 Wien  
Austria  
Telex: 132.332

**FINLAND**  
MARANTZ  
DIVISION OF OY PHILIPS Ab  
Kaivokatu 8  
00100 Helsinki  
Finland  
Telex: 124811

**BELGIUM**  
SVD DIVISION MARANTZ  
Industrialaan 1  
1720 Groot-Bijgaarden  
Belgium  
Telex: 24466

**FRANCE**  
MARANTZ FRANCE  
4 Rue Bernard Palissy  
92600 Asnières  
France  
Telex: 611651

**CHILE**  
MARANTZ  
DIVISION OF PHILIPS S.A.  
AV. Santa Maria, 0760  
Casilla 2687  
Santiago  
Telex: 240.239

**GERMANY**  
MARANTZ GERMANY GmbH  
Alexanderstrasse 1  
2000 Hamburg  
Germany

**DENMARK**  
MARANTZ  
DIVISION OF PHILIPS  
SERVICE A/S  
Prags Boulevard 80  
Postbox 1919  
DK-2300 København S  
Denmark  
Telex: 31201

**THE NETHERLANDS**  
Elpro Marantz  
Wint Hontlaan 28  
3526 KV Utrecht  
The Netherlands  
Telex: 4748

**NORWAY**  
MARANTZ  
DIVISION OF PHILIPS A/S  
Sandstuveien 40  
0680 Oslo 6  
Norway  
Telex: 72640

**GREAT BRITAIN**  
MARANTZ AUDIO U.K. Ltd  
Unit 15/16  
Saxon Way Industrial Estate  
Moor Lane  
Harmondsworth UB7 OLW  
Great Britain  
Telex: 935196

**GREECE**  
SHERTON ELECTRONICS S.A.  
P.O.Box 21025  
Hippocratus Street 188  
Athens 11471  
Greece  
Telex: 216.795

**JAPAN**  
MARANTZ JAPAN, Inc.  
35-1, 7-chome, Sagamiono  
Sagamihara-shi, Kanagawa  
Japan

**KUWAIT**  
AL ALAMIAH ELECTRONICS  
Ussama Building  
Fahd al Saleem Street  
P.O.Box 23781  
Safat-Kuwait  
Telex: 22694

**ITALY**  
MARANTZ ITALIANA S.P.A.  
Via Chiese, 74  
20126 Milano  
Italy

**SAUDI ARABIA**  
AL ALAMIAH ELECTRONICS  
P.O.Box 5954  
University Street  
Riyadh 11432  
Saudi Arabia  
Telex: 401530

**SOUTH AFRICA**  
MARANTZ  
DIVISION OF PHILIPS S.A.  
Main Road Martindale  
P.O. Box. 58088  
Newville 21114  
South Africa

**SPAIN**  
PHONO S.A.  
Ignacio Iglesias 10  
Badalona (Barcelona)  
Spain  
Telex: 59355

**SWEDEN**  
MARANTZ  
DIVISION OF PHILIPS  
Försäljning AB  
Tegeluddsvägen 1  
S-115 84 Stockholm  
Sweden  
Telex: 14060

**SWITZERLAND**  
MARANTZ  
Technischer Service  
Duenstrasse 3  
3186 Düringen  
Switzerland

**TURKEY**  
DOGRUOL Ltd.  
I.M.C.  
6 Blok N°6310  
Unkapani  
Istanbul  
Turkey  
Telex: 22085

**MALTA**  
CACHIA & GALEA  
Republic Street, 68D  
Valetta  
Telex: 1682

**PORTUGAL**  
MARANTZ  
Divisao philips S.A. service  
Outeira-carnaxide  
2795 Linda-A-VELHA  
Telex: 43906

All of the above locations are fully equipped to take care of your total service needs. Because various countries have differing configuration requirements, it is necessary that you contact the service facility in your particular country. In the event that there is no service location listed for your country, please, contact the nearest facility for the necessary assistance.

In case of difficulties, do not hesitate to contact the Technical Department at abovementioned address.

# marantz®

## model MX710

First issue : 1992  
4822 725 51006



## TECHNICAL SPECIFICATIONS


### CASSETTE DECK / PRE-AMPLIFIER UNIT

|                               |                                                                   |
|-------------------------------|-------------------------------------------------------------------|
| <b>Cassette decks</b>         |                                                                   |
| Track system                  | 4-track, 2-channel stereo                                         |
| Frequency response            | Metal tapes : 40 - 13,500 Hz<br>Normal tapes : 40 - 12,500 Hz     |
| Wow and flutter               | 0.14 % (WRMS)                                                     |
| Fast forward /<br>rewind time | Approx. 120 sec. (C-60)                                           |
| <b>Amplifier</b>              |                                                                   |
| Output power                  | 40 W × 2 (at 8 ohms, 0.9% distortion)                             |
| Graphic equalizer             | 7 band electronic                                                 |
| Spectrum analyzer             | 7 band                                                            |
| Inputs                        | PHONO : 2.5 mV / 50k ohms<br>VIDEO : 250 mV / 50k ohms            |
| Outputs                       | SUPER WOOFER OUT : 600 mV<br>SPEAKERS : 8 ohms<br>PHONES : 8 ohms |
| <b>General</b>                |                                                                   |
| Power requirements            |                                                                   |
| For model "74MX710 / 60B"     | AC : 230 V, 50 Hz                                                 |
| For model "74MX710 / 07B"     | AC : 240 V, 50 Hz                                                 |
| For model "74MX710 / 01B"     | AC : 120 / 220 / 240 V, 50 / 60 Hz                                |
| For model "MX710"             | AC : 120 / 220 / 240 V, 50 / 60 Hz                                |
| Power consumption             | 100 W                                                             |
| Dimensions(approx.)           | 270 (W) × 178 (H) × 317 (D) mm                                    |
| Weight(approx.)               | 6.4 kg                                                            |

### CD PLAYER / TUNER / TIMER UNIT


|                                                 |                                                                                               |
|-------------------------------------------------|-----------------------------------------------------------------------------------------------|
| <b>CD player</b>                                |                                                                                               |
| Channels                                        | 2-channel stereo                                                                              |
| Sampling frequency                              | 44.1 kHz                                                                                      |
| Pick-up                                         | Optical 3-beam semiconductor laser                                                            |
| Frequency response                              | 20 - 20,000 Hz                                                                                |
| Wow and flutter                                 | Below measurable limits                                                                       |
| <b>Tuner</b>                                    |                                                                                               |
| Reception frequency                             |                                                                                               |
| For model "74MX710 / 60B"                       | FM : 87.5 - 108 MHz<br>MW : 522 - 1,611 kHz<br>LW : 144 - 290 kHz                             |
| For model "74MX710 / 07B"                       | FM : 87.5 - 108 MHz<br>AM : 531 - 1,701 kHz                                                   |
| For model "74MX710 / 01B"                       | FM : 87.5 - 108 MHz<br>AM : 531 - 1,701 kHz (9 kHz steps)<br>: 530 - 1,700 kHz (10 kHz steps) |
| For model "MX710"                               | FM : 87.5 - 108 MHz<br>AM : 531 - 1,701 kHz (9 kHz steps)<br>: 530 - 1,700 kHz (10 kHz steps) |
| <b>General</b>                                  |                                                                                               |
| Dimensions(approx.)                             | 270 (W) × 178 (H) × 278 (D) mm                                                                |
| Weight(approx.)                                 | 2.9 kg                                                                                        |
| Specification subject to change without notice. |                                                                                               |

## SYSTEM CONNECTIONS




## CONTROLS

### CASSETTE DECK / AMPLIFIER UNIT



- Standby indicator (STANDBY)
- Power switch (POWER)
- Bass expander switch and indicator (BASS EQ)
- Display switch (DISPLAY)
- Preset sound mode switch (PRESET)
- Frequency / Memory switch (FREQ. / MEMO)
- Equalizer up / down switches (+ EQ -)
- Display
- Function Indicators (CD / TAPE / TUNER / PHONO / VIDEO)
- Function switch (FUNCTION)
- Volume control (VOLUME)
- Balance control (BALANCE)
- Deck B cassette holder
- Deck A eject button (EJECT)
- Deck A cassette holder
- Headphones socket (PHONES)
- Deck B eject button (EJECT)
- Fast wind switches (REW) / (F.FWD)
- Stop switch (STOP)
- Play switches and indicators (PLAY / PLAY)
- Record / Record pause switch and indicator (REC / PAUSE)
- Record muting switch (REC MUTE)
- High-speed dubbing switch (H.DUBBING)
- Dolby noise reduction switch (NR)
- Reverse mode switch (R. MODE)
- Deck select switch and indicator (DECK A / B)
- Deck A eject button (EJECT)
- Deck A cassette holder
- Headphones socket (PHONES)

### CD PLAYER / TUNER / TIMER UNIT




- Remote sensor (IR SENSOR)
- Clock switch (CLOCK)
- Sleep timer switch (SLEEP)
- ON / OFF timer switch (TIMER)
- Wake-up timer switch (WAKE UP)
- Display
- Memory switch (MEMO)
- Set / Clear switch (SET / CLEAR)
- Band select switch (BAND)
- FM / Tuning mode switch (FM / TUNING MODE)
- Tuning switches (DOWN TUNING UP)
- Preset / Automatic preset tuning switches
- Play / Pause switch (PLAY / PAUSE)
- Skip / Search, switches (SKIP / SEARCH)
- Stop / Clear switch (STOP)
- Disc tray open / close switch and (OPEN / CLOSE)
- Disc tray
- Repeat play switch (REPEAT)
- CD memory switch (CD MEMO)
- Random play switch (RANDOM)
- Computer recording switch (COMP. REC)
- Time / Fade-out switch (TIME FADE)
- Edit switch (EDIT)



CONTROLS

REMOTE CONTROLLER UNIT

- 1. Power switch (POWER)
- 2. Deck controls
  - : Record muting switch
  - /|| : Record/Record pause switch
  - DECK A/B : Deck select switch
  - ◀▶ : Play switches
  - : Stop switch
  - ◀▶ : Fast wind switches
- 3. CD player controls
  - MEMO : CD Memory switch
  - REPEAT : Repeat play switch
  - ▶/|| : Play/Pause switch
  - : Stop/Clear switch
  - ◀◀▶▶/▶▶ : Skip/Search switches
- 4. Sleep timer switch (SLEEP)
- 5. Tuner controls
  - PRESET : Preset tuning switch
  - TUNER/BAND : Tuner function/Band select switch
- 6. Function controls
  - VIDEO : Video function switch
  - PHONO : Phono function switch
  - CD : CD function switch
- 7. Audio muting switch (MUTE)
- 8. Volume controls (▼ VOL ▲)



PARTS LIST (ACCESSORIES, REMOCON & SPEAKER)

PRODUCT SAFETY NOTICE

Each precaution in this manual should be followed during servicing. Components identified with the IEC symbol ⚠ in the parts list and the schematic diagram designate components in which safety can be of special significance. When replacing a component identified ⚠, use only the replacement parts designated, or parts with the same ratings of resistance, wattage or voltage that are designated in the parts list in this manual. Leakage-current or resistance measurements must be made to determine that exposed parts are acceptably insulated from the supply circuit before returning the product to the customer.

CAUTION: Regular type resistors and capacitors are not listed. To know those values, refer to the schematic diagram.

ACCESSORIES

| Ref. No. | Part No.       | Description                          |
|----------|----------------|--------------------------------------|
| or       | 4822 736 21617 | INSTRUCTION MANUAL,MADE IN SINGAPORE |
|          | 4822 736 21617 | INSTRUCTION MANUAL,MADE IN MALAYSIA  |
| or       | 4822 303 50069 | LOOP ANTENNA,AM                      |
|          | 4822 526 10585 | ANTENNA,FM /01B-/07B                 |
|          | 4822 303 50062 | ANTENNA,FM /60B                      |
|          | 4822 303 50071 | ANTENNA,FM /60B                      |
|          | 4822 267 31608 | ASSY,CONNECTOR-P,19P,CD/TU TO DE/AMP |
|          | 4822 502 30673 | SCR WOOD RND 3.1X13, AM ANT          |

REMOTE CONTROLLER UNIT


REMOCON (RC710MX)

| Ref. No. | Part No.       | Description       |
|----------|----------------|-------------------|
|          | 4822 218 10493 | REMOTE CONTROLLER |

OPERATING THE RESET SWITCH

This CD/TUNER and TAPE DECK/AMPLIFIER unit is provided with a reset switch on the rear panel. The reset switch serves to initialize the microprocessor in the each units which controls the CD, TUNER, TAPE DECK and etc block. If the unit is to be serviced or key input is not acknowledged even when the CD/TUNER, TAPE DECK and etc. operation buttons are pressed, press the RESET switch and initialize the microprocessor following the step below.

- 1). Disconnect the AC power cord from the power outlet.
- 2). Keep the RESET switch depressed for 60 seconds.  
(The backed up electrolytic capacitor is discharged by keeping the RESET switch depress.)
- 3). Reconnect the AC power cord to the power outlet.
- 4). Press the CD/TUNER, TAPE DECK and etc. operations, and check their operation.





## TUNER / CD PLAYER UNIT

## ADJUSTMENT (TUNER) ————— FOR 01B · 07B

- Use a plastic screwdriver for adjustment.
- Adjust the intermediate frequency of AM and FM to the frequency of ceramic filter.
- AM CHANNEL STEP switch for GENERAL is set up to 9kHz.

SG RF Level : 75 ohm Open voltage dB $\mu$ V1. FM BAND Antenna : 75 ohm Direct, Modulation : 1kHz, Dev. :  $\pm 75$ kHz (mono) ·  $\pm 40$ kHz (main) ·  $\pm 6.75$ kHz(pilot)

| STEP | ITEMS              | TUNING FREQUENCY    | INPUT CONDITION             |                      | OUTPUT CONDITION     |                                  | PARTS                   | STANDARDS                                                             |
|------|--------------------|---------------------|-----------------------------|----------------------|----------------------|----------------------------------|-------------------------|-----------------------------------------------------------------------|
|      |                    |                     | MEASURE                     | INPUT                | MEASURE              | OUTPUT                           |                         |                                                                       |
| 1    | IF                 | 10.7MHz             | FM Sweep Generator          | TP211(H)<br>TP212(E) | FM Sweep Generator   | TP223(H)<br>TP224(E)             | T2201                   | V CURVE Wave : suitable                                               |
| 2    | COVER              | 87.9MHz<br>107.9MHz | -----                       | -----                | Digital Voltmeter    | TP202(H)<br>TP201(E)             | L2104<br>-----          | 1.0~1.3V<br>Confirm $\leq 8.5$ V (about 6.6V)                         |
| 3    | TRACKING           | 90.1MHz<br>106.1MHz | FM SG<br>(about 8dB)        | TP211(H)<br>TP212(E) | VTVM<br>Oscilloscope | TP233(L)<br>TP234(R)<br>TP235(E) | L2102<br>L2103<br>CT201 | Output : Maximum<br>Adjust to near<br>the I.H.F sensitivity           |
| 4    | IF(0V)             | 98.1MHz             | FM SG<br>(66dB)             | TP211(H)<br>TP212(E) | Digital Voltmeter    | TP203(H)<br>*TP204(E)            | T2202                   | 0 $\pm$ 0.05V                                                         |
| 5    | VCO                | 98.1MHz             | FM SG<br>(66dB)             | TP211(H)<br>TP212(E) | Frequency Counter    | TP206(H)<br>TP207(E)             | SVR23                   | **19KHz $\pm$ 50Hz                                                    |
| 6    | SEPARATION         | 98.1MHz             | FM SG<br>(about 66dB)       | TP211(H)<br>TP212(E) | VTVM<br>Oscilloscope | TP233(L)<br>TP234(R)<br>TP235(E) | -----                   | Confirm to<br>near the specification                                  |
| 7    | STEREO SENSITIVITY | 98.1MHz             | FM SG<br>Set to EXT(STEREO) | TP211(H)<br>TP212(E) | -----                | -----                            | -----                   | Confirm stereo indicator<br>light up within near the<br>specification |

# : TP204 is no earth point. \*\* : Adjust in the modulation off Tuner Mode : AUTO STEREO


## 2. AM BAND

Antenna : IRE Loop, Modulation : 1kHz 30% SG RF Level : 75 ohm Open voltage dB $\mu$ V

| STEP | ITEMS    | TUNING FREQUENCY  | INPUT CONDITION       |             | OUTPUT CONDITION     |                                  | PARTS          | STANDARDS                                                         |
|------|----------|-------------------|-----------------------|-------------|----------------------|----------------------------------|----------------|-------------------------------------------------------------------|
|      |          |                   | MEASURE               | INPUT       | MEASURE              | OUTPUT                           |                |                                                                   |
| 1    | COVER    | 531kHz<br>1701kHz | -----                 | -----       | Digital Voltmeter    | TP202(H)<br>TP201(E)             | -----<br>----- | Confirm 1.1 ~ 1.5V<br>Confirm $\leq 8.5$ V (about 7.7V)           |
| 2    | TRACKING | 603kHz<br>1404kHz | AM SG<br>(about 80dB) | LOOP<br>ANT | VTVM<br>Oscilloscope | TP233(L)<br>TP234(R)<br>TP235(E) | -----<br>----- | Output : Maximum<br>Confirm to near<br>the effective sensitivity. |
| 3    | SD       | 999kHz            | AM SG<br>(about 80dB) | LOOP<br>ANT | -----                | -----                            | -----          | Confirm auto tuning stops at<br>within near the specification     |

SD : Station Detection

## 3. PARTS LOCATION



## ADJUSTMENT (TUNER)

FOR 60B

- Use a plastic screwdriver for adjustment.
- Adjust the intermediate frequency of AM and FM to the frequency of ceramic filter.

SG RF Level : 75 ohm Open voltage dB $\mu$ V

## 1. FM BAND

Antenna : 75 ohm Direct, Modulation : 1kHz, Dev. :  $\pm 75$ kHz (mono) ·  $\pm 40$ kHz (main) ·  $\pm 6.75$ kHz(pilot)

| STEP | ITEMS  | TUNING FREQUENCY    | INPUT CONDITION |                      | OUTPUT CONDITION  |                       | PARTS          | STANDARDS                                             |
|------|--------|---------------------|-----------------|----------------------|-------------------|-----------------------|----------------|-------------------------------------------------------|
|      |        |                     | MEASURE         | INPUT                | MEASURE           | OUTPUT                |                |                                                       |
| 1    | COVER  | 87.5MHz<br>108.0MHz | -----           | -----                | Digital Voltmeter | TP202(H)<br>TP201(E)  | -----<br>----- | Confirm 1.4~1.6V<br>Confirm $\leq 8.5$ V (about 6.6V) |
| 2    | IF(0V) | 98.0MHz             | FM SG<br>(66dB) | TP211(H)<br>TP212(E) | Digital Voltmeter | TP203(H)<br>*TP204(E) | T2202          | 0 $\pm$ 0.05V                                         |
| 3    | VCO    | 98.0MHz             | FM SG<br>(66dB) | TP211(H)<br>TP212(E) | Frequency Counter | TP206(H)<br>TP207(E)  | SVR23          | **19KHz $\pm$ 50Hz                                    |

# : TP204 is no earth point. \*\* : Adjust in the modulation off Tuner Mode : AUTO STEREO

## 2. MW BAND


Antenna : IRE Loop, Modulation : 1kHz 30% SG RF Level : 75 ohm Open voltage dB $\mu$ V

| STEP | ITEMS    | TUNING FREQUENCY  | INPUT CONDITION       |             | OUTPUT CONDITION     |                                  | PARTS          | STANDARDS                                                         |
|------|----------|-------------------|-----------------------|-------------|----------------------|----------------------------------|----------------|-------------------------------------------------------------------|
|      |          |                   | MEASURE               | INPUT       | MEASURE              | OUTPUT                           |                |                                                                   |
| 1    | COVER    | 522kHz<br>1611kHz | -----                 | -----       | Digital Voltmeter    | TP202(H)<br>TP201(E)             | L2153<br>----- | Confirm 1.0 ~ 1.4V<br>Confirm $\leq 8.5$ V (about 7.7V)           |
| 2    | TRACKING | 603kHz<br>1404kHz | AM SG<br>(about 80dB) | LOOP<br>ANT | VTVM<br>Oscilloscope | TP233(L)<br>TP234(R)<br>TP235(E) | L2152<br>CT252 | Output : Maximum<br>Confirm to near<br>the effective sensitivity. |

## 3. LW BAND

| STEP | ITEMS    | TUNING FREQUENCY | INPUT CONDITION       |             | OUTPUT CONDITION     |                                  | PARTS          | STANDARDS                                                         |
|------|----------|------------------|-----------------------|-------------|----------------------|----------------------------------|----------------|-------------------------------------------------------------------|
|      |          |                  | MEASURE               | INPUT       | MEASURE              | OUTPUT                           |                |                                                                   |
| 1    | COVER    | 144kHz<br>290kHz | -----                 | -----       | Digital Voltmeter    | TP202(H)<br>TP201(E)             | L2154<br>----- | Confirm 1.3 ~ 1.8V<br>Confirm $\leq 8.5$ V (about 7.7V)           |
| 2    | TRACKING | 162kHz<br>279kHz | AM SG<br>(about 80dB) | LOOP<br>ANT | VTVM<br>Oscilloscope | TP233(L)<br>TP234(R)<br>TP235(E) | L2151<br>CT251 | Output : Maximum<br>Confirm to near<br>the effective sensitivity. |

## 4. PARTS LOCATION





## LASER BEAM SAFETY PRECAUTIONS (CD)

Do not look straight at the laser beam from the pickup and do not point the beam at your fingers or any other part of your body.

**Note:** The laser beam must never be allowed to enter the eyes since this may damage the eyes. Power must never be supplied to a pickup with a damaged laser output part (objective lens, etc.).

INVISIBLE LASER RADIATION EXPOSURE TO BEAM IS DANGEROUS CLASS 1 LASER PRODUCT  
OUTPUT POWER : 0.6 mW MAX WAVELENGTH : 790 nm

CLASS 1 LASER PRODUCT  
LUOKAN 1 LASERLAITE  
KLASS 1 LASERAPPARAT

## Structural Safety Interlock

This model has a disc chuck lever and top lid. This disc chuck lever and top lid prevent to expose the laser beam for users.

## BEFORE REPAIRING THE COMPACT DISC PLAYER PARTS

Many semiconductors (ICs and transistors) and a pickup (with a built-in laser diode) for reading the music signals on compact discs by means of a laser beam are used as the parts in the compact disc player unit.

## 1) Precautions for handling the pickup and semiconductors (particularly the ICs)

- ① The pickup and semiconductors (particularly the ICs) may be damaged if they come into contact with a source of high voltage static electricity. Do not bring them, therefore, into contact with or into the vicinity of anything which has been charged with high voltage static.
- ② The pickup consists of a large number of optical and precision parts. Do not store or repair it, therefore, in any location with a high temperature, high humidity, high magnetic fields or high dust concentration. (Since the pickup contains a powerful magnet, it must not be brought near any magnetized objects.)
- ③ Do not apply strong external pressure to the pickup or subject it to impact. Actions like these can cause the printed circuit board to crack or malfunctioning to occur.
- ④ Do not use a pickup which has been subjected to strong external pressure or to an impact. The performance of such a pickup may deteriorate gradually and cause malfunctioning.
- ⑤ The pickup is a single integrated part which has been very precisely adjusted. Therefore, its adjustment points and set screws must not be touched.

## 2) How to prevent static during handling

- ① When replacing any of the parts, disconnect the power plug from the unit being repaired.
- ② All measuring instruments, tools and repair equipment must be grounded. Cover the work bench where the repair work will be done with a grounded electrically conductive sheet.
- ③ Ground the metal part of the soldering iron in order to safeguard against leakage of electricity from the heater.
- ④ Repair personnel must wear grounding bands around their wrists to discharge static picked up by their bodies. These bands are grounded through a resistor (with a 1M ohms resistance).

**Note:** Under no circumstances must be the grounding bands be grounded without a resistor (with a 1M ohms resistance) since doing so involves the risk of electric shocks. Since static in the clothes of the repair personnel will not be discharged by wearing grounding bands, every care must be taken not to allow the clothes to touch the pickup and semiconductors (particularly the ICs).

- ⑤ The pickup, which is a single integrated part, is kept in a conductive bag. Use this bag to convey the pickup from one place to another. In order to avoid damage resulting from static which may occur when the pickup is removed from the bag, make sure that it is not placed on top of the bag.

## 3) Precautions with laser beam

- ① Do not look straight at the laser beam from the pickup and do not point the beam at your fingers or any other part of your body.

**Note:** The laser beam must never be allowed to enter the eyes since this may damage the eyes. Power must never be supplied to a pickup with a damaged laser output part (objective lens, etc.).

## 4) Cleaning the lens surface

- ① Blow off dust on the lens using the kind of air brush which is used for cameras.
- ② Remove stubborn dirt with a cotton swab dipped in isopropyl alcohol. Do not use any other type of cleaning fluid since it may mark the plastic lens.

**Notes:**

- ① Do not use too much isopropyl alcohol: the excess may seep inside the pickup.
- ② The lens is held in place by a very feeble support spring. Therefore, when cleaning the lens, avoid applying any more force by the cotton swab than is necessary since this may bend the support spring out of shape.


## CD MECHANISM REMOVAL

## 1). Preparations

- ① Do not apply unnecessary force to the pickup when handling it. Care should be taken not even to touch the lens or drive circuit sections.
- ② Do not apply unnecessary force (do not pull or push it forcefully) to remove the disc tray from its inside position. Unnecessary force may break the teeth on the tray gear (CM6).
- ③ In the descriptions which follow, the numbers in the parentheses after the parts are reference numbers in the exploded views. Refer to these views.

## 2). Removing and installing the disc tray

- ① Remove the stop screw (CTY1) of the disc tray (CT21). (①)
- ② Pull the disc tray (CT21) all the way forward by turning the tray drive gear (CM12) clockwise. (②)  
**Note:** Do not take hold of the disc tray (CT21) and pull it out by force.
- ③ Push the catch on the disc tray (CT21) in the direction shown by the arrow, and draw out the disc tray (CT21). (③)
- ④ To install the disc tray, turn the gear (CM12) in the direction of the arrow as far as it will go. (②)
- ⑤ Align the disc tray (CT21) with the mechanism chassis (CM39). Adjusting second tooth of the tray move gear (CM3). (④)
- ⑥ Push the disc tray (CT21) toward the rear, and interlock it with the tray drive gear (CM12) as shown in Fig. ④.
- ⑦ Secure it with the screw (CTY1) which was removed in step ①.




## 3). Disassembling the mechanism

## (1) Removing the pickup block

- ① Remove the disc tray (CT21). (Refer to steps ①, ② and ③ of the section entitled "Removing and installing the disc tray.")
- ② Turn the tray drive gear (CM12) counterclockwise (①), and move the pickup in the direction of arrow (②) as far as it will go.
- ③ Remove the spring wire (CM44) with tweezers. (③)
- ④ Remove the screw (CM11), and also remove the tray drive gear (CT12) and washer (CM13). (④)
- ⑤ Now remove the pick rack gears (CM16 and CM19).  
**Note:** It will not be possible to remove the pick rack gears (CM16 and CM19) unless the pickup has been moved all the way in the direction of arrow (②).
- ⑥ The pickup block can now be removed by taking out the screw (CM51) and spring coil (CM49).  
**Note:** If the timing gear (CM23) is in the state shown by "X" in the figure on the right, put it in the state shown by "O."

## (2) Replacing the turntable and spindle motor

- First, have the new turntable (CM45) and special washer (CM47) ready.  
**Note:** The turntable (CM45) and special washer (CM47) which have been removed cannot be reused because the heat from the soldering iron has deformed them.
- Have calipers with a dial ready.
- ① Apply heat for about a minute to the shaft of the spindle motor (CM48) underneath the turntable (CM45) using the soldering iron (at 60W). This will melt the bonding agent which bonds the spindle motor (CM48) shaft and turntable (CM45) together.
- ② Take off the turntable (CM45) from the spindle motor (CM48) shaft by gradually applying force in the upward direction at the center of the bottom surface of the turntable (CM45).
- ③ The spindle motor (CM48) can now be removed from the sub chassis (CM50) by removing the two screws (CM46) which secure the spindle motor (CM48).





## CD MECHANISM REMOVAL

- ④ When replacing the spindle motor (CM48), mount the new spindle motor onto the chassis (CM50) using the two screws (CM46) at the angle shown in the figure.
- ⑤ Insert the new special washer (CM47) into the shaft of the spindle motor (CM48) as shown in the figure.
- ⑥ Wipe the shaft (across an area extending from the end to 10 mm or more from the end) of the spindle motor (CM48) with a cloth dipped in alcohol (normal hexane).
- ⑦ Apply bonding agent to the sides of the spindle motor (CM48) shaft. Apply an amount equivalent to about half a grain of rice to the area of the shaft which is about 2 mm be-

### (3) Replacing and lubricating the pickup


- ④ Pull out the two pickup rails (CM43) from the chassis (CM50).
- ⑤ The pickup (CM52) can now be removed once the two pickup rails (CM43) have been taken out.
- ⑥ When the pickup has been replaced, be sure to wipe the two pickup rails (CM43) cleanly and apply grease (FLOIL G-474B) around the entire circumference of the rails and along their entire length.
- ⑦ Pass the two pickup rails (CM43) through the new pickup (CM52), insert them into the chassis (CM50), and fix them in place at an angle of 45° as shown in the figure.

Notes:

- ◆ When applying the grease, do not allow any grease to adhere to any other parts.
- ◆ If a part (indicated by the dots in the figure) of the chassis (CM50) is damaged in the process of removing or inserting the two pickup rails (CM43) from or into the chassis (CM50), wipe the damaged area with a cloth dipped in alcohol (normal hexane), and bond it together using a bonding agent (Cemedine #575).


#### (4) Replacing the loading/sled motor

- ① The loading/sled motor (CM38) can be removed from the chassis (CM39) once the screw (CM24) securing the motor (CM38) is removed.
- ② Mount the new loading/sled motor (CM38) onto the chassis (CM39) using the screw (CM24).




low its end. For the bonding agent, mix equal amounts of "Three Bond 2001" and "Three Bond 2105F."

- ⑧ Insert the new turntable (CM45) over the spindle motor (CM48) shaft, as shown in the figure, to mount.
- ⑨ Press down gently on the turntable (CM45) which has been mounted, align it with the mounting dimensions and fix it in place.
- ⑩ Check that the bonding agent does not ooze out (particularly at the top center area of the turntable (CM45)). If any agent is oozing out, wipe it away with a cloth dipped in alcohol (normal hexane).



#### (5) Checking the loading/sled motor's operation


- ① As shown in the figure, connect an ammeter and a DC power supply to the loading/sled motor (CM38), and set the tray open and end switches to the "off" positions.
- ② Check that the pickup (CM52) moves smoothly without stopping from the inner circumference of the compact disc toward its outer circumference when a DC 0.6V voltage is applied from the DC power supply.
- ③ The disc tray is housed inside and the gear (CM9) slips when a DC 4V voltage is applied from the DC power supply. Check that the ammeter indicates 120mA or more at this time.



## CD MECHANISM REMOVAL


#### 4). Checkpoints for CD mechanism assembly and lubrication

- (1) Lubricating and mounting the tray slide
  - ① Apply grease (FLOIL G-474B) to the area indicated by the diagonal in the figure.
  - ② When inserting the tray slide (CM15), set the position where it is installed vis-a-vis the base/tray timing gear (CM20) as shown in the figure.




### (2) Installing the tray gear

- ① Move the tray slide (CM15) in the direction of the arrow (1).
- ② Engage the gear section of the tray slide (CM15) with the inner gear of the tray gear (CM6) at the center line, as shown in the figure.
- ③ Align the tray move gear (CM3) with the position (○) of the hole in the outer gear of the tray gear (CM6), and engage the tray move gear (CM3), as shown in the figure.




(3) Installing the base up/down slide and timing gear

- ① Move the base up/down slide (CM14) in the direction of the arrow (1), and set the gears at the positions shown in the figure.
- ② Insert the timing gear (CM23), and mount it using the screw (CM21).
- ③ Turn the timing gear (CM23) counterclockwise.



- 4 Hook the gear tension spring (CM22) onto the timing gear (CM23).






CD MECHANISM REMOVAL


(4) Lubricating the base lever

- ◆ Apply grease (FLOIL G-474B) to the area indicated by the diagonal in the figure.




(5) Lubricating the pickup sled gear and clutch gear

- ◆ Apply grease (FLOIL G-474B) around the entire circumference of the lower gear of the pickup sled gear (CM12), as shown in the figure (area indicated by the diagonal).
- ◆ Apply grease (G-333) around the entire circumference of the outer clutch gear (CM9).
- ◆ Apply grease (FLOIL G-474B) to the area indicated by the diagonal part of the outer clutch gear (CM9) where it makes contact with the inner clutch gear (CM8).



(6) Arranging and securing the leads

- ◆ As shown in the figure, set the pickup (CM52) at a position on the innermost circumference of the compact disc, and pass the leads from the pickup (CM52) and spindle motor (CM48) through pin (a) of the chassis (CM39). Arrange the leads from the loading/sled motor (CM38) and sensor switch (micro switch) (CM26) by passing them through point (b) in the chassis (CM39). After securing the leads with the lug (CM41), check that the pickup (CM52) moves smoothly without the leads interfering with its movement.
- ◆ If no problems arise in the <1> check, secure the points shown in the figure using a bonding agent (Cemedine #575).



SERVICE MODE

Specifications

To enter any service mode other than timer debugging, first simultaneously press the OPEN/CLOSE and BAND keys on the CT unit. This accesses the service mode entry state. Now press one of the buttons on the CT unit to enter a service mode. As the service mode entry state is discontinued after 1 second elapses, the system will enter a service mode only if the next key is pressed within one second.

1. Confirm the clock


- When the CLOCK key is pressed during the service mode entry state, a rectangular wave with a frequency of one-fourth that of the oscillating frequency (1.048576MHz) is output from the micro processor's port CLKOUT.
- The clock output is stopped by pressing either the POWER or SET CLEAR key.

2. Timer debugging

- When the FAST key is pressed, the current time advances one minute and the seconds readout changes to 55 seconds. If the key is held down the time advances continuously.
  - The FAST key, a concealed key not actually mounted to the set.
- Note : For timer debugging, the service mode entry state (entered by simultaneously pressing the OPEN/CLOSE service mode entry key and the BAND key) is not necessary.

3. Checking the key input signal connections

- Enter this mode by pressing the MEMORY(TUNER) key during the service mode entry state.
- The entire LCD goes out once this mode is entered.
- In this mode, as keys on the CT unit (or remote control unit) are pressed segments on the LCD corresponding to each key on a one-to-one basis come on (i.e. the lit portions gradually increase). (Refer to Table 1.)



| KEY          | DISPLAY   | KEY         | DISPLAY       | KEY          | DISPLAY       |
|--------------|-----------|-------------|---------------|--------------|---------------|
| TIME / FADE  | TIME      | CLOCK       | REC           | FUNCTION     | DIGIT 3 : 8   |
| REPEAT       | REPEAT    | SLEEP       | SLEEP         | BAND         | DIGIT 4 : 8   |
| STOP         | ONE       | TUNING UP   | SIDE A        | PST UP       | 1 OF CALENDAR |
| CD MEMORY    | PROG.     | TUNING DOWN | SIDE B        | PST DOWN     | 2 OF CALENDAR |
| PLAY / PAUSE | ▶         | WAKE UP     | WAKE UP       | FM/TUNE MODE | 3 OF CALENDAR |
| RANDOM       | RANDOM    | TIMER       | TIMER         | WIDE         | 4 OF CALENDAR |
| OPEN / CLOSE | ALL       | SET / CLEAR | @             | FWD          | DISC          |
| EDIT         | EDIT      | MEMORY      | 5 OF CALENDAR | BACK         | TRACK         |
| COMPUTER REC | COMP. REC | POWER       | DIGIT 2 : 8   |              |               |

@ : Releases the key checking mode and returns the set to the normal mode.

TABLE 1 : CORRESPONDING KEYS AND DISPLAYS IN THE KEY CHECKING MODE




FIGURE 1 : LCD (LIQUID CRYSTAL DISPLAY)



SERVICE MODE

4. Checking LCD connections

- Enter this mode by pressing the OPEN/CLOSE key during the service mode entry state. (See note.)
- The entire LCD goes out once this mode is entered.
- In this mode, one segment of the LCD lights each time the OPEN/CLOSE key is pressed.
- Press the SET/CLEAR key to exit this mode and return to the normal mode.

5. System connector checking mode

- Enter this mode by pressing the BAND key during the service mode entry state.
- Before entering this mode, connect a jig at the beginning of the system connector cord as shown in Figure 2.
- In this mode, check the signal connections shown in Table 2 for the set's CT unit and system connector cord.
- The results of the checking of connections appear on the LCD as shown in Table 2.
- Press the SET/CLEAR key to release the system connector checking mode and return to the normal mode.




FIGURE 2 : CONNECTION DURING THE SYSTEM CONNECTOR CHECKING MODE




FIGURE 3 : CIRCUIT DIAGRAM OF THE CONNECTOR CHECKING JIG

| STATE          | DISPLAY | STATE        | DISPLAY |
|----------------|---------|--------------|---------|
| SO is N.G.     | 0       | BUSY is N.G. | 4       |
| SCK is N.G.    | 1       | IR is N.G.   | 5       |
| DUB-IN is N.G. | 2       |              |         |
| AT-AF is N.G.  | 3       | All OK       | -       |

Note: : The system connector checking mode cannot be entered when the SCK(AD unit) connection is defective.

TABLE 2 : DISPLAYS DURING SYSTEM CONNECTOR CHECKING

6. CD tracking balance adjusting mode

- Enter this mode by pressing the PLAY/PAUSE key during the service mode entry state.
- If the power is off when this mode is entered, the power automatically comes on.
- In this mode, the tracking balance adjustment state (tracking is off) is automatically entered after the tray is completely closed. If the PLAY key is pressed in this state, the tracking servo is turned on and playing is begun at the present position. Therefore, the readout on the display at the time playing is begun indicates the initial position of the pickup (i.e. the position of the limit switch).
- In this mode, the tracking balance adjustment state can be entered by pressing the MEMORY key during playing. Pressing the PLAY key in this state turns on the tracking servo and causes playing to begin.
- Turning off the power releases the CD tracking balance adjusting mode.

7. CD operation display mode

- Enter this mode by pressing the STOP key during the service mode entry state.
- If the power is off when this mode is entered, the power automatically comes on.

SERVICE MODE

- In this mode, when CD function are used, displays like those shown in Table 3 (which represent CD operations different than normally displayed) appear in the LCD track number display.
- In this mode, the calendar numbers shown in Table 4 come on when an error occurs in CD operations, at which time the track number and calendar displays become fixed at their current readouts. To release these fixed displays, press the STOP key while operations are stopped.
- This mode is released when the power is turned off.

| DISPLAY | OPERATION                                           | DISPLAY | OPERATION                                           |
|---------|-----------------------------------------------------|---------|-----------------------------------------------------|
| 00      | Focus search has been begun                         | 62      | TOC reading is in progress                          |
| 01      | Focus search has been begun                         | 6-      | TOC reading has been completed (success/failure)    |
| 02      | Waiting for focusing                                | 70      | L-point access has been begun                       |
| 03      | Focusing                                            | 71      | L-point access (REV64 track jump)                   |
| 04      | Spindle kick is in progress                         | 72      | L-point access (FWD64 track jump)                   |
| 05      | Both CLV and tracking are ON                        | 73      | L-point access (REV16 track jump)                   |
| 06      | Both CLV and tracking are ON                        | 74      | L-point access (FWD16 track jump)                   |
| 0-      | Focus search has been completed (success, failure)  | 75      | L-point access (REV1 track jump)                    |
| 20      | Tray closing has begun                              | 76      | L-point access has been completed                   |
| 21      | Tray closing is in progress                         | 80      | Pausing has begun                                   |
| 22      | Pick return (internal direction) is in progress     | 83      | Pause (REV16 track jump)                            |
| 23      | Pick return (external direction) is in progress     | 84      | Pause (FWD16 track jump)                            |
| 2-      | Tray closing (pick return) has been completed       | 85      | Pause (REV1 track jump)                             |
| 30      | Spindle braking has begun                           | 86      | Pause (trace)                                       |
| 31      | Spindle braking is in progress                      | 90      | Music access has begun                              |
| 32      | Pick return is in progress                          | 91      | Music access (high-speed access has begun)          |
| 3-      | Spindle braking and pick return have been completed | 92      | Music access (high-speed access is in progress)     |
| 40      | Fast forwarding is in progress                      | 93      | Music access (high-speed access has been completed) |
| 41      | Rewinding is in progress                            | 94      | Music access (high-speed access has been completed) |
| 50      | Playing has begun                                   | 95      | Music access (high-speed access has been completed) |
| 51      | Playing is in progress                              | 96      | Music access (REV64 track jump)                     |
| 52      | Playing is in progress (skip return operation)      | 97      | Music access (FWD64 track jump)                     |
| 60      | TOC reading has been begun                          | 98      | Music access (REV16 track jump)                     |
| 61      | TOC reading is in progress                          | 99      | Music access (FWD16 track jump)                     |
|         |                                                     | 9-      | Music access (final stage)                          |

TABLE 3 : DISPLAYS DURING THE CD OPERATION MODE

| NUMBER | STATE OF CD ERROR                                                      |
|--------|------------------------------------------------------------------------|
| 1      | Focusing is not possible in focus search.                              |
| 2      | The subcode is not input during disc startup.                          |
| 3      | TOC cannot be read.                                                    |
| 4      | The focus was lost while the servo was on (during playing, etc.).      |
| 5      | The subcode is not input while the servo is on (during playing, etc.). |
| 6      | The tray does not open completely.                                     |
| 7      | The tray does not close completely.                                    |

TABLE 4 : DISPLAY OF CD ERRORS



## CD ADJUSTMENT

### Electrical Adjustment

So far we have presented explanations regarding compact disc player handling, notes prior to repair, handling the pick-up and disassembly of the unit. Be sure to carefully read these instructions before making any adjustments.

### Preparations for Adjustments

Measuring instruments, tools and filter



- (1) Test disc.: 4822 397 60161 (SONY - YEDS 18)
- (2) Oscilloscope : SS5711 (10MHz or dual phenomenon)  
or Memoryscope : DSS6521 (Storagescope)
- (3) Digital voltmeter (Input impedance 1M ohm or more)

- (4) Oscillator (400Hz, 300mV RMS)
- (5) Frequency Counter (5MHz ; or more)
- (6) Screw drivers (non-metalic) for adjustments
- (7) Band Pass Filter
- (8) AC Voltage Meter

- Notes: a. The adjustments can be using the equipment produced by other manufactures provided that the performance of that equipment corresponds to that of the above listed models.
- b. Use a 10 : 1 probe for observing signals on the oscilloscope and storage scope.
- c. Test disc is subject change without notice.

### 1. Initial set

Set the SVR11 at its initial position of adjustment controls as shown in figure below.




### 2. Tracking Balance Adjustment (SVR11)


1. Connect the oscilloscope to TP3 (TE) and TP4 (GND.).
2. Turn on the power of the unit. Insert test disc.
3. Play-back the test disc.
4. Continuously press the forward search >> or backward search << button to do it

5. Adjust SVR11 so that the TE (Tracking Error) signal waveform of TP3 on the oscilloscope is vertically symmetrical relative to 0V. (See figure right side)

\*If the adjustment is imperfect, become run away the sled motor (pick-up sending motor), inferior playability.



←← SEARCH




SEARCH →→

## CD ADJUSTMENT

### 2. Other Adjustment of Tracking Balance (SVR11)


1. Set the service mode (CD tracking balance adjusting mode).  
Enter this mode by pressing the PLAY/PAUSE key during the service mode entry state. Pressing the PLAY/Pause key in this state turns on the tracking servo and causes playing to begin. (See service mode)
2. Connect the oscilloscope to TP3 (TE) and TP4 (GND).
3. Adjust SVR11 so that the TE (Traverse) signal waveform of TP3 on the oscilloscope is vertically symmetrical relative to 0V. Or may adjust SVR11 so that the DC voltage : (Peak Hold Level) - (Bottom Hold Level) of the traverse signal is 0V. (See figure right side)
4. If it were not for obtain waveform at the right figure, repeat item 2-1 ~2-3.



### 3. Focus Gain Confirmation

1. Connect the storage scope to TP2 (F.E : Focus Error) through the Band pass filter. (See BPF Figure)
2. Turn on the power of the unit.
3. Play-back the test disc.
4. Set the output of AF oscillator to 400Hz, 0.5V rms and connect to pin 24 (IC101) through the resistor : 120k ohms.
5. Confirm so that the voltage of the F.E signal waveform on the storage scope is 0.5V p-p, ±3db by through BPF.


\* If this CONFIRMATION is imperfect, become weak the mechanical shock, inferior playability, and can not playback the Disc.



### 4. Tracking Gain Confirmation


1. Connect the storage scope to TP3 (T.E) through the Band pass filter. (See BPF Figure).
2. Turn on the power of the unit.
3. playback the test disc.
4. Set the output of AF oscillator to 400Hz, 0.5V rms and connect to pin 14 (IC101) through resistor 47k ohms.
5. Confirm so that the voltage of T.E signal waveform on the storage scope is 0.5V p-p, ±3db by through BPF.

\* If this CONFIRMATION is imperfect, become weak the mechanical shock, inferior playability, and can not playback the Disc.





## EXPLODED VIEW (TUNER / CD UNIT)



## PARTS LIST (CD / TUNER UNIT)

## PRODUCT SAFETY NOTICE

Each precaution in this manual should be followed during servicing. Components identified with the IEC symbol  $\Delta$  in the parts list and the schematic diagram designate components in which safety can be of special significance. When replacing a component identified  $\Delta$ , use only the replacement parts designated, or parts with the same ratings of resistance, wattage or voltage that are designated in the parts list in this manual. Leakage-current or resistance measurements must be made to determine that exposed parts are acceptably insulated from the supply circuit before returning the product to the customer.

**CAUTION:** Regular type resistors and capacitors are not listed. To know those values, refer to the schematic diagram.

## CABINET

| Ref. No. | Part No.       | Description                    |
|----------|----------------|--------------------------------|
| CT1      | 4822 426 51609 | ASSY, PANEL, FRONT             |
| CT2      | 4822 425 40194 | ASSY, CABINET, TOP             |
| CT3      |                | PANEL, REAR, SINGAPORE /01B    |
| or       |                | PANEL, REAR, MALAYSIA /01B     |
| CT3      |                | PANEL, REAR, SINGAPORE /07B    |
| or       |                | PANEL, REAR, MALAYSIA /07B     |
| CT3      |                | PANEL, REAR, SINGAPORE /60B    |
| or       |                | PANEL, REAR, MALAYSIA /60B     |
| CT3      |                | PANEL, REAR, SINGAPORE /07B    |
| or       |                | PANEL, REAR, MADE IN MALAYSIA  |
| CT4      |                | ASSY, CABINET, BOTTOM          |
| CT5      | 4822 454 30476 | ESCUTCHEON, CD TRAY FRONT      |
| CT6      | 4822 410 62486 | BUTTON, TIMER ETC.             |
| CT7      | 4822 410 62486 | BUTTON, BAND ETC.              |
| CT8      | 4822 410 62414 | BUTTON, TUNER, TUNING · PRESET |
| CT9      | 4822 410 62415 | BUTTON, CD EDIT ETC.           |
| CT10     | 4822 410 62416 | BUTTON, CD SKIP/SEARCH         |
| CT11     | 4822 410 62417 | BUTTON, CD OPEN/CLOSE          |
| CT12     | 4822 410 62485 | BUTTON, CD STOP · PLAY         |

## CHASSIS

| Ref. No. | Part No.       | Description                       |
|----------|----------------|-----------------------------------|
| CT31     | 4822 691 30307 | TABLE, LOADING, CD                |
| CT32     | 4822 256 92014 | MOUNT-M, CD MECHANISM             |
| CT33     |                | BRACKET-E, TU PCB                 |
| CT34     |                | BRACKET-E, CD PCB                 |
| CT35     |                | MOUNT-E, TU PCB                   |
| CT36     | 4822 466 93016 | RUBBER CUSHION, MECHA FLOAT       |
| CT37     | 4822 502 13786 | SPECIAL SCREW, MECHA FIX          |
| CT38     |                | LABEL, LASER BEAM CAUTION         |
| CT39     |                | LABEL, SAFETY, LASER BEAM CAUTION |

## FIXING PARTS

| Ref. No. | Part No. | Description                                |
|----------|----------|--------------------------------------------|
| CTY1     |          | SCR S-TPG PAN 2X8, CD TRAY STOPPER         |
| CTY2     |          | SCR S-TPG BIN 2X8, CD TRAY ESCUTCHEON      |
| CTY3     |          | SCR S-TPG BIN 2.6X8, CD PCB                |
| CTY4     |          | SCR S-TPG BIN 2.6X10, FRONT PCB            |
| CTY5     |          | SCR S-TPG BIN 2.6X10, P.FRONT - BUTTON     |
| CTY6     |          | SCR S-TPG BIN 3X8, C.BOTTOM - MOUNT-M      |
| CTY7     |          | SCR S-TPG BIN 3X10, TU, CD PCB             |
| CTY8     |          | SCR S-TPG BIN 3X8, P.FRONT - C/BOTTOM      |
| CTY9     |          | SCR S-TPG BIN 3X8, CABINET                 |
| CTY10    |          | SCR S-TPG BIN 3X10, P.FRONT - BRACKET-E    |
| CTY11    |          | SCR S-TPG BIN 3X10, P.REAR - C.BOTTOM      |
| CTY12    |          | SCR S-TPG BIN 3X10, P.REAR-ANT. T, CONNECT |

## ELECTRICAL PARTS

| Ref. No. | Part No.       | Description                    |
|----------|----------------|--------------------------------|
| CT51     | 4822 321 61828 | CORD, 22P, FFC, CD MECHA-MICON |

## TUNER P.C.BOARD ASSY

| Ref. No.         | Part No.       | Description                                                                                                                                                      |
|------------------|----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| CT71<br>or<br>or |                | ASSY, PCB, TU MAIN /01B<br>ASSY, PCB, TU MAIN /07B<br>ASSY, PCB, TU MAIN /60B<br>SHIELD PLATE, SYMBOL SIDE /01B · /07B<br>SHIELD PLATE, PATTERN SIDE /01B · /07B |
| C2152            | 4822 121 43998 | POLYPRO 470P J 100V /60B                                                                                                                                         |
| C2155            | 4822 121 70001 | POLYPRO 560P J 100V /60B                                                                                                                                         |
| C2304            | 4822 121 42872 | POLYPRO 1000P J 100V                                                                                                                                             |
| C2458            | 4822 124 21903 | NP-ELECT 1U Q 50V                                                                                                                                                |
| CF201            | 4822 242 81287 | FILTER, CERAMIC, 10.7MHZ, FM                                                                                                                                     |
| CF202            | 4822 242 81287 | FILTER, CERAMIC, 10.7MHZ, FM                                                                                                                                     |
| CF204            | 4822 242 81038 | FILTER, 459KHZ, AM                                                                                                                                               |
| CF205            | 4822 242 80307 | I.F FILTER, 459KHZ, AM                                                                                                                                           |
| CN201            | 4822 290 61034 | TERMINAL, FM, ANT                                                                                                                                                |
| CN241            |                | PLUG, 14P, TO FRONT PCB                                                                                                                                          |
| CT201            | 4822 125 60173 | TRIMMER, 11PF, WH, AM /01B · /07B                                                                                                                                |
| CT251            | 4822 125 60174 | TRIMMER, 30PF, GR, LW /60B                                                                                                                                       |
| CT252            | 4822 125 60173 | TRIMMER, 11PF, WH, MW /60B                                                                                                                                       |
| D2101            | 4822 130 82642 | VARACTOR DIODE<br>SVC211-B /01B · /07B                                                                                                                           |
| D2102            | 4822 130 82642 | VARACTOR DIODE<br>SVC211-B /01B · /07B                                                                                                                           |
| D2103            | 4822 130 82642 | VARACTOR DIODE<br>SVC211-B /01B · /07B                                                                                                                           |
| D2104            | 4822 130 82633 | DIODE GMA01 /01B · /07B                                                                                                                                          |
| or               | 4822 130 33305 | DIODE 1SS133 /01B · /07B                                                                                                                                         |
| or               | 4822 130 33305 | DIODE 1SS176 /01B · /07B                                                                                                                                         |
| D2105            | 4822 130 82633 | DIODE GMA01 /01B · /07B                                                                                                                                          |
| or               | 4822 130 33305 | DIODE 1SS133 /01B · /07B                                                                                                                                         |
| or               | 4822 130 33305 | DIODE 1SS176 /01B · /07B                                                                                                                                         |
| D2151            | 4822 130 31542 | VARACTOR DIODE<br>SVC321SPA-C-2 /60B                                                                                                                             |
| D2152            | 4822 130 31542 | VARACTOR DIODE<br>SVC321SPA-C-2 /60B                                                                                                                             |
| D2201            | 4822 130 82633 | DIODE GMA01                                                                                                                                                      |
| or               | 4822 130 33305 | DIODE 1SS133                                                                                                                                                     |
| or               | 4822 130 33305 | DIODE 1SS176                                                                                                                                                     |
| D2301            | 4822 130 82633 | DIODE GMA01                                                                                                                                                      |
| or               | 4822 130 33305 | DIODE 1SS133                                                                                                                                                     |
| or               | 4822 130 33305 | DIODE 1SS176                                                                                                                                                     |
| D2302            | 4822 130 82633 | DIODE GMA01                                                                                                                                                      |
| or               | 4822 130 33305 | DIODE 1SS133                                                                                                                                                     |
| or               | 4822 130 33305 | DIODE 1SS176                                                                                                                                                     |
| IC201            | 4822 209 70439 | IC LA1265-AUD                                                                                                                                                    |
| IC202            | 4822 209 63077 | IC LA3361                                                                                                                                                        |
| IC203            | 4822 209 30152 | IC LM7001                                                                                                                                                        |
| L2102            | 4822 157 63652 | TRANS, RF, FM /01B · /07B                                                                                                                                        |
| L2103            | 4822 157 63653 | TRANS, RF, FM /01B · /07B                                                                                                                                        |
| L2104            | 4822 148 81302 | TRANS, OSC, FM /01B · /07B                                                                                                                                       |
| L2105            | 4822 157 63656 | FILTER, CHOKE, 2.2UH, FM /01B · /07B                                                                                                                             |
| L2150            | 4822 153 70053 | TUNER, COIL, RF, AM /01B · /07B                                                                                                                                  |
| L2151            | 4822 157 63353 | TRANS, RF, LW /60B                                                                                                                                               |
| L2152            | 4822 157 63352 | ANT COIL, MW /60B                                                                                                                                                |
| L2153            | 4822 148 81294 | TRANS, OSC, MW /60B                                                                                                                                              |
| L2154            | 4822 148 81295 | TRANS, OSC, LW /60B                                                                                                                                              |
| L2201            | 4822 157 63355 | FILTER, CHOKE, 1MH, AM /60B                                                                                                                                      |
| L2451            | 4822 157 63357 | FILTER, CHOKE, 100UH                                                                                                                                             |



## PARTS LIST (CD / TUNER UNIT)

| Ref. No. | Part No.        | Description                        |
|----------|-----------------|------------------------------------|
| Q2101    | 4822 130 41813  | TR 2SK193-LL /01B·/07B             |
| or       | 4822 130 41813  | TR 2SK193-ML /01B·/07B             |
| Q2102    | 4822 130 60886  | TR 2SC1923-Y /01B·/07B             |
| Q2103    | 4822 130 41813  | TR 2SK193-LL /01B·/07B             |
| or       | 4822 130 41813  | TR 2SK193-ML /01B·/07B             |
| Q2104    | 4822 130 60886  | TR 2SC1923-Y /01B·/07B             |
| Q2105    | 4822 130 60886  | TR 2SC1923-Y                       |
| Q2131    | 4822 130 43793  | TR 2SC1815-GR /60B                 |
| or       | 4822 130 43793  | TR 2SC945A-K /60B                  |
| Q2152    | 4822 130 43819  | TR 2SC2878-A /60B                  |
| or       | 4822 130 43819  | TR 2SC2878-B /60B                  |
| Q2153    | 4822 130 43819  | TR 2SC2878-A /60B                  |
| or       | 4822 130 43819  | TR 2SC2878-B /60B                  |
| Q2154    | 4822 130 43819  | TR 2SC2878-A /60B                  |
| or       | 4822 130 43819  | TR 2SC2878-B /60B                  |
| Q2155    | 4822 130 43819  | TR 2SC2878-A /60B                  |
| or       | 4822 130 43819  | TR 2SC2878-B /60B                  |
| Q2156    | 4822 130 43819  | TR 2SC2878-A /60B                  |
| or       | 4822 130 43819  | TR 2SC2878-B /60B                  |
| Q2157    | 4822 130 41813  | TR 2SK193-LL /60B                  |
| or       | 4822 130 41813  | TR 2SK193-ML /60B                  |
| Q2158    | 4822 130 43793  | TR 2SC1815-GR /60B                 |
| or       | 4822 130 43793  | TR 2SC945A-K /60B                  |
| Q2201    | 4822 130 62778  | TR 2SC380TM-O                      |
| Q2202    | 4822 130 43793  | TR 2SC1815-GR                      |
| or       | 4822 130 43793  | TR 2SC945A-K                       |
| Q2203    | 4822 130 62615  | TR 2SA1015-GR                      |
| Q2301    | 4822 130 43793  | TR 2SC1815-GR                      |
| or       | 4822 130 43793  | TR 2SC945A-K                       |
| Q2302    | 4822 130 62769  | TR RN2207                          |
| or       | 4822 130 62769  | TR BN1A4P                          |
| or       | 4822 130 62769  | TR DTA114YS                        |
| Q2351    | 4822 130 62769  | TR RN2207                          |
| or       | 4822 130 62769  | TR BN1A4P                          |
| or       | 4822 130 62769  | TR DTA114YS                        |
| Q2352    | 4822 130 62769  | TR RN2207                          |
| or       | 4822 130 62769  | TR BN1A4P                          |
| or       | 4822 130 62769  | TR DTA114YS                        |
| Q2354    | 4822 130 62769  | TR RN2207                          |
| or       | 4822 130 62769  | TR BN1A4P                          |
| or       | 4822 130 62769  | TR DTA114YS                        |
| Q2355    | 4822 130 62769  | TR RN2207                          |
| or       | 4822 130 62769  | TR BN1A4P                          |
| or       | 4822 130 62769  | TR DTA114YS                        |
| Q2451    | 4822 130 43793  | TR 2SC1815(L)-GR                   |
| or       | 4822 130 43793  | TR 2SC1815(L)-Y                    |
| Q2452    | 4822 130 43793  | TR 2SC1815(L)-GR                   |
| or       | 4822 130 43793  | TR 2SC1815(L)-Y                    |
| Q2461    | 4822 130 43793  | TR 2SC1815-GR                      |
| or       | 4822 130 43793  | TR 2SC945A-K                       |
| Q2701    | 4822 130 43793  | TR 2SC1815-GR                      |
| or       | 4822 130 43793  | TR 2SC945A-K                       |
| Q2702    | 4822 130 43819  | TR 2SC2878-A                       |
| or       | 4822 130 43819  | TR 2SC2878-B                       |
| Q2801    | 4822 130 43793  | TR 2SC1815-GR                      |
| or       | 4822 130 43793  | TR 2SC945A-K                       |
| Q2901    | 4822 130 43819  | TR 2SC2878-A                       |
| or       | 4822 130 43819  | TR 2SC2878-B                       |
| R2465    | △4822 052 10339 | CARBON 33 JB 1/4W                  |
| S2451    | 4822 277 21672  | SWITCH,SLIDE,<br>CHANNEL STEP /01B |
| SVR23    | 4822 100 11961  | POTENTIOMETER,10K(B),VCO           |
| or       | 4822 100 11961  | SEMI-FIXED V.R,10K(B),VCO          |
| T2201    | 4822 157 70385  | TRANS,IF,FM /01B·/07B              |
| T2202    | 4822 148 81179  | I.F.T,10.7MHZ,FM                   |
| T2203    | 4822 157 63361  | MX COIL /60B                       |
| T2701    | 4822 157 63356  | COIL,CHOKE,TRAP /60B               |
| T2801    | 4822 157 63356  | COIL,CHOKE,TRAP /60B               |
| TU201    | 4822 210 10518  | TUNER,FM /60B                      |
| X2451    | 4822 242 81381  | RESONATOR,7.2MHZ,FOR IC203         |
| or       | 4822 242 81381  | RESONATOR,7.2MHZ,FOR IC203         |

## CD SYSCON P.C.BOARD ASSY

| Ref. No. | Part No.       | Description                                 |
|----------|----------------|---------------------------------------------|
| CT72     |                | ASSY,PCB, CD MICON                          |
| C1301    | 4822 124 11313 | DL-ELECT 0.047F Z 5.5V,<br>FOR MICON BACKUP |
| C1302    |                | ELECT 1000U M 6.3V                          |
| C1522    |                | POLYESTER 1000P K 50V                       |
| C1523    |                | POLYESTER 1000P K 50V                       |
| C1608    |                | ELECT 2200U M 16V,FOR +9V                   |
| C1609    |                | ELECT 1000U M 16V,FOR -9V                   |
| CN131    |                | PLUG,13P,CD-FRONT                           |
| CN132    |                | PLUG,6P,CD-FRONT                            |
| CN141    | 4822 265 51341 | SOCKET,22P,CD-MECHA                         |
| or       | 4822 265 51341 | SOCKET,22P,CD-MECHA                         |
| CN161    | 4822 267 60344 | SOCKET,19P,CT-DA UNIT                       |
| D1301    | 4822 130 82634 | DIODE DS442X                                |
| or       | 4822 130 42112 | DIODE 1S2473                                |
| D1302    | 4822 130 83264 | ZENER DIODE GZA3.9Z                         |
| or       | 4822 130 83264 | ZENER DIODE MTZ3.9B                         |
| D1303    | 4822 130 82634 | DIODE DS442X                                |
| or       | 4822 130 42112 | DIODE 1S2473                                |
| D1304    | 4822 130 82634 | DIODE DS442X                                |
| or       | 4822 130 42112 | DIODE 1S2473                                |
| D1601    | 4822 130 32508 | DIODE DSF10C                                |
| or       | 4822 130 32816 | DIODE 1SR35-200A                            |
| D1602    | 4822 130 32508 | DIODE DSF10C                                |
| or       | 4822 130 32816 | DIODE 1SR35-200A                            |
| D1603    | 4822 130 32508 | DIODE DSF10C                                |
| or       | 4822 130 32816 | DIODE 1SR35-200A                            |
| D1604    | 4822 130 32508 | DIODE DSF10C                                |
| or       | 4822 130 32816 | DIODE 1SR35-200A                            |
| D1605    | 4822 130 42112 | DIODE 1S2473                                |
| or       | 4822 130 82634 | DIODE DS442X                                |
| IC103    | 4822 209 31687 | IC UPD75116GF-F56-3BE                       |
| IC107    | 4822 209 30161 | IC M5278D05                                 |
| IC108    | 4822 209 83825 | IC NJM79L05A                                |
| IC109    | 4822 209 71373 | IC NJM78L05A                                |
| L1301    | 4822 157 70343 | FILTER,CHOKE,10UH                           |
| L1501    | 4822 157 70341 | INDUCTOR,FERITE,FOR EMI,<br>CD OUT L-CH     |
| L1502    | 4822 157 70341 | INDUCTOR,FERITE,FOR EMI,<br>CD OUT R-CH     |
| Q1301    | 4822 130 42715 | TR 2SA933S-R                                |
| or       | 4822 130 42715 | TR 2SA933S-S                                |
| or       | 4822 130 42715 | TR 2SA1048-Y                                |
| Q1302    | 4822 130 42298 | TR 2SC1740S-R                               |
| or       | 4822 130 42298 | TR 2SC1740S-S                               |
| or       | 4822 130 42298 | TR 2SC2458-GR                               |
| Q1303    | 4822 130 42715 | TR 2SA933S-R                                |
| or       | 4822 130 42715 | TR 2SA933S-S                                |
| or       | 4822 130 42715 | TR 2SA1048-Y                                |
| Q1304    | 4822 130 42298 | TR 2SC1740S-R                               |
| or       | 4822 130 42298 | TR 2SC1740S-S                               |
| or       | 4822 130 42298 | TR 2SC2458-GR                               |
| Q1305    | 4822 130 42715 | TR 2SA933S-R                                |
| or       | 4822 130 42715 | TR 2SA933S-S                                |
| or       | 4822 130 42715 | TR 2SA1048-Y                                |
| Q1500    | 4822 130 62768 | TR 2SD1468S-S                               |
| Q1501    | 4822 130 62768 | TR 2SD1468S-S                               |
| S1301    | 4822 276 13304 | SWITCH,TACT,RESET                           |
| X1301    | 4822 242 81291 | RESONATOR,XTAL,4.19MHZ,FOR<br>IC103         |

## CD MAIN P.C.BOARD ASSY

| Ref. No. | Part No.        | Description                 |
|----------|-----------------|-----------------------------|
| CT73     |                 | ASSY,PCB,CD MECHA           |
| CN101    | 4822 267 51207  | SOCKET,13P,FOR PICKUP(FFC)  |
| CN102    |                 | PLUG,4P,FOR MOTOR           |
| CN103    |                 | PLUG,3P,FOR SWITCH          |
| CN104    | 4822 267 60345  | SOCKET,22P,TO CD MICON(FFC) |
| or       | 4822 267 60345  | SOCKET,22P,TO CD MICON(FFC) |
| IC101    | 4822 209 31678  | IC LA9210M                  |
| IC102    | △4822 209 31679 | IC LA6524                   |
| IC104    | 4822 209 31778  | IC LC7866E                  |

## PARTS LIST (CD / TUNER UNIT)

| Ref. No. | Part No.       | Description                     |
|----------|----------------|---------------------------------|
| IC105    | 4822 209 31682 | IC SM5870DS                     |
| IC106    | 4822 209 30159 | IC XRA15218F                    |
| or       | 4822 209 30159 | IC BA15218F                     |
| Q101     | 4822 130 62938 | TR 2SA1037K-R                   |
| Q102     | 4822 130 61537 | TR 2SC2412K-R                   |
| Q103     | 4822 130 61537 | TR 2SC2412K-R                   |
| SVR11    | 4822 100 11961 | POTENTIOMETER,10K(B),T.BAL      |
| TP101    |                | TERMINAL,TEST POINT,RF          |
| TP102    |                | TERMINAL,TEST POINT,FE          |
| TP103    |                | TERMINAL,TEST POINT,TE          |
| TP104    |                | TERMINAL,TEST POINT,GND         |
| TP105    |                | TERMINAL,TEST POINT,PLL         |
| X101     | 4822 242 81387 | RESONATOR,16.93MHZ,FOR<br>IC104 |

## FRONT P.C.BOARD ASSY

| Ref. No. | Part No.       | Description                                |
|----------|----------------|--------------------------------------------|
| CT74     |                | ASSY,PCB, FRONT /01B·/07                   |
| or       |                | ASSY,PCB, FRONT /60B                       |
|          |                | REFLECTOR,LCD                              |
|          |                | SHEET,LCD                                  |
| CN251    | 4822 267 51208 | SOCKET,13P,CD MICON PCB                    |
| CN252    | 4822 267 41076 | SOCKET,6P,CD MICON PCB                     |
| CN253    | 4822 267 51209 | SOCKET,14P,TUNER PCB                       |
| D2501    | 4822 130 42112 | DIODE 1S1588                               |
| or       | 4822 130 42112 | DIODE 1S2473                               |
| or       | 4822 130 82634 | DIODE DS442X                               |
| D2502    | 4822 130 42112 | DIODE 1S1588                               |
| or       | 4822 130 42112 | DIODE 1S2473                               |
| or       | 4822 130 82634 | DIODE DS442X                               |
| IC251    | 4822 209 31686 | IC UPD75306GF-225-3B9                      |
| L2501    | 4822 157 63357 | FILTER,CHOKE,100UH                         |
| LCD21    | 4822 130 91168 | LCD(LIQUID CRYSTAL DISPLAY)                |
| S2511    | 4822 276 30418 | SWITCH,TACT,OPEN/CLOSE                     |
| S2512    | 4822 276 30418 | SWITCH,TACT,PLAY/PAISE                     |
| S2513    | 4822 276 30418 | SWITCH,TACT,STOP                           |
| S2514    | 4822 276 30418 | SWITCH,TACT,REPEAT                         |
| S2515    | 4822 276 30418 | SWITCH,TACT,CD MEMORY                      |
| S2516    | 4822 276 30418 | SWITCH,TACT,C.REC                          |
| S2517    | 4822 276 30418 | SWITCH,TACT,EDIT                           |
| S2518    | 4822 276 30418 | SWITCH,TACT,TIME/FADE                      |
| S2521    | 4822 276 30418 | SWITCH,TACT,CLOCK                          |
| S2522    | 4822 276 30418 | SWITCH,TACT,SLEEP                          |
| S2523    | 4822 276 30418 | SWITCH,TACT,WAKE UP                        |
| S2524    | 4822 276 30418 | SWITCH,TACT,TIMER                          |
| S2525    | 4822 276 30418 | SWITCH,TACT,PST DOWN                       |
| S2526    | 4822 276 30418 | SWITCH,TACT,FWD                            |
| S2527    | 4822 276 30418 | SWITCH,TACT,BACK                           |
| S2528    | 4822 276 30418 | SWITCH,TACT,RANDOM                         |
| S2531    | 4822 276 30418 | SWITCH,TACT,BAND                           |
| S2532    | 4822 276 30418 | SWITCH,TACT,CLEAR                          |
| S2533    | 4822 276 30418 | SWITCH,TACT,TU MEMORY                      |
| S2534    | 4822 276 30418 | SWITCH,TACT,MODE                           |
| S2535    | 4822 276 30418 | SWITCH,TACT,PST UP                         |
| S2536    | 4822 276 30418 | SWITCH,TACT,TUN UP                         |
| S2537    | 4822 276 30418 | SWITCH,TACTTUN DOWN                        |
| S2540    | 4822 130 83315 | PHOTO DIODE SPS-422-1,<br>IR RECEIVER      |
| or       | 4822 130 83315 | OPTO CONNECTOR,IR RESEIVER                 |
| X2501    | 4822 242 81288 | RESONATOR,CERAMIC,3P,<br>4.19MHZ,FOR IC251 |


## LED (LCD BACK LIGHT) P.C.BOARD ASSY

| Ref. No. | Part No.       | Description                       |
|----------|----------------|-----------------------------------|
| CT75     |                | ASSY,PCB, LED                     |
| CN562    |                | ASSY,CONNECTOR-S,2P,FROM<br>FRONT |
| D5551    | 4822 130 83272 | LED CL-170G-CD-AL                 |
| or       | 4822 130 83272 | LED CL-170G-CD-BL                 |
| or       | 4822 130 83272 | LED CL-170G-CD-CL                 |

| Ref. No. | Part No.       | Description       |
|----------|----------------|-------------------|
| D5552    | 4822 130 83272 | LED CL-170G-CD-AL |
| or       | 4822 130 83272 | LED CL-170G-CD-BL |
| or       | 4822 130 83272 | LED CL-170G-CD-CL |
| D5553    | 4822 130 83272 | LED CL-170G-CD-AH |
| or       | 4822 130 83272 | LED CL-170G-CD-BH |
| or       | 4822 130 83272 | LED CL-170G-CD-CH |
| D5554    | 4822 130 83272 | LED CL-170G-CD-AH |
| or       | 4822 130 83272 | LED CL-170G-CD-BH |
| or       | 4822 130 83272 | LED CL-170G-CD-CH |
| D5555    | 4822 130 83272 | LED CL-170G-CD-AH |
| or       | 4822 130 83272 | LED CL-170G-CD-BH |
| or       | 4822 130 83272 | LED CL-170G-CD-CH |
| D5556    | 4822 130 83272 | LED CL-170G-CD-AL |
| or       | 4822 130 83272 | LED CL-170G-CD-BL |
| or       | 4822 130 83272 | LED CL-170G-CD-CL |
| D5557    | 4822 130 83272 | LED CL-170G-CD-AL |
| or       | 4822 130 83272 | LED CL-170G-CD-BL |
| or       | 4822 130 83272 | LED CL-170G-CD-CL |
| D5558    | 4822 130 83272 | LED CL-170G-CD-AL |
| or       | 4822 130 83272 | LED CL-170G-CD-BL |
| or       | 4822 130 83272 | LED CL-170G-CD-CL |
| D5559    | 4822 130 83272 | LED CL-170G-CD-AH |
| or       | 4822 130 83272 | LED CL-170G-CD-BH |
| or       | 4822 130 83272 | LED CL-170G-CD-CH |
| D5560    | 4822 130 83272 | LED CL-170G-CD-AL |
| or       | 4822 130 83272 | LED CL-170G-CD-BL |
| or       | 4822 130 83272 | LED CL-170G-CD-CL |
| D5561    | 4822 130 83272 | LED CL-170G-CD-AH |
| or       | 4822 130 83272 | LED CL-170G-CD-BH |
| or       | 4822 130 83272 | LED CL-170G-CD-CH |
| D5562    | 4822 130 83272 | LED CL-170G-CD-AL |
| or       | 4822 130 83272 | LED CL-170G-CD-BL |
| or       | 4822 130 83272 | LED CL-170G-CD-CL |
| D5563    | 4822 130 83272 | LED CL-170G-CD-AH |
| or       | 4822 130 83272 | LED CL-170G-CD-BH |
| or       | 4822 130 83272 | LED CL-170G-CD-CH |
| D5564    | 4822 130 83272 | LED CL-170G-CD-AH |
| or       | 4822 130 83272 | LED CL-170G-CD-BH |
| or       | 4822 130 83272 | LED CL-170G-CD-CH |
| D5565    | 4822 130 83272 | LED CL-170G-CD-AL |
| or       | 4822 130 83272 | LED CL-170G-CD-BL |
| or       | 4822 130 83272 | LED CL-170G-CD-CL |
| D5566    | 4822 130 83272 | LED CL-170G-CD-AH |
| or       | 4822 130 83272 | LED CL-170G-CD-BH |
| or       | 4822 130 83272 | LED CL-170G-CD-CH |
| D5567    | 4822 130 83272 | LED CL-170G-CD-AH |
| or       | 4822 130 83272 | LED CL-170G-CD-BH |
| or       | 4822 130 83272 | LED CL-170G-CD-CH |
| D5568    | 4822 130 83272 | LED CL-170G-CD-AL |
| or       | 4822 130 83272 | LED CL-170G-CD-BL |
| or       | 4822 130 83272 | LED CL-170G-CD-CL |
| D5569    | 4822 130 83272 | LED CL-170G-CD-AH |
| or       | 4822 130 83272 | LED CL-170G-CD-BH |
| or       | 4822 130 83272 | LED CL-170G-CD-CH |
| D5570    | 4822 130 83272 | LED CL-170G-CD-AL |
| or       | 4822 130 83272 | LED CL-170G-CD-BL |
| or       | 4822 130 83272 | LED CL-170G-CD-CL |



## EXPLODED VIEW (CD MECHANISM)



## CD MECHANISM (PM-DAD EX22S / SP)

| Ref. No. | Part No.       | Description                 | Ref. No. | Part No.       | Description                 |
|----------|----------------|-----------------------------|----------|----------------|-----------------------------|
| CM2      | 4822 532 12082 | WASHER V 2X6X0.4,GEAR FIX   | CM33     | 4822 502 21235 | SCR S-TPG PAN 2X6,BRACKET   |
| CM3      | 4822 522 33094 | GEAR,TRAY MOVE              | CM34     | 4822 402 61384 | BRACKET-M,TRAY GUIDE(R)     |
| CM5      | 4822 532 12082 | WASHER V 2X6X0.4,GEAR FIX   | CM35     | 4822 402 61436 | LEVER,BASE                  |
| CM6      | 4822 522 33095 | GEAR,TRAY                   | CM36     | 4822 492 42555 | SPRING,COMP,BASE LEVER MOVE |
| CM8      | 4822 522 33294 | ASSY,GEAR,CLUTCH            | CM38     | 4822 361 30356 | ASSY,MOTOR,LOADING/SLED     |
| CM9      | 4822 522 33292 | GEAR,CLUTCH OUTER           | CM39     | 4822 464 50962 | CHASSIS,LOADING             |
| CM10     | 4822 502 13787 | SPECIAL SCREW,SLIDE 14      | CM33     | 4822 502 21235 | SCR S-TPG PAN 2X6,BRACKET   |
| CM12     | 4822 522 33097 | GEAR,PICK SLED              | CM40     | 4822 502 13787 | SPECIAL SCREW,BOSS          |
| CM13     | 4822 532 52479 | SPECIAL WASHER,PICK GEAR 12 |          |                | REINFORCEMENT               |
| CM14     | 4822 402 61386 | SLIDE,BASE UP/DOWN          | CM41     |                | LUG,WIRE DRESS              |
| CM15     | 4822 402 61391 | SLIDE,TRAY                  | CM43     | 4822 535 93332 | SHAFT,PICK RAIL             |
| CM16     | 4822 522 33098 | GEAR,PICK RACK UPPER        | CM44     | 4822 492 71175 | SPRING,WIRE,PICK BACK       |
| CM17     | 4822 502 13787 | SPECIAL SCREW,GEAR 20 FIX   | CM45     | 4822 528 10824 | TURNTABLE,CD CHUCKING       |
| CM18     | 4822 492 42554 | SPRING,COMP,RACK BACK       | CM46     | 4822 502 13788 | SCR PAN+SW 2X4,SPINDLE M    |
| CM19     | 4822 522 33099 | GEAR,PICK RACK LOWER        | CM47     | 4822 532 52353 | SPECIAL WASHER,ADHESIVE     |
| CM20     | 4822 522 33101 | GEAR,BASE/TRAY TIMING       |          |                | ESCAPE STOP                 |
| CM21     | 4822 502 13787 | SPECIAL SCREW,GEAR 23       | CM48     | 4822 361 30357 | COMMUTATE MOTOR,SPINDLE     |
| CM22     | 4822 492 33348 | SPRING,TENSION,GEAR 23      | CM49     | 4822 492 33347 | SPRING,TENS,CHASSIS PULLUP  |
| CM23     | 4822 522 33293 | GEAR,TIMING                 | CM50     | 4822 464 50926 | CHASSIS,BASE                |
| CM24     | 4822 502 13788 | SCR PAN+SW 2X4,SLED MOTOR   | CM51     | 4822 502 13789 | SCR S-TPG BRZ+FLG 3X6       |
| CM25     | 4822 276 13124 | SWITCH,LIMIT                | CM52     | 4822 691 30289 | PICKUP,LASER,SF-P1PS        |
| CM26     | 4822 276 13124 | SWITCH,TRAY OPEN            | or       | 4822 691 30289 | PICKUP,LASER,SF-90PS        |
| CM27     | 4822 492 71176 | SPRING PLATE,CHUCKING       | CM53     | 4822 321 61827 | CORD,PICK UP                |
| CM28     | 4822 502 13789 | SCR S-TPG BRZ+FLG 3X6       | CM56     | 4822 532 12186 | SPECIAL WASHER,GEAR 8 FIX   |
| CM30     | 4822 528 50327 | ASSY,PULLEY                 | CM57     | 4822 466 62249 | CUSHION,MOTOR LEAD FIX      |
| CM32     | 4822 402 61383 | BRACKET-M,TRAY GUIDE(L)     |          |                |                             |

## MEMO




## IC BLOCK DIAGRAM (CD)

## IC101 LA9210M (Servo Signal Processor)

| No. | PIN NAME | I/O | FUNCTION                               |
|-----|----------|-----|----------------------------------------|
| 1   | NC       |     | Non Connection                         |
| 2   | VEE      |     | -5V                                    |
| 3   | E        | I   | IV Convert Input (from Photo Diode E)  |
| 4   | F        | I   | IV*Convert Input (from Photo diode F)  |
| 5   | FN       | I   | IV Converter Input                     |
| 6   | FO       | O   | IV Converter Output                    |
| 7   | TEAO     | O   | Tracking Error Amplifier Output        |
| 8   | VREF2    | I   | Reference Voltage 2                    |
| 9   | VREF3    | I   | Reference Voltage 3                    |
| 10  | TES1     | I   | Test Input                             |
| 11  | ATSC     | I   | + Input of Anti Shock Detect Amplifier |
| 12  | ATSC-    | I   | - Input of Anti Shock Detect Amplifier |
| 13  | TPA +    | I   | - Input of Tracking Pulse Amplifier    |
| 14  | TPA-     | I   | + Input of Tracking Pulse Amplifier    |
| 15  | TPAO     | O   | Tracking Pulse Amplifier Output        |
| 16  | TOFS     | I   | Input for Tracking Offset              |
| 17  | THDS     | I   | Tracking Servo Hold Switch             |
| 18  | TD +     | I   | Add the Track Jump Pulse               |
| 19  | JPO      | O   | Track Jump Pulse Amplifier Output      |
| 20  | SLEQ     | I   | Input for Sled Servo Equalizer         |
| 21  | TDO      | O   | Tracking Actuator Coil Driver Output   |
| 22  | FDO      | O   | Focus Actuator Coil Driver Output      |
| 23  | FD-      | I   | Input for Focus Actuator Coil Driver   |
| 24  | FSW      | I   | Focus Servo Switch                     |
| 25  | NC       |     | Non Connection                         |
| 26  | FEAO     | O   | Focus Error Amplifier Output           |
| 27  | FE +     | I   | + Input of Focus Error Amplifier       |
| 28  | FD +     | I   | + Input of Focus Actuator Coil Driver  |
| 29  | SPO      | O   | CLV Error Amplifier Output             |
| 30  | SPO-     | I   | Input for Spindle Motor Driver         |
| 31  | SPDO     | O   | Spindle Motor Driver Output            |
| 32  | VEE      |     | -5V                                    |
| 33  | SLDO     | O   | Sled Motor Driver Output               |
| 34  | SL-      | I   | - Input of Sled Motor Driver           |
| 35  | SL+      | I   | + Input of Sled Motor Driver           |
| 36  | VCC      |     | +5V                                    |
| 37  | SLSW     | I   | Sled Servo Switch                      |
| 38  | DEFO     | O   | Defect Signal Output                   |
| 39  | 2FREQ    | I   | Input for VCO                          |
| 40  | DRF      | O   | Focusing Servo ON : High Level         |

## IC102 LA6524 (Dual Motor &amp; Actuator Coil Driver)



## IC BLOCK DIAGRAM (CD SYSCON)

IC103  $\mu$ PD75116GF-F56-3BE (Micro Processor)



| PIN No. | SIGNAL NAME | PORT NAME | DESCRIPTION                                                              | I/O |
|---------|-------------|-----------|--------------------------------------------------------------------------|-----|
| 1       | CD MUTE     | P41       | Control Signal of Analogue Muting                                        | O   |
| 2       | P CONT      | P40       | Control Signal of Power Supply for CD Circuit                            | O   |
| 3       | NC          | P53       | Not Used (Open)                                                          | O   |
| 4       | FC          | P52       | Function Control C Signal                                                | O   |
| 5       | FB          | P51       | Function Control B Signal                                                | O   |
| 6       | FA          | P50       | Function Control A Signal                                                | O   |
| 7       | RESET       | RESET     | System Reset                                                             | I   |
| 8       | X2          | XO        | X'tal Out (4.19 MHz)                                                     | O   |
| 9       | X1          | XI        | X'tal In (4.19 MHz)                                                      | I   |
| 10      | V CHK       | P63       | Detection Signal of the Stoppage Failure of Electricity                  | I   |
| 11      | V DEC O     | P62       | Detection Signal Out of Voltage Drop                                     | O   |
| 12      | V DEC I     | P61       | Detection Signal In of Voltage Drop                                      | I   |
| 13      | TU MUTE     | P60       | Control Signal of Tuner Muting                                           | O   |
| 14      | NC          | P73       | Not Used (Ground)                                                        | I   |
| 15      | NC          | P72       | Not Used (Ground)                                                        | I   |
| 16      | DUB IN      | P71       | Dubbing Signal                                                           | I   |
| 17      | TA AF       | P70       | Function Signal for Tape Deck                                            | I   |
| 18      | NC          | P83       | Not Used (Open)                                                          | O   |
| 19      | NC          | P82       | Not Used (Open)                                                          | O   |
| 20      | CLV GAIN    | P81       | Select Signal for CLV (Constant Linear Velocity) Gain                    | O   |
| 21      | AMP SO      | P80       | Data Out to AD Micro Processor ( $\mu$ PD75512)                          | O   |
| 22      | AMP SCK     | P93       | Clock Out to AD Micro Processor ( $\mu$ PD75512)                         | O   |
| 23      | TRAY LED    | P92       | CD Tray Indicator LED                                                    | O   |
| 24      | SUB SO      | P91       | Data Out to Sub Micro Processor ( $\mu$ PD73508)                         | O   |
| 25      | SUB SCK     | P90       | Clock Out to Sub Micro Processor ( $\mu$ PD73508)                        | O   |
| 26      | VSS         | VSS       | Ground                                                                   |     |
| 27      | SUB BUSY    | P13/INT3  | Busy Signal In from Sub Micro Processor ( $\mu$ PD73508)                 | I   |
| 28      | AMP BUSY    | P12/INT2  | Busy Signal In from AD Micro Processor ( $\mu$ PD75512)                  | I   |
| 29      | WRQ         | P11/INT1  | DSP (Digital Signal Processor) Interface [Sub Q Request]                 | I   |
| 30      | IR          | P10/INT0  | Infrared Ray Receiving (Remocon) Signal                                  | I   |
| 31      | KEY3        | PTH03     | Key Input Signal                                                         | I   |
| 32      | KEY2        | PTH02     | Key Input Signal                                                         | I   |
| 33      | KEY1        | PTH01     | Key Input Signal                                                         | I   |
| 34      | KEY0        | PTH00     | Key Input Signal                                                         | I   |
| 35      | NC          | T10       | Not Used (Open)                                                          |     |
| 36      | NC          | T11       | Not Used (Open)                                                          |     |
| 37      | CLOSE       | P23       | Control Signal of Tray Close                                             | O   |
| 38      | CLK OUT     | P22/PCL   | Clock Signal for Adjustment                                              | O   |
| 39      | OPEN        | P21/PT01  | Control Signal of Tray Open                                              | O   |
| 40      | RWC         | P20/PT00  | DSP (Digital Signal Processor) Interface [Command Latch]                 | O   |
| 41      | SQOUT       | P03/SI    | DSP (Digital Signal Processor) Interface [Sub Q Data]                    | I   |
| 42      | COIN        | P02/SO    | DSP (Digital Signal Processor) Interface [Command Data]                  | O   |
| 43      | CQCK        | P01/SCK   | DSP (Digital Signal Processor) Interface [Clock]                         | O   |
| 44      | DRF         | P00/INT4  | DRF Signal                                                               | I   |
| 45      | OPN SW      | P123      | Switch Detection Signal for Open End of CD Tray                          | I   |
| 46      | LIM SW      | P122      | Switch Detection Signal for Limit of Pickup                              | I   |
| 47      | NC          | P121      | Not Used (Ground)                                                        | I   |
| 48      | NC          | P120      | Not Used (Ground)                                                        | I   |
| 49      | NC          | P133      | Not Used (Ground)                                                        | I   |
| 50      | NC          | P132      | Not Used (Ground)                                                        | I   |
| 51      | SW PRE      | P131      | Select Signal from ON/OFF Switch for Pre Muting                          | I   |
| 52      | SW HI AC    | P130      | Select Signal from ON/OFF Switch for High Speed Access                   | I   |
| 53      | SW DAC      | P143      | Select Signal from ON/OFF Switch for DAC (Digital to Analogue Converter) | I   |
| 54      | SW BAND     | P142      | Select Signal from TU/BAND or FM Switch for Remocon Function             | I   |
| 55      | SW PST      | P141      | Select Signal from PST UP or SCAN Switch for Remocon Function            | I   |
| 56      | SW S D      | P140      | Select Signal from S/D Series Switch                                     | I   |
| 57      | NC          | NC        | Not Connection                                                           |     |
| 58      | VDD         | VDD       | Power Supply +5V                                                         |     |
| 59      | PULL UP     | P33       | Power supply to Pull Up Resistors                                        | O   |
| 60      | NC          | P32       | Not Used (Open)                                                          | O   |
| 61      | DSP RES     | P31       | Reset Control Signal for DSP (Digital Signal Processor)                  | O   |
| 62      | ATT         | P30       | DAC (Digital to Analogue Converter) Interface [Data]                     | O   |
| 63      | SHIFT       | P43       | DAC (Digital to Analogue Converter) Interface [Clock]                    | O   |
| 64      | LATCH       | P42       | DAC (Digital to Analogue Converter) Interface [Latch]                    | O   |



## IC BLOCK DIAGRAM (CD)

## IC104 LC7866E (Digital Signal Processor)

| No | PIN NAME | I/O | DESCRIPTION                                                                                                                     | No | PIN NAME | I/O | DESCRIPTION                                                                                                                                                                                                                |
|----|----------|-----|---------------------------------------------------------------------------------------------------------------------------------|----|----------|-----|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1  | TEST1    | I   | For TEST. Normal time is non connection.                                                                                        | 31 | SMP2     | O   | Output of signal to DAC, Signal of Latch & L/R select, Signal for Sampling Hold                                                                                                                                            |
| 2  | AO       | O   | Input from VCO output in LA9210 (8.6436MHz)                                                                                     | 32 | SMP1     | O   | Output of signal to DAC, Signal of Latch & L/R select, Signal for Sampling Hold                                                                                                                                            |
| 3  | AI       | I   | Phase comparison output of VCO and EFM signal.                                                                                  | 33 | LRCLK    | O   | Output of signal to DAC, Signal of Latch & L/R select, Signal for Sampling Hold                                                                                                                                            |
| 4  | PDO      | O   | GND                                                                                                                             | 34 | SMP      | O   | Output of signal to DAC, Signal of Latch & L/R select, Signal for Sampling Hold                                                                                                                                            |
| 5  | VSS      |     | GND                                                                                                                             | 35 | DFOUT    | O   | Output of signal to DAC, Signal of Latch & L/R select, Signal for Sampling Hold                                                                                                                                            |
| 6  | EFMO     | O   | Negative output through amplitude limiter. Antiphase of EFMO. This signal use SLICE LEVEL CONTROL.                              | 36 | DACLK    | O   | Output of signal to DAC, Signal of Latch & L/R select, Signal for Sampling Hold                                                                                                                                            |
| 7  | EFMO     | O   | Positive output through amplitude limiter. Antiphase of EFMO. This signal use SLICE LEVEL CONTROL.                              | 37 | TESTB    | O   | For TEST. Normal time is non connection.                                                                                                                                                                                   |
| 8  | EFMIN    | I   | Inputting HF signal of 1~2Vp.p. This signal use SLICE LEVEL CONTROL.                                                            | 38 | TESTC    | O   | For TEST. Normal time is non connection.                                                                                                                                                                                   |
| 9  | TEST2    | I   | For TEST. Normal time is non connection.                                                                                        | 39 | CK2      | O   | For output of signal that Comply with CD-ROM                                                                                                                                                                               |
| 10 | CLV+     | O   | Output for DISC MOTOR CONTROL.                                                                                                  | 40 | ROMO     | O   | For output of signal that Comply with CD-ROM                                                                                                                                                                               |
| 11 | CLV-     | O   | Output for DISC MOTOR CONTROL.                                                                                                  | 41 | C2FLCK   | O   | For output of signal that Comply with CD-ROM                                                                                                                                                                               |
| 12 | V/P      | O   | CLV rough Servo time : Output "H"<br>Phase control time : Output "L"                                                            | 42 | C2F      | O   | For output of signal that Comply with CD-ROM                                                                                                                                                                               |
| 13 | FOCS     | O   | Output "H" : Lens pull up with slowly than stop the Focus Servo. If FZD generate, it reset output of FOCS. For lead-in of Focus | 43 | DOUT     | O   | Output of DIGITAL OUT                                                                                                                                                                                                      |
| 14 | FST      | O   |                                                                                                                                 | 44 | SBSY     | O   | Synchronizing signal of sub-code block.                                                                                                                                                                                    |
| 15 | FZD      | I   |                                                                                                                                 | 45 | EFLG     | O   | For correction monitor of C1, C2, single, double.                                                                                                                                                                          |
| 16 | HFL      | I   | Comply with command of track jump, it oscillate kick Pulse, JP+ & JP-. It jump the prescribed number of track (1,4,16,64).      | 46 | PW       | O   | SFSY is Synchronizing signal of sub-code & frame. Clock of eighth send to SBCK then read out the sub-code of P, Q, R, S, T, U, V, & W.                                                                                     |
| 17 | TES      | I   | Comply with command of track jump, it oscillate kick Pulse, JP+ & JP-. It jump the prescribed number of track (1,4,16,64).      | 47 | SFSY     | O   |                                                                                                                                                                                                                            |
| 18 | PCK      | O   | PCK Monitor (4.3218MHz)                                                                                                         | 48 | SBCK     | I   |                                                                                                                                                                                                                            |
| 19 | FSEQ     | O   | SYNC(FS of truth) detected from EFM signal = SYNC of counter : "H" (Latch Output during in 1 frame)                             | 49 | FSX      | O   | Output of Synchronizing signal (7.35KHz)                                                                                                                                                                                   |
| 20 | TOFF     | O   | Comply with command of track jump, it oscillate kick Pulse, JP+ & JP-. It jump the prescribed number of track (1,4,16,64).      | 50 | WRQ      | O   | Data sub-code Q pass the CRC check then WRQ do "H". It detect at external, Data read out from SQOUT by send the CQCK. RWC set the "H" by Micro Processor then it let command by send with Synchronizing CQCK command data. |
| 21 | TGL      | O   |                                                                                                                                 | 51 | RWC      | I   |                                                                                                                                                                                                                            |
| 22 | THLD     | O   |                                                                                                                                 | 52 | SQOUT    | O   |                                                                                                                                                                                                                            |
| 23 | TEST3    | I   | For TEST. Normal time is non connection.                                                                                        | 53 | COIN     | I   |                                                                                                                                                                                                                            |
| 24 | VDD      |     | +5V                                                                                                                             | 54 | CQCK     | I   |                                                                                                                                                                                                                            |
| 25 | JP+      | O   | Comply with command of track jump, it oscillate kick Pulse, JP+ & JP-. It jump the prescribed number of track (1,4,16,64).      | 55 | RES      | I   | Turn on the Power Supply time : Once "L"                                                                                                                                                                                   |
| 26 | JP-      | O   |                                                                                                                                 | 56 | M/L      | I   | Data of SQOUT want at the LBS first time : M/L set the "L".                                                                                                                                                                |
| 27 | DEMO     | I   | For adjustment of production process. Sound on function.                                                                        | 57 | LASER    | O   | This output can control at Serial Control from Micro Processor                                                                                                                                                             |
| 28 | TEST4    | I   | For TEST. Normal time is non connection.                                                                                        | 58 | 16M      | O   | 16M Output (16.9344MHz)                                                                                                                                                                                                    |
| 29 | EMPH     | O   | Output is "H" time, it need de-emphasis                                                                                         | 59 | 4M       | O   | 4M Output (4.2336MHz)                                                                                                                                                                                                      |
| 30 | TESTA    | I   | For TEST. Normal time is "H".                                                                                                   | 60 | CONT     | O   | This output can control at Serial Control from Micro Processor                                                                                                                                                             |
|    |          |     |                                                                                                                                 | 61 | TEST5    | I   | For TEST. Normal time is non connection.                                                                                                                                                                                   |
|    |          |     |                                                                                                                                 | 62 | CS       | I   | Chip select Terminal. This terminal "L" : LC7866 is active (Internal Resistor : Pull Down)                                                                                                                                 |
|    |          |     |                                                                                                                                 | 63 | XIN      | I   | Connection Terminal of crystal oscillation (16.9344MHz)                                                                                                                                                                    |
|    |          |     |                                                                                                                                 | 64 | XOUT     | O   | Connection Terminal of crystal oscillation (16.9344MHz)                                                                                                                                                                    |





## IC BLOCK DIAGRAM (CD)


## IC105 SM5870DS (D/A Converter)

| No. | PIN NAME | I/O | FUNCTION                                                  |   |                        |                 |
|-----|----------|-----|-----------------------------------------------------------|---|------------------------|-----------------|
| 1   | XTO      | O   | Output Terminal of Oscillation                            |   |                        |                 |
| 2   | XVSS     |     | GND Terminal of Crystal Route (0V)                        |   |                        |                 |
| 3   | CKSLN    | I   | Frequency Select of XTI, CKO                              |   |                        |                 |
| 4   | CKO      | O   | Oscillation Part, Output of Clock                         |   |                        |                 |
| 5   | TSTN     | I   | Test Terminal H = Normal, L = Test Mode                   |   |                        |                 |
| 6   | NODN     | I   | A                                                         |   | MODN                   |                 |
|     |          |     | T                                                         |   | H                      | L               |
| 7   | ATTN     | I   | T                                                         | H | Release                | Soft Mute Hold  |
|     |          |     | N                                                         | L | Soft Mute              |                 |
| 8   | LRCI     | I   | Sample rate (fs) Clock of Input Data<br>H = L-ch L = R-ch |   |                        |                 |
| 10  | DIN      | I   | Bit Clock of Input Data                                   |   |                        |                 |
| 11  | DFS1     | I   | D                                                         |   | DSF1                   |                 |
|     |          |     | S                                                         |   | L                      | H               |
|     |          |     | F                                                         | L | De-Emphasis On 44.1kHz | De-Emphasis Off |
|     |          |     |                                                           |   | De-Emphasis On 48.0kHz |                 |
|     |          |     |                                                           |   | De-Emphasis Off        |                 |
|     |          |     |                                                           |   | De-Emphasis On 32.0kHz |                 |

| No. | PIN NAME | I/O | FUNCTION                           |  |
|-----|----------|-----|------------------------------------|--|
| 13  | MOTEO    | O   | Output of nfinity Zero Detector    |  |
| 14  | RSTN     | I   | System Reset H = Normal, L = Reset |  |
| 15  | DVSS     |     | Digital GND Terminal (0V)          |  |
| 16  | DVDD     |     | Digital VDD Terminal (5V)          |  |
| 17  | AVDD1    |     | Analog VDD Terminal 1 (5V)         |  |
| 18  | LO       | O   | PWM Output of L-channel (+)        |  |
| 19  | AVSS1    |     | Analog GND Terminal 1 (0V)         |  |
| 20  | LON      | O   | PWM Output of L-channel (-)        |  |
| 21  | AVDD2    |     | Analog VDD Terminal 2 (5V)         |  |
| 22  | AVDD3    |     | Analog VDD Terminal 3 (5V)         |  |
| 23  | RON      | O   | PWM Output of R-channel (-)        |  |
| 24  | AVSS2    |     | Analog GND Terminal 2 (0V)         |  |
| 25  | RO       | O   | PWM Output of R-channel (+)        |  |
| 26  | AVDD     |     | Analog VDD Terminal 4 (5V)         |  |
| 27  | XVDD     |     | VDD Terminal of Crystal Route (5V) |  |
| 28  | XTI      | I   | Input Terminal of Oscillation      |  |




## IC106 XRA15218F (Dual Operational Amplifier)






IC BLOCK DIAGRAM (CD & TUNER)


IC107 M5278D05 (3-Terminal Voltage Regulator)




IC108 NJM79L05A (3-Terminal Voltage Regulator)




IC109 NJM78L05A (3-Terminal Voltage Regulator)




IC201 LA1265-AUD (Tuner IF System)



IC202 LA3361 (FM PLL MPX. Stereo Demodulator)



IC203 LM7001 (PLL Frequency Synthesizer)



IC BLOCK DIAGRAM (FRONT)

IC251 µPD75306GF-225-3B9 (Micro Processor)



| PIN No. | SIGNAL NAME    | PORT NAME       | DESCRIPTION                                                          | I/O                 | CONNECT         |
|---------|----------------|-----------------|----------------------------------------------------------------------|---------------------|-----------------|
| 1       | SEG12          | S12             | Segment of Liquid Crystal Display                                    |                     | LCD             |
| 2       | SEG13          | S13             | Segment of Liquid Crystal Display                                    |                     | LCD             |
| 3       | SEG14          | S14             | Segment of Liquid Crystal Display                                    |                     | LCD             |
| 4       | SEG15          | S15             | Segment of Liquid Crystal Display                                    |                     | LCD             |
| 5       | SEG16          | S16             | Segment of Liquid Crystal Display                                    |                     | LCD             |
| 6       | SEG17          | S17             | Segment of Liquid Crystal Display                                    |                     | LCD             |
| 7       | SEG18          | S18             | Segment of Liquid Crystal Display                                    |                     | LCD             |
| 8       | SEG19          | S19             | Segment of Liquid Crystal Display                                    |                     | LCD             |
| 9       | SEG20          | S20             | Segment of Liquid Crystal Display                                    |                     | LCD             |
| 10      | SEG21          | S21             | Segment of Liquid Crystal Display                                    |                     | LCD             |
| 11      | SEG22          | S22             | Segment of Liquid Crystal Display                                    |                     | LCD             |
| 12      | SEG23          | S23             | Segment of Liquid Crystal Display                                    |                     | LCD             |
| 13      | SEG24          | S24 / BP0       | Segment of Liquid Crystal Display                                    |                     | LCD             |
| 14      | SEG25          | S25 / BP1       | Segment of Liquid Crystal Display                                    |                     | LCD             |
| 15      | SEG26          | S26 / BP2       | Segment of Liquid Crystal Display                                    |                     | LCD             |
| 16      | SEG27          | S27 / BP3       | Segment of Liquid Crystal Display                                    |                     | LCD             |
| 17      | AUTO           | S28 / BP4       | Auto Tuning Signal                                                   | ACTIVE : HIGH LEVEL | O TUNER         |
| 18      | NC             | S29 / BP5       | Not Used (Open)                                                      | O                   | OPEN            |
| 19      | NC             | S30 / BP6       | Not Used (Open)                                                      | O                   | OPEN            |
| 20      | NC             | S31 / BP7       | Not Used (Open)                                                      | O                   | OPEN            |
| 21      | COM 0          | COM0            | Common of Liquid Crystal Display                                     |                     | LCD             |
| 22      | COM 1          | COM1            | Common of Liquid Crystal Display                                     |                     | LCD             |
| 23      | COM 2          | COM2            | Common of Liquid Crystal Display                                     |                     | LCD             |
| 24      | COM 3          | COM3            | Common of Liquid Crystal Display                                     |                     | LCD             |
| 25      | BIAS           | BIAS            | Bias of Liquid Crystal Display                                       |                     |                 |
| 26      | VLC0           | VLC0            | Power Supply for Drive of Liquid Crystal Display                     |                     |                 |
| 27      | VLC1           | VLC1            | Power Supply for Drive of Liquid Crystal Display                     |                     |                 |
| 28      | VLC2           | VLC2            | Power Supply for Drive of Liquid Crystal Display                     |                     |                 |
| 29      | STEP           | P40             | AM Step Selection 9kHz (V <sub>DD</sub> ) / 10kHz (V <sub>SS</sub> ) | I                   | TUNER           |
| 30      | ST             | P41             | ST Signal                                                            | ACTIVE : LOW LEVEL  | I TUNER         |
| 31      | SD             | P42             | SD Signal                                                            | ACTIVE : LOW LEVEL  | I TUNER         |
| 32      | NC             | P43             | Not Used (Ground)                                                    | I                   | V <sub>SS</sub> |
| 33      | VSS            | V <sub>SS</sub> | Ground                                                               |                     |                 |
| 34      | CE (S)         | P50             | Data Signal from LM7001 (For S Series)                               | O                   | TUNER           |
| 35      | CLK (S)        | P51             | Data Signal from LM7001 (For S Series)                               | O                   | TUNER           |
| 36      | DO (S)         | P52             | Data Signal from LM7001 (For S Series)                               | O                   | TUNER           |
| 37      | MONO (S)       | P53             | Compulsion Monaural (For S Series)                                   | ACTIVE : HIGH LEVEL | O TUNER         |
| 38      | NC             | P00 / INT4      | Not Used (Ground)                                                    | I                   | V <sub>SS</sub> |
| 39      | SCK            | P01 / SCK       | Clock Signal In from Main Micro Processor (µPD65117)                 | I                   | MAIN µCON       |
| 40      | NC             | P02 / SO / SB0  | Not Used (Ground)                                                    |                     | V <sub>SS</sub> |
| 41      | SI             | P03 / SI / SB1  | Data In from Main Micro Processor (µPD65117)                         | I                   | MAIN µCON       |
| 42      | NC             | P10 / INT0      | Not Used (Ground)                                                    | I                   | V <sub>SS</sub> |
| 43      | NC             | P11 / INT1      | Not Used (Ground)                                                    | I                   | V <sub>SS</sub> |
| 44      | NC             | P12 / INT2      | Not Used (Ground)                                                    | I                   | V <sub>SS</sub> |
| 45      | NC             | P13 / T10       | Not Used (Ground)                                                    | I                   | V <sub>SS</sub> |
| 46      | WIDE           | P20 / PT100     | Select Signal for AM Signal Type Wide (HIGH) / Narrow (LOW)          | O                   | TUNER           |
| 47      | PCON (S)       | P21             | Tuner Power Signal (For S Series)                                    | ACTIVE : HIGH LEVEL | O TUNER         |
| 48      | MUTE           | P22 / PCL       | Tuner Mute Signal                                                    | ACTIVE : HIGH LEVEL | O TUNER         |
| 49      | BUSY           | P23 / BUZ       | Busy Signal Out to Main Micro Processor (µPD65117)                   | O                   | MAIN µCON       |
| 49      | BUSY           | P23 / BUZ       | Busy Signal Out to Main Micro Processor (µPD65117)                   | O                   | MAIN µCON       |
| 50      | S0             | P30 / LCDCL     | Initial Set for User = Country (Open or Ground)                      | I                   |                 |
| 51      | S1             | P31 / SYNC      | Initial Set for User = Country (Open or Ground)                      | I                   |                 |
| 52      | S2             | P32             | Initial Set for User = Country (Open or Ground)                      | I                   |                 |
| 53      | S3 (FM MUTE)   | P33             | Select Signal for FM Auto Mute SET (Open) / NOT (V <sub>SS</sub> )   | I                   |                 |
| 54      | VDD            | V <sub>DD</sub> | Power Supply +5V                                                     |                     | V <sub>DD</sub> |
| 55      | NC             | XT1             | Not Used (Ground) OSC X'tal Terminal for Main Clock                  | I                   | V <sub>SS</sub> |
| 56      | NC             | XT2             | Not Used (Open) OSC X'tal Terminal for Main Clock                    | O                   |                 |
| 57      | NC             | NC              | Non Connection                                                       |                     |                 |
| 58      | X1             | XI              | X'tal In (4.194304 MHz)                                              | I                   |                 |
| 59      | X2             | XO              | X'tal Out (4.194304 MHz)                                             | O                   |                 |
| 60      | S4 (12H / 24H) | P60 / KR0       | Select Signal for CLOCK 24H (Open) / 12H (V <sub>SS</sub> )          | I                   |                 |
| 61      | S5 (AM IF)     | P61 / KR1       | Select Signal for AM IF SET (Open) / NOT (V <sub>SS</sub> )          | I                   | TUNER           |
| 62      | S6 (D / S)     | P62 / KR2       | Select Signal for D & S Series SET (Open) / NOT (V <sub>SS</sub> )   | I                   |                 |
| 48      | MUTE           | P22 / PCL       | Tuner Mute Signal                                                    | ACTIVE : HIGH LEVEL | O TUNER         |
| 63      | MONO (D)       | P63 / KR3       | Compulsion Monaural (For D Series)                                   | ACTIVE : HIGH LEVEL | O TUNER         |
| 64      | DO (D)         | P70 / KR4       | Data Signal from LM7001 (For D Series)                               | O                   | TUNER           |
| 65      | CLK (D)        | P71 / KR5       | Data Signal from LM7001 (For D Series)                               | O                   | TUNER           |
| 66      | CE (D)         | P72 / KR6       | Data Signal from LM7001 (For D Series)                               | O                   | TUNER           |
| 67      | PCON (D)       | P73 / KR7       | Tuner Power Signal (For D Series)                                    | ACTIVE : HIGH LEVEL | O TUNER         |
| 68      | RESET          | RESET           | System Reset Signal                                                  |                     | RESET CIRCUIT   |
| 69      | SEG0           | S0              | Segment of Liquid Crystal Display                                    |                     | LCD             |
| 70      | SEG1           | S1              | Segment of Liquid Crystal Display                                    |                     | LCD             |



## IC BLOCK DIAGRAM (FRONT)


| PIN No. | SIGNAL NAME | PORT NAME | DESCRIPTION                       | I/O | CONNECT |
|---------|-------------|-----------|-----------------------------------|-----|---------|
| 71      | SEG2        | S2        | Segment of Liquid Crystal Display |     | LCD     |
| 72      | SEG3        | S3        | Segment of Liquid Crystal Display |     | LCD     |
| 73      | SEG4        | S4        | Segment of Liquid Crystal Display |     | LCD     |
| 74      | SEG5        | S5        | Segment of Liquid Crystal Display |     | LCD     |
| 75      | SEG6        | S6        | Segment of Liquid Crystal Display |     | LCD     |
| 76      | SEG7        | S7        | Segment of Liquid Crystal Display |     | LCD     |
| 77      | SEG8        | S8        | Segment of Liquid Crystal Display |     | LCD     |
| 78      | SEG9        | S9        | Segment of Liquid Crystal Display |     | LCD     |
| 79      | SEG10       | S10       | Segment of Liquid Crystal Display |     | LCD     |
| 80      | SEG11       | S11       | Segment of Liquid Crystal Display |     | LCD     |

## LCD (CT UNIT)





| NO. | COM. 1    | COM. 2  | COM. 3 | COM. 4 | NO. | COM. 1 | COM. 2 | COM. 3 | COM. 4 |
|-----|-----------|---------|--------|--------|-----|--------|--------|--------|--------|
| 1   | CONT      | ALL     | ONE    | REPEAT | 17  | INTRO  | 5b.c   | 5g     |        |
| 2   | 13        | 14      | 15     | ▶      | 18  | 6f     | 6g     | 6e     | 6d     |
| 3   | 12        | 11      | 10     | 9      | 19  | 6a     | 6b     | 6c     | MONO   |
| 4   | 5         | 6       | 7      | 8      | 20  | 7f     | 7g     | 7e     | 7d     |
| 5   | 4         | 3       | 2      | 1      | 21  | 7a     | 7b     | 7c     | FADE   |
| 6   | SLEEP     | WAKE UP | TIMER  | REC    | 22  | RANDM  | :      | .      | TIME   |
| 7   | COMP. REC | LEVEL   | DISC   | PROG.  | 23  | 8f     | 8g     | 8e     | 8d     |
| 8   | 1h        | 1a.e.f  | 1b.c   | 1d     | 24  | 8a     | 8b     | 8c     | EDIT   |
| 9   | 2f        | 2g      | 2e     | 2d     | 25  | 9f     | 9g     | 9e     | 9d     |
| 10  | 2a        | 2b      | 2c     | ST     | 26  | 9a     | 9b     | 9c     |        |
| 11  | 3f        | 3g      | 3e     | 3d     | 27  | OFF    | ON     | KHz    | MHz    |
| 12  | 3a        | 3b      | 3c     | TRACK  | 28  | DISE A | DISE B | AM     | PM     |
| 13  | 4f        | 4g      | 4e     | 4d     | 29  | COM. 1 |        |        |        |
| 14  | 4a        | 4b      | 4c     | AUTO   | 30  |        | COM. 2 |        |        |
| 15  | WIDE      | FM      | MW     | LW     | 31  |        |        | COM. 3 |        |
| 16  | CLOCK     | 1 (FM)  | 2 (FM) | AM     | 32  |        |        |        | COM. 4 |

## BLOCK DIAGRAM (CD)










# SCHEMATIC DIAGRAM (CD)





















## SCHEMATIC DIAGRAM (TUNER)

FOR 07B


















VOLTAGES OF IC (CD)

(Unit : Volt)

|                   |      |      |      |      |      |      |      |      |      |      |       |      |      |      |      |      |
|-------------------|------|------|------|------|------|------|------|------|------|------|-------|------|------|------|------|------|
| IC101 LA9210M     |      |      |      |      |      |      |      |      |      |      |       |      |      |      |      |      |
| Measuring Pin No. | 1    | 2    | 3    | 4    | 5    | 6    | 7    | 8    | 9    | 10   | 11    | 12   | 13   | 14   | 15   | 16   |
| Stop Mode         | 0    | -5.0 | 0    | 0    | 0    | 0    | 0    | 0    | 0    | 2.59 | 2.54  | 2.55 | 0    | 0    | 0    | 0    |
| Play Mode         | 0    | -5.0 | Fluc | Fluc | Fluc | Fluc | Fluc | 0    | 0    | Fluc | Fluc  | Fluc | Fluc | Fluc | Fluc | Fluc |
| Measuring Pin No. | 17   | 18   | 19   | 20   | 21   | 22   | 23   | 24   | 25   | 26   | 27    | 28   | 29   | 30   | 31   | 32   |
| Stop Mode         | 0    | 0    | 0    | 0    | Fluc | Fluc | 0    | 0    | 0    | 0    | Fluc  | 2.43 | 0    | 0    | 0    | -5.0 |
| Play Mode         | Fluc | Fluc | Fluc | Fluc | Fluc | Fluc | Fluc | Fluc | 0    | Fluc | Fluc  | Fluc | Fluc | Fluc | Fluc | -5.0 |
| Measuring Pin No. | 33   | 34   | 35   | 36   | 37   | 38   | 39   | 40   | 41   | 42   | 43    | 44   | 45   | 46   | 47   | 48   |
| Stop Mode         | 0    | 0    | 0    | 5.0  | 4.39 | 0    | 0    | 0    | 0    | 0    | 0     | 0    | 4.97 | 4.92 | 4.07 | 4.07 |
| Play Mode         | Fluc | Fluc | Fluc | 5.0  | Fluc | Fluc | Fluc | Fluc | 0    | Fluc | Fluc  | Fluc | Fluc | Fluc | Fluc | Fluc |
| Measuring Pin No. | 49   | 50   | 51   | 52   | 53   | 54   | 55   | 56   | 57   | 58   | 59    | 60   | 61   | 62   | 63   | 64   |
| Stop Mode         | 4.07 | 0    | 0    | 0    | 2.52 | 2.49 | 2.50 | 5.0  | 2.51 | 2.51 | 2.54  | 3.92 | 2.60 | 2.33 | 4.92 | 0    |
| Play Mode         | Fluc | Fluc | Fluc | Fluc | Fluc | Fluc | Fluc | 5.0  | Fluc | Fluc | Fluc  | Fluc | Fluc | Fluc | Fluc | 0    |
| Measuring Pin No. | 65   | 66   | 67   | 68   | 69   | 70   | 71   | 72   | 73   | 74   | 75    | 76   | 77   | 78   | 79   | 80   |
| Stop Mode         | 0    | 0.4  | -0.4 | 0    | -0.5 | -0.5 | 0    | -0.5 | 0    | 4.82 | -4.97 | 4.83 | 5.0  | 0    | 0    | 0    |
| Play Mode         | 0    | Fluc | Fluc | Fluc | Fluc | Fluc | 0    | Fluc | Fluc | Fluc | Fluc  | Fluc | 5.0  | Fluc | Fluc | 0    |

IC102 LA6524

Fluc : Fluctuation

|                   |      |      |     |      |      |      |      |    |      |      |
|-------------------|------|------|-----|------|------|------|------|----|------|------|
| Measuring Pin No. | 1    | 2    | 3   | 4    | 5    | 6    | 7    | 8  | 9    | 10   |
| Play Mode         | Fluc | Fluc | -11 | Fluc | Fluc | Fluc | Fluc | 10 | Fluc | 8.60 |

IC103  $\mu$ PD75116

|                   |     |     |    |       |       |       |       |      |     |     |     |     |       |     |     |       |
|-------------------|-----|-----|----|-------|-------|-------|-------|------|-----|-----|-----|-----|-------|-----|-----|-------|
| Measuring Pin No. | 1   | 2   | 3  | 4     | 5     | 6     | 7     | 8    | 9   | 10  | 11  | 12  | 13    | 14  | 15  | 16    |
| Stop Mode         | 0   |     |    | (0)   | (0)   | (0)   |       |      |     |     |     |     |       |     |     | (0)   |
| Play Mode         | 4.8 | 5.0 | 0  | (5.0) | (5.0) | (5.0) | 5.0   | 2.5  | 2.5 | 4.7 | 5.0 | 5.0 | 0     | 0   | 0   | (4.8) |
| Measuring Pin No. | 17  | 18  | 19 | 20    | 21    | 22    | 23    | 24   | 25  | 26  | 27  | 28  | 29    | 30  | 31  | 32    |
| Stop Mode         |     |     |    |       |       |       | (0)   | 0    |     |     |     |     |       |     |     |       |
| Play Mode         | 0   | 0   | 0  | 0     | 0     | 5.0   | (5.0) | Fluc | 2.5 | 0   | 4.7 | 4.8 | 0     | 5.0 | 5.0 | 5.0   |
| Measuring Pin No. | 33  | 34  | 35 | 36    | 37    | 38    | 39    | 40   | 41  | 42  | 43  | 44  | 45    | 46  | 47  | 48    |
| Stop Mode         |     |     |    |       | (0)   |       | (5.0) |      |     |     |     | 0   |       |     |     |       |
| Play Mode         | 5.0 | 5.0 | 0  | 0     | (5.0) | 0     | (0)   | 0    | 0   | 0   | 5.0 | 4.0 | 5.0   | 5.0 | 0   | 0     |
| Measuring Pin No. | 49  | 50  | 51 | 52    | 53    | 54    | 55    | 56   | 57  | 58  | 59  | 60  | 61    | 62  | 63  | 64    |
| Stop Mode         |     |     |    |       |       |       |       |      |     |     |     |     | (0)   |     |     | 0     |
| Play Mode         | 0   | 0   | 0  | 0     | 0     | 5.0   | 0     | 0    | 5.0 | 5.0 | 5.0 | 5.0 | (5.0) | 0   | 5.0 | 5.0   |

- NOTES :
- PIN 4 :

Stop Mode = OTHER

Play Mode = TAPE & TUNER

PIN 5 :

Stop Mode = OTHER

Play Mode = CD & PHONO

PIN 6 :

Stop Mode = OTHER

Play Mode = TUNER , AV & CD
- PIN 16 :

Stop Mode = OTHER

Play Mode = WAIT THE SYNCRO

PIN 23 :

Stop Mode = ON THE DISC

Play Mode = ON THE NO DISC

PIN 37 :

Stop Mode = OTHER

Play Mode = CLOSING THE TRAY
- PIN 39 :

Stop Mode = OTHER

Play Mode = OPENING THE TRAY

PIN 62 :

Stop Mode = EMPHASIS ON

Play Mode = EMPHASIS OFF

IC104 LC7866E

|                   |      |      |      |      |      |      |      |      |        |      |      |      |      |      |      |      |
|-------------------|------|------|------|------|------|------|------|------|--------|------|------|------|------|------|------|------|
| Measuring Pin No. | 1    | 2    | 3    | 4    | 5    | 6    | 7    | 8    | 9      | 10   | 11   | 12   | 13   | 14   | 15   | 16   |
| Stop Mode         | 0    | 2.31 | 2.34 | 2.51 | 0    | 2.46 | 2.48 | 2.52 | 0      | 0    | 0    | 4.92 | 0    | 2.51 | 4.07 | 4.07 |
| Play Mode         | Fluc | Fluc | Fluc | Fluc | 0    | Fluc | Fluc | Fluc | Fluc   | Fluc | Fluc | Fluc | Fluc | Fluc | Fluc | Fluc |
| Measuring Pin No. | 17   | 18   | 19   | 20   | 21   | 22   | 23   | 24   | 25     | 26   | 27   | 28   | 29   | 30   | 31   | 32   |
| Stop Mode         | 4.07 | 2.5  | 0    | 4.95 | 4.97 | 0    | 0    | 5.0  | 0      | 0    | 0    | 0    | 0    | 5.0  | 1.25 | 1.25 |
| Play Mode         | Fluc | Fluc | Fluc | Fluc | Fluc | Fluc | Fluc | 5.0  | Fluc   | Fluc | Fluc | Fluc | Fluc | 5.0  | Fluc | Fluc |
| Measuring Pin No. | 33   | 34   | 35   | 36   | 37   | 38   | 39   | 40   | 41     | 42   | 43   | 44   | 45   | 46   | 47   | 48   |
| Stop Mode         | 2.5  | 2.5  | 0    | 2.5  | 0    | 2.5  | 2.41 | 1.63 | 2.5    | 4.5  | 2.52 | Fluc | 2.28 | 0    | 2.5  | 0    |
| Play Mode         | Fluc | Fluc | Fluc | Fluc | Fluc | Fluc | Fluc | Fluc | 0(4.5) | Fluc | Fluc | Fluc | Fluc | Fluc | Fluc | Fluc |
| Measuring Pin No. | 49   | 50   | 51   | 52   | 53   | 54   | 55   | 56   | 57     | 58   | 59   | 60   | 61   | 62   | 63   | 64   |
| Stop Mode         | 2.5  | Fluc | Fluc | Fluc | 0    | 5.0  | 4.48 | 0    | 4.92   | Fluc | 2.33 | 4.93 | 0    | 0    | 2.28 | 2.47 |
| Play Mode         | Fluc | Fluc | Fluc | Fluc | 0    | 5.0  | Fluc | 0    | Fluc   | Fluc | Fluc | Fluc | Fluc | 0    | Fluc | Fluc |

IC105 SM5870DS

|                   |     |     |    |     |     |     |     |     |     |     |     |     |    |     |    |     |
|-------------------|-----|-----|----|-----|-----|-----|-----|-----|-----|-----|-----|-----|----|-----|----|-----|
| Measuring Pin No. | 1   | 2   | 3  | 4   | 5   | 6   | 7   | 8   | 9   | 10  | 11  | 12  | 13 | 14  | 15 | 16  |
| Play Mode         | 3.0 | 0   | 0  | 0   | 5.0 | 5.0 | 5.0 | 2.5 | 2.4 | 1.6 | 5.0 | 0   | 0  | 4.8 | 0  | 5.0 |
| Measuring Pin No. | 17  | 18  | 19 | 20  | 21  | 22  | 23  | 24  | 25  | 26  | 27  | 28  |    |     |    |     |
| Play Mode         | 5.0 | 2.4 | 0  | 2.4 | 5.0 | 5.0 | 2.4 | 0   | 2.4 | 5.0 | 5.0 | 1.3 |    |     |    |     |

IC106 XRA15218F

|                   |      |     |     |      |     |     |      |     |
|-------------------|------|-----|-----|------|-----|-----|------|-----|
| Measuring Pin No. | 1    | 2   | 3   | 4    | 5   | 6   | 7    | 8   |
| Play Mode         | Fluc | 1.3 | 1.3 | -5.0 | 1.3 | 1.3 | Fluc | 5.0 |

VOLTAGES OF IC & TRANSISTOR (CD)

|                    |         |         |        |         |        |         |         |         |        |
|--------------------|---------|---------|--------|---------|--------|---------|---------|---------|--------|
| Transistor No.     | IC107   |         |        | IC108   |        |         | IC109   |         |        |
| Measuring Pin Name | 1 (OUT) | 2 (GND) | 3 (IN) | 1 (COM) | 2 (IN) | 3 (OUT) | 1 (OUT) | 2 (GND) | 3 (IN) |
| Stop Mode          | 5.0     | 0       | 11     | -11.5   | 0      | -5.0    | 5.6     | 0.6     | 12     |
| Play Mode          | 5.0     | 0       | 10     | -11.5   | 0      | -5.0    | 5.6     | 0.6     | 12     |


TRANSISTOR

(Unit : Volt)

|                    |       |     |      |       |      |      |       |     |     |       |     |     |
|--------------------|-------|-----|------|-------|------|------|-------|-----|-----|-------|-----|-----|
| Transistor No.     | Q101  |     |      | Q102  |      |      | Q103  |     |     | Q1301 |     |     |
| Measuring Pin Name | E     | C   | B    | E     | C    | B    | E     | C   | B   | E     | C   | B   |
| Stop Mode          | 5.0   | 0   | 4.7  | 2.0   | 2.5  | 2.5  | 0     | 0   | 0.6 |       |     |     |
| Play Mode          | 3.6   | 1.8 | 3.0  |       |      |      | 0     | 4.9 | 0   | 5.0   | 5.0 | 0   |
| Transistor No.     | Q1302 |     |      | Q1303 |      |      | Q1304 |     |     | Q1305 |     |     |
| Measuring Pin Name | E     | C   | B    | E     | C    | B    | E     | C   | B   | E     | C   | B   |
| Stop Mode          |       |     |      | 4.8   | 4.8  | 0    | 0     | 0   | 0.6 | 5.0   | 5.0 | 4.3 |
| Play Mode          | 0     | 5.0 | 0    | 0     | -5.0 | 0    | 0     | 0   | 0.6 | 5.0   | 5.0 | 4.3 |
| Transistor No.     | Q1500 |     |      | Q1501 |      |      |       |     |     |       |     |     |
| Measuring Pin Name | E     | C   | B    | E     | C    | B    |       |     |     |       |     |     |
| Stop Mode          | 0     | 0   | 0.6  | 0     | 0    | 0.6  |       |     |     |       |     |     |
| Play Mode          | 0     | 0   | -5.0 | 0     | 0    | -5.0 |       |     |     |       |     |     |



# WIRING CONNECTION (TUNER / CD UNIT)





TAPE DECK / AMPLIFIER UNIT

ADJUSTMENT (TAPE DECK)

1. Amplifier Adjustment

| STEP | ITEM                 | DECK             | TEST TAPE | INPUT                   | DOLBY SW | OUTPUT      | ADJUST POINT                                                 | REMARKS                                                                                                  |
|------|----------------------|------------------|-----------|-------------------------|----------|-------------|--------------------------------------------------------------|----------------------------------------------------------------------------------------------------------|
| 1    | Head Azimuth         | DECK A<br>DECK B | VTT738    | -                       | OFF      | TAPE<br>OUT | Azimuth<br>Screw                                             | Adjust so as 10kHz output become maximum.                                                                |
| 2    | Playback Level       | DECK A<br>DECK B | TCC130    | -                       | OFF      | TAPE<br>OUT | SVR30 (L-ch)<br>SVR31 (R-ch)<br>SVR32 (L-ch)<br>SVR33 (R-ch) | Adjust so as TAPE OUT output become 0.54V.                                                               |
| 3    | Rec / Play Level     | DECK A           | AC224     | 1kHz<br>-18dB           | OFF      | TAPE<br>OUT | SVR34 (L-ch)<br>SVR35 (R-ch)                                 | Adjust SVR so as Monitor o/p = R/P Level = 0dB ± 1dB.                                                    |
| 4    | Rec / Play Frequency | DECK B           | AC224     | 1kHz<br>/10kHz<br>-28dB | OFF      | TAPE<br>OUT | SVR36 (L-ch)<br>SVR37 (R-ch)                                 | R/P signal, set frequency characteristic 1kHz output to 0dB. Adjust SVR so as 10kHz output become ± 1dB. |


**Note.** 1. During alignment, measurement Beat cancel SW is at 1 condition fundamentally, confirm Rec / Play frequency characteristic, dolby effect also by 2 condition, when ship out set SW to 1 position.

2. Tape Speed Adjustment


Connect the FREQUENCY COUNTER to TAPE OUT.

1. Insert the test tape(MTT-111N, etc. : 3000Hz) into the DECK A.
2. Press the FWD PLAY button.
3. Adjust SVR001 so that a frequency counter reading of  $3000 \pm 5$  Hz is obtained.
4. Press the STOP button, and eject the test tape.
5. Insert the test tape(TCW-211, etc. : 1500Hz) into the DECK A.
6. Insert the tape (C-60 Blank tape) into the DECK B.
7. Press the REC button of DECK B and press the DECK A/B button.  
Press the FWD PLAY button. Both mechanism become normal speed dubbing.
8. Short the high speed test pin to the high speed position.  
(The mechanism is high speed dubbing.)
9. Confirm that a frequency counter reading of 2700 ~ 3300Hz is obtained.

**Note :** Set the test tape near the tape end.



3. Parts Location



PCS 67 739

ADJUSTMENT & TORQUE (TAPE DECK)


4. Torque Measurements

| ITEM          | TAKE-UP TORQUE                                                  | BACK TENSION                                                 | TAPE TENSION                                            |
|---------------|-----------------------------------------------------------------|--------------------------------------------------------------|---------------------------------------------------------|
| Test cassette | PLAY : TW2111(FWD)<br>PLAY : TW2121(REV)<br>F.FWD / REW; TW2231 | PLAY : TW2111(FWD)<br>PLAY : TW2121(REV)<br>REW: Torque Gage | Driving power cassette:<br>TW-2412(FWD)<br>TW-2422(REV) |
| PLAY          | 30 ~ 60gr.cm                                                    | 2.0 ~ 5.0gr.cm                                               | > 80g                                                   |
| F.FWD         | 70 ~ 140gr.cm                                                   | -                                                            |                                                         |
| REW           | 70 ~ 140gr.cm                                                   | -                                                            |                                                         |


5. Replacement of Head

Lead Connection Method of Rotary Head

1. Fix the leads from the head at the stem with the rubber adhesives.
2. Twist the fixed leads.




6. Replacement of Motor and Belt





EXPLODED VIEW (TAPE DECK / AMPLIFIER UNIT)



PARTS LIST (TAPE DECK / PRE-AMPLIFIER UNIT)

PRODUCT SAFETY NOTICE

Each precaution in this manual should be followed during servicing. Components identified with the IEC symbol  $\Delta$  in the parts list and the schematic diagram designate components in which safety can be of special significance. When replacing a component identified  $\Delta$ , use only the replacement parts designated, or parts with the same ratings of resistance, wattage or voltage that are designated in the parts list in this manual. Leakage-current or resistance measurements must be made to determine that exposed parts are acceptably insulated from the supply circuit before returning the product to the customer.

CAUTION: Regular type resistors and capacitors are not listed. To know those values, refer to the schematic diagram.

CABINET

| Ref. No. | Part No.       | Description                     | Ref. No. | Part No.       | Description                                |
|----------|----------------|---------------------------------|----------|----------------|--------------------------------------------|
| DA1      | 4822 443 41204 | ASSY, PANEL, FRONT              | DAY07    |                | SCR S-TPG BIN 3X8, FRONT-BOTTOM FIX        |
| DA2      | 4822 443 10126 | ASSY, CABINET, TOP              | DAY08    |                | SCR S-TPG BIN 3X8, HEAT SINK-BRACKET FIX   |
| DA3      | 4822 426 20229 | ASSY, PANEL, REAR /01B          | DAY09    |                | SCR S-TPG BIN 3X8, BRACKET-PCB FIX         |
| DA3      | 4822 426 20231 | ASSY, PANEL, REAR /07B          | DAY10    |                | SCR S-TPG BIN 3X8, PCB-BOTTOM FIX          |
| DA3      | 4822 426 20232 | ASSY, PANEL, REAR /60B          | DAY11    |                | SCR S-TPG BIN 3X8, 3-TERMINALS FIX         |
| DA4      |                | ASSY, CABINET, BOTTOM           | DAY12    |                | SCR S-TPG BIN 3X8, SHIELD-SIDE PCB FIX     |
| DA5      | 4822 443 63806 | ASSY, COVER, TAPE A             | DAY13    |                | SCR S-TPG BIN 3X8, D.MECHA - BRACKET-E FIX |
| DA6      | 4822 443 63807 | ASSY, COVER, TAPE B             | DAY14    |                | SCR S-TPG BIN 3X8, REAR PANEL FIX          |
| DA7      | 4822 454 21081 | ASSY, ESCUTCHEON, LCD           | DAT15    | 4822 502 13808 | SCR S-TPG BRZ+FLG 3X8, DECK PCB FIX        |
| DA8      | 4822 454 21079 | ESCUTCHEON, LCD VIEW AREA COVER | DAY16    |                | SCR S-TPG BIN 3X10, CABINET                |
| DA9      | 4822 450 62005 | WINDOW, TAPE-VIDEO(LED)         | DAY17    |                | SCR S-TPG BIN 3X10, GEAR                   |
| DA10     | 4822 450 62006 | WINDOW, DYNAMIC BASS(LED)       | DAY18    | 4822 502 13783 | SCR S-TPG BRZ+FLG 3X14, HEAT SINK-POWER IC |
| DA11     | 4822 413 41763 | KNOB, ROTARY, VOLUME            | DAY19    |                | SCR S-TPG BIN 3X25, MECHANISM FIX          |
| DA12     | 4822 413 31725 | KNOB, ROTARY, BALANCE           | DAY20    |                | SCR S-TPG BIM 4X8, P.T                     |
| DA13     | 4822 410 62418 | BUTTON, POWER                   | DAY21    |                | WASHER Z 3X10X1, PHONO EARTH               |
| DA14     | 4822 410 62491 | ASSY, BUTTON, PRESET            | DAY22    |                | WASHER OUT TW 3, PHONO EARTH               |
| DA15     | 4822 410 62419 | BUTTON, EQUALIZER               |          |                |                                            |
| DA16     | 4822 410 62421 | BUTTON, FUNCTION                |          |                |                                            |
| DA17     | 4822 410 62422 | BUTTON, F.FWD/REWIND            |          |                |                                            |
| DA18     | 4822 413 31726 | KNOB, LEVER, EJECT A            |          |                |                                            |
| DA19     | 4822 413 41772 | KNOB, LEVER, EJECT B            |          |                |                                            |
| DA20     | 4822 410 62424 | ASSY, BUTTON, REC               |          |                |                                            |
| DA21     | 4822 410 62425 | ASSY, BUTTON, PLAY              |          |                |                                            |
| DA22     |                | COVER, PANEL REAR               |          |                |                                            |
| DA23     | 4822 532 12223 | FIXER, AC CORD                  |          |                |                                            |
| DA24     |                | SCREW, SPECIAL, PHONO EARTH     |          |                |                                            |

CHASSIS

| Ref. No. | Part No.       | Description                 | Ref. No. | Part No.                | Description                                |
|----------|----------------|-----------------------------|----------|-------------------------|--------------------------------------------|
| DA31     | 4822 443 63808 | ASSY, LID, CASSETTE, TAPE A | DA51     |                         | POWER CORD, AC-IN /07B                     |
| DA32     | 4822 443 63809 | ASSY, LID, CASSETTE, TAPE B | DA51 or  |                         | POWER CORD, AC-IN /01B /60B                |
| DA33     | 4822 403 70797 | LEVER, EJECT L              | DA52     | $\Delta$ 4822 070 31252 | POWER CORD, AC-IN /01B /60B                |
| DA34     | 4822 403 70798 | LEVER, EJECT R              |          |                         | FUSE 250V T1.25A, POWER (FU999)            |
| DA35     | 4822 492 33375 | SPRING, TENS, EJECT         | DA53     | $\Delta$ 4822 146 21713 | POWER TRANSFORMER /01B                     |
| DA36     | 4822 522 33336 | ASSY, GEAR, CASSETTE DUMPER | DA53     | $\Delta$ 4822 146 21714 | POWER TRANSFORMER /07B                     |
| DA37     | 4822 529 10293 | MOUNT-M, DUMPER GEAR FIX    | DA53     | $\Delta$ 4822 146 21715 | POWER TRANSFORMER /60B                     |
| DA38     | 4822 492 71276 | SPRING WIRE, CASSETTE OPEN  | DA54     |                         | HEAT SINK, FOR IC700                       |
| DA39     | 4822 492 71277 | SPRING WIRE, CASSETTE OPEN  | DA55     | $\Delta$ 4822 253 30146 | FUSE 250V T3.15A, SPEAKER (FU701-801)      |
| DA40     |                | BRACKET-E, DECK PCB         |          |                         | CORD, 17P, FRONT-MAIN(FFC)                 |
| DA41     | 4822 532 12224 | FIXER, DECK PCB             | DA56     | 4822 321 61848          | INSULATOR, P.T COVER                       |
| DA42     |                | BRACKET-M, HEAT SINK        | DA57     |                         | LUG, EARTH                                 |
| DA43     |                | SHIELD, RCA SOCKET          | DA58     | $\Delta$ 4822 253 30429 | FUSE 250V T2.5A(FU998) /01B                |
| DA44     | 4822 532 12225 | FIXER, MAIN PCB             | DA59     | $\Delta$ 4822 272 10343 | SWITCH, SELECTOR, VOLTAGE /01B             |
| DA45     | 4822 532 12226 | INSULATOR, SPEAKER SOCKET   | DA60     |                         | ASSY, CONNECTOR-S, 3P, FRONT-PRE           |
|          |                | FIXER, DRESS LEAD           | DA61     |                         | ASSY, CONNECTOR-S, 4P, FRONT-SP            |
|          |                |                             | DA62     |                         | ASSY, CONNECTOR-S, 8P, MAIN-MECHA.A(CN001) |
|          |                |                             | DA63     |                         | ASSY, CONNECTOR-S, 8P, MAIN-MECHA.B(CN002) |
|          |                |                             | DA64     |                         | ASSY, CONNECTOR-S, 9P, PRE-DECK(CN301)     |
|          |                |                             | DA65     |                         | ASSY, CONNECTOR-S, 9P, MAIN-DECK(CN302)    |
|          |                |                             | DA66     |                         |                                            |

FIXING PARTS

| Ref. No. | Part No.       | Description                               |
|----------|----------------|-------------------------------------------|
| DAY01    |                | SCR S-TPG BIN 2.6X8, LED PCB FIX          |
| DAY02    |                | SCR S-TPG BIN 2.6X10, FRONT PCB FIX       |
| DAY03    |                | SCR S-TPG BIN 2.6X10, DECK PCB FIX        |
| DAY04    |                | SCR S-TPG BIN 3X6, IC-TR FIX              |
| DAY05    |                | SCR S-TPG BIN 3X6, LUG FIX                |
| DAY06    | 4822 502 13789 | SCR S-TPG BRZ+FLG 3X6, BRACKET-BOTTOM FIX |



## PARTS LIST (TAPE DECK / AMPLIFIER UNIT)

| Ref. No. | Part No. | Description                               |
|----------|----------|-------------------------------------------|
| DA67     |          | ASSY, CONNECTOR-S, 2P,<br>E HEAD(CN341)   |
| DA68     |          | ASSY, CONNECTOR-S, 3P,<br>P HEAD(CN381)   |
| DA69     |          | ASSY, CONNECTOR-S, 5P,<br>R/P HEAD(CN382) |

## PRE-AMPLIFIER P.C.BOARD ASSY

| Ref. No. | Part No.       | Description                          |
|----------|----------------|--------------------------------------|
| DA71     |                | ASSY, PCB, PRE-AMP. /01B             |
| or       |                | ASSY, PCB, PRE-AMP. /07B             |
| or       |                | ASSY, PCB, PRE-AMP. /60B             |
| C4516    |                | MT-POLYEST 0.082U J 63V              |
| C4517    |                | MT-POLYEST 0.27U J 63V               |
| C4518    |                | MT-POLYEST 0.033U J 63V              |
| C4519    |                | MT-PLLYEST 0.1U J 63V                |
| C4572    | 4822 121 70253 | POLYESTER 0.1U J 50V                 |
| C4573    | 4822 121 70253 | POLYESTER 0.1U J 50V                 |
| C4574    | 4822 121 70253 | POLYESTER 0.1U J 50V                 |
| C4575    | 4822 121 70253 | POLYESTER 0.1U J 50V                 |
| C4578    |                | POLYESTER 0.056U J 50V               |
| C4616    |                | MT-POLYEST 0.082U J 63V              |
| C4617    |                | MT-POLYEST 0.27U J 63V               |
| C4618    |                | MT-POLYEST 0.033U J 63V              |
| C4619    |                | MT-PLLYEST 0.1U J 63V                |
| C4672    | 4822 121 70253 | POLYESTER 0.1U J 50V                 |
| C4673    | 4822 121 70253 | POLYESTER 0.1U J 50V                 |
| C4674    | 4822 121 70253 | POLYESTER 0.1U J 50V                 |
| C4675    | 4822 121 70253 | POLYESTER 0.1U J 50V                 |
| C4678    |                | POLYESTER 0.056U J 50V               |
| CN301    |                | PLUG, 9P, TO DECK                    |
| CN411    | 4822 267 51211 | SOCKET, 10P, TO MAIN-AMP.            |
| CN412    | 4822 267 51212 | SOCKET, 8P, TO MAIN-AMP.             |
| CN413    | 4822 267 51213 | SOCKET, 7P, TO MAIN AMP.             |
| CN414    | 4822 267 41077 | SOCKET, 6P, TO MAIN-AMP.             |
| CN431    | 4822 267 41078 | SOCKET, 4P, RCA,<br>PHONO & VIDEO IN |
| CN432    | 4822 267 31609 | SOCKET, 1P, RCA, EXT SP              |
| CN441    |                | PLUG, 3P, TO FRONT (VR)              |
| D4330    | 4822 130 33305 | DIODE 1SS176                         |
| or       | 4822 130 33305 | DIODE 1SS133                         |
| or       | 4822 130 82633 | DIODE GMA01                          |
| D4350    | 4822 130 33948 | ZENER DIODE MTZ5.6B                  |
| D4450    | 4822 130 33948 | ZENER DIODE MTZ5.6B                  |
| D4500    | 4822 130 82703 | ZENER DIODE MTZ5.1B                  |
| D4501    | 4822 130 80318 | ZENER DIODE MTZ6.8C                  |
| D4502    | 4822 130 80318 | ZENER DIODE MTZ6.8C                  |
| IC701    | 4822 209 30798 | IC LA6458S                           |
| IC702    | 4822 209 62253 | IC BU4051B                           |
| IC703    | 4822 209 30798 | IC LA6458S                           |
| IC704    | 4822 209 30798 | IC LA6458S                           |
| IC705    | 4822 209 71783 | IC LC7522                            |
| IC706    | 4822 209 30798 | IC LA6458S                           |
| IC707    | 4822 209 30193 | IC LB1641                            |
| IC711    | 4822 209 30798 | IC LA6458S                           |
| IC802    | 4822 209 62253 | IC BU4051B                           |
| L4190    | 4822 157 63376 | COIL, CHOKE                          |
| Q4301    | 4822 130 61188 | TR BA1L4Z                            |
| or       | 4822 130 61188 | TR DTC144TS                          |
| Q4302    | 4822 130 43793 | TR 2SC1815-GR                        |
| or       | 4822 130 43793 | TR 2SC945A-K                         |
| Q4303    | 4822 130 61188 | TR BA1L4Z                            |
| or       | 4822 130 61188 | TR DTC144TS                          |
| Q4304    | 4822 130 61188 | TR BA1L4Z                            |
| or       | 4822 130 61188 | TR DTC144TS                          |
| Q4305    | 4822 130 43793 | TR 2SC1815-GR                        |
| or       | 4822 130 43793 | TR 2SC945A-K                         |
| Q4306    | 4822 130 43793 | TR 2SC1815-GR                        |
| or       | 4822 130 43793 | TR 2SC945A-K                         |
| Q4307    | 4822 130 43793 | TR 2SC1815-GR                        |
| or       | 4822 130 43793 | TR 2SC945A-K                         |

PCS 67 741

| Ref. No. | Part No.        | Description                         |
|----------|-----------------|-------------------------------------|
| Q4308    | 4822 130 61188  | TR DTC144TS                         |
| or       | 4822 130 61188  | TR BA1L4Z                           |
| Q4309    | 4822 130 61188  | TR DTC144TS                         |
| or       | 4822 130 61188  | TR BA1L4Z                           |
| Q4330    | 4822 130 43819  | TR 2SC2878-A                        |
| or       | 4822 130 43819  | TR 2SC2878-B                        |
| Q4504    | 4822 130 43793  | TR 2SC1815-GR                       |
| or       | 4822 130 43793  | TR 2SC945A-K                        |
| Q4505    | 4822 130 43793  | TR 2SC1815-GR                       |
| or       | 4822 130 43793  | TR 2SC945A-K                        |
| Q4506    | 4822 130 43793  | TR 2SC1815-GR                       |
| or       | 4822 130 43793  | TR 2SC945A-K                        |
| Q4507    | 4822 130 43793  | TR 2SC1815-GR                       |
| or       | 4822 130 43793  | TR 2SC945A-K                        |
| Q4508    | 4822 130 43793  | TR 2SC1815-GR                       |
| or       | 4822 130 43793  | TR 2SC945A-K                        |
| Q4509    | 4822 130 43793  | TR 2SC1815-GR                       |
| or       | 4822 130 43793  | TR 2SC945A-K                        |
| Q4510    | 4822 130 43793  | TR 2SC1815-GR                       |
| or       | 4822 130 43793  | TR 2SC945A-K                        |
| Q4570    | 4822 130 43793  | TR 2SC1815-GR                       |
| or       | 4822 130 43793  | TR 2SC945A-K                        |
| Q4571    | 4822 130 43793  | TR 2SC1815-GR                       |
| or       | 4822 130 43793  | TR 2SC945A-K                        |
| Q4604    | 4822 130 43793  | TR 2SC1815-GR                       |
| or       | 4822 130 43793  | TR 2SC945A-K                        |
| Q4605    | 4822 130 43793  | TR 2SC1815-GR                       |
| or       | 4822 130 43793  | TR 2SC945A-K                        |
| Q4606    | 4822 130 43793  | TR 2SC1815-GR                       |
| or       | 4822 130 43793  | TR 2SC945A-K                        |
| Q4607    | 4822 130 43793  | TR 2SC1815-GR                       |
| or       | 4822 130 43793  | TR 2SC945A-K                        |
| Q4608    | 4822 130 43793  | TR 2SC1815-GR                       |
| or       | 4822 130 43793  | TR 2SC945A-K                        |
| Q4609    | 4822 130 43793  | TR 2SC1815-GR                       |
| or       | 4822 130 43793  | TR 2SC945A-K                        |
| Q4610    | 4822 130 43793  | TR 2SC1815-GR                       |
| or       | 4822 130 43793  | TR 2SC945A-K                        |
| Q4670    | 4822 130 43793  | TR 2SC1815-GR                       |
| or       | 4822 130 43793  | TR 2SC945A-K                        |
| Q4671    | 4822 130 43793  | TR 2SC1815-GR                       |
| or       | 4822 130 43793  | TR 2SC945A-K                        |
| R4190    | △4822 116 60314 | FUSIBLE RES 10 J- 1/4W              |
| RA450    | 4822 111 91513  | RESISTOR, 100K X8                   |
| or       | 4822 111 91513  | RESISTOR, 100K X8                   |
| RA451    | 4822 111 91513  | RESISTOR, 100K X8                   |
| or       | 4822 111 91513  | RESISTOR, 100K X8                   |
| S3101    | 4822 277 21543  | SWITCH, BEAT CANCEL                 |
| or       | 4822 277 21543  | SWITCH, BEAT CANCEL                 |
| S4302    | 4822 276 30421  | SWITCH, TACT, RESET                 |
| VR451    | 4822 100 11896  | VR, ROTARY, 100K(B),<br>MAIN VOLUME |

## MAIN- AMPLIFIER P.C.BOARD ASSY

| Ref. No. | Part No.       | Description                 |
|----------|----------------|-----------------------------|
| DA72     |                | ASSY, PCB, MAIN-AMP. /01B   |
| or       |                | ASSY, PCB, MAIN-AMP. /07B   |
| or       |                | ASSY, PCB, MAIN-AMP. /60B   |
| C4907    |                | ELECT 3300U M 50V           |
| C4908    |                | ELECT 3300U M 50V           |
| C4925    |                | ELECT 2200U M 35V           |
| C5000    |                | ELECT 1000U M 6.3V          |
| CN001    |                | PLUG, 8P, TO MECHA. A       |
| CN002    |                | PLUG, 8P, TO MECHA. B       |
| CN302    |                | PLUG, 9P, TO DECK-AMP.      |
| CN321    |                | PLUG, 6P, TO FRONT SW1      |
| CN322    |                | PLUG, 6P, TO FRONT SW2      |
| CN500    | 4822 267 51215 | SOCKET, 17P, TO FRONT (FFC) |
| CN802    | 4822 290 81555 | SOCKET, 4P, TO SP TERMINAL  |
| CN850    |                | SOCKET, 3P, TO REGULATOR IC |
| or       |                | SOCKET, 3P, TO REGULATOR IC |

## PARTS LIST (TAPE DECK / AMPLIFIER UNIT)

| Ref. No. | Part No.        | Description                   |
|----------|-----------------|-------------------------------|
| CN870    |                 | SOCKET, 5P, TO P.T SEC        |
| or       |                 | SOCKET, 5P, TO P.T SEC        |
| CN871    |                 | SOCKET, 3P, TO P.T PRI        |
| CN900    | 4822 290 81556  | SOCKET, 19P, TO CD/TUNER UNIT |
| CN911    |                 | PLUG, 10P, TO PRE-AMP         |
| CN912    |                 | PLUG, 8P, TO PRE-AMP          |
| CN913    |                 | PLUG, 7P, TO PRE-AMP          |
| CN914    |                 | PLUG, 6P, TO PRE-AMP          |
| D4741    | 4822 130 83271  | ZENER DIODE MTZ12B            |
| D4900    | △4822 130 82658 | DIODE RBV-402LF-A             |
| or       | △4822 130 82658 | DIODE RBA-402LF-A             |
| D4901    | △4822 130 32816 | DIODE 1SR35-200A              |
| D4902    | △4822 130 32816 | DIODE 1SR35-200A              |
| D4903    | △4822 130 32816 | DIODE 1SR35-200A              |
| D4904    | △4822 130 32816 | DIODE 1SR35-200A              |
| D4905    | 4822 130 33305  | DIODE 1SS133                  |
| or       | 4822 130 82633  | DIODE GMA01                   |
| or       | 4822 130 33305  | DIODE 1SS176                  |
| D4911    | 4822 130 33305  | DIODE 1SS133                  |
| or       | 4822 130 82633  | DIODE GMA01                   |
| or       | 4822 130 33305  | DIODE 1SS176                  |
| D4912    | 4822 130 82633  | DIODE GMA01                   |
| or       | 4822 130 33305  | DIODE 1SS133                  |
| or       | 4822 130 33305  | DIODE 1SS176                  |
| D4913    | 4822 130 82668  | ZENER DIODE MTZ15C            |
| D4950    | 4822 130 33305  | DIODE 1SS133                  |
| or       | 4822 130 82633  | DIODE GMA01                   |
| or       | 4822 130 33305  | DIODE 1SS176                  |
| D4951    | 4822 130 33305  | DIODE 1SS133                  |
| or       | 4822 130 82633  | DIODE GMA01                   |
| or       | 4822 130 33305  | DIODE 1SS176                  |
| D4952    | 4822 130 33305  | DIODE 1SS133                  |
| or       | 4822 130 82633  | DIODE GMA01                   |
| or       | 4822 130 33305  | DIODE 1SS176                  |
| D4953    | 4822 130 33305  | DIODE 1SS133                  |
| or       | 4822 130 82633  | DIODE GMA01                   |
| or       | 4822 130 33305  | DIODE 1SS176                  |
| D5000    | 4822 130 33305  | DIODE 1SS133                  |
| or       | 4822 130 82633  | DIODE GMA01                   |
| or       | 4822 130 33305  | DIODE 1SS176                  |
| D5005    | 4822 130 33305  | DIODE 1SS133                  |
| or       | 4822 130 82633  | DIODE GMA01                   |
| or       | 4822 130 33305  | DIODE 1SS176                  |
| D5006    | 4822 130 33305  | DIODE 1SS133                  |
| or       | 4822 130 33305  | DIODE 1SS176                  |
| or       | 4822 130 82633  | DIODE GMA01                   |
| D5007    | 4822 130 33305  | DIODE 1SS133                  |
| or       | 4822 130 33305  | DIODE 1SS176                  |
| or       | 4822 130 82633  | DIODE GMA01                   |
| D5200    | 4822 130 33948  | ZENER DIODE MTZ5.6B           |
| D5201    | 4822 130 33305  | DIODE 1SS133                  |
| or       | 4822 130 82633  | DIODE GMA01                   |
| or       | 4822 130 33305  | DIODE 1SS176                  |
| D5202    | 4822 130 33305  | DIODE 1SS176                  |
| or       | 4822 130 82633  | DIODE GMA01                   |
| or       | 4822 130 33305  | DIODE 1SS133                  |
| D5300    | 4822 130 33948  | ZENER DIODE MTZ5.6B           |
| D5301    | 4822 130 33948  | ZENER DIODE MTZ5.6B           |
| HS401    | △4822 209 32134 | HEAT SINK, FOR IC900          |
| HS402    | △4822 209 32132 | HEAT SINK, FOR IC903          |
| HS403    | △4822 209 32061 | HEAT SINK, FOR Q4903          |
| HS404    | △4822 209 61847 | HEAT SINK, FOR Q4904          |
| IC500    | 4822 209 32134  | IC UPD75516GF-412-3B9         |
| IC501    | 4822 209 31502  | IC BA3826S                    |
| IC700    | △4822 209 32132 | IC STK4162MK2                 |
| IC900    | △4822 209 32061 | IC L780S12                    |
| IC901    | △4822 209 61847 | IC NJM78M05FA                 |
| or       | △4822 209 61847 | IC UPC78M05H                  |
| or       | △4822 209 61847 | IC L78M05                     |
| IC903    | △4822 209 32061 | IC L780S12                    |
| Q4720    | 4822 130 43819  | TR 2SC2878-A                  |
| or       | 4822 130 43819  | TR 2SC2878-B                  |

| Ref. No. | Part No.        | Description                                |
|----------|-----------------|--------------------------------------------|
| Q4721    | 4822 130 43819  | TR 2SC2878-A                               |
| or       | 4822 130 43819  | TR 2SC2878-B                               |
| Q4740    | △4822 130 63198 | TR 2SC2655-Y                               |
| Q4741    | 4822 130 43793  | TR 2SC1815-GR                              |
| or       | 4822 130 43793  | TR 2SC945A-K                               |
| Q4742    | 4822 130 61189  | TR RN1211                                  |
| or       | 4822 130 61189  | TR BA1A4Z                                  |
| or       | 4822 130 61189  | TR DTC114TS                                |
| Q4820    | 4822 130 43819  | TR 2SC2878-A                               |
| or       | 4822 130 43819  | TR 2SC2878-B                               |
| Q4821    | 4822 130 43819  | TR 2SC2878-A                               |
| or       | 4822 130 43819  | TR 2SC2878-B                               |
| Q4901    | 4822 130 43793  | TR 2SC1815-GR                              |
| or       | 4822 130 43793  | TR 2SC945A-K                               |
| Q4902    | 4822 130 43793  | TR 2SC1815-GR                              |
| or       | 4822 130 43793  | TR 2SC945A-K                               |
| Q4903    | △4822 130 63224 | TR TIP29B                                  |
| Q4904    | △4822 130 63223 | TR TIP32B                                  |
| Q4905    | 4822 130 42959  | TR 2SA1015-Y                               |
| Q4906    | 4822 130 43793  | TR 2SC1815-GR                              |
| or       | 4822 130 43793  | TR 2SC945A-K                               |
| Q5001    | 4822 130 61189  | TR RN1211                                  |
| or       | 4822 130 61189  | TR BA1A4Z                                  |
| Q5002    | 4822 130 61189  | TR RN1211                                  |
| or       | 4822 130 61189  | TR BA1A4Z                                  |
| Q5003    | 4822 130 60588  | TR RN1202                                  |
| or       | 4822 130 60588  | TR BA1A4M                                  |
| Q5004    | 4822 130 60588  | TR RN1202                                  |
| or       | 4822 130 60588  | TR BA1A4M                                  |
| Q5005    | 4822 130 60588  | TR RN1202                                  |
| or       | 4822 130 60588  | TR BA1A4M                                  |
| Q5006    | 4822 130 61227  | TR RN2202                                  |
| or       | 4822 130 61227  | TR BN1A4M                                  |
| Q5007    | 4822 130 61227  | TR RN2202                                  |
| or       | 4822 130 61227  | TR BN1A4M                                  |
| Q5008    | 4822 130 61227  | TR RN2202                                  |
| or       | 4822 130 61227  | TR BN1A4M                                  |
| Q5200    | 4822 130 61187  | TR BN1L4Z                                  |
| or       | 4822 130 61187  | TR DTA144TS                                |
| Q5201    | 4822 130 42591  | TR 2SA1175-FF                              |
| or       | 4822 130 42591  | TR 2SA1048-GR                              |
| or       | 4822 130 42591  | TR 2SA1175-EF                              |
| Q5202    | 4822 130 60588  | TR RN1202                                  |
| or       | 4822 130 60588  | TR BA1A4M                                  |
| or       | 4822 130 60588  | TR DTC114ES                                |
| R4706    |                 | CARBON 2.2K JB 1/2W                        |
| R4741    | △4822 111 90744 | FUSIBLE RES 100 J- 1/4W                    |
| R4806    |                 | CARBON 2.2K JB 1/2W                        |
| R4841    | △4822 111 90744 | FUSIBLE RES 100 J- 1/4W                    |
| R4844    | △4822 111 90744 | FUSIBLE RES 100 J- 1/4W                    |
| R4909    | △4822 116 82524 | FUSIBLE RES 27 J- 1/2W                     |
| R4910    | △4822 117 10204 | FUSIBLE RES 47 J- 1/2W                     |
| RA500    | 4822 111 91276  | RESISTOR, 10K X6, SHRINK                   |
| or       | 4822 111 91276  | RESISTOR, 10K X6, SHRINK                   |
| RA501    | 4822 111 91677  | RESISTOR, 10K X3, SHRINK                   |
| or       | 4822 111 91677  | RESISTOR, 10K X3, SHRINK                   |
| RA502    | 4822 111 91276  | RESISTOR, 10K X6, SHRINK                   |
| or       | 4822 111 91276  | RESISTOR, 10K X6, SHRINK                   |
| RA503    | 4822 111 92134  | RESISTOR, 10K X5, SHRINK                   |
| or       | 4822 111 92134  | RESISTOR, 10K X5, SHRINK                   |
| X5000    | 4822 242 80324  | RESONATOR, CERAMIC, 3P, 4.19MHZ, FOR IC500 |



## PARTS LIST (TAPE DECK / AMPLIFIER UNIT)

| Ref. No. | Part No.        | Description               |
|----------|-----------------|---------------------------|
| FCLP6    | △4822 157 70342 | FUSE HOLDER, FU999        |
| FCLP7    |                 | FUSE HOLDER, FU998 /01B   |
| FCLP8    |                 | FUSE HOLDER, FU998 /01B   |
| L9999    |                 | INDUCTOR, FERITE, AC LINE |

## P.T SECONDARY P.C.BOARD ASSY

| Ref. No. | Part No.                                          | Description              |
|----------|---------------------------------------------------|--------------------------|
| DA74     | △4822 209 61685<br>△4822 209 61685<br>△<br>△<br>△ | ASSY, PCB, P.T-SEC /01B  |
| or       |                                                   | ASSY, PCB, P.T-SEC /07B  |
| or       |                                                   | ASSY, PCB, P.T-SEC /60B  |
| CN770    |                                                   | SOCKET, 5P, TO MAIN-AMP. |
| or       |                                                   | SOCKET, 5P, TO MAIN-AMP. |
| CN771    |                                                   | SOCKET, 3P, TO MAIN-AMP. |
| ICP51    |                                                   | IC PROTECTOR ICP-N38     |
| ICP52    |                                                   | IC PROTECTOR ICP-N38     |
| R4997    |                                                   | RESISTOR 0.33 J- 1/2W    |
| R4998    |                                                   | RESISTOR 0.33 J- 1/2W    |
| R4999    |                                                   | RESISTOR 0.33 J- 1W      |

## REGULATOR IC P.C.BOARD ASSY

| Ref. No. | Part No.                                                                 | Description             |
|----------|--------------------------------------------------------------------------|-------------------------|
| DA75     | △4822 209 60826<br>△4822 209 60826<br>△4822 209 60826<br>△4822 209 60826 | ASSY, PCB, REG. IC /01B |
| or       |                                                                          | ASSY, PCB, REG. IC /07B |
| or       |                                                                          | ASSY, PCB, REG. IC /60B |
| CN750    |                                                                          | SOCKET, 3P, MAIN-AMP.   |
| or       |                                                                          | SOCKET, 3P, MAIN-AMP.   |
| IC902    |                                                                          | IC NJM7812FA            |
| or       |                                                                          | IC L7812ML              |
| or       |                                                                          | IC UPC7812HF            |
| or       |                                                                          | IC AN7812F              |

## SPEAKER TERMINAL P.C.BOARD ASSY

| Ref. No. | Part No.       | Description                 |
|----------|----------------|-----------------------------|
| DA76     | 4822 290 81538 | ASSY, PCB, SP TERMINAL /01B |
| or       |                | ASSY, PCB, SP TERMINAL /07B |
| or       |                | ASSY, PCB, SP TERMINAL /60B |
| C4170    |                | LUG, EARTH /60B             |
| C4171    |                | POLYESTER 0.01U K 50V /60B  |
| C4172    |                | POLYESTER 5600P K 50V /60B  |
| CN700    |                | POLYESTER 5600P K 50V /60B  |
| CN701    |                | TERMINAL, 4P, SPEAKER       |
| CN702    |                | PLUG, 4P, TO FRONT          |
| D4750    |                | SOCKET, 4P, TO MAIN-AMP.    |
| or       |                | DIODE 1SS133                |
| or       |                | DIODE GMA01                 |
| or       |                | DIODE 1SS176                |
| FCLP1    |                | FUSE HOLDER, FOR FU701      |
| FCLP2    |                | FUSE HOLDER, FOR FU701      |
| FCLP3    |                | FUSE HOLDER, FOR FU801      |
| FCLP4    |                | FUSE HOLDER, FOR FU801      |
| R4750    | 4822 052 11568 | CARBON 5.6 JB 1/2W          |
| R4751    | 4822 111 90724 | CARBON 330 JB 1/2W          |
| R4850    | 4822 052 11568 | CARBON 5.6 JB 1/2W          |
| R4851    | 4822 111 90724 | CARBON 330 JB 1/2W          |
| RY700    | 4822 280 20487 | RELAY, SPEAKER              |

## FRONT P.C.BOARD ASSY

| Ref. No. | Part No.       | Description               |
|----------|----------------|---------------------------|
| DA77     | 4822 267 51214 | ASSY, PCB, FRONT /01B     |
| or       |                | ASSY, PCB, FRONT /07B     |
| or       |                | ASSY, PCB, FRONT /60B     |
| CN551    |                | REFLECTOR, LCD            |
| CN553    |                | SHEET, LCD                |
|          |                | SOCKET, 17P, TO MAIN-AMP. |
|          |                | PLUG, 4P, TO SP TERMINAL  |

| Ref. No. | Part No.       | Description                  |
|----------|----------------|------------------------------|
| CN554    | 4822 267 31528 | JACK, PHONE                  |
| CN555    | 4822 130 83332 | PLUG, 3P, TO PRE-AMP.        |
| D5501    |                | LED SLZ-181C-15-T2, STAND BY |
| D5502    |                | DIODE GMA01                  |
| or       |                | DIODE 1SS133                 |
| D5503    |                | DIODE GMA01                  |
| or       |                | DIODE 1SS133                 |
| D5511    |                | LED SLZ-181C-15-T2, VIDEO    |
| D5512    |                | LED SLZ-181C-15-T2, PHONO    |
| D5513    |                | LED SLZ-181C-15-T2, TUNER    |
| D5514    |                | LED SLZ-181C-15-T2, TAPE     |
| D5515    | 4822 130 83277 | LED SLZ-181C-15-T2, CD       |
| D5516    | 4822 130 83278 | LED SLZ-381C-15-T2, D'BASS   |
| IC551    | 4822 209 31683 | IC LC7582                    |
| LCD51    | 4822 130 91167 | LCD(LIQUID CRYSTAL DISPLAY)  |
| Q5501    | 4822 130 60588 | TR RN1202                    |
| or       | 4822 130 60588 | TR BA1A4M                    |
| or       | 4822 130 60588 | TR DTC114ES                  |
| Q5502    | 4822 130 43793 | TR 2SC1815-GR                |
| or       | 4822 130 43793 | TR 2SC945A-K                 |
| Q5503    | 4822 130 61188 | TR BA1L4Z                    |
| or       | 4822 130 61188 | TR DTC144TS                  |
| S5501    | 4822 276 30419 | SWITCH, TACT, POWER          |
| S5502    | 4822 276 30419 | SWITCH, TACT, FUNCTION       |
| S5514    | 4822 276 30419 | SWITCH, TACT, EQ-            |
| S5515    | 4822 276 30419 | SWITCH, TACT, BASS EXPANDER  |
| S5516    | 4822 276 30419 | SWITCH, TACT, DISPLAY        |
| S5517    | 4822 276 30419 | SWITCH, TACT, FREQ/MEMO      |
| S5518    | 4822 276 30419 | SWITCH, TACT, PRESET         |
| S5519    | 4822 276 30419 | SWITCH, TACT, EQ+            |
| VR551    | 4822 100 11965 | VR, ROTARY, BALANCE          |

## FRONT SWITCH 1 P.C.BOARD ASSY

| Ref. No. | Part No.       | Description                        |
|----------|----------------|------------------------------------|
| DA78     | 4822 130 83274 | ASSY, PCB, FRONT SW1 /01B          |
| or       |                | ASSY, PCB, FRONT SW1 /07B          |
| or       |                | ASSY, PCB, FRONT SW1 /60B          |
| CN322    |                | ASSY, CONNECTOR-S, 6P, TO MAIN-AMP |
| D3203    |                | LED SLZ-181C-09-A-T1, REC          |
| or       |                | LED SLZ-181C-09-B-T1, REC          |
| D3204    |                | LED SLP-381C-51-AB, TAPE A         |
| D3205    |                | LED SLP-181C-51-A, TAPE B          |
| or       |                | LED SLP-181C-51-B, TAPE B          |
| Q3201    |                | TR DTA114ES                        |
| or       | 4822 130 61227 | TR RN2202                          |
| or       | 4822 130 61227 | TR BN1A4M                          |
| Q3202    | 4822 130 61227 | TR DTA114ES                        |
| or       | 4822 130 61227 | TR RN2202                          |
| or       | 4822 130 61227 | TR BN1A4M                          |
| S3206    | 4822 276 13306 | SWITCH, TACT, A/B                  |
| S3207    | 4822 276 20514 | SWITCH, TACT, DIR                  |
| S3208    | 4822 276 20514 | SWITCH, TACT, DOLBY                |
| S3209    | 4822 276 20514 | SWITCH, TACT, DUB                  |
| S3210    | 4822 276 20514 | SWITCH, TACT, REC MUTE             |
| S3211    | 4822 276 13306 | SWITCH, TACT, REC                  |

## FRONT SWITCH 2 P.C.BOARD ASSY

| Ref. No. | Part No.       | Description                         |
|----------|----------------|-------------------------------------|
| DA79     | 4822 130 83275 | ASSY, PCB, FRONT SW2 /01B           |
| or       |                | ASSY, PCB, FRONT SW2 /07B           |
| or       |                | ASSY, PCB, FRONT SW2 /60B           |
| CN321    |                | ASSY, CONNECTOR-S, 6P, TO MAIN-AMP. |
| D3201    |                | LED SLZ-381C-09-A-T1, FOW           |
| or       |                | LED SLZ-381C-09-B-T1, FOW           |
| D3202    |                | LED SLZ-381C-09-A-T1, REV           |
| or       |                | LED SLZ-381C-09-B-T1, REV           |
| S3201    |                | SWITCH, TACT, STOP                  |

## PARTS LIST (TAPE DECK / AMPLIFIER UNIT)

| Ref. No. | Part No.       | Description       |
|----------|----------------|-------------------|
| S3202    | 4822 276 20514 | SWITCH, TACT, FOW |
| S3203    | 4822 276 20514 | SWITCH, TACT, REV |
| S3204    | 4822 276 20514 | SWITCH, TACT, F.F |
| S3205    | 4822 276 20514 | SWITCH, TACT, REW |

## LED (LCD BACK LIGHT) P.C.BOARD ASSY

| Ref. No. | Part No.       | Description                     |
|----------|----------------|---------------------------------|
| DA80     | 4822 130 83272 | ASSY, PCB, LED                  |
| CN562    |                | ASSY, CONNECTOR-S, 2P, TO FRONT |
| D5551    |                | LED CL-170G-CD-AL               |
| or       |                | LED CL-170G-CD-BL               |
| or       |                | LED CL-170G-CD-CL               |
| D5552    |                | LED CL-170G-CD-AL               |
| or       |                | LED CL-170G-CD-BL               |
| or       |                | LED CL-170G-CD-CL               |
| D5553    |                | LED CL-170G-CD-AH               |
| or       |                | LED CL-170G-CD-BH               |
| or       |                | LED CL-170G-CD-CH               |
| D5554    | 4822 130 83272 | LED CL-170G-CD-AH               |
| or       | 4822 130 83272 | LED CL-170G-CD-BH               |
| or       | 4822 130 83272 | LED CL-170G-CD-CH               |
| D5555    | 4822 130 83272 | LED CL-170G-CD-AH               |
| or       | 4822 130 83272 | LED CL-170G-CD-BH               |
| or       | 4822 130 83272 | LED CL-170G-CD-CH               |
| D5556    | 4822 130 83272 | LED CL-170G-CD-AL               |
| or       | 4822 130 83272 | LED CL-170G-CD-BL               |
| or       | 4822 130 83272 | LED CL-170G-CD-CL               |
| D5557    | 4822 130 83272 | LED CL-170G-CD-AL               |
| or       | 4822 130 83272 | LED CL-170G-CD-BL               |
| or       | 4822 130 83272 | LED CL-170G-CD-CL               |
| D5558    | 4822 130 83272 | LED CL-170G-CD-AL               |
| or       | 4822 130 83272 | LED CL-170G-CD-BL               |
| or       | 4822 130 83272 | LED CL-170G-CD-CL               |
| D5559    | 4822 130 83272 | LED CL-170G-CD-AH               |
| or       | 4822 130 83272 | LED CL-170G-CD-BH               |
| or       | 4822 130 83272 | LED CL-170G-CD-CH               |
| D5560    | 4822 130 83272 | LED CL-170G-CD-AL               |
| or       | 4822 130 83272 | LED CL-170G-CD-BL               |
| or       | 4822 130 83272 | LED CL-170G-CD-CL               |
| D5561    | 4822 130 83272 | LED CL-170G-CD-AH               |
| or       | 4822 130 83272 | LED CL-170G-CD-BH               |
| or       | 4822 130 83272 | LED CL-170G-CD-CH               |
| D5562    | 4822 130 83272 | LED CL-170G-CD-AL               |
| or       | 4822 130 83272 | LED CL-170G-CD-BL               |
| or       | 4822 130 83272 | LED CL-170G-CD-CL               |
| D5563    | 4822 130 83272 | LED CL-170G-CD-AH               |
| or       | 4822 130 83272 | LED CL-170G-CD-BH               |
| or       | 4822 130 83272 | LED CL-170G-CD-CH               |
| D5564    | 4822 130 83272 | LED CL-170G-CD-AH               |
| or       | 4822 130 83272 | LED CL-170G-CD-BH               |
| or       | 4822 130 83272 | LED CL-170G-CD-CH               |
| D5565    | 4822 130 83272 | LED CL-170G-CD-AL               |
| or       | 4822 130 83272 | LED CL-170G-CD-BL               |
| or       | 4822 130 83272 | LED CL-170G-CD-CL               |
| D5566    | 4822 130 83272 | LED CL-170G-CD-AH               |
| or       | 4822 130 83272 | LED CL-170G-CD-BH               |
| or       | 4822 130 83272 | LED CL-170G-CD-CH               |
| D5567    | 4822 130 83272 | LED CL-170G-CD-AH               |
| or       | 4822 130 83272 | LED CL-170G-CD-BH               |
| or       | 4822 130 83272 | LED CL-170G-CD-CH               |
| D5568    | 4822 130 83272 | LED CL-170G-CD-AL               |
| or       | 4822 130 83272 | LED CL-170G-CD-BL               |
| or       | 4822 130 83272 | LED CL-170G-CD-CL               |
| D5569    | 4822 130 83272 | LED CL-170G-CD-AH               |
| or       | 4822 130 83272 | LED CL-170G-CD-BH               |
| or       | 4822 130 83272 | LED CL-170G-CD-CH               |
| D5570    | 4822 130 83272 | LED CL-170G-CD-AL               |
| or       | 4822 130 83272 | LED CL-170G-CD-BL               |
| or       | 4822 130 83272 | LED CL-170G-CD-CL               |

## DECK AMPLIFIER P.C.BOARD ASSY

| Ref. No. | Part No.       | Description                   |
|----------|----------------|-------------------------------|
| DA81     | 4822 130 82633 | ASSY, PCB, DECK-AMP /01B /07B |
| or       |                | ASSY, PCB, DECK-AMP /60B      |
| C3303    |                | SHIELD PLATE                  |
| C3304    |                | POLYESTER 0.015U J 50V        |
| CN301    |                | POLYESTER 1500P K 50V         |
| CN302    |                | PLUG, 9P, TO PRE-AMP.         |
| CN303    |                | PLUG, 9P, TO MAIN-AMP.        |
| CN331    |                | PLUG, 2P, HIGH SPEED          |
| CN371    |                | PLUG, 2P, E HEAD              |
| CN371    |                | PLUG, 4P, P HEAD              |
| CN372    | 4822 130 82633 | PLUG, 5P, R/P HEAD            |
| CN373    |                | SOCKET, 3P, TAPE OUT          |
| D3101    |                | DIODE GMA01                   |
| or       |                | DIODE 1SS133                  |
| D3102    |                | DIODE GMA01                   |
| or       |                | DIODE 1SS133                  |
| D3103    |                | DIODE GMA01                   |
| or       |                | DIODE 1SS133                  |
| D3104    |                | DIODE GMA01                   |
| or       |                | DIODE 1SS133                  |
| D3105    | 4822 130 82634 | DIODE DS442X                  |
| or       |                | DIODE 1S2473                  |
| D3106    |                | DIODE GMA01                   |
| or       |                | DIODE 1SS133                  |
| HS301    |                | HEAT SINK, BIAS LEAK          |
| IC351    |                | IC CXA1331S                   |
| IC370    |                | IC LA3246                     |
| IC371    |                | IC MLC4066B                   |
| or       |                | IC BU4066B                    |
| or       |                | IC TC4066BP                   |
| or       | 4822 209 62251 | IC UPD4066BC                  |
| IC374    |                | IC CXA1298AP                  |
| IC375    |                | IC UPC1330HA                  |
| L3300    |                | TRANS, OSC                    |
| L3700    |                | FILTER, 1000UH                |
| L3730    |                | MX COIL, 85KHZ                |
| L3731    |                | INDUCTOR, FERITE, 3.3MH       |
| L3750    |                | MX COIL, 85KHZ                |
| L3800    |                | FILTER, 1000UH                |
| L3830    |                | MX COIL, 85KHZ                |
| L3831    | 4822 157 70344 | INDUCTOR, FERITE, 3.3MH       |
| L3850    |                | MX COIL, 85KHZ                |
| Q3101    |                | TR DTC144ES                   |
| or       |                | TR BA1L4M                     |
| or       |                | TR AA1L4M                     |
| or       |                | TR RN1204                     |
| Q3102    |                | TR DTA144ES                   |
| or       |                | TR BN1L4M                     |
| or       |                | TR AN1L4M                     |
| or       |                | TR RN2204                     |
| Q3103    | 4822 130 42594 | TR DTC144ES                   |
| or       |                | TR BA1L4M                     |
| or       |                | TR AA1L4M                     |
| or       |                | TR RN1204                     |
| Q3104    |                | TR DTC144TS                   |
| or       |                | TR BA1L4Z                     |
| Q3105    |                | TR DTC144ES                   |
| or       |                | TR BA1L4M                     |
| or       |                | TR AA1L4M                     |
| or       |                | TR RN1204                     |
| Q3106    | 4822 130 42594 | TR DTC144ES                   |
| or       |                | TR BA1L4M                     |
| or       |                | TR AA1L4M                     |
| or       |                | TR RN1204                     |
| Q3107    |                | TR DTA144ES                   |
| or       |                | TR BN1L4M                     |
| or       |                | TR AN1L4M                     |
| or       |                | TR RN2204                     |
| Q3108    |                | TR DTC144ES                   |
| or       |                | TR BA1L4M                     |
| or       |                | TR AA1L4M                     |
| or       |                | TR RN1204                     |



## PARTS LIST (TAPE DECK / AMPLIFIER UNIT)


| Ref. No. | Part No.       | Description            |
|----------|----------------|------------------------|
| Q3109    | 4822 130 61188 | TR DTC144TS            |
| or       | 4822 130 61188 | TR BA1L4Z              |
| Q3160    | 4822 130 42594 | TR DTC144ES            |
| or       | 4822 130 42594 | TR BA1L4M              |
| or       | 4822 130 42594 | TR AA1L4M              |
| or       | 4822 130 42594 | TR RN1204              |
| Q3161    | 4822 130 42682 | TR DTA144ES            |
| or       | 4822 130 42682 | TR BN1L4M              |
| or       | 4822 130 42682 | TR AN1L4M              |
| or       | 4822 130 42682 | TR RN2204              |
| Q3300    | 4822 130 43793 | TR 2SC1815-GR          |
| or       | 4822 130 43793 | TR 2SC945A-K           |
| Q3301    | 4822 130 60696 | TR 2SC1627-Y           |
| Q3302    | 4822 130 62615 | TR 2SA1015-GR          |
| or       | 4822 130 62615 | TR 2SA733-P            |
| Q3303    | 4822 130 43793 | TR 2SC1815-GR          |
| or       | 4822 130 43793 | TR 2SC945A-K           |
| or       | 4822 130 42298 | TR 2SC1740S-S          |
| Q3730    | 4822 130 62768 | TR 2SD1468S-S          |
| Q3830    | 4822 130 62768 | TR 2SD1468S-S          |
| SVR30    | 4822 100 11962 | SEMI-FIXED V.R.,20K(B) |
| SVR31    | 4822 100 11962 | SEMI-FIXED V.R.,20K(B) |
| SVR32    | 4822 100 11962 | SEMI-FIXED V.R.,20K(B) |
| SVR33    | 4822 100 11962 | SEMI-FIXED V.R.,20K(B) |
| SVR34    | 4822 100 11963 | SEMI-FIXED V.R.,10K(B) |
| SVR35    | 4822 100 11963 | SEMI-FIXED V.R.,10K(B) |
| SVR36    | 4822 100 11964 | SEMI-FIXED V.R.,50K(B) |
| SVR37    | 4822 100 11964 | SEMI-FIXED V.R.,50K(B) |

## MEMO

| Ref. No. | Part No.       | Description            |
|----------|----------------|------------------------|
| Q3109    | 4822 130 61188 | TR DTC144TS            |
| or       | 4822 130 61188 | TR BA1L4Z              |
| Q3160    | 4822 130 42594 | TR DTC144ES            |
| or       | 4822 130 42594 | TR BA1L4M              |
| or       | 4822 130 42594 | TR AA1L4M              |
| or       | 4822 130 42594 | TR RN1204              |
| Q3161    | 4822 130 42682 | TR DTA144ES            |
| or       | 4822 130 42682 | TR BN1L4M              |
| or       | 4822 130 42682 | TR AN1L4M              |
| or       | 4822 130 42682 | TR RN2204              |
| Q3300    | 4822 130 43793 | TR 2SC1815-GR          |
| or       | 4822 130 43793 | TR 2SC945A-K           |
| Q3301    | 4822 130 60696 | TR 2SC1627-Y           |
| Q3302    | 4822 130 62615 | TR 2SA1015-GR          |
| or       | 4822 130 62615 | TR 2SA733-P            |
| Q3303    | 4822 130 43793 | TR 2SC1815-GR          |
| or       | 4822 130 43793 | TR 2SC945A-K           |
| or       | 4822 130 42298 | TR 2SC1740S-S          |
| Q3730    | 4822 130 62768 | TR 2SD1468S-S          |
| Q3830    | 4822 130 62768 | TR 2SD1468S-S          |
| SVR30    | 4822 100 11962 | SEMI-FIXED V.R.,20K(B) |
| SVR31    | 4822 100 11962 | SEMI-FIXED V.R.,20K(B) |
| SVR32    | 4822 100 11962 | SEMI-FIXED V.R.,20K(B) |
| SVR33    | 4822 100 11962 | SEMI-FIXED V.R.,20K(B) |
| SVR34    | 4822 100 11963 | SEMI-FIXED V.R.,10K(B) |
| SVR35    | 4822 100 11963 | SEMI-FIXED V.R.,10K(B) |
| SVR36    | 4822 100 11964 | SEMI-FIXED V.R.,50K(B) |
| SVR37    | 4822 100 11964 | SEMI-FIXED V.R.,50K(B) |



## EXPLODED VIEW (TAPE DECK MECHANISM)



## PARTS LIST (TAPE DECK MECHANISM)

## TAPE DECK MECHANISM (TM-SF3J / SP)

| Ref. No. | Part No.       | Description                              |
|----------|----------------|------------------------------------------|
| TM01     |                | ASSY, CHASSIS, TAPE DECK                 |
| TM02     | 4822 492 71278 | SPRING PLATE, CASSETTE PRESS             |
| TM03     | 4822 528 60404 | ASSY, FLYWHEEL, REV, D2.0                |
| TM04     | 4822 528 60405 | ASSY, FLYWHEEL, NOR, D2.2                |
| TM05     | 4822 532 12217 | SPECIAL WASHER, REV FW FIX               |
| TM06     | 4822 532 12218 | SPECIAL WASHER, NOR FW FIX               |
| TM07     | 4822 532 12219 | SPECIAL WASHER, OIL PROOF REV            |
| TM08     | 4822 532 12221 | SPECIAL WASHER, NOR OIL PROOF            |
| TM09     | 4822 361 21601 | ASSY, COMMUTATE MOTOR                    |
| TM10     |                | BRACKET-E, MOTOR                         |
| TM11     | 4822 358 31238 | BELT, SQUARE, A-MECHA DRIVE              |
| TM12     | 4822 358 31239 | BELT, SQUARE, B-MECHA DRIVE              |
| TM13     | 4822 528 50346 | PULLEY, BELT DUMMY                       |
| TM14     | 4822 532 12222 | SPECIAL WASHER, D. PULLEY                |
| TM15     | 4822 403 70804 | LEVER, PLAY GEAR                         |
| TM16     | 4822 522 33337 | ASSY, GEAR, PLAY CLUTCH                  |
| TM17     |                | PIPE, PLAY SLIP FIX                      |
| TM18     | 4822 462 71894 | CUSHION, BELT TUTCH(B)                   |
| TM19     | 4822 462 71895 | CUSHION, BELT TUTCH(A)                   |
| TM20     | 4822 492 33376 | SPRING, TENS, PLAY LEVER RESET           |
| TM21     | 4822 522 33333 | GEAR, RELAY FIXED                        |
| TM22     |                | PIPE, GEAR FIX                           |
| TM23     | 4822 522 33338 | ASSY, GEAR, TAKE UP MOVE                 |
| TM24     | 4822 403 70799 | LEVER, TAKE UP MOVE B                    |
| TM25     | 4822 492 71279 | SPRING, WIRE, B MECHA REEL CHANGE CLIC   |
| TM26     | 4822 522 33334 | GEAR, REEL RELAY                         |
| TM27     | 4822 522 33335 | GEAR, REEL                               |
| TM28     | 4822 528 10871 | REEL, RIGHT                              |
| TM29     | 4822 528 10872 | REEL, LEFT                               |
| TM30     | 4822 492 52349 | SPRING, COMP, BACK TENSION LEFT REEL     |
| TM31     | 4822 403 70805 | ASSY, LEVER, PINCH, LEFT                 |
| TM32     | 4822 403 70806 | ASSY, LEVER, PINCH, RIGHT                |
| TM33     | 4822 492 71281 | SPRING, WIRE, PINCH LEFT                 |
| TM34     | 4822 492 71282 | SPRING, WIRE, PINCH RIGHT                |
| TM35     | 4822 403 10306 | LEVER, BRAKE R                           |
| TM36     | 4822 403 10305 | LEVER, BRAKE L                           |
| TM37     | 4822 417 50282 | SLIDE, DOOR LOCK A                       |
| TM38     | 4822 417 50283 | SLIDE, DOOR LOCK B                       |
| TM39     | 4822 403 70807 | SLIDE, EJECT RELAY A                     |
| TM40     | 4822 403 70808 | SLIDE, EJECT RELAY B                     |
| TM41     | 4822 492 33377 | SPRING, TENS, EJECT RELAY RESET          |
| TM42     | 4822 526 20207 | MAGNETIC COIL, CAM GEAR TRIGGER SOLENOID |
| TM43     |                | ASSY, PCB, MECHA                         |
| TM44     |                | SHIELD, HEAD PCB                         |
| TM45     |                | PCB, P LEAD RELAY                        |
| TM46     |                | PCB, R/P LEAD RELAY                      |
| TM47     | 4822 403 70801 | LEVER, D. SLIDE LOCK                     |
| TM48     | 4822 492 71283 | SPRING, WIRE, LOCK LEVER RESET           |
| TM49     | 4822 403 70802 | LEVER, HEAD SLIDE UP A                   |
| TM50     | 4822 403 70803 | LEVER, HEAD SLIDE UP B                   |
| TM51     | 4822 403 70824 | ASSY, SLIDE, HEAD                        |
| TM52     | 4822 492 71293 | SPRING, WIRE, HEAD SLIDE RESET           |
| TM53     | 4822 492 71294 | SPRING, TENS, HEAD SILENT CONT           |
| TM54     | 4822 403 70819 | GUIDE, TAPE                              |
| TM55     |                | ASSY, BRACKET-E, HEAD LOCATE             |
| TM56     | 4822 249 10476 | HEAD, REC/PLAY                           |
| TM57     | 4822 249 30193 | HEAD, PLAY                               |
| TM58     | 4822 522 33339 | GEAR, HEAD ROTARY                        |
| TM59     | 4822 532 12229 | SPECIAL WASHER, HEAD THRUST              |
| TM60     | 4822 403 70827 | LEVER, SECTOR                            |
| TM61     | 4822 492 71295 | SPRING, WIRE, HEAD CLIC                  |
| TM62     | 4822 492 52352 | SPRING, COMP, AZIMUTH COIL               |
| TM63     | 4822 502 21293 | SPECIAL SCREW, AZIMUTH BISS              |

| Ref. No. | Part No.       | Description                               |
|----------|----------------|-------------------------------------------|
| TM64     | 4822 492 71296 | SPRING, WIRE, HEAD SLIDE EARTH            |
| TM65     | 4822 403 70828 | LEVER, R/F A                              |
| TM66     | 4822 403 70829 | LEVER, R/F B                              |
| TM67     | 4822 522 33341 | GEAR, R/F MOVE                            |
| TM68     |                | PIPE, R/F MOVE GEAR FIX                   |
| TM69     | 4822 522 33342 | GEAR, D. CAM                              |
| TM70     | 4822 403 70831 | LEVER, MAIN TRIGGER                       |
| TM71     | 4822 403 70832 | LEVER, SUB TRIGGER                        |
| TM72     | 4822 403 70821 | SLIDE, DRIVE                              |
| TM73     | 4822 492 71297 | SPRING, WIRE, D. SLIDE RESET              |
| TM74     | 4822 403 70822 | SLIDE, A/B MECHA CHANGE                   |
| TM75     | 4822 492 33378 | SPRING, TENS, MECHANISM CHANGE SLIDE      |
| TM76     | 4822 492 33379 | SPRING, TENS, TRIGGER INNER FORCE         |
| TM77     | 4822 403 70825 | ASSY, SLIDE, HEAD CHANGE                  |
| TM78     | 4822 492 71298 | SPRING, WIRE, CHANGE SLIDE RESET          |
| TM79     | 4822 403 70823 | SLIDE, REEL CHANGE NO.1                   |
| TM80     | 4822 403 70826 | ASSY, SLIDE, REEL CHANGE NO.2             |
| TM81     | 4822 271 30795 | SWITCH, LEAF, PACK1, S003                 |
| or       | 4822 271 30795 | SWITCH, LEAF, PACK2, S004                 |
| or       | 4822 271 30795 | SWITCH, LEAF, CROM1, S005                 |
| or       | 4822 271 30795 | SWITCH, LEAF, CROM2, S006                 |
| or       | 4822 271 30795 | SWITCH, LEAF, URVWD, S007                 |
| or       | 4822 271 30795 | SWITCH, LEAF, URREV, S008                 |
| TM82     | 4822 466 62302 | CUSHION, RUBBER, SILEN                    |
| TM83     | 4822 466 62303 | CUSHION, RF LEVER TOUTCH                  |
| TM84     | 4822 466 62304 | CUSHION, RUBBER, DRIVE SLIDE WIRE STOPPER |
| TM85     | 4822 466 62305 | CUSHION, RUBBER, H.S. STOPPER             |
| TM86     |                | CUSHION, RUBBER, RF LEVER TOUTCH          |

## FIXING PARTS FOR MECHANISM

| Ref. No. | Part No.       | Description         |
|----------|----------------|---------------------|
| TY01     |                | SCR PAN-FLG 2.6X2.8 |
| TY02     |                | SCR S-TPG BIN 3X8   |
| TY03     | 4822 502 13788 | SCR PAN+SW 2X4      |
| TY04     |                | SCR S-TPG BIN 2X6   |
| TY05     |                | SCR S-TPG PAN 2X6   |
| TY06     |                | SCR PAN PCS 1.6X6   |
| TY07     |                | SCR PAN PCS 2X2     |


## TAPE DECK MECHANISM P. C. BOARD ASSY

| Ref. No. | Part No.       | Description                        |
|----------|----------------|------------------------------------|
| TM43     |                | ASSY, PCB, MECHANISM               |
| CN001    |                | PLUG, 8P, CN001, TAPE A            |
| CN002    |                | PLUG, 8P, CN002, TAPE B            |
| CN003    |                | SOCKET, 4P, CN003, TO MOTOR        |
| D001     | 4822 130 32508 | DIODE DSF10C                       |
| or       | 4822 130 32816 | DIODE 1SR35-200A                   |
| D002     | 4822 130 82633 | DIODE GMA01                        |
| or       | 4822 130 33305 | DIODE 1SS133                       |
| D003     | 4822 130 82703 | ZENER DIODE GZS5.1Y                |
| or       | 4822 130 82703 | ZENER DIODE MTZ5.1B                |
| DH001    | 4822 130 83279 | PHOTO COUPLE SPI-335-34-C          |
| DH002    | 4822 130 83279 | PHOTO COUPLE SPI-335-34-C          |
| ICP01    | 4822 252 51025 | IC PROTECTOR ICP-N10               |
| Q001     | 4822 130 62849 | TR 2SB621-S                        |
| Q002     | 4822 130 42715 | TR 2SA1048-GR                      |
| or       | 4822 130 42715 | TR 2SA933S-S                       |
| Q003     | 4822 130 62849 | TR 2SB621-S                        |
| S001     | 4822 277 21631 | SWITCH, LEVER, PLAY                |
| S002     | 4822 277 21631 | SWITCH, LEVER, STOP                |
| SVR001   | 4822 100 11962 | SEMI-FIXED V.R. 20K(B), TAPE SPEED |




IC BLOCK DIAGRAM (TAPE DECK)


IC351 CXA1331S (Dolby Noise Reduction)



IC371 MLC4066B (Quad Electrical Switch)




LOGIC DIAGRAM AND TRUTH TABLE




| CONTROL | SWITCH |
|---------|--------|
| 0=VSS   | OFF    |
| 1=VDD   | ON     |

IC375 IPC1330H (2-ch Head Select Switch)




IC370 LA3246 (Pre & Mixing Amplifier

with Electrical Switch)



IC374 CXA1298AP (Equalizer Amplifier for Record)



IC BLOCK DIAGRAM (AMPLIFIER)

IC500  $\mu$ PD75516GF-412-3B9 (Micro Processor)

| PIN No. | SIGNAL NAME    | I/O | DESCRIPTION                                        | ACTIV   | P OFF |
|---------|----------------|-----|----------------------------------------------------|---------|-------|
| 1       | AN0            | I   | AD Key Input                                       | ---     | ---   |
| 2       | AVref          | I   | Reference Voltage of AD                            | ---     | ---   |
| 3       | VDD            | I   | +5V                                                | ---     | ---   |
| 4       | VDD(VPP)       | I   | Connect VDD for PROM                               | ---     | ---   |
| 5       | PULL UP 1      | O   | Set Pull up Signal of AVref Backup Time : LOW      | H       | H     |
| 6       | L/R            | O   | L/R Selection Control for BA3826S                  | L       | L     |
| 7       | BAND RESET     | O   | Reset Control for BA3826S                          | H       | L     |
| 8       | BAND A         | I/O | Band Pass A Control of BA3826S                     | L       | L     |
| 9       | BAND B         | I/O | Band Pass B Control of BA3826S                     | L       | L     |
| 10      | BAND C         | I/O | Band Pass C Control of BA3826S                     | L       | L     |
| 11      | BASS           | O   | BASS Xpander Control Signal (LED)                  | L       | H     |
| 12      | DO SURR ON/OFF | O   | Dolby Surround Control Signal (LED)                | L       | H     |
| 13      | REAR VOL UP    | O   | Rear Volume Up Signal                              | H       | L     |
| 14      | REAR VOL DOWN  | O   | Rear Volume Down Signal                            | H       | L     |
| 15      | CK7522         | O   | Equalizer Clock of LC7522                          | H       | L     |
| 16      | DI7522         | O   | Data In from LC7522                                | H       | L     |
| 17      | NC             | I   | Not Used (VSS)                                     | ---     | ---   |
| 18      | DA7522         | O   | Data Signal to LC7522                              | H       | L     |
| 19      | CK7522         | O   | Clock Signal to LC7522                             | H       | L     |
| 20      | NC             | I   | Not Used (VSS)                                     | ---     | ---   |
| 21      | CE7522         | O   | CE(Chip Enable) of LC7522                          | H       | L     |
| 22      | FUNC C         | O   | C Control Signal of Function IC BU4051             | H       | L     |
| 23      | FUNC B         | O   | B Control Signal of Function IC BU4051             | H       | L     |
| 24      | FUNC A         | O   | A Control Signal of Function IC BU4051             | H       | L     |
| 25      | DO ON/OFF      | O   | Dolby ON/OFF Control Signal H : OFF L : ON         | H       | L     |
| 26      | DO B/C         | O   | Dolby B/C Control Signal H : B L : C               | H       | L     |
| 27      | SPEED          | O   | High Speed Signal for Motor H : HIGH               | H       | L     |
| 28      | PLUNGER        | O   | Plunger ON Signal                                  | H       | L     |
| 29      | KARAOKE        | I   | Not Used (VSS)                                     | ---     | ---   |
| 30      | AMSS           | I   | Not Used (VSS)                                     | ---     | ---   |
| 31      | PACK A         | I   | Pack A Detection Signal                            | L : ON  | ---   |
| 32      | STOP SW        | I   | Stop Switch Detection Signal                       | L : ON  | ---   |
| 33      | VSS            | --- | Ground                                             | ---     | ---   |
| 34      | G REV          | I   | Anti Record Detection Signal for Reverse Direction | L : ON  | ---   |
| 35      | G FWD          | I   | Anti Record Detection Signal for Forward Direction | L : ON  | ---   |
| 36      | PACK B         | I   | Pack B Detection Signal                            | L : ON  | ---   |
| 37      | PLAY SW        | I   | Play Switch Detection Signal                       | L : ON  | ---   |
| 38      | PULL UP 2      | O   | Set Pull up Signal of AVref                        | H       | L     |
| 39      | MOTOR          | O   | Motor ON Signal                                    | H       | L     |
| 40      | SP RELAY       | O   | Speaker Relay ON Signal                            | H       | L     |
| 41      | -20dB MUTE     | O   | -20dB Muting Signal                                | H       | L     |
| 42      | ∞ MUTE         | O   | ∞ Muting Signal                                    | H       | L     |
| 43      | POWER ON       | O   | Power ON Signal                                    | H       | L     |
| 44      | VOL UP         | O   | Volume Up Signal                                   | H       | L     |
| 45      | VOL DOWN       | O   | Volume Down Signal                                 | H       | L     |
| 46      | REEL B         | I   | Reel B Rotate Detection Signal (Edge)              | ---     | ---   |
| 47      | REEL A         | I   | Reel A Rotate Detection Signal (Edge)              | ---     | ---   |
| 48      | AMSS           | I   | Input of Music Brank Brank : L                     | ---     | ---   |
| 49      | IR             | I   | Infrared Ray Receiving (Remocon) Signal            | ---     | ---   |
| 50      | CT DATA        | I   | Micon Data from CT Unit                            | ---     | ---   |
| 51      | NC             | I   | Not Used (VSS)                                     | ---     | ---   |
| 52      | CT CLK         | I   | Clock from CT Unit                                 | ---     | ---   |
| 53      | P DOWN         | I   | AC ON/OFF Detection Signal H : ON                  | ---     | ---   |
| 54      | VSS            | --- | Ground                                             | ---     | ---   |
| 55      | NC             | I   | Not Used (VSS)                                     | ---     | ---   |
| 56      | XT2            | O   | Not Used (VSS)                                     | ---     | ---   |
| 57      | IC             | --- | Ground                                             | ---     | ---   |
| 58      | X1             | I   | X'tal In (4.19 MHz)                                | ---     | ---   |
| 59      | X2             | O   | X'tal Out (4.19 MHz)                               | ---     | ---   |
| 60      | RESET          | I   | Reset Signal                                       | L       | ---   |
| 61      | BUSY           | O   | Busy Signal                                        | H       | L     |
| 62      | OSC            | O   | OSC Signal                                         | H : REC | L     |
| 63      | REV IND        | O   | Reverse Indicator (LED) Signal                     | L       | H     |
| 64      | 1/2 IND        | O   | Deck A/B Selection Signal                          | L : B   | L     |
| 65      | FOR IND        | O   | Forward Indicator (LED) Signal                     | L       | H     |
| 66      | DOLBY R/P      | O   | Dolby Rec/Play Control Signal                      | H : REC | L     |
| 67      | C STOP         | O   | CD Stop Signal                                     | L       | H     |
| 68      | DUB IN/OUT     | O   | Dubbing IN/OUT Selection Signal                    | L       | H     |
| 69      | P MUTE         | O   | Play Muting Signal                                 | H       | H     |
| 70      | R MUTE         | O   | Record Muting Signal                               | H       | H     |
| 71      | REC IND        | O   | Record Indicator (LED) Signal                      | L       | H     |
| 72      | DISCO PARTY    | O   | Not Used (VSS)                                     | ---     | ---   |




IC BLOCK DIAGRAM (AMPLIFIER)


| PIN No. | SIGNAL NAME     | I/O | DESCRIPTION                  | ACTIV | P OFF |
|---------|-----------------|-----|------------------------------|-------|-------|
| 73      | A-VSS           |     | AD Ground                    | ---   | ---   |
| 74      | PHONO OR VIDEO  | I   | Not Used (VSS)               |       |       |
| 75      | MOTOR OR ELECT  | I   | Not Used (VDD)               |       |       |
| 76      | REMOCON KEY     | I   | Not Used (VDD)               |       |       |
| 77      | NC              | I   | Not Used (VSS)               |       |       |
| 78      | BAND LEVEL IN   | I   | Band Pass VO-IN from BA3826S |       |       |
| 79      | VOL LEVEL DC IN | I   | Volume Level DC OUT          |       |       |
| 80      | AN1             | I   | AD Key Input                 |       |       |

ACTIV : Active Level P OFF : Power Off Time Level


IC501 BA3826S (Band Pass Filter for Spectrum Analyzer)



IC551 LC7582 (LCD Driver)




IC700 STK4162MKII (AF Power Amplifier)



IC BLOCK DIAGRAM (AMPLIFIER)

IC702 · 802 BU4051B (3-Input 8-Channel Multiplexer / De-Multiplexer)




TRUTH TABLE


| CONTROL INPUTS |   |   |   | [ON] CHANNEL |
|----------------|---|---|---|--------------|
| INHIBIT        | C | B | A | 4051         |
| L              | L | L | L | 0            |
| L              | L | L | H | 1            |
| L              | L | H | L | 2            |
| L              | L | H | H | 3            |
| L              | H | L | L | 4            |
| L              | H | L | H | 5            |
| L              | H | H | L | 6            |
| L              | H | H | H | 7            |
| H              | X | X | X | NONE         |
| X : DON'T CARE |   |   |   |              |

IC701 · 703 · 704 · 706 · 711


LA6458S (Dual Operational Amplifier)



IC705 LC7522 (7-Segment Electronic Variable Resistor)



IC707 LB1641 (Volume Motor Driver)




| Input           |                 | Output           |                  | Action                  |
|-----------------|-----------------|------------------|------------------|-------------------------|
| IN <sub>1</sub> | IN <sub>2</sub> | OUT <sub>1</sub> | OUT <sub>2</sub> |                         |
| 0               | 0               | 0                | 0                | Brake                   |
| 1               | 0               | 1                | 0                | Normal (Reverse) Rotary |
| 0               | 1               | 0                | 1                | Reverse (Normal) Rotary |
| 1               | 1               | 0                | 0                | Brake                   |




IC BLOCK DIAGRAM (AMPLIFIER)


IC900 903 L780S12 (5-Terminal Voltage Regulator)





IC901 L78M05 (3-Terminal Voltage Regulator)



IC902 L7812ML (3-Terminal Voltage Regulator)




LCD (SPECTRUM ANALYZER)




| NO. | COM. 1 | COM. 2   | NO. | COM. 1 | COM. 2    | NO. | COM. 1  | COM. 2   | NO. | COM. 1 | COM. 2 |
|-----|--------|----------|-----|--------|-----------|-----|---------|----------|-----|--------|--------|
| 1   |        | a        | 16  | E3     | F3        | 31  | B       | ● (CLAS) | 46  | C9     | D9     |
| 2   | A5     | B5       | 17  |        | 2.4K · 6K | 32  | C       | ● (VOCA) | 47  | C10    | D10    |
| 3   | A4     | B4       | 18  | E2     | F2        | 33  | KARAOKE | ● (KARA) | 48  | C11    | D11    |
| 4   | A3     | B3       | 19  | E1     | F1        | 34  | G7      | d        | 49  | C8     | D8     |
| 5   | A2     | B2       | 20  | G4     | B (DOLBY) | 35  | G8      | ● (BGM)  | 50  | C7     | D7     |
| 6   | A1     | B1       | 21  | G3     | C (DOLBY) | 36  | G9      | ● (DISC) | 51  | C6     | D6     |
| 7   |        | 60 · 150 | 22  | G1     | 15K       | 37  | G10     | ● (ROCK) | 52  | A10    | B10    |
| 8   | C5     | D5       | 23  | G2     | c         | 38  | G11     | ● (POP)  | 53  | A11    | B11    |
| 9   | C4     | D4       | 24  |        | b         | 39  | E8      | F8       | 54  | A8     | B8     |
| 10  | C3     | D3       | 25  | G5     | DOLBY NR  | 40  | E9      | F9       | 55  | A7     | B7     |
| 11  | C2     | D2       | 26  | G6     | PRESET    | 41  | E10     | F10      | 56  | A6     | B6     |
| 12  |        | 400 · 1K | 27  | (      | MUTE      | 42  | E11     | F11      | 57  | COM. 1 |        |
| 13  | C1     | D1       | 28  | →      | ←         | 43  | E7      | F7       | 58  |        | COM. 2 |
| 14  | E5     | F5       | 29  | M      | )         | 44  | E6      | F6       |     |        |        |
| 15  | E4     | F4       | 30  | A      | ● (JAZZ)  | 45  | C9      | D9       |     |        |        |




**SCHEMATIC DIAGRAM (FRONT)**




### SCHEMATIC DIAGRAM (TAPE MECHANISM)




















### WIRING DIAGRAM (TAPE DECK AMPLIFIER)












# WIRING DIAGRAM (PRE-AMPLIFIER & FRONT)














-FOR 01B























### WIRING DIAGRAM (SYSCON & POWER-AMPLIFIER)





# WIRING CONNECTION (TAPE DECK / AMPLIFIER UNIT)

