


Pioneer

Service Manual



DDJ-T1

ORDER NO.
RRV4164

DJ CONTROLLER

DDJ-T1

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Model	Type	Power Requirement	Remarks
DDJ-T1	SVYXJ8	AC 100 V to 240 V	
DDJ-T1	UXJCB	AC 100 V to 240 V	
DDJ-T1	FLPXJ	AC 100 V to 240 V	
DDJ-T1	KXJ5	AC 100 V to 240 V	
DDJ-T1	AXJ5	AC 100 V to 240 V	



For details, refer to "Important Check Points for good servicing".

PIONEER CORPORATION 1-1, Shin-ogura, Saiwai-ku, Kawasaki-shi, Kanagawa 212-0031, Japan

PIONEER ELECTRONICS (USA) INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.

PIONEER EUROPE NV Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium

PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 253 Alexandra Road, #04-01, Singapore 159936

©PIONEER CORPORATION 2011

SAFETY INFORMATION



This service manual is intended for qualified service technicians; it is not meant for the casual do-it-yourselfer. Qualified technicians have the necessary test equipment and tools, and have been trained to properly and safely repair complex products such as those covered by this manual.

Improperly performed repairs can adversely affect the safety and reliability of the product and may void the warranty. If you are not qualified to perform the repair of this product properly and safely, you should not risk trying to do so and refer the repair to a qualified service technician.

WARNING

This product may contain a chemical known to the State of California to cause cancer, or birth defects or other reproductive harm.

Health & Safety Code Section 25249.6 - Proposition 65


(FOR USA MODEL ONLY)

1. SAFETY PRECAUTIONS

The following check should be performed for the continued protection of the customer and service technician.

LEAKAGE CURRENT CHECK

Measure leakage current to a known earth ground (water pipe, conduit, etc.) by connecting a leakage current tester such as Simpson Model 229-2 or equivalent between the earth ground and all exposed metal parts of the appliance (input/output terminals, screwheads, metal overlays, control shaft, etc.). Plug the AC line cord of the appliance directly into a 120 V AC 60 Hz outlet and turn the AC power switch on. Any current measured must not exceed 0.5 mA.



AC Leakage Test

ANY MEASUREMENTS NOT WITHIN THE LIMITS OUTLINED ABOVE ARE INDICATIVE OF A POTENTIAL SHOCK HAZARD AND MUST BE CORRECTED BEFORE RETURNING THE APPLIANCE TO THE CUSTOMER.

2. PRODUCT SAFETY NOTICE

Many electrical and mechanical parts in the appliance have special safety related characteristics. These are often not evident from visual inspection nor the protection afforded by them necessarily can be obtained by using replacement components rated for voltage, wattage, etc. Replacement parts which have these special safety characteristics are identified in this Service Manual.

Electrical components having such features are identified by marking with a ⚠ on the schematics and on the parts list in this Service Manual.

The use of a substitute replacement component which does not have the same safety characteristics as the PIONEER recommended replacement one, shown in the parts list in this Service Manual, may create shock, fire, or other hazards.

Product Safety is continuously under review and new instructions are issued from time to time. For the latest information, always consult the current PIONEER Service Manual. A subscription to, or additional copies of, PIONEER Service Manual may be obtained at a nominal charge from PIONEER.

[Important Check Points for Good Servicing]

In this manual, procedures that must be performed during repairs are marked with the below symbol. Please be sure to confirm and follow these procedures.

1. Product safety



Please conform to product regulations (such as safety and radiation regulations), and maintain a safe servicing environment by following the safety instructions described in this manual.

- ① Use specified parts for repair.

Use genuine parts. Be sure to use important parts for safety.

- ② Do not perform modifications without proper instructions.

Please follow the specified safety methods when modification (addition/change of parts) is required due to interferences such as radio/TV interference and foreign noise.

- ③ Make sure the soldering of repaired locations is properly performed.

When you solder while repairing, please be sure that there are no cold solder and other debris. Soldering should be finished with the proper quantity. (Refer to the example)

- ④ Make sure the screws are tightly fastened.

Please be sure that all screws are fastened, and that there are no loose screws.

- ⑤ Make sure each connectors are correctly inserted.

Please be sure that all connectors are inserted, and that there are no imperfect insertion.

- ⑥ Make sure the wiring cables are set to their original state.

Please replace the wiring and cables to the original state after repairs. In addition, be sure that there are no pinched wires, etc.

- ⑦ Make sure screws and soldering scraps do not remain inside the product.

Please check that neither solder debris nor screws remain inside the product.

- ⑧ There should be no semi-broken wires, scratches, melting, etc. on the coating of the power cord.

Damaged power cords may lead to fire accidents, so please be sure that there are no damages. If you find a damaged power cord, please exchange it with a suitable one.

- ⑨ There should be no spark traces or similar marks on the power plug.

When spark traces or similar marks are found on the power supply plug, please check the connection and advise on secure connections and suitable usage. Please exchange the power cord if necessary.

- ⑩ Safe environment should be secured during servicing.

When you perform repairs, please pay attention to static electricity, furniture, household articles, etc. in order to prevent injuries. Please pay attention to your surroundings and repair safely.

2. Adjustments



To keep the original performance of the products, optimum adjustments and confirmation of characteristics within specification. Adjustments should be performed in accordance with the procedures/instructions described in this manual.

3. Lubricants, Glues, and Replacement parts



Use grease and adhesives that are equal to the specified substance. Make sure the proper amount is applied.

4. Cleaning



For parts that require cleaning, such as optical pickups, tape deck heads, lenses and mirrors used in projection monitors, proper cleaning should be performed to restore their performances.

5. Shipping mode and Shipping screws



To protect products from damages or failures during transit, the shipping mode should be set or the shipping screws should be installed before shipment. Please be sure to follow this method especially if it is specified in this manual.

CONTENTS

	SAFETY INFORMATION	2
A	1. SERVICE PRECAUTIONS	5
	1.1 NOTES ON SOLDERING	5
	1.2 SERVICE NOTICE	5
	2. SPECIFICATIONS	6
	2.1 SPECIFICATIONS	6
	2.2 PANEL FACILITIES	7
	3. BASIC ITEMS FOR SERVICE	13
	3.1 CHECK POINTS AFTER SERVICING	13
	3.2 JIGS LIST	13
	3.3 PCB LOCATIONS	14
	4. BLOCK DIAGRAM	16
	4.1 OVERALL WIRING DIAGRAM	16
	4.2 OVERALL BLOCK DIAGRAM	18
	4.3 POWER BLOCK DIAGRAM	20
B	5. DIAGNOSIS	22
	5.1 POWER ON SEQUENCE	22
	5.2 TROUBLESHOOTING	23
	5.3 VOLTAGE MONITORING	31
	5.4 HOW TO CHECK OPERATIONS USING THE TRAKTOR SOFTWARE	32
	6. SERVICE MODE	36
	6.1 OUTLINE OF SERVICE MODE	36
	6.2 DETAILS ON SERVICE MODE	37
	6.3 ABOUT THE DEVICE	40
	7. DISASSEMBLY	41
	8. EACH SETTING AND ADJUSTMENT	49
C	8.1 NECESSARY ITEMS TO BE NOTED	49
	8.2 CONFIRMATION OF THE VERSIONS OF THE FIRMWARE	49
	8.3 UPDATING OF THE FIRMWARE	50
	8.4 COPYING THE PROGRAM FOR THE USB CONTROLLER	51
	8.5 JOG DIAL ROTATION LOAD ADJUSTMENT	52
	9. EXPLODED VIEWS AND PARTS LIST	54
	9.1 PACKING SECTION	54
	9.2 EXTERIOR SECION	56
	9.5 JOG SECTION	62
	10. SCHEMATIC DIAGRAM	64
	10.1 JACB ASSY	64
	10.2 UCOM ASSY (1/6)	66
	10.3 UCOM ASSY (2/6)	68
D	10.4 UCOM ASSY (3/6)	70
	10.5 UCOM ASSY (4/6)	72
	10.6 UCOM ASSY (5/6)	74
	10.7 UCOM ASSY (6/6)	76
	10.8 CDCB 1, CDCB 2, TCHB and JOGB ASSYS	78
	10.9 LEDB ASSY	80
	10.10 CDJ1B ASSY	82
	10.11 CDJ2B ASSY	84
	10.12 DJMB ASSY	86
	10.13 MICB ASSY	88
	10.14 CHFD, CRFD and HPJK ASSYS	90
	10.15 USBB ASSY	92
E	10.16 VOLTAGES	94
	10.17 WAVEFORMS	95
	11. PCB CONNECTION DIAGRAM	100
	11.1 JACB ASSY	100
	11.2 UCOM ASSY	102
	11.3 CDCB 1 ASSY	106
	11.4 CDCB 2 ASSY	107
	11.5 TCHB, JOGB and LEDB ASSYS	108
	11.6 CDJ1B ASSY	112
	11.7 CDJ2B ASSY	116
	11.8 DJMB ASSY	120
	11.9 CHFD and CRFD ASSYS	124
F	11.10 MICB ASSY	128
	11.11 HPJK ASSY	129
	11.12 USBB ASSY	130
	12. PCB PARTS LIST	131

1. SERVICE PRECAUTIONS

1.1 NOTES ON SOLDERING

- For environmental protection, lead-free solder is used on the printed circuit boards mounted in this unit.
Be sure to use lead-free solder and a soldering iron that can meet specifications for use with lead-free solders for repairs accompanied by reworking of soldering.
- Compared with conventional eutectic solders, lead-free solders have higher melting points, by approximately 40 °C. Therefore, for lead-free soldering, the tip temperature of a soldering iron must be set to around 373 °C in general, although the temperature depends on the heat capacity of the PC board on which reworking is required and the weight of the tip of the soldering iron.

Do NOT use a soldering iron whose tip temperature cannot be controlled.

Compared with eutectic solders, lead-free solders have higher bond strengths but slower wetting times and higher melting temperatures (hard to melt/easy to harden).

The following lead-free solders are available as service parts:

- Parts numbers of lead-free solder:
GYP1006 1.0 in dia.
GYP1007 0.6 in dia.
GYP1008 0.3 in dia.

1.2 SERVICE NOTICE

- For checking of audio and operating elements, the DJ application (TRAKTOR) included with this product is used. TRAKTOR must be installed in your PC. For details on installation, see "5.4 HOW TO CHECK OPERATIONS USING THE TRAKTOR SOFTWARE."
For connection of this product with a PC, be sure to use the supplied USB cable (registered jig tool), whose operation with this product is guaranteed.

Voltage Monitoring

This unit always monitors for power failure and will shut itself off immediately after an error is detected. All LEDs are unlit after an error is generated. After the unit shuts itself off because of an error, disconnect the AC adapter and USB cable and wait at least 1 minute before turning the unit back on. Repair the unit according to the diagnostic procedures described in "5.3 VOLTAGE MONITORING."

Limitations when the unit is operating on USB-bus power

There are some limitations in operations of this unit while it is operated on USB-bus power, as shown below.

- The JOG dial indicator does not light.
- Lighting of the indicators (excluding that for the JOG dial) becomes dim.
- The AUX IN and MIC connectors are disabled.
- The sound volume through the headphones is reduced.

On the EEPROM on the UCOM ASSY

No program has been stored in the EEPROM (IC2003) on the UCOM Assy (blank ROM) when it is supplied as a part for service.

After the EEPROM is replaced, be sure to copy the program for the USB controller to it. For details, see "8.4 Copying the Program for the USB Controller."

Replacement of the MAIN_UCOM

When replacement of the MAIN_UCOM (IC701) is required, order a microcomputer dedicated for service (PEG850A8-K).

2. SPECIFICATIONS

2.1 SPECIFICATIONS

- A
- AC adapter
- Power.....AC 100 V to 240 V, 50 Hz/ 60 Hz
- Rated current.....300 mA
- Rated output.....DC 5 V, 2 A

General – Main Unit

- Power consumption (when using AC adapter).....700 mA
- Power consumption (when using USB bus power)....500 mA
- Main unit weight.....4.9 kg (10.8 lb)
- Max. dimensions.....680 mm (W) × 95.2 mm (H) × 317.7 mm (D)
(26.8 in. (W) × 3.7 in. (H) × 12.5 in. (D))
- Tolerable operating temperature.....+5 °C to +35 °C (+41 °F to +95 °F)
- B Tolerable operating humidity.....5 % to 85 % (no condensation)

Audio Section


- Rated output level
- MASTER OUT 1.....4.2 Vrms
- MASTER OUT 2.....2.1 Vrms
- Total harmonic distortion
- MASTER OUT 1.....0.006 %
- MASTER OUT 2.....0.006 %
- Frequency characteristic
- MASTER OUT 1.....20 Hz to 20 kHz
- MASTER OUT 2.....20 Hz to 20 kHz
- C S/ N ratio (when playing on computer)
- MASTER OUT 1.....103 dB or greater (at rated output)
- MASTER OUT 2.....103 dB or greater (at rated output)

- Input impedance
- AUX.....24 kΩ
- MIC.....10 kΩ
- Output impedance
- MASTER OUT 1.....1 kΩ or less
- MASTER OUT 2.....1 kΩ or less
- PHONES.....41 Ω
- Input / Output terminals
- USB terminal
- B type.....1 set
- MASTER OUT 1 output terminal
- TRS phone jack (Ø 6.3 mm).....1 set
- MASTER OUT 2 output terminal
- RCA pin jacks.....1 sets
- PHONES output terminal
- Stereo phone jack (Ø 6.3 mm).....1 set
- Stereo mini phone jack (Ø 3.5 mm).....1 set
- AUX input terminal
- RCA pin jack.....1 sets
- MIC input terminal
- Phone jack (Ø 6.3 mm).....1 set

- For improvement purposes, specifications and design of this unit and the included software are subject to change without notice.


Accessories

- AC adapter (DWR1491)
- Power plug (SVYXJ8: DKX1048, DKX1049) (UXJCB: DKX1047) (FLPXJ: DKX1048, DKX1049, DKX1047, DKX1050, DKX1051) (KXJ5: DKX1051) (AXJ5: DKX1052)
- TRAKTOR Pioneer DDJ-T1 EDITION software CD-ROM (DXX2665)
- Driver software CD-ROM (DXX2666)
- USB cable (DDE1140)
- Operating instructions (SVYXJ8: DRB1537, DRB1563) (UXJCB: DRB1536) (FLPXJ: DRB1539) (KXJ5: DRB1541) (AXJ5: DRB1540)



2.2 PANEL FACILITIES

Rear panel



1 MASTER OUT 1 terminal

Connect powered speakers, etc., here.
This is a TRS phone jack, so both balanced and unbalanced outputs are supported.

- The sound will be distorted if the level is raised too high when using unbalanced outputs.

2 MASTER OUT 2 terminal

Connect to a power amplifier, etc.

3 AUX IN terminal

Connect to the output terminal of an external device (sampler, portable audio device, etc.)

- This cannot be used when operating on USB bus power.

4 VOL control

Adjusts the audio level input to the [AUX IN] terminals.

5 Kensington security slot

6 USB terminal

Connect to a computer.

- Connect this unit and the computer directly using the included USB cable.
- A USB hub cannot be used.

7 ON/OFF switch

Turns this unit's power on and off.

8 DC IN terminal


Connect to a power outlet using the included AC adapter (with the power plug mounted).
Wait until connection of all equipment is completed before connecting the AC adapter.
Only use the included AC adapter.

9 Cord hook

Catch the AC adapter's power cord and USB cable on this hook when using this unit.

- The sound will be interrupted if the AC adapter or USB cable is disconnected during playback.

Front panel



1 PHONES terminal

Connect headphones here.
Both stereo phone plugs (Ø 6.3 mm) and stereo mini phone plugs (Ø 3.5 mm) can be used.

- The volume decreases when headphones are connected simultaneously to both the stereo phone jack and the stereo mini phone jack.

2 AUX/MIC selector switch

Switches the audio input between the external device and the microphone.

- [AUX]: The external device connected to the [AUX] terminals is selected.
- [MIC]: The microphone connected to the [MIC] terminal is selected.

3 VOL control



Adjusts the audio level input to the [MIC] terminal.

4 MIC jack

Connect a microphone here.

- This cannot be used when operating on USB bus power.

A ■ Control panel



1 Browser

2 Deck

3 Mixer

4 Effect


The above screen shows just one example of the display.

The contents displayed differ according to the resolution of your computer's monitor.

The contents displayed on the screen can be changed using the procedure below.

- Click [F1]: Switches the full screen display on and off.
- Double-click the deck's track information display section (the part where the track name, BPM, etc., are displayed): Opens and closes the track information display section.
- Click [▲] under the [ACTIVE] button: Opens and closes the advanced panel.

1 Browser



1 TREE button

- Turn the rotary selector while pressing the **[TREE]** button: Moves the cursor in the **[TREE]** area. The section marked **1** on the above screen is called the **[TREE]** area.
- Press the rotary selector while pressing the **[TREE]** button: Opens/closes the folder.

2 Rotary selector

- Turn the rotary selector: Moves the cursor in the **[TRACK]** area. The section marked **2** on the above screen is called the **[TRACK]** area.
- Press the rotary selector: Turns the enlarged display of the **[BROWSE]** area on/off. The **[TREE]** area, **[TRACK]** area and **[FAVORITES]** area are collectively called the **[BROWSE]** area.

Turn the rotary selector while pressing the **[SHIFT]** button: Moves the cursor in the **[TRACK]** area page by page.



3 FAVORITES (REC) button

- Turn the rotary selector while pressing the **[FAVORITES (REC)]** button: Moves the cursor in the **[FAVORITES]** area. The section marked **3** on the above screen is called the **[FAVORITES]** area.
- Press the **[FAVORITES (REC)]** button while pressing the **[SHIFT]** button: Starts/stops recording.
 - To display the **[AUDIO RECORDER]** panel, click the **[REC]** icon in the upper right of the screen.
 - Recording can be started/stopped even when the **[AUDIO RECORDER]** panel is not displayed.
 - To play files you have recorded, select **[Audio Recordings]** in the **[TREE]** area. The location where recorded files are stored can be checked and changed at **[Recording]** under **[Preferences]**.

4 LOAD button

Loads the track selected with the cursor in each of the decks.

A 2 Deck



1 PLAY/PAUSE ►/II button

Use this to play/pause tracks.

2 CUE button

When the **[CUE]** button is pressed while pausing, the cue point is set at the position where playback is pausing.

- When TRAKTOR's **[SNAP]** function is on: The cue and loop points can be set at the desired position.
- When TRAKTOR's **[SNAP]** function is on: The cue and loop points are set to the nearest **[Beat Grid]**.

When the **[CUE]** button is pressed during playback, playback returns to the set cue point, cues there, and the pause mode is set (back cue).

When you keep pressing the **[CUE]** button after returning to the cue point, playback continues as long as the button is pressed.

3 SHIFT button

When another button is pressed while pressing the **[SHIFT]** button, a different function is called out.

4 AUTO LOOP (MOVE GRID) control

- Turn the **[AUTO LOOP (MOVE GRID)]** control: Changes the loop size.
- Press the **[AUTO LOOP (MOVE GRID)]** control: Switches loop playback on/off.
- Turn the **[AUTO LOOP (MOVE GRID)]** control while pressing the **[SHIFT]** button: The **[Beat Grid]** can be adjusted. This adjusts the difference with the results of analysis.
 - When adjusting the **[Beat Grid]**, create at least one **[BEAT MARKER]**.
 - When creating **[BEAT MARKER]**, set the hot cue **[CUE TYPE]** to **[Grid]**.
 - [CUE TYPE]** (the type of hot cue) can be changed by clicking **[▼]** to the left of the **[Grid]** icon.

5 IN (IN ADJUST) button, OUT (OUT ADJUST) button, ACTIVE button

- IN (IN ADJUST) button**
During playback, press the **[IN (IN ADJUST)]** button at the position at which you want to start loop playback (the loop in point) to set the loop in point.

The loop in point can be fine-adjusted by pressing the **[IN (IN ADJUST)]** button during loop playback then using the jog dial.

- During fine-adjustment of the loop point, the **[IN (IN ADJUST)]** button flashes rapidly and the **[OUT (OUT ADJUST)]** button is off.
- To return to normal loop playback, press the **[IN (IN ADJUST)]** button.

Real-time cue: When the **[IN (IN ADJUST)]** button is pressed during playback, the cue point is set at the position at which the button was pressed.

• OUT (OUT ADJUST) button

Press the **[OUT (OUT ADJUST)]** button at the position at which you want to stop loop playback (the loop out point) to set the loop out point.

The loop out point is set, playback returns to the loop in point and loop playback starts.

The loop out point can be fine-adjusted by pressing the **[OUT (OUT ADJUST)]** button during loop playback then using the jog dial.

After switching **[MOVE MODE]** to **[Loop Out]**, use the jog dial to fine-adjust the loop out point.

- During fine-adjustment of the loop out point, the **[OUT (OUT ADJUST)]** button flashes rapidly and the **[IN (IN ADJUST)]** button is off.
- To return to normal loop playback, press the **[OUT (OUT ADJUST)]** button.
- ACTIVE button**
Switches loop playback on/off.

6 FUNCTION button

Switches the **[NEEDLE SEARCH]** pad's function.

7 NEEDLE SEARCH pad

- When the **[FUNCTION]** button is off:
The **[NEEDLE SEARCH]** function can be used.
 - The sound at the position at which the **[NEEDLE SEARCH]** pad is touched can easily be played.
- When the **[FUNCTION]** is on:
The desired function can be assigned.
 - Upon purchase, nothing is assigned.

8 DECK button

Switches the deck to be operated.

- Deck on left side of this unit: Deck **[A]** or **[C]**
- Deck on right side of this unit: Deck **[B]** or **[D]**

9 Filter control

- Turn counterclockwise while filter function is on: Low pass filter.
- Turn clockwise while filter function is on: High pass filter.

10 FILTER button

Switches the filter function on/off.

11 MOVE/HOT CUE selector button

Switches **[Move Panel]** and **[Cue Panel]** in the advanced panel.

- To open the advanced panel, click **[▼]** below **[ACTIVE]** in TRAKTOR.

12 MOVE PANEL/HOT CUE PANEL

- **MOVE PANEL** operation
[MOVE MODE] (the loop moving mode) switches each time the **[MODE DELETE]** button is pressed.

→ **[Beat Jump]** → **[Loop]** → **[Loop In]** → **[Loop Out]** →

- **[Beat Jump]**: The position of playback moves.
- **[Loop]**: The loop moves.
- **[Loop In]**: The loop in point moves.
- **[Loop Out]**: The loop out point moves.

Use the **[SIZE ◀/▶]** buttons to set the amount of movement of the playback position or loop by fractions of the beat.

Use the **[◀ BWD/FWD ▶]** buttons to move the playback position or loop by the amount of movement set with the **[SIZE ◀/▶]** buttons.

- **HOT CUE PANEL** operation

When a button at which nothing is set is pressed in the play or pause mode, a hot cue (**[1]** – **[4]**) is set at the position at which the button was pressed.

When a button at which a hot cue (**[1]** – **[4]**) is set is pressed in the play or pause mode, a hot cue (**[1]** – **[4]**) is called out.

To cancel a hot cue (**[1]** – **[4]**), press the corresponding button (**[1]** – **[4]**) while pressing the **[DELETE]** button.

Buttons **[1]** – **[4]** at which hot cues are set flash while the **[DELETE]** button is pressed.

- To set or call out hot cues **[5]** to **[8]**, press buttons **[1]** to **[4]** while pressing the **[SHIFT]** button.
- To delete a hot cue from **[5]** to **[8]**, press buttons **[1]** to **[4]** while pressing the **[SHIFT]** and **[DELETE]** buttons.
- **[CUE TYPE]** (the type of hot cue) can be changed by clicking **[▼]** to the left of the **[CUE TYPE]** icon.

13 KEY LOCK button

Switches the key lock function on/off.

When the key lock function is on, the key does not change even when the playing speed is changed with the **[TEMPO]** slider.

14 TEMPO RANGE button

The **[TEMPO]** slider's range of variation switches each time this is pressed.

→ **[±6]** → **[±10]** → **[±16]** → **[±100]** →


15 TEMPO slider

- Move towards the + (front) side: The playing speed increases.
- Move towards the – (back) side: The playing speed decreases.

16 Jog dial


- Scratch
 Spin the jog dial while pressing down on the top: The sound is played according to the direction and speed of rotation.
- Pitch bend
 During playback, spin the outer section of the jog dial.
 - Spin clockwise: The playing speed increases.
 - Spin counterclockwise: The playing speed decreases.
 - Stop spinning: Playback at the normal speed resumes.

3 Mixer



1 MAIN VOL control

Adjusts the sound level output from the master.



2 HEADPHONES MIX control

Adjusts the monitor volume balance between the sound of the deck for which the **[CUE]** button is pressed and the sound of **[MASTER OUT 1]** and **[MASTER OUT 2]**.

A

3 HEADPHONES VOL control

Adjusts the audio level output from the **[PHONES]** terminal.

4 GAIN control

Adjusts the sound level input to the various decks.

5 EQ (HI, MID, LOW) controls

These adjust the sound quality input to the various decks.

These adjust the **[HI]** (high range), **[MID]** (medium range) and **[LOW]** (low range), respectively.

6 Effect assign buttons

Press the **[1]** or **[2]** button to assign TRAKTOR effect unit **[FX 1]** or **[FX 2]** to the deck.

B

7 CUE button

The sound of decks for which the headphones **[CUE]** button is pressed can be monitored over headphones. When multiple headphones **[CUE]** buttons are pressed, the sound of the decks for which the buttons are pressed is mixed and output from the headphones.

8 SYNC button

The track on the deck for which the **[SYNC]** button is pressed is synchronized to the **[BPM]** and **[Beat Grid]** of the deck for which the **[MASTER]** button is pressed or of the master clock.

9 MASTER button

Sets the tempo of the deck for which the **[MASTER]** button is pressed as the master for synchronizing with the beat sync function.

10 Channel fader

Adjusts the sound level output from the various decks.

11 CH FADER START switch

Switches the **[CH FADER START]** function on/off.

When the **[CH FADER START]** switch is set to **[ON]**, the fader start and back cue functions can be used according to the movement of the channel faders.

- Fader start: When the channel fader is moved from the front-most position towards the back while pausing at the cue point, playback starts immediately.
- Back cue: When the channel fader is returned from the back to the front-most position, playback returns to the set cue point, cues there, and the pause mode is set immediately.


12 Crossfader

Switches the sound of the decks assigned to the left and right sides of the crossfader for output.

The deck assignment can be changed with the **[Deck Assign Button]** at the sides of the TRAKTOR crossfader.

Do not pull on the channel fader and crossfader knobs with excessive force. The knobs are not designed to be removed. Pulling the knobs strongly may result in damaging the unit.

C

4 Effect

- The **[Advanced]** mode cannot be selected with TRAKTOR Pioneer DDJ-T1 EDITION.
- The effect panel can be switched to the **[Advanced]** mode when you upgrade to TRAKTOR PRO or TRAKTOR SCRATCH PRO.

1 ADVANCED/CHAINED selector button

- **[Chained]** mode: Up to 3 effects can be selected on the effect panels and operated simultaneously.
- **[Advanced]** mode: The parameters of the one selected effect can be adjusted in detail.

2 Effect button

This button is exclusively for use in the **[Advanced]** mode.

3 DRY/WET control

Changes the balance between the effect sound and original sound.

4 SELECT/BACK button

The effect type switches each time the button is pressed. With TRAKTOR Pioneer DDJ-T1 EDITION, the 6 types of effects below can be used.

→ **[no Effect]** → **[Delay]** → **[Reverb]** → **[Filter]** → **[Beatmasher2]** → **[Gater]** → **[Flanger]**

- When the **[SELECT/BACK]** button is pressed while pressing the **[SHIFT]** button, the direction in which the effect types switch is reversed.

- When in the **[Advanced]** mode, the effect type is switched by pressing the **[1]** button for **[SELECT/BACK]**.

5 Effect control

- Effect control dials

The linked functions differ depending on the TRAKTOR effect panel's mode.

— **[Chained]** mode: Adjusts the balance between the effect sound of the each effects and the original sound.

— **[Advanced]** mode: Adjusts the various parameters of the selected effect.

- Effect control buttons

The linked functions differ depending on the TRAKTOR effect panel's mode.

— **[Chained]** mode: Switches the various effects on/off.

— **[Advanced]** mode: When the effect control **[1]** button is pressed, all the effect setting values return to the default setting values.

When effect control buttons **[2]** and **[3]** are pressed, the various parameters switch between on and off. The types of parameters differ according to the effect.

D

E

F

3. BASIC ITEMS FOR SERVICE

3.1 CHECK POINTS AFTER SERVICING

Items to be checked after servicing

To keep the product quality after servicing, confirm recommended check points shown below.

No.	Procedures	Check points
1	Confirm that the customer complaint has been resolved. If the problem pointed out by the customer occurs with a specific source or operation, such as PC input, AUX/MIC input, Fader, or VOL, input that specific source then perform that specific operation for checking.	The customer complain must not be reappeared. Audio and operations must be normal.
2	Confirmation of operation of operating elements ① Enter Service mode.	There must be no errors in operations of each button, LED, the JOG dial, and NeedleSearch.
3	Confirmation of operation of operating elements ② Connect this unit with a PC with the DJ application (TRAKTOR) installed, via USB.	There must be no errors in operations of volume controls, faders, and rotary encoders.
4	Check the analog audio output. Connect this unit with a PC with the DJ application (TRAKTOR) installed, via USB, then play back audio	There must be no errors, such as noise, in audio signals and operations of the MASTER/HEADPHONES outputs.
5	Check the analog audio input. Input an audio signal via AUX/MIC. (Make the input settings, referring to "Inputting Audio from Microphones or External Equipment" in the Operating Instructions.)	Audio and operations must be normal.
6	Confirmation of USB-bus Power Disconnect the AC adapter and operate the unit only on USB-bus power.	Audio and operations must be normal. (For details on limitations of USB-bus power, refer to the Operating Instructions.)
7	Check the appearance of the product.	No scratches or dirt on its appearance after receiving it for service.

See the table below for the items to be checked regarding audio.

Item to be checked regarding audio
Distortion
Noise
Volume too low
Volume too high
Volume fluctuating
Sound interrupted

3.2 JIGS LIST

Jigs List


Jig Name	Part No.	Purpose of use / Remarks
USB cable	GGP1188	for PC connection, accessory
AC adapter	DWR1491	Accessory (Note: The power plug part is different.)

Lubricants and Glues List



Name	Part No.	Remarks
Lubricating oil	GYA1001	Refer to "9.5 JOG SECTION".

3.3 PCB LOCATIONS



NOTES: • Parts marked by “NSP” are generally unavailable because they are not in our Master Spare Parts List.
• The  mark found on some component parts indicates the importance of the safety factor of the part.
Therefore, when replacing, be sure to use parts of identical designation.

Mark	No.	Description	Part No.	Mark	No.	Description	Part No.
LIST OF ASSEMBLIES							
E	NSP	1..MAIN ASSY	DWM2421	NSP	1..DJM1 ASSY	DWM2424	
		2..UCOM ASSY	DWX3209		2..CHFD ASSY	DWX3212	
		2..CDCB 1 ASSY	DWX3210		2..CRFD ASSY	DWX3213	
		2..CDCB 2 ASSY	DWX3224		2..MICB ASSY	DWX3215	
NSP		1..CDJ1 ASSY	DWM2422		2..HPJK ASSY	DWX3216	
		2..CDJ1B ASSY	DWS1430	NSP	1..DJM2 ASSY	DWM2426	
		2..JOGB ASSY	DWS1432		2..DJMB ASSY	DWX3211	
		2..TCHB ASSY	DWS1433		2..JACB ASSY	DWX3214	
		2..LEDB ASSY	DWS1434		2..USBB ASSY	DWX3222	
F	NSP	1..CDJ2 ASSY	DWM2423				
		2..CDJ2B ASSY	DWS1431				
		2..JOGB ASSY	DWS1432				
		2..TCHB ASSY	DWS1433				
		2..LEDB ASSY	DWS1434				

■

5

■

6

■

7

■

8

■

A

■

B

■

C

■

D

■

E

■

F

■

5

■

6

■

7

■

8

■


DDJ-T1


15

F




4.2 OVERALL BLOCK DIAGRAM






4.3 POWER BLOCK DIAGRAM

A
B
C
D
E
F




C CDCB 1 ASSY



5. DIAGNOSIS

5.1 POWER ON SEQUENCE



5.2 TROUBLESHOOTING

In this section, causes of failure, diagnostics points, and corrective measures can be searched for according to symptoms. Before disassembling this unit, it is recommended to infer a failure point by referring to the error code.

For the relationship of each power-supply system, see “4.3 POWER SUPPLY BLOCK DIAGRAM.”

If software of the product is updated before performing diagnostics, check that software updating has been performed properly before proceeding to diagnostics.

If software updating has not been performed properly, update the software, following the instructions in “8.3 UPDATING OF THE FIRMWARE.”

Contents

- [0] Prior Confirmation
- [1] Failure in Startup (Failure in power-on, all LEDs unlit)
- [2] Display (LED indicators)
- [3] Operations (Buttons/VRs/Sliders/NeedleSearch/JOG)
- [4] USB connection
- [5] AUDIO OUT
- [6] AUDIO IN
- [7] Basic Operation Check of the MAIN_UCOM

The waveform numbers and voltage confirmation-point numbers described in this section correspond to the numbers on the schematic diagrams and PCBs.

Be sure to check the failure points, as well as checking for failure in their peripheral circuits.

[0] Prior Confirmation

[0-1] Checking in Service Mode

No.	Cause/Symptom	Point to be checked	Item to be checked	How to distinguish a defective point and/or corrective action	Reference
1	—	Service Mode	Identify a failure point.	After a failure point is identified, see the section referenced in this manual.	6. SERVICE MODE

[0-2] Checking Internal Cables

No.	Cause/Symptom	Point to be checked	Item to be checked	How to distinguish a defective point and/or corrective action	Reference
1	Disconnection, breakage, or loose connection of internal cables	Cables	Check that all the cables are securely connected. Check that there is no breakage in the cables.	Securely connect a cable if it is not connected. If a cable is broken, replace it. Note: If an FFC cable is disconnected, be careful of the orientation of the contacts when reconnecting it, referring to the printed guide on the board.	4.1 OVERALL CONNECTION DIAGRAM

[1] Failure in Startup (Failure in power-on, all LEDs unlit)

[1-1] Failure in the power system

In a case where the unit does not start up, even after it is turned ON, when it is powered via the AC adapter or USB-bus power connection.

No.	Cause/Symptom	Point to be checked	Item to be checked	How to distinguish a defective point and/or corrective action	Reference
1	Failure in the AC adapter	USBB Assy V+ADP5	Set the POWER switch to OFF. Check that the voltage of the V+ADP5 power line is in the range of 4.75–5.25 V.	If the voltage is outside the range of 4.75–5.25 V, failure in the AC adapter and its periphery may be suspected. AC adapter (DWR1491), DC jack (JA2501), FETs (Q2523, Q2525), Tra ()	4.3 POWER SUPPLY BLOCK DIAGRAM 10.17 WAVEFORMS AC adapter ④
2	Failure in USB-bus power	USBB Assy V+USB5	Set the POWER switch to OFF. Check that the voltage of the V+ADP5 power line is in the range of 4.75–5.25 V.	If the voltage is outside the range of 4.75–5.25 V, failure in the USB-bus power and its periphery may be suspected. Check the USB cable and USB connector.	4.3 POWER SUPPLY BLOCK DIAGRAM 10.17 WAVEFORMS Power bus power ①
3-1	Power failure in the MAIN_UCOM on the UCOM Assy	UCOM Assy MAIN_UCOM	Set the POWER switch to ON. If V+3R3_UCOM is abnormal (2.7 V or less) and V+4R7_STB is normal (4.2–5.0 V)	The regulator (IC105), the MAIN_UCOM (IC701), or their peripheral circuits may be defective.	4.3 POWER SUPPLY BLOCK DIAGRAM
3-2	Power failure in the USB_UCOM on the UCOM Assy	UCOM Assy USB_UCOM	Set the POWER switch to ON. If V+3R3_USB is abnormal (2.7 V or less) and the V+5_USB is normal (4.5 V–5.25 V)	The regulator (IC102), the USB_UCOM (IC202), or their peripheral circuits may be defective.	4.3 POWER SUPPLY BLOCK DIAGRAM

A

No.	Cause/Symptom	Point to be checked	Item to be checked	How to distinguish a defective point and/or corrective action	Reference
4-1	Power failure ①	UCOM Assy FAULT_DET	Check if the voltage monitoring circuit was activated: Turn the unit ON then check the voltages shown below. V+5_D: FAULT_DET, R147 (0 Ω) :	Turn the unit ON then check the voltages shown below. V+5_D: 2 V or less (abnormal voltage), 4.5 V or higher (normal voltage) FAULT_DET, R147(0 Ω): 0 V (abnormal voltage detection), 3.3 V (normal voltage) In a case of abnormal voltage detection, see [4-2] Power failure ②. In a case of normal voltage, poor control over the microcomputer system may be suspected.	4.3 POWER SUPPLY BLOCK DIAGRAM 5.3 VOLTAGE MONITORING 10.17 WAVEFORMS Abnormal voltage detection ②⑤
4-2	Power failure ② Identification of defective Assy	UCOM Assy FAULT_DET CDJB CDCB DJMB JACB HPJK MICB	Identify the Assy on which a voltage error was generated. Remove all cables other than the cable for CN1004 (USBB to UCOM) from the UCOM Assy. Turn the unit ON then check the V+5_D voltage. V+5_D: FAULT_DET, R147 (0 Ω):	Remove all cables other than the cable for CN1004 (USBB to UCOM) from the UCOM Assy. Turn the unit ON then check the V+5_D voltage. V+5_D: 4.5 V or higher (normal) FAULT_DET, R147(0 Ω): 3.3 V normal, no detection of a voltage error In a case of normal voltage, see [4-3] Abnormal voltage detection ③. In a case of abnormal voltage detection, see [4-4] Power failure, UCOM Assy.	4.1 OVERALL CONNECTION DIAGRAM 4.3 POWER SUPPLY BLOCK 10.17 WAVEFORMS Abnormal voltage detection ②⑤
4-3	Power failure ③ Identification of defective Assy	UCOM Assy FAULT_DET CDJB CDCB DJMB JACB HPJK MICB	With all cables other than the cable for CN1004 (USBB to UCOM) disconnected from the UCOM_ASSY, identify the defective Assy by connecting each connector on the UCOM Assy one by one for voltage checks.	Identify the defective ASSY, by connecting each connector on the UCOM Assy, as shown below, one by one for voltage checks: CDJ1B: CN905, CN906 CDJ2B: CN903, CN904 CDCB: CN901, CN902 DJMB: CN1001, 1002 JACB: CN302, CN501 HPJK: CN301 MICB: CN303 Repair the defective part of the defective Assy. If further identification of defective Assys is required, see the notes in "5.3 Voltage Monitoring" before proceeding to further diagnostics.	4.1 OVERALL CONNECTION DIAGRAM 4.3 POWER SUPPLY BLOCK 5.3 VOLTAGE MONITORING
4-4	Power failure ④ UCOM Assy Identification of defective Assy	UCOM Assy FAULT_DET	Deactivate the voltage monitoring circuit then check the section with improper voltage.	The voltage monitoring circuit can be deactivated by removing R147 (0 Ω) on the FAULT_DET. See the notes in "5.3 Voltage Monitoring" before proceeding to further diagnostics. To identify the section with improper voltage, check the voltage at each point on the UCOM Assy.	4.3 POWER SUPPLY BLOCK 5.3 VOLTAGE MONITORING

D

[1-2] Failure in the microcomputer system

No.	Cause/Symptom	Point to be checked	Item to be checked	How to distinguish a defective point and/or corrective action	Reference
1	Power failure in the MAIN_UCOM	UCOM Assy	Check if a voltage error was detected. Check the power terminal of the MAIN_UCOM (IC701).	If the detected voltage error is confirmed, check conduction between the power supply and GND. Check the power line and the parts, such as coils (beads), resistors, and capacitors. If no problem was found with the parts, power line, and conduction between the power supply and GND, the MAIN_UCOM (IC701) may be defective.	Abnormal Voltage Detection 10.17 WAVEFORMS MAIN UCOM start up
2	MAIN_UCOM Reset circuit error	UCOM Assy	Check the Reset terminal (Pin 17) of the MAIN_UCOM (IC701). (High/Low)	In normal operation, the voltage of the Reset terminal (Pin 17) is high. If the voltage of the Reset terminal is low, check the power line, resistors, capacitors, and the Reset IC (IC106). If the voltage level remains low after the Reset IC (IC106) is replaced, the MAIN_UCOM (IC701) may be defective.	10.17 WAVEFORMS MAIN UCOM start up ⑱
3	MAIN_UCOM X'tal error	UCOM Assy	Check the oscillation waveforms of the X'tal (X701).	Check the waveforms of the X'tal (X701). If an error is found, check the power line, resistors, and capacitors. If the waveform remains abnormal after the X'tal (X701) is replaced, the MAIN_UCOM (IC701) may be defective.	10.17 WAVEFORMS MAIN UCOM start up ⑲
4	MAIN_UCOM startup error	UCOM Assy	After startup, check the lighting statuses of the LEDs. (For example, although some of the LEDs light properly, the unit is not started up properly.)	Refer to "[4] Error Indications" in the 6. Service Mode. If there is no corresponding error indication, reload the program via USB. If the normal status is not recovered after all above steps are performed, the MAIN_UCOM (IC701) may be defective.	6. Service Mode [4] Error Indications

F

No.	Cause/Symptom	Point to be checked	Item to be checked	How to distinguish a defective point and/or corrective action	Reference
5	Power failure in the USB_UCOM	UCOM Assy	Check if a voltage error was detected. Check the power terminal of the USB_UCOM (IC202).	If the detected voltage error is confirmed, check conduction between the power supply and GND. Check the power line and the parts, such as coils (beads), resistors, and capacitors. If no problem was found with the parts, power line, and conduction between the power supply and GND, the USB_UCOM (IC202) may be defective.	Abnormal Voltage Detection 10.17 WAVEFORMS USB UCOM start up
6	USB_UCOM Reset circuit error	UCOM Assy	Check the Reset terminal (Pin 10) of the USB_UCOM (IC202). (High/Low)	In normal operation, the voltage of the Reset terminal (Pin 10) is high. If the voltage level at the Reset terminal is low, check for abnormal voltage detection, and check the power line, resistors, and capacitors. If no problem was found with the above circuit, parts, and power line, and if the voltage level is low, the USB_UCOM (IC202) or the MAIN_UCOM (IC701) may be defective.	Abnormal Voltage Detection 10.17 WAVEFORMS USB UCOM start up (12)
7	USB_UCOM X'tal error	UCOM Assy	Check the oscillation waveforms of the X'tal (X201).	If an error is found, check the power line, resistors, and capacitors. If the waveform remains abnormal after the X'tal (X201) is replaced, the USB_UCOM (IC202) may be defective.	10.17 WAVEFORMS USB UCOM start up (13)
8	USB_UCOM I2C communication error	UCOM Assy	Check the I2C communication waveforms of the EEPROM (IC201) immediately after startup.	Data of the EEPROM (IC201) are loaded only during startup. If an error is generated, check the power supply to the EEPROM, resistors, capacitors, and SW IC (IC203) on the communication line. If no problem is found with the power supply, communication line, and parts, the EEPROM (IC201) or USB_UCOM (IC202) may be defective.	10.17 WAVEFORMS I2C USB UCOM EEPROM
9	EEPROM error	UCOM Assy	Reload the program via USB.	If no problem is found with the communication waveform in [8] above, reload the program via USB. If reloading is successfully performed, the USB_UCOM (IC202) may be defective. If reloading fails, the EEPROM (IC201) may be defective.	8.4 COPYING THE PROGRAM FOR THE USB CONTROLLER

[2] Display (LED indicators)

[2-1] Any one of the LEDs does not light.

No.	Cause/Symptom	Point to be checked	Item to be checked	How to distinguish a defective point and/or corrective action	Reference
1	Defective LED	LERelated point	Check the connections of the LED then check the forward voltage (approx. 2.2 V) between both ends of the LED.	If the forward voltage is abnormal, the LED may be defective.	LED waveform 10.SCHEMATIC DIAGRAM

[2-2] Several LEDs do not light.

No.	Cause/Symptom	Point to be checked	Item to be checked	How to distinguish a defective point and/or corrective action	Reference
1	Signal errors	UCOM Assy CDJ1B CDJ2B DJMB	Check for any loose connections between the MAIN_UCOM (IC701) and the LEDs. Check also that the control signal for the LEDs is output.	If the control signal is not output, check the mounting status of the MAIN_UCOM (IC701). If it is properly mounted, then the IC701 itself may be defective.	Basic Operation Check of the MAIN_UCOM
2	Defective LEDs	Related point	Check the forward voltage (approx. 2.2 V) between both ends of the LEDs.	If the forward voltage is abnormal, the LEDs may be defective.	LED waveform 10.SCHEMATIC DIAGRAM
3	Defective transistors	Related point	Check the transistors.	The transistors may be defective.	10.SCHEMATIC DIAGRAM

[3] Operations (Buttons/VRs/Sliders/NeedleSearch/JOG)

Operation of all buttons, variable controls, and the JOG dial can be confirmed in Service mode.

[3-1] The push buttons are disabled.

No.	Cause/Symptom	Point to be checked	Item to be checked	How to distinguish a defective point and/or corrective action	Reference
1	Loose connection or defective switches	Related point	Check for any loose connections on the signal line from the switch to GRID_IC (IC702), KEY_BUFFER (IC1101, 1102), and main microcomputer (IC701).	If other SWs connected to the same signal line function properly and if the connections are properly made, the SW may be defective.	Each Signal Levels
2	Defective MAIN_UCOM (IC701)	UCOM Assy	If the symptom persists after the above corrections.	Go to [7-1] Basic Operation Check of the Microcomputer.	Basic Operation Check of the MAIN_UCOM

A [3-2] Rotary selector not controllable

No.	Cause/Symptom	Point to be checked	Item to be checked	How to distinguish a defective point and/or corrective action	Reference
1	Defective AUTO_LOOP of the CDJ1	CDJ1 Assy	Check that the signal lines (L_ENC1_1/ L_ENC1_2) are normal during rotation of the rotary selector. L_ENC1_1: CN3002-1 pin L_ENC1_2: CN3002-2 pin	If the signals are not normal, check the connections of the signal lines. If the connections are properly made, the rotary selector (S3030) may be defective. Replace it.	Each Signal Levels
2	Defective AUTO_LOOP of the CDJ2	CDJ2 Assy	Check that the signal lines (L_ENC2_1/ L_ENC2_2) are normal during rotation of the rotary selector. L_ENC2_1: CN3502-6 pin L_ENC2_2: CN3502-5 pin	If the signals are not normal, check the connections of the signal lines. If the connections are properly made, the rotary selector (S3527) may be defective. Replace it.	Each Signal Levels
3	Defective DJM BROWSE	DJMB Assy	Check that the signal lines (CUR_ENC1/ CUR_ENC2) are normal during rotation of the rotary selector. CUR_ENC1: CN4002-21 pin CUR_ENC2: CN4002-22 pin	If the signals are not normal, check the connections of the signal lines. If the connections are properly made, the rotary selector (S4027) may be defective. Replace it.	Each Signal Levels
4	Defective MAIN_UCOM (IC701)	UCOM Assy	If the symptom persists after the above corrections.	Check the mounting status of the MAIN_UCOM (IC701). If it is properly mounted, then the IC701 itself may be defective.	Basic Operation Check of the MAIN_UCOM

[3-3] VRs or sliders not controllable

The variable controls on the CDJ1 and CDJ2 Assys or the sliders on the CHFD and CRFD ASSYs are not controllable.

No.	Cause/Symptom	Point to be checked	Item to be checked	How to distinguish a defective point and/or corrective action	Reference
1	Loose connection	CDJ1/CDJ2 Assy CHFD Assy CRFD Assy	Check for any loose connections on the signal line from the MAIN_UCOM (IC701) to each variable control or slider.	If any connection on the signal line is improper, resolder the parts.	—
2	Defective sliders or VRs	CDJ1/CDJ2 Assy CHFD Assy CRFD Assy	VRs: Check the signal level. Tempo slider: Check the levels of the ADCT and ADIN signals. CHFD, CRFD: Check the signal level.	VRs: If the voltage of the signal from a VR (Pin 2) does not change between 3.3 V and 0 V, that VR may be defective. Tempo slider: If the value of the voltage of the ADCT signal (Pin 4) is other than 1.65 V, or if the voltage of the ADIN signal (Pin 2) does not change between 3.3 V and 0 V, the tempo slider may be defective. CHFD, CRFD: If the voltage of the signal from the CHFD or CRFD (Pin 2) does not change between 3.3 V and 0 V, the slider may be defective.	Each Signal Levels
3	Defective MAIN_UCOM (IC701)	UCOM Assy	If the symptom persists after the above corrections.	Check the mounting status of the MAIN_UCOM (IC701). If it is properly mounted, then the IC701 itself may be defective.	Basic Operation Check of the MAIN_UCOM

VRs on the DJMB ASSY not controllable.

4	Loose connection	DJMB Assy	Check for any loose connections on the signal line from each VR to Analog SW_IC (IC4001, IC4002, IC4003) and the main microcomputer (IC701). Signal line: AD_0-4, AD_SW_A, AD_SW_B	If any connection on the signal line is improper, resolder the parts.	—
5	Defective VRs	DJMB Assy	VRs: Check the signal level.	VRs: If the voltage of the signal from a VR (Pin 2) does not change between 3.3 V and 0 V, that VR may be defective.	Each Signal Levels
6	Defective MAIN_UCOM (IC701)	UCOM Assy	If the symptom persists after the above corrections.	Check the mounting statuses of the MAIN_UCOM (IC701) and the Analog SW_IC (IC4001, IC4002, IC4003). If they are properly mounted, then the IC701, IC4001, IC4002, or IC4003 may be defective.	Basic Operation Check of the MAIN_UCOM

[3-4] NeedleSearch error

No.	Cause/Symptom	Point to be checked	Item to be checked	How to distinguish a defective point and/or corrective action	Reference
1	CDC IC Error/ Needlepad disabled (Incl. steps 4 and 5 of [4] Error indications in the 6. Service Mode)	UCOM/CDCB Assy	Check the communication waveform between the needlepad and the MAIN_UCOM (IC701).	If the waveform is not proper, check the communication line, resistors, and capacitors. Check also that the cables between the boards and their connections are proper. If the normal status is not recovered after all above steps are performed, the CDC IC or the MAIN_UCOM (IC701) may be defective.	10.17 WAVEFORMS CDC IC control 1/2
2	Only some of the commands from the needlepad are recognized.	UCOM/CDCB Assy	Check that no foreign matter is between the Needlepad board and the cabinet.	If the Needlepad operates improperly although there is no foreign matter between the Needlepad board and the cabinet, check [2] above.	

[3-5] Abnormalities regarding the JOG dial

After the JOG Assy is disassembled then reassembled, be sure to check that the load value for the JOG dial is within the specified range. Refer to the "8.5 JOG DIAL ROTATION LOAD ADJUSTMENT".)

Turning of the JOG dial is not detected.

No.	Cause/Symptom	Point to be checked	Item to be checked	How to distinguish a defective point and/or corrective action	Reference
1	Defective JOGB photo interrupter	UCOM Assy CDJ1ssy /CDJ2 Assy LEDB Assy JOGB Assy	Check the waveforms on the JOG1_1, JOG1_2, JOG2_1, and JOG2_2 signal lines. JOG1_1: CN905-2 pin JOG1_2: CN905-3 pin JOG2_1: CN905-24 pin JOG2_2: CN905-23 pin	If any waveform cannot be recognized, connection of that signal line may be loose or the photo interrupter (PC3201) may be defective.	10.17 WAVEFORMS
2	Defective MAIN_UCOM (IC701)	UCOM Assy	If the symptom persists after the above corrections.	Check the mounting status of the MAIN_UCOM (IC701). If it is properly mounted, then the IC701 itself may be defective.	Basic Operation Check of the MAIN_UCOM

Pressing on the JOG dial cannot be detected.

No.	Cause/Symptom	Point to be checked	Item to be checked	How to distinguish a defective point and/or corrective action	Reference
3	Defective TCHB photo interrupter	UCOM Assy CDJ1 Assy /CDJ2 Assy TCHB Assy JOGB Assy	Check the signal level of the JOG_TCH1/2 (Pins 46/47 of IC701) when the JOG dial is pressed.	If the signal level of the JOG_TCH1/2 (Pins 46/47 of IC701) does not become L when the dial is pressed and H when the dial is released (not pressed,) loose connection of the signal line or a defective photo interrupter (IC3301) may be suspected.	Each Signal Levels 10.17 WAVEFORMS JOG rotation operation 58
4	Defective MAIN_UCOM (IC701)	UCOM Assy	If the symptom persists after the above corrections.	Check the mounting status of the MAIN_UCOM (IC701) and SW IC (IC702). If they are properly mounted, then the IC701 or IC702 may be defective.	—

Noise is heard when the JOG dial is turned.

No.	Cause/Symptom	Point to be checked	Item to be checked	How to distinguish a defective point and/or corrective action	Reference
5	Defective gear Defective JOG DIAL B	JOG Assy	There may be any scratches on the gear or some foreign matter between the gears.	If there are any scratches, replace the scratched gear with a new one. If there is any foreign matter, remove it then replace the gears with new ones. Gears to be replaced: Load gear, Encoder gear, JOG shaft	—
			There may be any scratches or some foreign matter on the JOG DIAL B or the Roller B Assy.	If there are any scratches, replace the scratched gear with a new one. If any foreign matter is attached, remove it.	—

The JOG dial turns too freely. (The load value for the JOG dial is outside the specified range.)

No.	Cause/Symptom	Point to be checked	Item to be checked	How to distinguish a defective point and/or corrective action	Reference
6	Improper adjustment or assembly of the JOG dial	JOG Assy	Check that the load value for the JOG dial is within the specified range, referring to "Measuring method" in "8.5 JOG Dial Rotation Load Adjustment."	If it is outside the specified range, adjust the position of the Adjust Plate to change the load value for the JOG dial, referring to "Load adjustment method" in "8.5 JOG Dial Rotation Load Adjustment."	8.5 JOG Dial Rotation Load Adjustment.
				During the above adjustment, if the upper-limit adjustment position of the Adjust Plate is reached, oil may have been spattered on the Adjust Plate. Replace the washer, load gear, and cam plate with new ones, then reassemble.	8.5 JOG Dial Rotation Load Adjustment.

Resistance to turning the JOG dial is too strong. (The load value for the JOG dial is outside the specified range.)

No.	Cause/Symptom	Point to be checked	Item to be checked	How to distinguish a defective point and/or corrective action	Reference
7	Improper adjustment of the JOG dial or defective washer, gear, or cam plate	JOG Assy	Check that the load value for the JOG dial is within the specified range, referring to "Measuring method" in "8.5 JOG Dial Rotation Load Adjustment."	If it is outside the specified range, adjust the position of the Adjust Plate to change the load value for the JOG dial, referring to "Load adjustment method" in "8.5 JOG Dial Rotation Load Adjustment."	8.5 JOG Dial Rotation Load Adjustment.
				During the above adjustment, if the lower-limit adjustment position of the Adjust Plate is reached, shavings from the worn-out washer may have increased the friction. Replace the washer, load gear, and cam plate with new ones, then reassemble.	8.5 JOG Dial Rotation Load Adjustment.

[4] USB connection

[4-1] The unit cannot be recognized by the PC when connected to the PC via USB connection.

Check the following, with a Windows/MAC PC connected via the USB port of the unit, using the supplied USB cable:

No.	Cause/Symptom	Point to be checked	Item to be checked	How to distinguish a defective point and/or corrective action	Reference
1	Failure in startup	UCOM/USBB Assy	Check the lighting statuses of the LEDs during startup.	If no LED lights, see [1] Failure in Startup.	[1] Failure in Startup
2	Defective USB_UCOM	UCOM/USBB Assy	Check the communication waveforms of the USB DP/DN lines.	If the unit is connected to a PC via the USB cable, communication will be performed through the USB DP/DN lines. If communication cannot be performed, check the USB cable, connectors, internal cables, resistors, capacitors, and filters. If nothing is wrong with them, check the items listed in "Failure in the microcomputer system" and "USB UCOM startup error."	Failure in the microcomputer system USB_UCOM startup error 10.17 WAVEFORMS USB DP/DN (1),(2) 29, 30

[5] AUDIO OUT

[5-1] No signal is output from the MASTER connectors

No.	Cause/Symptom	Point to be checked	Item to be checked	How to distinguish a defective point and/or corrective action	Reference
1	—	MASTER1/2	Identify the connector(s) that do(es) not output signals.	Check if no signal is output from both MASTER 1 and 2 or either of them. • If neither MASTER 1 nor 2 connector outputs, go to [2]. • If only the MASTER 1 connector does not output, go to [7]. • If only the MASTER 2 connector does not output, go to [8].	—
2	—	UCOM Assy	Check the audio signal, using Pins 5 and 9 of the CN501 on the UCOM Assy.	If no audio signal is output, loose connection or defective parts in the UCOM Assy may be suspected. • If an audio signal is output, go to [7] or [8]. • If an audio signal is not output, go to [3].	10.4 UCOM ASSY (3/6)
3	—	UCOM Assy	Check that an audio signal is output from DAC (IC506).	• If an audio signal is output, go to [5]. • If an audio signal is not output, go to [4].	10.4 UCOM ASSY (3/6)
4	Loose connection /defective parts	UCOM Assy	Check the digital input signals to DAC (IC506). • DAC_RST • MCLK • BCLK • LRCK • MASTER_DATA	If any of the signals is not input, check the soldering status of DAC (IC506). If the level of DAC_RST is L, check the connections of the MAIN_UCOM (IC701). If nothing is wrong with the connections, then the MAIN_UCOM (IC701) itself may be defective. If other signals are not input, check the connections of the USB_UCOM (IC202). If nothing is wrong with the connections, then the USB_UCOM (IC202) itself may be defective.	10.4 UCOM ASSY (3/6) 10.17 WAVEFORMS DAC reset cancel DAC I2S (1),(2)
5	Loose connection /defective parts	UCOM Assy	Check that the MUTE signal level is L (muting canceled).	If the MUTE signal level is L (muting canceled,) check the connections between the DAC and CN501. If nothing is wrong with the connections, soldering of the OP amp (IC501) or the OP amp itself may be defective. If the MUTE signal level is H, go to [6].	10.4 UCOM ASSY (3/6) 10.17 WAVEFORMS Output MUTE cancel 64
6	Loose connection /defective parts	UCOM Assy	Check that the A_MUTE signal level is L (muting canceled).	If the A_MUTE signal level is L (muting canceled,) check that the signal logics for Q583/Q505/Q506/Q581/Q582 are the same as those described in the schematic diagrams. If any of the signal logic is not the same, repair the defective point. If the A_MUTE signal level is not L (muting canceled,) the soldering status of the MAIN_UCOM (IC701) or the MAIN_UCOM itself may be defective.	10.4 UCOM ASSY (3/6) 10.17 WAVEFORMS Output MUTE cancel 63
7	Loose connection /defective parts	JACB Assy	Identify the point where the audio signal is interrupted on the line from CN4401 to the jacks (JA4402/JA4404).	If the audio signal is interrupted at the periphery of the OP amp (IC4403/IC4405), check the soldering status of the OP amp. If it is properly soldered, then the OP amp itself may be defective.	10.1 JACB ASSY
8	Loose connection /defective parts	JACB Assy	Identify the point where the audio signal is interrupted on the line from CN4401 to the jacks (JA4403).	If the audio signal is interrupted at the periphery of the OP amp (IC4404), check the soldering status of the OP amp. If it is properly soldered, then the OP amp itself may be defective.	10.1 JACB ASSY

[5-2] No signal is output from the HP connector

No.	Cause/Symptom	Point to be checked	Item to be checked	How to distinguish a defective point and/or corrective action	Reference
1	—	UCOM Assy	Check the audio signal, using Pins 3 and 5 of the CN301 on the UCOM Assy.	If no audio signal is output, loose connection or defective parts in the UCOM Assy may be suspected. • If an audio signal is output, go to [5]. • If an audio signal is not output, go to [2].	10.3 UCOM ASSY (2/6)
2	—	UCOM Assy	Check that the audio signal is output from DAC (IC304).	• If an audio signal is output, go to [4]. • If an audio signal is not output, go to [3].	10.3 UCOM ASSY (2/6)
3	Loose connection /defective parts	UCOM Assy	Check the digital input signals to DAC (IC304). • DAC_RST (IC304-5 pin) • HP_DATA (IC304-3 pin)	For DAC_RST, check the soldering status of DAC (IC304). If the HP_DATA signal is not input, check the connections of the USB_UCOM (IC202). If nothing is wrong with the connections, then the USB_UCOM (IC202) itself may be defective.	10.3 UCOM ASSY (2/6)
4	Loose connection /defective parts	UCOM Assy	Identify the point where the audio signal is interrupted on the line from DAC (IC304) to the CN301.	If the audio signal is interrupted at the periphery of the OP amp (IC305), soldering of the OP amp or the OP amp itself may be defective.	10.3 UCOM ASSY (2/6)
5	Loose connection /defective parts	HPJK Assy	Identify the point where the audio signal is interrupted on the line from CN4801 to the JA4801.	If the audio signal is interrupted at the periphery of the OP amp (IC4801), soldering of the OP amp or the OP amp itself may be defective.	10.14 HPJK ASSY

[6] AUDIO IN

[6-1] The input signal to AUX/MIC is not output.

No.	Cause/Symptom	Point to be checked	Item to be checked	How to distinguish a defective point and/or corrective action	Reference
0	Prior confirmation of input TRAKTOR setting AC adaptor connection	AUX/MIC	Check that the TRAKTOR input setting is properly made. Check that the AC adaptor is properly connected. (When USB-bus power is used, the signal input to AUX/MIC is not available.)		Operating Instructions
1	—	AUX/MIC	Identify the connector(s) whose input signal(s) is(are) not output.	Check if the signal can be input neither AUX nor MIC or either of them. • If neither of them can receive signals, go to [2]. • If only the AUX connector cannot receive signals, go to [7]. • If only the MIC connector cannot receive signals, go to [8].	10.3 UCOM ASSY (2/6)
2	Loose connection /defective parts	UCOM Assy	Check that the audio signal is input to the ADC (IC303).	• If an audio signal is output, go to [3]. • If an audio signal is not output, go to [5].	10.3 UCOM ASSY (2/6)
3	Loose connection /defective parts	UCOM Assy	Check the digital input signals to ADC (IC303). • ADC_RST (IC303-13 pin) • MIC_AUX_DATA (IC303-1,2 pins)	If the level of ADC_RST is L, check the connections of the MAIN_UCOM (IC701). If nothing is wrong with the connections, then the MAIN_UCOM (IC701) itself may be defective. If the MIC_AUX_DATA signal is not input, check the connections. If nothing is wrong with the connections, then the ADC (IC303) may be defective.	10.3 UCOM ASSY (2/6) 10.17 WAVEFORMS ADC reset cancel 61 ADC I2S(1),(2),(3) 73
4	Loose connection /defective parts	UCOM Assy	Check the connections of the USB_UCOM (IC202).	If nothing is wrong with the connections, then soldering of the USB_UCOM (IC202) or the USB_UCOM itself may be defective.	10.2 UCOM ASSY (1/6)
5	Loose connection /defective parts	UCOM Assy	Check that the AIN_MUTE signal level is L (muting canceled).	If it is not L (muting canceled,) check Q509. If the symptom persists, soldering of the MAIN_UCOM (IC701) or the MAIN_UCOM itself is defective.	10.4 UCOM ASSY (3/6) 10.17 WAVEFORMS Input MUTE cancel 65
6	Loose connection /defective parts	UCOM Assy	Check the connections between the SW AMP (IC301/IC302) and ADC (IC303) of the MAIN.	If the connections are properly made, soldering of the SW AMP (IC301/IC302) or the SW AMP itself is defective.	10.3 UCOM ASSY (2/6)
7	Loose connection /defective parts	JACB Assy	Check that an audio signal is input to Pins 4 and 6 of the CN4402.	If a signal is input, go to [9]. If a signal is not input, identify the point where the audio signal is interrupted on the line from the AUX terminal (JA4401) to the CN4402. If an audio signal is interrupted at the periphery of the OP amp (IC4401/IC4402), soldering of the OP amp or the OP amp itself may be defective.	10.1 JACB ASSY
8	Loose connection /defective parts	MICB Assy	Check that an audio signal is input to Pin 4 of the CN4601.	If a signal is input, go to [9]. If a signal is not input, identify the point where the audio signal is interrupted on the line from the MIC terminal (JA4601) to the CN4601. If an audio signal is interrupted at the periphery of the OP amp (IC4601), soldering of the OP amp or the OP amp itself may be defective.	10.13 MICB ASSY
9	Loose connection /defective parts	UCOM Assy	Check the connections between CN302 (AUX)/CN303 (MIC) and SW AMP (IC301/IC302).	If the connection is improperly made, correct it.	10.3 UCOM ASSY (2/6)
10	Loose connection /defective parts	UCOM Assy	Check AUX_MIC_SEL. • When AUX is selected: "H" • When MIC is selected: "L"	If it is not, check Q301. If the symptom persists, soldering of the MAIN_UCOM (IC701) or the MAIN_UCOM itself is defective.	10.3 UCOM ASSY (2/6) 10.17 WAVEFORMS MIC,AUX No. 70

[7] Basic Operation Check of the MAIN_UCOM

Note: First, check if the voltage at each section is OK.

No.	Cause/Symptom	Point to be checked	Item to be checked	How to distinguish a defective point and/or corrective action	Reference
1	GRID Operation Check (No operation with keys, VRs, sliders, or LEDs)	UCOM Assy	Check the power to and the input/output waveforms of the GRID IC (IC702)	If the waveform is not proper, check the GRID line and the parts, such as resistors and capacitors. If the output waveform is not proper, check item [2]. If nothing is wrong with the parts, the GRID IC (IC702) or the MAIN_UCOM (IC701) may be defective.	10.17 WAVEFORMS GRID control 1, GRID control 2
2		UCOM Assy Assy corresponding to each key	Check the output waveform of the GRID IC (IC702), with the FFC cable of the UCOM Assy disconnected.	If the waveform returns to normal, the PCB Assy that is connected with the UCOM Assy via the FFC cable may be defective. If the waveform does not return to normal, the GRID IC (IC702) may be defective.	10.17 WAVEFORMS GRID control 1, GRID control 2
3	KEY Buffer operation (key input disabled)	UCOM Assy	Check the power supply to the KEY Buffer ICs (IC1101 and 1102) and the input/output waveforms when a key is pressed.	If the input waveform appears but the output waveform does not when a corresponding key is pressed, the KEY Buffer ICs (IC1101 and 1102) may be defective. If the input waveform does not appear when a corresponding key is pressed, check item [4].	No operation button is effective. 10.17 WAVEFORMS KEY operation 1,2
4		UCOM Assy Assy corresponding to each key	Check the connection of the FFC cable. Check also the key input circuit of the PCB Assy connected.	If the key input circuit of the board connected is normal, the KEY Buffer ICs (IC1101 and 1102) may be defective.	10.7 UCOM ASSY (6/6)

5.3 VOLTAGE MONITORING

The MAIN_UCOM of this unit always monitors for power failure of the unit and will shut the unit off immediately after an error is detected.

● Content to be monitored

Any power failure generated inside the Power block on the UCOM_ASSY, such as voltage drop and voltage rise.
Power to be monitored: V+5_D, V+5_A, V+6, V-6, V+3R3_D, V+3R3_UCOM

● Microcomputer Detection terminal and its terminal voltage

TP103 (F-DET, TP terminal) or IC701 (MAIN_UCOM) 23-pin FAULT_DET terminal
Normal: 3.3 V
Abnormal: 0 V

● Timing of monitoring start

400 msec after the unit is turned ON

● Timing upon judgment as a failure

50 msec after an error is detected

● LED indication when an error is generated

All LEDs are unlit after an error is generated.
With other models, the Standby LED flashes to notify of a power failure. However, this does not apply to this model, because a Standby LED is not provided with it.

● Restoration method

After the unit shuts itself off because of an error, after completing diagnosis, disconnect the AC adapter and USB cable and wait at least 1 minute before turning the unit back on.

● Diagnostic procedure

- ① Disconnect the AC adapter and USB cable.
- ② Remove R147 from the UCOM Assy. Note: This step will disable power monitoring.
- ③ Reconnect the AC adapter and USB cable.
- ④ As the unit is turned on in a normal way, check each voltage in this state.
Note: Because power will be forcibly supplied even if any voltage is abnormal, if abnormal voltage continues, the defective point may produce heat, which may be dangerous. Therefore, during diagnosis, be sure to disconnect the AC adapter and USB cable several seconds after they are connected so that forcible powering will not continue.
- ⑤ If the voltage of any power IC is abnormal, the circuit that uses that power or the power IC itself may be defective.
- ⑥ Repair the defective part then check that the voltage of the repaired part becomes normal.
- ⑦ Return R147 to its original position on the UCOM Assy.
Note: This step will enable power monitoring.

5.4 HOW TO CHECK OPERATIONS USING THE TRAKTOR SOFTWARE

Operation check of the volume controls, faders, and rotary encoders must be performed with the TRAKTOR software. The TRAKTOR software is also required for checking the analog audio input/output. For operation check using the TRAKTOR software, proceed as follows:

[Preparations]

Make preparations, as indicated below, on the PC before performing an operation check of the DDJ-T1.

1. Installation of TRAKTOR PIONEER DDJ-T1 EDITION (for Windows)
2. Installation of the Driver Software (for Windows)
3. Standard use setting of TRAKTOR
4. Import tracks to TRAKTOR.

Use TRAKTOR in Demo mode ("Run Demo").

A PC with the following specifications is required for operation of TRAKTOR:

Supported operating systems		
Mac OS X	10.5	✓
	10.6	✓
Windows® 7 Home Premium/Professional/Ultimate	32-bit version	✓
	64-bit version	✓
Windows Vista® Home Basic/Home Premium/Business/Ultimate (SP1 or later)	32-bit version	✓
	64-bit version	✓
Windows® XP Home Edition/Professional (SP3 or later)	32-bit version	✓

For the latest information on the operating environment and compatibility, and to acquire the latest operating system, please visit the following Native Instruments website:
<http://www.native-instruments.com/traktor>

Minimum operating environment for TRAKTOR		
CPU	For Mac OS X	Macintosh computer equipped with an Intel® Core™ Duo processor of 1.66 GHz or greater
	For Windows® 7, Windows Vista® and Windows® XP	PC/AT compatible computer equipped with a Pentium® 4 or AMD Athlon 1.4 GHz (SSE1) or greater processor PC/AT compatible computer equipped with a 2 GHz or greater Intel® Pentium® 4 (or compatible) processor
	Required memory	1 GB or more of RAM
Hard disc	Free space of 100 MB or greater	
CD drive	Optical disc drive on which the CD-ROM can be read	
Internet connection	An Internet connection environment is required for user registration with Native Instruments, to update the TRAKTOR software, etc. Use the most recent version of the web browser.	
USB port	A USB port is required to connect the computer with this unit.	

1. Installation of TRAKTOR PIONEER DDJ-T1 EDITION (for Windows)

The compressed installer file for "TRAKTOR PIONEER DDJ-T1 EDITION" will be posted on the Niis Web site:

Folder names: Traktor Installer Win.zip (for Windows) and Traktor Installer Mac.mpkg.zip (for Macintosh)

Download the necessary zip folder from Niis then unzip it.

[Installation Procedures]

Double-click on "Traktor Setup PC.exe" (unzipped file) to display the Setup screen.

Click on [Next] to proceed.

After the Setup screen is started, click on "Next" to proceed.

When the "License Agreement" screen is displayed, check the "I accept . . ." checkbox then click on "Next."

On other screens, basically proceed to the next screen by clicking on "Next" without doing anything.

When installation is finished, click on "Finish."

The three icons are displayed on the desktop.

This completes installation of TRAKTOR PIONEER DDJ-T1 EDITION.



2. Installation of the Driver Software (for Windows)

The driver software for this product is posted on the Pioneer Web site. Download it, as required.

This driver software is an Audio Stream Input Output (ASIO) driver for Windows.

The DDJ-T1 can play audio without this driver installed if you select "PIONEER DDJ-T1(DirectSound)" for "Audio Device" in Audio Setup (mentioned later) for TRAKTOR. However, this driver provides an advantage in audio-data transmission delay (latency time) over the standard Windows audio driver. In addition, when this driver is installed, the DDJ-1 Version Display Utility is installed, as well. With this utility installed, you can confirm the versions of the driver software and DDJ-T1 firmware. (Without this utility installed, the version of the DDJ-T1 firmware cannot be confirmed.) Therefore, be sure to install this driver software.

[Installation Procedures]

Double-click on "Pioneer_DDJ_Driver_XXXXX.exe" (downloaded file).

Select "I agree" then click on "Install."


After installation is finished, click on "Close."

This completes driver software installation.


*For details on the installation method, refer to the Operating Instructions.

3. Standard use setting of TRAKTOR

Double-click on the "Traktor" icon on the desktop.




Click on "Run Demo."




Select "Pioneer" on the pulldown menu for the manufacturer and "DDJ-T1" for the model then click on "Next."



Click on "Next."



Select "No Timecode Control" then click on "Next."




Select "Yes" then click on "Next."



Click on "Finish" to complete operation of the Setup Wizard.


- A After the TRAKTOR screen is displayed, select “File” then “Preference.”



B

C


Select “Pioneer DDJ ASIO” in “Audio Setup.”



Select Input Routing then set “Input Channel D,” as shown in the figure above. Click on “Close” to exit the Preference menu.

D

E



After selecting “Output Routing,” select “Internal” then set the Monitor and Master settings, as shown in the figure above.

F



After “4D Int. Mixer” is selected for the deck layout, the screen layout will be changed to that shown in the figure above. The external inputs (AUX/MIC) will be assigned to Deck D.

Click on the triangular symbol beneath D to display the pulldown menu then select “Audio Through.” This enables control of the external inputs on Deck D.

This completes the basic settings.

The settings will be stored and continue to be effective after the next startup.


Notes:

- The usable time for the demo version is limited to 30 minutes. (After activation [license registration] of this software, the usage time limitation will be canceled.) If 30 minutes have elapsed with the demo running, terminate the demo version of TRAKTOR. You can restart and use the demo version as many times as you wish.
- On the normal version of TRAKTOR PIONEER DDJ-T1 EDITION, the external inputs (AUX/MIC) are assigned to Deck D, but on the demo version they are assigned to Deck A. This is why “Input Channel D” must be set for the Input Routing setting.

4. Import tracks to TRAKTOR

Drag and drop music files or folders containing music files into “Track Collection” of the “TREE” area of TRAKTOR, using Explorer or Finder.

[Connection Examples]



[Checking Track Playback]

1. While holding the TREE button pressed, turn the rotary selector to select a folder.
2. Turn the rotary selector without holding the TREE or FAVORITES button pressed to select a track.
3. Press the LOAD button of the deck into which you wish to load the selected track, to load it.
4. Press the PLAY/PAUSE button to start playback of the track.

[Checking Analog Audio Output]

• Via MASTER OUT

1. Adjust the audio input level, by turning the GAIN control of each deck.
2. Adjust the audio output level with the channel fader of each deck.
3. Select the decks whose audio signals are to be output with the crossfader, as indicated below.
Leftmost position: Audio from Deck A or C is to be output.
Center position: Mixed audio of all decks is to be output.
Rightmost position: Audio from Deck B or D is to be output.
4. Turn the MAIN VOL control. Audio will be output from the MASTER 1 and 2 connectors.

• Via the headphone

1. Connect the headphones to the PHONES connector.
2. Press the headphones CUE button of the deck you wish to monitor.
3. Turn the HEADPHONES MIX control, as indicated below.
Turning counterclockwise: The volume from the deck whose headphones CUE button is pressed will be relatively increased.
Center position: The volume from the deck whose headphones CUE button is pressed and that via the MASTER OUT 1 and 2 connectors will become the same.
Turning clockwise: The volume via the MASTER OUT 1 and 2 connectors will be relatively increased.
4. Turn the HEADPHONES VOL control to output audio from the deck whose headphones CUE button is pressed.

[Checking Analog Audio Input]

1. Connect an external device or a microphone to the AUX IN or MIC connector, respectively.
2. With TRAKTOR, assign the audio of the external device to a desired deck.
3. Click on the ▼ symbol beneath the assigned deck to display the pulldown menu then select "Audio Through."
4. On the TRAKTOR screen and via the audio output, check if the connected audio signal is input.

Note:

With the initial setting of TRAKTOR Pioneer DDJ-T1 EDITION, the audio signal from an external device connected via the AUX IN or MIC connector is input to Deck D.
However, with the initial setting of Demo mode, which is used for servicing, it is assigned to Deck A.

A [Operation Check of Each Operating Element]

Operation check of the following operating elements cannot be performed in Service mode.

Connect the unit with a PC then check that the TRACTOR software operates properly, using each operating element.

Operating Element	DECK	MIXER	FX
Volume	FILTER CONTROL	GAIN CONTROL A to D EQ HI A to D EQ MID A to D MAIN VOL HEADPHONE MIX HEADPHONE VOL	DRY/WET CONTROL EFFECT 1 to 3 CONTROL
Fader	TEMPO FADER A to D CROSS FADER		
Rotary encoder	AUTO LOOP CONTROL		

B

C

6. SERVICE MODE

6.1 OUTLINE OF SERVICE MODE

The following test modes are prepared for this machine.

- D ① Check of operator input and a display function.
It is the mode which checks each input and display function of buttons, JOG dials, encoders, slide switches and needle pads.
- ② Quality judging of JOG dial load.
It is the mode which judges the quality of the load when rotating JOG dial.
- ③ Error display.
Error detection and its display method of a device are shown.
- ④ Firmware update.
Explanation of the method of firmware update.
Refer to the "8.3 UPDATING OF THE FIRMWARE."
- E

F

6.2 DETAILS ON SERVICE MODE

[1] Check of operator input and a display function.

When it spends a power supply while pushing a FUNCTION button and a IN (IN ADJUST) button of left deck simultaneously, enters into this mode. (Please continue pushing until an opening display is completed.)

In this mode, the input of each buttons, JOGs, slide switches, needle pads are correct, and it can check that a display can also be performed correctly.

In addition, display of a button is turned on only while pushing the button.

In addition, neither volume nor an encoder can be checked only by the controller.

Please check the display which connects with TRAKTOR and corresponds in the usual mode.

Part	Operator	Device	LED Display
	DECK A		DECK A
	DECK C		DECK C
	DECK B		DECK B
	DECK D		DECK D
FX1/FX2	ADVANCED/CHAINED	BUTTON	ADVANCED→CHAINDE→OFF→ (Cyclic)
	DRY/WET ON/OFF	BUTTON	DRY/WET
	DRY/WET CONTROL	ROTARY VOLUME	*
	SELECT/BACK 1	BUTTON	EFFECT 1
	SELECT/BACK 2	BUTTON	EFFECT 2
	SELECT/BACK 3	BUTTON	EFFECT 3
	EFFECT 1 ON/OFF	BUTTON	EFFECT 1
	EFFECT 2 ON/OFF	BUTTON	EFFECT 2
	EFFECT 3 ON/OFF	BUTTON	EFFECT 3
	EFFECT 1 CONTROL	ROTARY VOLUME	*
	EFFECT 2 CONTROL	ROTARY VOLUME	*
	EFFECT 3 CONTROL	ROTARY VOLUME	*
DECK A/C DECK B/D	FUNCTION	BUTTON	FUNCTION
	NEEDLE SEARCH	PAD	JOG LED ROTATION
	FILTER ON/OFF	BUTTON	FILTER
	FILTER CONTROL	ROTARY VOLUME	*
	IN	BUTTON	IN
	OUT	BUTTON	OUT
	ACTIVE	BUTTON	ACTIVE
	MOVE/CUE	BUTTON	MOVE→CUE→OFF→ (Cyclic)
	MODE/DELETE	BUTTON	MODE/DELETE
	HOT CUE 1/SIZE←	BUTTON	HOT CUE 1/SIZE←
	HOT CUE 2/SIZE→	BUTTON	HOT CUE 2/SIZE→
	HOT CUE 3/BWD	BUTTON	HOT CUE 3/BWD
	HOT CUE 4/FWD	BUTTON	HOT CUE 4/FWD
	AUTO LOOP CONTROL	ENCODER	*
	AUTO LOOP PUSH	ENCODER	IN
	SHIFT	BUTTON	OUT
	KEY LOCK	BUTTON	KEY LOCK
	TEMPO RANGE	BUTTON	FILTER
	CUE	BUTTON	CUE
	PLAY/PAUSE	BUTTON	PLAY/PAUSE
	TEMPO	SLIDE VOLUME	*
	JOG ROTATION	DIAL	JOG LED ROTATION
	JOG TOUCH	DIAL	JOG LED ALL ON
MIXER	LOAD A	BUTTON	FX 1 A
	LOAD B	BUTTON	FX 1 B
	LOAD C	BUTTON	FX 1 C
	LOAD D	BUTTON	FX 1 D
	TREE	BUTTON	HEADPHONE CUE A
	FAVORITES/REC	BUTTON	HEADPHONE CUE B

A

Part	Operator	Device	LED Display
MIXER	BROWSE CONTROL	ENCODER	JOG LED ROTATION A/B
	BROWSE PUSH	ENCODER	ALL LED BRIGHT→DARK→OFF→ (Cyclic)
	GAIN CONTROL A	ROTARY VOLUME	*
	GAIN CONTROL B	ROTARY VOLUME	*
	GAIN CONTROL C	ROTARY VOLUME	*
	GAIN CONTROL D	ROTARY VOLUME	*
	EQ HI A	ROTARY VOLUME	*
	EQ HI B	ROTARY VOLUME	*
	EQ HI C	ROTARY VOLUME	*
	EQ HI D	ROTARY VOLUME	*
	EQ MID A	ROTARY VOLUME	*
	EQ MID B	ROTARY VOLUME	*
	EQ MID C	ROTARY VOLUME	*
	EQ MID D	ROTARY VOLUME	*
	EQ LOW A	ROTARY VOLUME	*
	EQ LOW B	ROTARY VOLUME	*
	EQ LOW C	ROTARY VOLUME	*
	EQ LOW D	ROTARY VOLUME	*
	MAIN VOL	ROTARY VOLUME	*
	HEADPHONE MIX	ROTARY VOLUME	*
	HEADPHONE VOL	ROTARY VOLUME	*
	FX 1 A	BUTTON	FX 1 A
	FX 1 B	BUTTON	FX 1 B
	FX 1 C	BUTTON	FX 1 C
	FX 1 D	BUTTON	FX 1 D
	FX 2 A	BUTTON	FX 2 A
	FX 2 B	BUTTON	FX 2 B
	FX 2 C	BUTTON	FX 2 C
	FX 2 D	BUTTON	FX 2 D
	HEADPHONE CUE A	BUTTON	HEADPHONE CUE A
	HEADPHONE CUE B	BUTTON	HEADPHONE CUE B
	HEADPHONE CUE C	BUTTON	HEADPHONE CUE C
	HEADPHONE CUE D	BUTTON	HEADPHONE CUE D
	SYNC A	BUTTON	SYNC A
	SYNC B	BUTTON	SYNC B
	SYNC C	BUTTON	SYNC C
	SYNC D	BUTTON	SYNC D
	MASTER A	BUTTON	MASTER A
	MASTER B	BUTTON	MASTER B
	MASTER C	BUTTON	MASTER C
	MASTER D	BUTTON	MASTER D
	FADER A	SLIDE VOLUME	*
	FADER B	SLIDE VOLUME	*
	FADER C	SLIDE VOLUME	*
	FADER D	SLIDE VOLUME	*
	CH FADER START A	SLIDE SWITCH	FX 2 A
	CH FADER START B	SLIDE SWITCH	FX 2 B
	CH FADER START C	SLIDE SWITCH	FX 2 C
	CH FADER START D	SLIDE SWITCH	FX 2 D
	CROSS FADER	SLIDE VOLUME	*

Note: It cannot check only by the controller. Please connect with TRAKTOR, use it and check a related display in the usual mode.

F

[2] Quality judging of JOG dial load.

When it spends a power supply while pushing a FUNCTION button and a ACTIVE button of left deck simultaneously, enters into this mode. (Please continue pushing until an opening display is completed.)

It is the mode which judges the load (light/heavy) when rotating JOG dial .

It goes into this mode, when JOG dial was turned with sufficient vigor, the following top speed and rotation fall time are measured and top speed becomes more than 7 times, rotation fall time is evaluated, and it judges whether it goes into the range of regular, and a result is displayed on LED.

The rotation direction, right rotation and left rotation, either is OK.

TOP SPEED : Top speed (let the time of turning one rotation in 1.8 second be 1 time speed)

ROTATION FALL TIME : Time taken for rotation to fall to 1.5 times speed from 3 times speed

It is necessary to make it rotate top speed to 7.0 or more times to measure the rotation fall time required.

Not more than 7.0 times faster, it is made to blink 3 times and warns of JOG illuminations.

4 times displays the number of times of measurement on L ED.

The 1st end HOT CUE 1 (SIZE <-) lighting

The 2nd end HOT CUE 2 (SIZE ->) lighting

The 3rd end HOT CUE 3 (BWD <-) lighting

The 4th end HOT CUE 4 (FWD ->) lighting

After measurement finishes 4 times, an average is taken, and rotation fall time judges whether it goes into the range of regular, and displays a result on LED.

Regulation value is 100 ± 40 [msec].

OK LOOP ACTIVE lighting

NG (Light) LOOP OUT lighting

NG (Heavy) LOOP IN lighting

Measurement is performed although the number of times is not displayed 5th henceforth.

Each time, an average is taken and a result is displayed on LED.

[3] Error display

When abnormalities are detected during the time of carrying out power supply ON, or operation, it displays by LED.

	Abnormalities	LED/Display	Note
1	Abnormalities of a power supply	All LED put out the light.	When abnormalities are detected by the state of DC power supply and USB bus power supply, it will be in this state. Opening display is not performed, either, when abnormalities are detected at the time of starting.
2	Abnormalities in FLASH ROM of MAIN microcomputer	Left deck/IN (IN ADJUST) Lighting	When update goes wrong and FLASH-ROM is not written correctly, it will be in this state. Even in this case, update can be performed succeedingly. However, "3" is displayed while it can be communicating neither with the case where USB cable is not connected, nor USB controller, correctly also at this time.
3	Abnormalities of USB controller	Left deck/OUT (OUT ADJUST) Blinks in a cycle of 0.5 seconds.	When the time when it cannot communicate with USB controller correctly although USB cable is connected at the time of starting, and controllers are abnormalities, it will be in this state.
4	Abnormalities of the needle pad controller of the left deck	Right deck/IN (IN ADJUST) Blinks in a cycle of 0.5 seconds.	When the time when it cannot communicate with a needle pad controller correctly, and controllers are abnormalities, it will be in this state. However, this display is performed at the time of "[1] Check of operator input and a display function." It will be used in usual use, with a needle pad not operating.
5	Abnormalities of the needle pad controller of the right deck	Right deck/OUT (OUT ADJUST) Blinks in a cycle of 0.5 seconds.	

[4] Firmware update

Refer to the "8.3 UPDATING OF THE FIRMWARE."


6.3 ABOUT THE DEVICE

Device Name	Function	Part No.	Ref No.	Assy
MAIN UCOM	Main microcomputer, All operating elements/LED control	DYW1801 PEG850A8-K	IC701	UCOM Assy
USB UCOM	USB control, audio control	TUSB3200A	IC202	UCOM Assy
CDC	Needle search control	AD7147ACPZ500RL7	IC2001 IC2101	CDCB 1 Assy CDCB 2 Assy


7. DISASSEMBLY

Note: Even if the unit shown in the photos and illustrations in this manual may differ from your product, the procedures described here are common.


Knobs and Volumes Location




A Dial Knob S (DAA1264) ×2




B Slide Knob (Metal) (DNK5876) ×2




C Rotary Knob L (Gray) (DAA1267) ×10




D Dial Knob (DAA1259) ×1



E Rotary Knob S (Black) (DAA1262) ×7



F Rotary Knob L (Black) (DAA1261) ×12




G Slider Knob 1 (DAC2684) ×5 + Slider Knob 2 (DAC2685) ×5 + Slider Knob Stopper (DNK5888) ×5

Slider Knob 2

Slider Knob 1

Slider Knob Stopper





A Disassembly

[1] Chassis Section

[1-1] Volumes and knobs

- (1) Remove the two dial knobs S.
- (2) Remove the 10 rotary knobs L (Gray).
- (3) Remove the 12 rotary knobs L (Black).
- (4) Remove the one dial knob.
- (5) Remove the seven rotary knobs S (Black).
- (6) Remove the two slide knobs (Metal).
- (7) Remove the five slider knobs 2, five slider knobs 1, five slider knob stoppers. (See below.)

The reference of the direction






• Disassembly of the slider knob

The new slider knob adopted by this product is designed so that it is not pulled out easily. Therefore, the method for removing the slider knob is different from the conventional method; it can only be pulled out after slider knob 2 is removed.

- ① Find the side on which the line reaches the bottom.


- ② Insert a pair of tweezers etc. beneath the line then push the slider knob 2 upward. To protect the panel from being scratched, use protective material.

- ③ Remove the slider knob 2.




*: During reassembly, fully push down Slider knob 2 until it is dented into Slider knob 1.

- ④ Remove the slider knob 1.




- ⑤ Remove the slider knob stopper.



[1-2] Chassis section



- (1) Reverse the product.
- (2) Remove the four screws. (PMB30P080FTB)
- (3) Remove the two feet.



- (4) Remove the six screws. (BPZ30P080FNI)
- (5) Remove the 14 screws. (BBZ30P060FTC)
- (6) Remove the chassis A.

Screw tightening order

The other screws are random order.





A [2] Mixer and Fader Section

[2-1] UCOM Assy

- (1) Release the clumper.
- (2) Disconnect the seven flexible cables and eight connectors. (CN4403, CN301 - CN303, CN501, CN901 - CN906, CN1001 - CN1004)
- (3) Remove the four screws. (BBZ30P060FTC)
- (4) Remove the UCOM Assy.


Screw tightening order

B The other screws are random order.




[2-2] Mixer and fader section

- (1) Remove the two screws. (BPZ30P080FNI)
- (2) Remove the FFC guard M.
- (3) Remove the 20 screws. (BPZ30P080FNI)
- (4) Remove the three cord clumpers.
- (5) Remove the mixer and fader section.




[2-3] CRFD, CHFD and DJMB Assemblies

- (1) Remove the four Caps/FDR.
- (2) Remove the 19 nut and 19 washers.
- (3) Remove the eight screws. (PMH20P040FTC)
- (4) Remove the two screws. (IMZ30P040FTC)
- (5) Remove the VR stay L.



Clamper styling



A [3] Deck Section

[3-1] MICB, HPJK, USBB and JACB Assemblies

Release the jumper wires, as required.

• MICB Assy

- (1) Remove the two screws. (BPZ30P080FNI)
- (2) Remove the MICB Assy.
- (3) Remove the slide SW packing (B).

• HPJK Assy


- (4) Remove the two screws. (BPZ30P080FNI)
- (5) Remove the HPJK Assy.

• USBB Assy

- (6) Remove the one screw and remove the cord hook. (BBZ30P060FTB)
- (7) Remove the one screw. (BBZ30P060FTB)
- (8) Remove the one screw. (DBA1340)
- (9) Remove the two screws. (BPZ30P080FNI)
- (10) Remove the USBB Assy.


• JACB Assy

- (11) Remove the two nuts. (NKX2FTC)
- (12) Remove the phone spacer.
- (13) Remove the one screw. (BBZ30P060FTB)
- (14) Remove the two screws. (BPZ30P080FTB)
- (15) Remove the two screws. (BPZ30P080FNI)
- (16) Remove the JACB Assy.



• Bottom view

D Screw tightening order




[3-2] CDJ1B and CDJ2B Assy

• CDJ1B Assy

- (1) Disconnect the three flexible cables and one connector.
(CN902, CN905, CN906, CN6001)
- (2) Remove the three screws. (BPZ30P080FNI)
- (3) Remove the FFC guard 1.
- (4) Remove the 24 screws. (BPZ30P080FNI)
- (5) Remove the CDJ1B Assy.


• CDJ2B Assy

- (6) Disconnect the three flexible cables and one connector.
(CN901, CN903, CN904, CN6001)
- (7) Remove the three screws. (BPZ30P080FNI)
- (8) Remove the FFC guard 1.
- (9) Remove the 24 screws. (BPZ30P080FNI)
- (10) Remove the two cord clampers.
- (11) Remove the CDJ2B Assy.




Screw tightening order

The other screws are random order.



• Stay

- (1) Remove the five nuts and five washers.
- (2) Remove the two VR stays S.
- (3) Remove the rear stay L and R.



A [3-3] CDCB 1, CDCB 2 Assy and JOG section

• CDCB 1 Assy

- (1) Remove the three screws and remove the three CDC stoppers. (BPZ30P080FNI)
- (2) Remove the CDCB 1 Assy.

• CDCB 2 Assy

- (3) Remove the three screws and remove the three CDC stoppers. (BPZ30P080FNI)
- (4) Remove the CDCB 2 Assy.

• JOG section



- (5) Remove the eight screws. (BPZ30P100FTB)
- (6) Remove the two JOG sections.

Note:

Either the CDCB 1 Assy or CDCB 2 Assy is assembled here. The CDCB 1 Assy and CDCB 2 Assy are interchangeably used and handled similarly in their production management.


Screw tightening order

The other screws are random order.



D [3-4] LEDB Assy

- (1) Disconnect the one connector. (CN6002)
- (2) Disconnect the one connector. (CN3301)
- (3) Remove the LEDB Assy.



8. EACH SETTING AND ADJUSTMENT

8.1 NECESSARY ITEMS TO BE NOTED

Before repairing, be sure to check the version of the firmware, and if it is not the latest one, update to the latest version. Perform the each item when the following parts are replaced.



- UCOM ASSY (MAIN UCOM: IC701) → • Confirmation of the version of the firmware
• Updating to the latest version of the firmware
- EEPROM on the UCOM ASSY: IC201 → • Copying the program for the USB controller
• Updating to the latest version of the firmware
- Component parts of the JOG dial section → • JOG dial rotation load adjustment

8.2 CONFIRMATION OF THE VERSIONS OF THE FIRMWARE

Confirmation of the firmware version can be performed on a PC connected with this product. How to confirm differs depending on the type of OS used.

1. Confirmation of the Versions of the DDJ-T1 Firmware (for Windows)

To confirm the versions of the driver software and DDJ-T1 firmware, with the DDJ-T1 connected with a PC, click on "Start" then select "All Programs," "Pioneer," "DDJ," then "DDJ Version Display Utility."




2. Confirmation of the Version of the DDJ-T1 Firmware (for Macintosh)

As the standard audio driver for the Macintosh OS is to be used, neither driver software nor a version display utility for Macintosh are provided.


For confirmation of the version of the DDJ-T1 firmware, proceed as follows:

How to Confirm the Version of the DDJ-T1 Firmware on Mac OS X

1. Select "Application" then "Utility," then start "System Profiler."



2. Click on "USB" then "DDJ-T1." The version of the DDJ-T1 firmware is displayed in the version field.



8.3 UPDATING OF THE FIRMWARE

- A
- The devices which update a firmware are MAIN microcomputer and USB controller.
USB connection of the controller is made at PC/MAC, and it updates by performing the update program of exclusive use.

File name


■


WindowsDDJT1_xxx.exeNote: xxx is version number. If it is Ver1.00, it is DDJT1_100.exe/DDJT1_100.dmg.


MacDDJT1_xxx.dmgNote: In the case of Mac, since an icon will appear if dmg file is double-clicked, it is performed.


CAUTION: When you update, please terminate all DJ applications, such as TRAKTOR.

Example (Windows)

- B
- 
- Starting/Selection of a language
(English is chosen.)

- C
- 
- Check of a version

- D
- 
- Progress display

- E
- 
- End.
Controller is re-started automatically.

Recovery when failing

- F
- When update goes wrong, USB cable is extracted on the way or the power supply has been turned off,
usual DJ operation becomes impossible after that.
In this case, the recovery mode which only updates operates (State of 2 or 3 in "[3] Error display").
Update program can be used like usual also at this time.

8.4 COPYING THE PROGRAM FOR THE USB CONTROLLER

Copy the program for the USB controller according to the following procedure after the EEPROM (IC201) on the UCOM Assy is replaced: A

- ① Turn the DDJ-T1 off then connect this unit with a PC, via USB.
- ② Set the POWER switch to ON while simultaneously holding the FUNCTION and LOOP OUT buttons on the left deck pressed.
- ③ Copying of the program is successfully completed if the ADVANCED LED on the left deck lights then goes dark in about 3 seconds. (The ADVANCED LED flashes if nothing is connected to the USB port of this unit or copying failed for some reason.) ■

After copying is completed, turn the unit off then back on again.

B

C

D

E

F

8.5 JOG DIAL ROTATION LOAD ADJUSTMENT

1. How to Enter JOG Load Measurement Mode

Set the POWER switch to ON while holding the FUNCTION and ACTIVE buttons on the left panel pressed.
=> JOG Load Measurement mode is entered when the KEY LOCK LEDs on the left and right panels light.

2. Measurement Method

Rotate the JOG dial clockwise swiftly.*

*If the rotation speed is high enough (successful measurement)

When the 1st measurement is finished, HOT CUE 1 (SIZE ←) lights.

When the 2nd measurement is finished, HOT CUE 2 (SIZE →) lights.

When the 3rd measurement is finished, HOT CUE 3 (BWD ←) lights.

When the 4th measurement is finished, HOT CUE 4 (FWD →) lights.

If the rotation speed is not high enough (measurement fails)

The JOG dial flashes 3 times, after which it goes dark.

Perform measurements four times, each time after confirming that the previous measurement was successfully finished, which is shown as mentioned above.

3. Judgment

After four measurements are successfully finished, the level of the measured JOG load value with regard to the reference value will be displayed.

Reference value: 100 ± 40 (msec)

OK: LOOP ACTIVE lit

NG (measured value is smaller than the reference value): LOOP OUT lit

NG (measured value is larger than the reference value): LOOP IN lit

4. Adjustment When the JOG Load Value is Outside the Specified Range

When LOOP OUT is lit:

Because the load value is too small, detach and shift the Adjust Plate toward the + direction then secure it.

When LOOP IN is lit:

Because the load value is too large, detach and shift the Adjust Plate toward the – direction then secure it.

After adjustment of the Adjust Plate location, repeat Steps 1 to 3 until the measurement result becomes OK.




Fig. 1

■

5

■

6

■

7

■

8

■

A

■

B

■

C

■

D

■

E

■

F

■

5

■

6

■

7

■


8

■

9. EXPLODED VIEWS AND PARTS LIST

- NOTES:
- Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
 - The $\triangle$ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
 - Screws adjacent to ∇ mark on product are used for disassembly.
 - For the applying amount of lubricants or glue, follow the instructions in this manual. (In the case of no amount instructions, apply as you think it appropriate.)

9.1 PACKING SECTION



(1) PACKING SECTION PARTS LIST

Mark No.	Description	Part No.	Mark No.	Description	Part No.
⚠ 1	AC Adapter	DWR1491	15	Operating Instructions	See Contrast table (2)
⚠ 2	Power Plug (EU)	See Contrast table (2)	16	Operating Instructions	See Contrast table (2)
⚠ 3	Power Plug (UK)	See Contrast table (2)	NSP 17	Warranty Card	See Contrast table (2)
⚠ 4	Power Plug (US)	See Contrast table (2)	NSP 18	License Key Label AS	DXA2242
⚠ 5	Power Plug (AUS)	See Contrast table (2)	19	Caution Card/ADP	DRM1345
⚠ 6	Power Plug (KOR)	See Contrast table (2)	20	Caution Card/CU	See Contrast table (2)
⚠ 7	Power Plug (CHI)	See Contrast table (2)	21	Caution Card/PLG	See Contrast table (2)
8	USB Cable	DDE1140	22	•••••	
9	TRAKTOR Pioneer DDJ-T1 EDITION software CD-ROM	DXX2665	23	Recycle Label (M)	See Contrast table (2)
10	Driver software CD-ROM	DXX2666	NSP 24	Polyethylene Bag	AHG7117
11	Operating Instructions	See Contrast table (2)	25	Vinyl Bag	See Contrast table (2)
12	Operating Instructions	See Contrast table (2)	26	Packing Sheet	RHC1023
13	Operating Instructions	See Contrast table (2)	27	Plastic Handle (PE)	VEC2292
14	Operating Instructions	See Contrast table (2)	28	Spacer (PE)	VEC2293
			29	Accessory Pad	DHA1875
			30	Pad A	DHA1871
			31	Pad B	DHA1872
			32	Packing Case	See Contrast table (2)


(2) CONTRAST TABLE

DDJ-T1/SVYXJ8, UXJCB, FLPXJ, KXJ5 and AXJ5 are constructed the same except for the following:

Mark	No.	Symbol and Description	DDJ-T1/SVYXJ8	DDJ-T1/UXJCB	DDJ-T1/FLPXJ	DDJ-T1/KXJ5	DDJ-T1/AXJ5
⚠	2	Power Plug (EU)	DKX1048	Not used	DKX1048	Not used	Not used
⚠	3	Power Plug (UK)	DKX1049	Not used	DKX1049	Not used	Not used
⚠	4	Power Plug (US)	Not used	DKX1047	DKX1047	Not used	Not used
⚠	5	Power Plug (AUS)	Not used	Not used	DKX1050	Not used	Not used
⚠	6	Power Plug (KOR)	Not used	Not used	DKX1051	DKX1051	Not used
⚠	7	Power Plug (CHI)	Not used	Not used	Not used	Not used	DKX1052
	11	Operating Instructions (En/Fr/De)	DRB1537	Not used	Not used	Not used	Not used
	12	Operating Instructions (It/Nl/Es/Ru)	DRB1563	Not used	Not used	Not used	Not used
	13	Operating Instructions (En)	Not used	DRB1536	Not used	Not used	Not used
	14	Operating Instructions (En/Es/Zhtw)	Not used	Not used	DRB1539	Not used	Not used
	15	Operating Instructions (Ko)	Not used	Not used	Not used	DRB1541	Not used
	16	Operating Instructions (Zhcn/En)	Not used	Not used	Not used	Not used	DRB1540
NSP	17	Warranty Card	ARY7107	Not used	Not used	Not used	Not used
	20	Caution Card/CU	Not used	DRM1353	Not used	Not used	Not used
	21	Caution Card/PLG	Not used	Not used	DRM1346	Not used	Not used
	23	Recycle Label (M)	Not used	Not used	Not used	DRW2307	Not used
	25	Vinyl Bag	Not used	Not used	Z21-013	Not used	Not used
	32	Packing Case	DHG3055	DHG3056	DHG3057	DHG2987	DHG2985

1 2 3 4

9.2 EXTERIOR SECTION



(1) EXTERIOR SECTION SECTION PARTS LIST

Mark	No.	Description	Part No.	
	1	Dial Knob	DAA1259	
	2	Rotary Knob L (Black)	DAA1261	A
	3	Rotary Knob S (Black)	DAA1262	
	4	Dial Knob S	DAA1264	
	5	Rotary Knob L (Gray)	DAA1267	
	6	Slider Knob 1	DAC2684	
	7	Slider Knob 2	DAC2685	
	8	Slide Sheet	DAH2836	
	9	Rubber Foot (H6)	DEB1996	
	10	CDC Sheet	DEC3354	
	11	Chassis	See Contrast table (2)	B
	12	Foot	DNK5864	
	13	Slide Knob (Metal)	DNK5876	
	14	Slider Knob Stopper	DNK5888	
	15	Rubber Foot	VEB1349	
	16	•••••		
	17	•••••		
	18	Screw	PMB30P080FTB	
	19	Screw	BBZ30P060FTC	
	20	Screw	BPZ30P080FNI	C


(2) CONTRAST TABLE

DDJ-T1/SVYXJ8, UXJCB, FLPXJ, KXJ5 and AXJ5 are constructed the same except for the following:

Mark	No.	Symbol and Description	DDJ-T1/SVYXJ8	DDJ-T1/UXJCB	DDJ-T1/FLPXJ	DDJ-T1/KXJ5	DDJ-T1/AXJ5
	11	Chassis	DNA1419	DNA1414	DNA1415	DNA1416	DNA1416

9.3 PCB LAYER SECTION

A • Bottom view



PCB LAYER SECTION PARTS LIST

Mark No.	Description	Part No.	Mark No.	Description	Part No.	
1	UCOM Assy	DWX3209	46	•••••		
2	CDCB 1 Assy	DWX3210	47	•••••		A
3	CDCB 2 Assy	DWX3224	48	Screw	PMH20P040FTC	
4	CDJ1B Assy	DWS1430	49	Screw	IMZ30P040FTC	
5	LEDB Assy	DWS1434	50	•••••		
6	CDJ2B Assy	DWS1431	51	Screw	BBZ30P060FTC	
7	CHFD Assy	DWX3212	52	Screw	BPZ30P080FNI	
8	CRFD Assy	DWX3213	53	Screw	BPZ30P100FTB	
9	MICB Assy	DWX3215	54	Screw (M3x5)	DBA1340	
10	HPJK Assy	DWX3216	55	Screw	BBZ30P060FTB	
11	DJMB Assy	DWX3211	56	Screw	BPZ30P080FTB	B
12	JACB Assy	DWX3214				
13	USBB Assy	DWX3222				
14	25P FFC	DDD1543				
15	19P FFC	DDD1545				
16	8P FFC	DDD1547				
17	15P FFC	DDD1548				
18	FFC/20P	DDD1561				
19	Crimp Connector	DKP3894				
20	Crimp Connector	DKP3897				C
21	Crimp Connector	DKP3900				
22	Crimp Connector	DKP3920				
23	Crimp Connector	DKP3921				
24	Crimp Connector	DKP3922				
25	Crimp Connector	DKP3923				
26	Connector Assy	PF03PP-C06				
27	Clamper	CNV3477				
28	Cap/FDR	DAC2771				
29	Slide SW Packing (B)	DEC2590				D
30	Phone Spacer	DEC2914				
31	FFC Guard 1	DEC3362				
32	FFC Guard M	DEC3364				
33	•••••					
34	Front Stay L	DNH2959				
35	Front Stay R	DNH2960				
36	Rear Stay L	DNH2961				
37	Rear Stay R	DNH2962				
38	VR Stay L	DNH2963				E
39	VR Stay S	DNH2964				
40	CDC Stopper	DNK5863				
41	Cord Hook	DNK5928				
42	Cord Clamper (Steel)	RNH-184				
43	Binder	ZCA-SKB90BK				
44	Nut M12	DBN1018				
45	Nut	NKX2FTC				F

A • Bottom view


B

C

D

E

F



(1) BUTTON LAYER SECTION PARTS LIST

Mark No.	Description	Part No.	
1	Button L (Opal)	DAC2657	
2	Cue Button R	DAC2658	A
3	Load Button A	DAC2659	
4	Load Button B	DAC2660	
5	Shift Button	DAC2661	
6	Button S (Opal)	DAC2662 *	
7	Button S (Black)	DAC2663 *	
8	FX Assign Button	DAC2664	
9	Deck Select Button A	DAC2665	
10	Deck Select Button B	DAC2666	
11	FX Select Button 1	DAC2667	B
12	FX Select Button 2	DAC2668	
13	FX Select Button 3	DAC2669	
14	Loop Button	DAC2671	
15	Deck Select Button C	DAC2677	
16	Deck Select Button D	DAC2678	
17	Filter Button	DAC2680	
18	Active Button	DAC2681	
19	Play Button	DAC2682	
20	Button S (Gray)	DAC2683 *	C
21	Load Button C	DAC2687	
22	Load Button D	DAC2688	
23	Fader Packing	DEC3355	
24	Lens	DNK5862	
25	1..Control PNL Assy	See Contrast table (2)	
26	2..Control Panel	DNK5859	
27	2..Front Panel	DNK5869	
28	2..Rear Panel	See Contrast table (2)	D

*: Note that there are two types of button S, as some of them have to be split into two when used.

(2) CONTRAST TABLE

DDJ-T1/SVYXJ8, UXJCB, FLPXJ, KXJ5 and AXJ5 are constructed the same except for the following:

Mark	No.	Symbol and Description	DDJ-T1/SVYXJ8	DDJ-T1/UXJCB	DDJ-T1/FLPXJ	DDJ-T1/KXJ5	DDJ-T1/AXJ5
	25	Control PNL Assy	DXB2096	DXB2106	DXB2107	DXB2110	DXB2108
	28	Rear Panel	DNK5870	DNK5878	DNK5879	DNK5882	DNK5880

1 2 3 4

9.5 JOG SECTION

A



B

C

D

E

F




JOG SECTION PARTS LIST

Mark No.	Description	Part No.	
1	JOGB Assy	DWS1432	
2	TCHB Assy	DWS1433	A
3	JOG Plate	DAH2837	
4	Arm Spring	DBH1612	
5	Lever Spring	DBH1626	
6	Load Spring	DBH1676	
7	Encoder Plate	DEC2889	
8	Lever Cushion (A)	DEC3001	
9	Lever Cushion (B)	DEC3002	
10	JOG Lever	DNK4763	
11	JOG Shaft	DNK4934	B
12	Encoder Arm	DNK4936	
13	Encoder Gear	DNK4937	
14	Load Smoother	DNK4939	
15	Adjust Plate	DNK4943	
16	Load Gear	DNK5178	
17	Lever Holder	DNK5206	
18	JOG Dial A	DNK5860	
19	JOG Dial B	DNK5861	
20	Ring Lens	DNK5945	C
21	Roller B Assy	DXB1877	
22	JOG Holder Assy	DXB2002	
23	Binder	ZCA-SKB90BK	
24	Washer	WA41D070D025	
25	Washer	WT32D080D050	
26			
27			
28	Screw	BPZ20P060FTC	
29	Screw (FE)	DBA1265	D




4


B



Power Fault Detection




5V→3.3V Typ 113mA Max 118mA Needle Search
JOG_PHOTO
VOL Slider




5V→-6V
Typ 70mA
Max 129mA


5V→+6V Typ 116mA
Max 201mA Audio Power




6V→5V Typ 46mA
Max 72mA DAC,ADC Power



5V→3.3V Typ 63.5mA USB3.3V Power



B1/6 UCOM ASSY (DWX3209)



*CAPACITORS
Indicated in Capacity/Voltage(V)
unless otherwise noted. u : μ F, p : pF

*RESISTORS
Indicated in
Q : $\pm$ 5% tolerance
unless otherwise noted. k : k Ω , M : M Ω .

NOTES

NM is No Mount

RS1/10SR***J

RS1/16SS***J

RS1/18SQ***J

RS1/10SR***D

or RS1/16SS***D

CKSRVB***K

CCSRCH***J

CKSRVB***K

CCSRCH***J

△



DDJ-T1

A



69

△

△



△

△

△

△

B3/6 UCOM ASSY (DWX3209)

A



B

C


D

E


F



10.5 UCOM ASSY (4/6)




B 4/6



4





4:3G;4:6A;4:7H;4A
CDC

B 4/6


B 5/6 UCOM ASSY (DWX3209)

*CAPACITORS
Indicated in Capacity(V)
unless otherwise noted. u : μ F, p : pF


*RESISTORS
Indicated in Ω , $\pm 5\%$ tolerance
unless otherwise noted. k : k Ω , M : M Ω .

NOTES	
NM	is No Mount
SS	RS1/10SR***J
SS	RS1/16SS***J
SS	RS1/8SQ***J
SS	RS1/10SR***D, or RS1/16SS***D
CH	CKSRYB***K
CH	CCSRCH***J
SS	CKSSYB***K
SS	CCSSCH***J

PLAYER1-1 (LEFT1)



PLAYER1-2 (LEFT2)



DDJ-T1

B 5/6

4



A



*CAPACITORS
Indicated in Capacity/Voltage(V)
unless otherwise noted. u : μ F, p : pF



*RESISTORS
Indicated in Ω , $\pm 5\%$ tolerance
unless otherwise noted. k : k Ω , M : M Ω .



△

The CDCB 1 Assy and CDCB 2 Assy are interchangeably used and handled similarly in their production management.

F



A



C


D



F

10.9 LEDB ASSY


R6001 ~ R6048 : 180 Ω
D6001 ~ D6024 : SLI-343U3R(HJKL)-TS
Q6005 ~ Q6008 : LSA1576UB(QR)-TLB
Q6009 ~ Q6014 : 2SC4154(EFG)-TLB



A




H CDJ1B ASSY (DWS1430)



Q3038～Q:

*RESISTORS
Indicated in Ω , $\pm 5\%$ tolerance
unless otherwise noted. k : k Ω , M : M Ω .



NOTES	
NM	is No Mount
	RS1/10SR***J
 SQ	RS1/8SQ***J
	CKSRYB***K
	CEJO***

CDJ2B ASSY (DWS1431)




Q3538~

*CAPACITORS
Indicated in Capacity/Voltage(V)
unless otherwise noted. u : μ F, p : pF

*RESISTORS
Indicated in Ω , $\pm 5\%$ tolerance
unless otherwise noted. k : k Ω , M : M Ω .

NOTES

NM is No Mount
RS1/10SR***J
SQ RS1/8SQ***J
CKSRYB***K
CEJO***



A

B

C

D

E

F

△

Q4017～Q4019 : 2SC4154(EFG)-TLB




A




10.13 MICB ASSY

K MICB ASSY (DWX3215)



*C,
*RI



*CAPACITORS
Indicated in Capacity/Voltage(V)
unless otherwise noted. u : μ F , p : pF


*RESISTORS
Indicated in Ω , $\pm$ 5% tolerance
unless otherwise noted. k : k Ω , M : M Ω .

NOTES

NM	is No Mount
	RS1/10SR***J
	RS1/10SR****D
	CKSRYB***K
	CCSRCH***J
	CFTLA***J
	CEJQ***

10.14 CHFD, CRFD and HPJK ASSYS

CHFD ASSY (DWX3212)



*CAPACITORS
Indicated in Capacity/Voltage(V)
unless otherwise noted. u : μF , p : pF

*RESISTORS
Indicated in Ω , $\pm 5\%$ tolerance
unless otherwise noted. k : k Ω , M : M Ω .

A




C

□

F



10.15 USBB ASSY



A

V+5_D



C



F

F

10.16 VOLTAGES

A • Power supply system





Name	Normal Voltage Level	Relations Assy
V+USB5	4.75 to 5.25 V	USBB Assy
V+ADP5	4.75 to 5.25 V	USBB Assy
V+5_USB	4.75 to 5.25 V	USBB Assy UCOM Assy
V+3R3_USB	3.2 to 3.4 V	UCOM Assy
V+4R7_STB	5.15 to 4.5 V	USBB Assy UCOM Assy
V+3R3_UCOM	3.2 to 3.4 V	UCOM Assy
V+5_D	4.5 to 5.15 V	USBB Assy UCOM Assy CDJ1/2B Assy LEDB Assy DJMB Assy
V+3R3_D	3.2 to 3.4 V	UCOM Assy CDJ1/2B Assy CDCB1/2 Assy LEDB Assy TCHB Assy JOGB Assy
V+3R3_AD	3.2 to 3.4 V	UCOM Assy CDJ1/2B Assy DJMB Assy CHFD Assy CRFD Assy
V+6	5.8 to 6.2 V	UCOM Assy MICB Assy JACB Assy HPJK Assy
V-6	-5.8 to -6.2 V	UCOM Assy MICB Assy JACB Assy HPJK Assy
V+5_A	4.9 to 5.1 V	UCOM Assy

Measuring equipment: Oscilloscope (Tektronix TDS3054)
Probe (Tektronix P6139A/P5050; Input Capacitance: 8 to 11.1 [pF], Input Impedance: 10 M[Ω])




The display voltage value of the oscilloscope is a reference value. The voltage value changes by the filter of the oscilloscope and a difference of the measuring function and a probe.

NOTE: The following waveforms were measured at the point of the corresponding balloon number in the schematic diagram.

USBB ASSY



UCOM ASSY




BUCOM ASSY

MAIN UCOM start up

Mode: POWER ON


- ①⑥ TP1043/CN1004 - pin 4 (V+4R7_STB)
V: 5.0 V/div. H: 4 mS/div.
- ①⑦ TP102/IC105 - pin 5 (V+3R3_UCOM)
V: 5.0 V/div. H: 4 mS/div.
- ①⑧ IC106 - pin 1 (MAIN_RST)
V: 5.0 V/div. H: 4 mS/div.
- ①⑨ IC701 - pin 20 (XIN)
V: 5.0 V/div. H: 4 mS/div.



AUDIO power supply

Mode: POWER ON


- ②⑦ CN1004 - pin 1 (V+5_D)
V: 5.0 V/div. H: 20 mS/div.
- ②① CN501 - pin 2 (V+6)
V: 5.0 V/div. H: 20 mS/div.
- ②② CN501 - pin 3 (V-6)
V: 5.0 V/div. H: 20 mS/div.
- ②③ TP104/IC103 - pin 5 (V+5_A)
V: 5.0 V/div. H: 20 mS/div.



DIGITAL power supply

Mode: POWER ON


- ②⑦ CN1004 - pin 1 (V+5_D)
V: 2.0 V/div. H: 40 mS/div.
- ②④ TP106/IC102 - pin 5 (V+3R3_D)
V: 2.0 V/div. H: 40 mS/div.



Abnormal voltage detection

Mode: POWER ON


- ①⑦ TP102/IC105 - pin 5 (V+3R3_UCOM)
V: 5.0 V/div. H: 40 mS/div.
- ②④ TP106/IC102 - pin 5 (V+3R3_D)
V: 5.0 V/div. H: 40 mS/div.
- ②⑦ CN1004 - pin 1 (V+5_D)
V: 5.0 V/div. H: 40 mS/div.
- ②⑤ TP103/IC701 - pin 23 (FAULT_DET)
V: 2.0 V/div. H: 40 mS/div.



Abnormal voltage detection

Mode: POWER ON, TRIGGER: CH1, 2 V


- ②① CN501 - pin 2 (V+6)
V: 5.0 V/div. H: 40 mS/div.
- ②③ TP104/IC103 - pin 5 (V+5_A)
V: 2.0 V/div. H: 40 mS/div.
- ②⑤ TP103/IC701 - pin 23 (FAULT_DET)
V: 2.0 V/div. H: 40 mS/div.



USB UCOM I2S

Mode: IDLING


- ②⑥ IC202 - pin 44 (MCLK)
V: 2.0 V/div. H: 20 μ S/div.
- ②⑦ IC202 - pin 34 (BCLK)
V: 5.0 V/div. H: 20 μ S/div.
- ②⑧ IC202 - pin 35 (LRCK)
V: 5.0 V/div. H: 20 μ S/div.



USB DP/DN (1)

Mode: IDLING


- ②⑨ IC202 - pin 7 (USB_DP)
V: 5.0 V/div. H: 400 μ S/div.
- ③⑦ IC202 - pin 8 (USB_DN)
V: 5.0 V/div. H: 400 μ S/div.



USB DP/DN (2)

Mode: IDLING


- ②⑨ IC202 - pin 7 (USB_DP)
V: 5.0 V/div. H: 400 nS/div.
- ③⑦ IC202 - pin 8 (USB_DN)
V: 5.0 V/div. H: 400 nS/div.



GRID control 1

Mode: IDLING

- ③① TP1010/CN1001 - pin 16 (GRID0)
V: 5.0 V/div. H: 200 μ S/div.
- ③② TP1008/CN1001 - pin 18 (GRID1)
V: 5.0 V/div. H: 200 μ S/div.
- ③③ TP1005/CN1001 - pin 22 (GRID2)
V: 5.0 V/div. H: 200 μ S/div.
- ③④ TP1003/CN1001 - pin 24 (GRID3)
V: 5.0 V/div. H: 200 μ S/div.




BUCOM ASSY

GRID control 2

Mode: IDLING


- ③⑤ TP1009/CN1001 - pin 17 (GRID4)
V: 5.0 V/div. H: 200 μ S/div.
- ③⑥ TP1007/CN1001 - pin 19 (GRID5)
V: 5.0 V/div. H: 200 μ S/div.
- ③⑦ TP1006/CN1001 - pin 21 (GRID6)
V: 5.0 V/div. H: 200 μ S/div.
- ③⑧ TP1004/CN1001 - pin 23 (GRID7)
V: 5.0 V/div. H: 200 μ S/div.



CDC IC control 1

Mode: IDLING


- ③⑨ CN902 - pin 1 (CDC_INT1)
V: 2.0 V/div. H: 2.0 mS/div.
- ④⑩ CN902 - pin 2 (CDC_CS1)
V: 2.0 V/div. H: 2.0 mS/div.
- ④⑪ CN902 - pin 4 (CDC_SCLK)
V: 2.0 V/div. H: 2.0 mS/div.



CDC IC control 2

Mode: IDLING


- ④① CN902 - pin 4 (CDC_SCLK)
V: 2.0 V/div. H: 4.0 μ S/div.
- ④② CN902 - pin 6 (CDC_DSI)
V: 2.0 V/div. H: 4.0 μ S/div.
- ④③ CN902 - pin 7 (CDC_DSO)
V: 2.0 V/div. H: 4.0 μ S/div.



KEY operation 1 (PLAYER1 PLAY)

Mode: PLAY KEY


- ③⑦ TP1006/CN1001 - pin 21 (GRID6)
V: 2.0 V/div. H: 200 μ S/div.
- ④④ TP988/CN908 - pin 11 (KEY_IN4)
V: 2.0 V/div. H: 200 μ S/div.
- ④⑤ IC1101 - pin 14 (KEY4)
V: 2.0 V/div. H: 200 μ S/div.



KEY operation 2 (PLAYER1 SHIFT)

Mode: SHIFT KEY


- ③② TP1008/CN1001 - pin 18 (GRID1)
V: 2.0 V/div. H: 400 μ S/div.
- ④④ TP988/CN906 - pin 11 (KEY_IN4)
V: 2.0 V/div. H: 400 μ S/div.
- ④⑤ IC1101 - pin 14 (KEY4)
V: 2.0 V/div. H: 400 μ S/div.



Volume operation 1 (PLAYER1 DRY/WET)

Mode: PLAYER1 DRY/WET VOL operation


- ④⑥ TP954/CN905 - pin 13 (V+3R3_AD)
V: 2.0 V/div. H: 200 mS/div.
- ④⑦ TP959/CN905 - pin 21 (AD_DRYWET1)
V: 1.0 V/div. H: 200 mS/div.



Volume operation 2 (MIXER GAIN A)(1)

Mode: MIXER GAIN A VOL operation


- ④⑥ TP954/CN905 - pin 13 (V+3R3_AD)
V: 2.0 V/div. H: 2.0 mS/div.
- ④⑧ TP1018/CN1001 - pin 2 (AD_SW_A)
V: 2.0 V/div. H: 2.0 mS/div.
- ④⑨ TP1019/CN1001 - pin 1 (AD_SW_B)
V: 2.0 V/div. H: 2.0 mS/div.
- ⑤⑩ TP1024/CN1002 - pin 5 (AD_0)
V: 2.0 V/div. H: 2.0 mS/div.



Volume operation 2 (MIXER GAIN A)(2)

Mode: MIXER GAIN A VOL operation


- ④⑥ TP954/CN905 - pin 13 (V+3R3_AD)
V: 2.0 V/div. H: 100 mS/div.
- ④⑧ TP1018/CN1001 - pin 2 (AD_SW_A)
V: 2.0 V/div. H: 100 mS/div.
- ④⑨ TP1019/CN1001 - pin 1 (AD_SW_B)
V: 2.0 V/div. H: 100 mS/div.
- ⑤⑩ TP1024/CN1002 - pin 5 (AD_0)
V: 2.0 V/div. H: 100 mS/div.



CH FADER operation (CH A)

Mode: MIXER CH A FADER operation

- ④⑥ TP954/CN905 - pin 13 (V+3R3_AD)
V: 2.0 V/div. H: 40 mS/div.
- ⑤① TP1031/CN1003 - pin 14 (AD_FADER_A)
V: 2.0 V/div. H: 40 mS/div.




BUCOM ASSY

CROSS FADER operation

Mode: MIXER CROSS FADER operation


- (46) TP954/CN905 - pin 13 (V+3R3_AD)
V: 2.0 V/div. H: 40 mS/div.
- (52) TP1035/CN1003 - pin 9 (AD_CROSSF)
V: 2.0 V/div. H: 40 mS/div.



PITCH FADER operation (PLAYER1)

Mode: PLAYER1 PITCH FADER operation


- (46) TP954/CN905 - pin 13 (V+3R3_AD)
V: 2.0 V/div. H: 40 mS/div.
- (53) TP964/CN905 - pin 14 (AD_PITCH2_1)
V: 1.0 V/div. H: 40 mS/div.
- (54) TP965/CN905 - pin 12 (AD_PITCH2_2)
V: 2.0 V/div. H: 40 mS/div.



ROTARY ENCODER(PLAYER) operation

Mode: PLAYER1 AUTO LOOP operation


- (55) TP957/CN905 - pin 25 (L_ENC1_1)
V: 2.0 V/div. H: 20 mS/div.
- (56) TP958/CN905 - pin 24 (L_ENC1_2)
V: 2.0 V/div. H: 20 mS/div.



JOG rotation operation

Mode: JOG TOUCH & Release operation


- (57) TP106/IC102 - pin 5 (V+3R3_D)
V: 2.0 V/div. H: 40 mS/div.
- (58) TP973/CN906 - pin 1 (JOG_TCH1)
V: 1.0 V/div. H: 40 mS/div.



ADC reset cancel

Mode: POWER ON


- (23) TP104/IC103 - pin 5 (V+5_A)
V: 5.0 V/div. H: 100 μS/div.
- (60) IC303 - pin 7 (VD)
V: 5.0 V/div. H: 100 μS/div.
- (26) IC202 - pin 44 (MCLK)
V: 2.0 V/div. H: 100 μS/div.
- (61) IC701 - pin 98 (ADC_RST)
V: 5.0 V/div. H: 100 μS/div.



DAC reset cancel

Mode: POWER ON


- (23) TP104/IC103 - pin 5 (V+5_A)
V: 5.0 V/div. H: 40 nS/div.
- (26) IC202 - pin 44 (MCLK)
V: 5.0 V/div. H: 40 nS/div.
- (62) IC701 - pin 99 (DAC_RST)
V: 2.0 V/div. H: 40 nS/div.



Output MUTE cancel

Mode: POWER ON


- (63) IC701 - pin 70 (A_MUTE)
V: 2.0 V/div. H: 2.0 S/div.
- (3) CN2501 - pin 4 (V+4R7_STB)
V: 2.0 V/div. H: 2.0 S/div.
- (64) TP505/CN501 - pin 1 (MUTE)
V: 2.0 V/div. H: 2.0 S/div.



Input MUTE cancel

Mode: POWER ON


- (65) IC701 - pin 76 (AIN_MUTE)
V: 2.0 V/div. H: 40 mS/div.
- (23) TP104/CN103 - pin 5 (V+5_A)
V: 2.0 V/div. H: 40 mS/div.
- (66) R523/R528 (ADC_MUTE)
V: 2.0 V/div. H: 40 mS/div.



MIC

Mode: AUX 1 kHz input, at SW MIC selection

- (67) TP317/CN303 - pin 4 (MIC_IN)
V: 1.0 V/div. H: 1.0 mS/div.
- (68) IC303 - pin 2 (AINL)
V: 5.0 V/div. H: 1.0 mS/div.
- (69) TP316/CN303 - pin 6 (MIC_AUX_DET)
V: 2.0 V/div. H: 1.0 mS/div.
- (70) IC701 - pin 71 (AUX_MIC_SEL)
V: 2.0 V/div. H: 1.0 mS/div.



B UCOM ASSY

AUX


Mode: AUX 1 kHz input, at SW AUX selection

⑦① TP311/CN302 - pin 4 (AUX_R_IN)
V: 500 mV/div. H: 1.0 mS/div.

⑦② IC303 - pin 1 (AINR)
V: 5.0 V/div. H: 1.0 mS/div.

⑥⑨ TP316/CN303 - pin 6 (MIC_AUX_DET)
V: 2.0 V/div. H: 1.0 mS/div.

⑦⑦ IC701 - pin 71 (AUX_MIC_SEL)
V: 2.0 V/div. H: 1.0 mS/div.




ADC I2S (1)

Mode: AUX 1 kHz input, at SW AUX selection

⑥⑧ IC303 - pin 2 (AINL)
V: 2.0 V/div. H: 1.0 μ S/div.

②⑦ IC202 - pin 34 (BCLK)
V: 2.0 V/div. H: 1.0 μ S/div.

⑦③ TP302/IC202 - pin 39 (MIC_AUX_DATA)
V: 2.0 V/div. H: 1.0 μ S/div.




ADC I2S (2)

Mode: AUX 1 kHz input, at SW AUX selection

⑥⑧ IC303 - pin 2 (AINL)
V: 2.0 V/div. H: 400 μ S/div.

②⑦ IC202 - pin 34 (BCLK)
V: 2.0 V/div. H: 400 μ S/div.

⑦③ TP302/IC202 - pin 39 (MIC_AUX_DATA)
V: 2.0 V/div. H: 400 μ S/div.




DAC I2S (1)

Mode: 1 kHz playback, at MASTER output

⑦④ IC506 - pin 11 (AOCTL)
V: 2.0 V/div. H: 1.0 μ S/div.

②⑦ IC202 - pin 34 (BCLK)
V: 2.0 V/div. H: 1.0 μ S/div.

⑦⑤ IC202 - pin 36 (MASTER_DATA)
V: 2.0 V/div. H: 1.0 μ S/div.




DAC I2S (2)

Mode: 1 kHz playback, at MASTER output

⑦④ IC506 - pin 11 (AOCTL)
V: 2.0 V/div. H: 400 μ S/div.

②⑦ IC202 - pin 34 (BCLK)
V: 2.0 V/div. H: 400 μ S/div.

⑦⑤ IC202 - pin 36 (MASTER_DATA)
V: 2.0 V/div. H: 400 μ S/div.




MASTER OUT

Mode: 1 kHz playback, at MASTER output

⑦⑥ TP503/CN501 - pin 5 (MASTER_L)
V: 2.0 V/div. H: 400 μ S/div.

⑦⑦ TP508/CN501 - pin 9 (MASTER_R)
V: 2.0 V/div. H: 400 μ S/div.




HEADPHONE

Mode: 1 kHz playback, at HEADPHONE output

⑦⑧ TP306/CN301 - pin 3 (HP_L)
V: 2.0 V/div. H: 400 μ S/div.

⑦⑨ TP305/CN301 - pin 5 (HP_R)
V: 2.0 V/div. H: 400 μ S/div.




DAC control

Mode: POWER ON

⑧① IC304 - pin 6 (DAC_CS1)
V: 2.0 V/div. H: 10 μ S/div.

⑧① IC304 - pin 7 (DAC_CCLK)
V: 2.0 V/div. H: 10 μ S/div.

⑧② IC304 - pin 8 (DAC_CDTI)
V: 2.0 V/div. H: 10 μ S/div.



A JACB ASSY


MASTER OUT1

Mode: 1 kHz playback, at MASTER output

⑧③ TP503/CN501 - pin 5 (MASTER_L)
V: 5.0 V/div. H: 400 μ S/div.

⑧④ JA4402 - pin 3 (MASTER1_L+)
V: 5.0 V/div. H: 400 μ S/div.


⑧⑤ JA4402 - pin 2 (MASTER1_L-)
V: 5.0 V/div. H: 400 μ S/div.



11.2 UCOM ASSY

SIDE A

B UCOM ASSY



B

A



CN4201

B

103

- | | |
|--------|--------|
| Q102 | IC104 |
| IC101 | |
| | IC102 |
| Q101 | Q103 |
| | Q106 |
| Q581 | Q104 |
| Q582 | Q105 |
| Q506 | IC103 |
| Q505 | |
| Q508 | |
| Q583 | IC506 |
| IC501 | IC203 |
| | IC201 |
| Q507 | |
| | IC105 |
| | Q202 |
| | Q203 |
| | Q201 |
| Q303 | IC205 |
| IC303 | IC304 |
| Q302 | |
| | |
| | IC106 |
| | IC1101 |
| IC702 | |
| | |
| | IC701 |
| IC1102 | |
| | Q701 |
| | |
| IC301 | |
| Q503 | |
| Q504 | IC303 |
| IC302 | |
| | |
| Q501 | Q301 |
| Q502 | Q509 |

F

SIDE B

A

B


C

D

E

F

B UCOM ASSY



B

SIDE B

A


B

C

D

E

F



11.3 CDCB 1 ASSY



SIDE A

Either the CDCB 1 Assy or CDCB 2 Assy is assembled here.
The CDCB 1 Assy and CDCB 2 Assy are interchangeably used and handled similarly in their production management.

SIDE B

C CDCB 1 ASSY

C CDCB 1 ASSY





11.4 CDCB 2 ASSY

SIDE A

Either the CDCB 1 Assy or CDCB 2 Assy is assembled here.
The CDCB 1 Assy and CDCB 2 Assy are interchangeably used and handled similarly in their production management.

SIDE B

A



B

C

D


F

F

11.5 TCHB, JOGB and LEDB ASSYS

SIDE A

G LEDB ASSY





E G

SIDE A

A

SY



B

C

D

E

F

F G

SIDE B

A

B

C



D

E

F



G LEDB ASSY



F JOGB ASSY

(DNP2629-A)
or
(DNP2630-A)


SIDE B

A

Q6014
Q6012

Q6008


Q6013
Q6007
Q6003
Q6004



B

C

D



(DNP2629-A)
or
(DNP2630-A)

E TCHB ASSY

E


F

E G

11.6 CDJ1B ASSY

SIDE A

CDJ1B ASSY





SIDE B

A



B

C

D


F

F



11.7 CDJ2B ASSY

SIDE A



SIDE B

CDJ2B ASSY

CN3502

Q3540

Q3544
Q3546
Q3530
Q3532

Q3533


Q3545
Q3547
Q3531
Q3539

Q3542

Q3541

Q3538

Q3543



SIDE B

A



B

C


D

E

F



(DNP2630-A)

SIDE A

1


2

3

4

SIDE B

J DJMB ASSY



DDJ-T1

J


122

1

2

3

4



IC4002
IC4003
IC4001
Q4018
Q4019

Q4002 Q4006 Q4007
Q4008 Q4003
Q4004 Q4010 Q4005 Q4014
Q4016 Q4011 Q4013 Q4015
Q4012 Q4001
Q4017 Q4009

(DNP2635-C)

DDJ-T1

SIDE A

DWX3213-
CRFD /2


VR430T

LM

DDJ-T1

VR4202

VR4204



SIDE B

A

B



C

D

E

F

L CHFD ASSY

**M CRFD ASSY**

SIDE B

A



B

C

D

E

F



SIDE A

SIDE A

A


B

C

D


E

F



SIDE B

SIDE B



SIDE A**SIDE B****SIDE B**

O

DDJ-T1

12. PCB PARTS LIST

- NOTES: ● Parts marked by “NSP” are generally unavailable because they are not in our Master Spare Parts List.
 ● The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
 ● When ordering resistors, first convert resistance values into code form as shown in the following examples.

Ex.1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47 k ohm (tolerance is shown by J = 5%, and K = 10%).

560 Ω $\rightarrow$ 56×10^1 $\rightarrow$ 561.....RD1/4PU $\begin{bmatrix} 5 & 6 & 1 \end{bmatrix}$ J
 47 k Ω $\rightarrow$ 47×10^3 $\rightarrow$ 473.....RD1/4PU $\begin{bmatrix} 4 & 7 & 3 \end{bmatrix}$ J
 0.5 Ω $\rightarrow$ R50.....RN2H $\begin{bmatrix} R & 5 & 0 \end{bmatrix}$ K
 1 Ω $\rightarrow$ 1R0.....RSIP $\begin{bmatrix} 1 & R & 0 \end{bmatrix}$ K

Ex.2 When there are 3 effective digits (such as in high precision metal film resistors).

5.62 k Ω $\rightarrow$ 562×10^1 $\rightarrow$ 5621.....RN1/4PC $\begin{bmatrix} 5 & 6 & 2 & 1 \end{bmatrix}$ F

- Meaning of the figures and others in the parentheses in the parts list.

Example) IC 301 is on the point (face A, 91 of x-axis, and 111 of y-axis) of the corresponding PC board.

IC 301 (A, 91, 111) IC NJM2068V

Mark No. Description Part No.

LIST OF ASSEMBLIES

NSP	1..MAIN ASSY	DWM2421
	2..UCOM ASSY	DWX3209
	2..CDCB 1 ASSY	DWX3210
	2..CDCB 2 ASSY	DWX3224
NSP	1..CDJ1 ASSY	DWM2422
	2..CDJ1B ASSY	DWS1430
	2..JOGB ASSY	DWS1432
	2..TCHB ASSY	DWS1433
	2..LEDB ASSY	DWS1434
NSP	1..CDJ2 ASSY	DWM2423
	2..CDJ2B ASSY	DWS1431
	2..JOGB ASSY	DWS1432
	2..TCHB ASSY	DWS1433
	2..LEDB ASSY	DWS1434
NSP	1..DJM1 ASSY	DWM2424
	2..CHFD ASSY	DWX3212
	2..CRFD ASSY	DWX3213
	2..MICB ASSY	DWX3215
	2..HPJK ASSY	DWX3216
NSP	1..DJM2 ASSY	DWM2426
	2..DJMB ASSY	DWX3211
	2..JACB ASSY	DWX3214
	2..USB ASSY	DWX3222

* Either the CDCB 1 Assy or CDCB 2 Assy is assembled here. The CDCB 1 Assy and CDCB 2 Assy are interchangeably used and handled similarly in their production management.

Mark No. Description Part No.

A JACB ASSY SEMICONDUCTORS

IC 4401,4402	NJM4565MD
IC 4403-4405	NJM4580MD
Q 4401-4412	INC2002AC1

MISCELLANEOUS

L 4401-4404 INDUCTOR	CTF1378
JA 4401,4403 PIN JACK (2P)	AKB7181
JA 4402,4404 HEADPHONE JACK	DKN1622

Mark No. Description Part No.

KN 4401 SCREW PLATE	VNE1948
VR 4401 POTENTIOMETER	DCS1115
CN 4401 L-PLUG (9P)	KM200NA9L
CN 4402 L-PLUG (7P)	KM200NA7L
CN 4403 CONNECTOR	B2PS-VH
VA 4401-4404 VARISTORS	EZJZ1V27ORM

RESISTORS

R 4401,4402	RS1/10SR1102D
R 4403,4404	RS1/10SR1001D
R 4405-4408	RS1/10SR1202D
R 4409,4429-4432,4464	RS1/10SR5600D
R 4410,4463,4467,4474	RS1/10SR4301D
R 4413-4420	RS1/10SR4701D
R 4421,4423,4425,4427	RS1/10SR1002D
R 4422,4424,4426,4428	RS1/10SR9101D
R 4445,4447,4453,4455	RS1/10SR1200D
R 4468,4473	RS1/10SR5600D

Other Resistors

RS1/10SR###J

CAPACITORS

C 4401	CCSRCH102J50
C 4402-4405,4422-4429	CCSRCH101J50
C 4406,4408,4420,4421	CEJQ101M16
C 4407,4410,4416,4418	CEJQ470M16
C 4412-4415	CEJQ100M35

C 4430,4431,4438-4443	CEJQ101M16
C 4444-4449	DCE1016
C 4457,4460,4462	CKSRYB103K50
C 4458	CKSRYB104K16

B UCOM ASSY SEMICONDUCTORS

Δ IC 101	BD9851EFV
Δ IC 102,104,105	S-1200B33-M5
Δ IC 103	S-1200B50-M5
IC 106	S-80927CNMC-G8X
IC 201	S-24CS64A0I

IC 202	TUSB3200ACPAH
IC 203	TC7SB66FU
IC 205	S-80942CNMC-G9C
IC 301,302	NJM2121MD
IC 303	AK5358AET

Mark No. Description**Part No.****Mark No. Description****Part No.**

A

IC 304,506 AK4387ET
 IC 305 NJM4565MD
 IC 501 NJM4580MD
 IC 701 PEG850A8-K
 IC 702 TC74VHC238FK



IC 1101,1102 TC74LCX541FK
 Q 101 RTQ025P02
 Q 102 RTQ045N03
 Q 103,106 LSA1576UB
 Q 104,203,301 RT1N241M

B

Q 105,202,501,581 LSC4081UB
 Q 201 RT3N22M
 Q 302,303,503,504 INC2002AC1
 Q 502,505,582 LTC124EUB
 Q 506,509,583 LTA124EUB

C

Q 507,508 INC2002AC1
 Q 701 RT3P22M
 D 101,102 RB160L-40
 D 103-105 1SS352
 D 301,303 1SS302

D 302 RKZ3.3KG(B2)
 D 304,305,501,502 HSU119
 D 701,702 RB160M-30

C

MISCELLANEOUS

L 101,102 POWER INDUCTOR ATH7047
 L 201,202 CHIP BEEDS FILTER BTX1042
 L 203 COIL ATH7015
 L 206 CHIP BEEDS FILTER BTX1042
 L 501-504 CHIP INDUCTOR (10U) DTL1105

L 701-704 CHIP BEEDS FILTER BTX1042
 KN 1003,1004 EARTH METAL FITTING VNF1109
 KN 1006 EARTH METAL FITTING VNF1109
 X 201 CRYSTAL RESONATOR (6.0 MHz) DSS1136
 X 701 CERAMIC OSCILLATOR CSS1616

D

CN 301,501 CONNECTOR AKM1295
 CN 302 CONNECTOR AKM1293
 CN 303 CONNECTOR AKM1292
 CN 901,902 CONNECTOR AKM1294
 CN 903,905,1001 25P CONNECTOR VKN1429

CN 904,906 20P CONNECTOR VKN1424
 CN 1002 8P CONNECTOR VKN1300
 CN 1003 15P CONNECTOR VKN1307
 CN 1004 CONNECTOR AKM1299
 JP 501 CRIMP CONNECTOR DKP3926

E

RESISTORS

R 101 RS1/10SR4701D
 R 102 RS1/10SR1202D
 R 103,114 RS1/10SR222J
 R 104 RS1/10SR1003D
 R 105,106 RS1/10SR1502D

R 107,115 RS1/10SR153J
 R 108,116,131 RS1/10SR333J
 R 109 RS1/10SR1002D
 R 110,146 RS1/10SR562J
 R 111 RS1/10SR1802D

F

R 112 RS1/10SR8202D
 R 113 RS1/10SR8201D
 R 120,147,230 RS1/8SQ0R0J
 R 121,122,128 RS1/10SR103J

R 123,125,326

RS1/10SR223J

R 124 RS1/10SR203J
 R 126 RS1/10SR273J
 R 127,130,139,325 RS1/10SR473J
 R 132-134,137,144 RS1/10SR103J
 R 135,141,143 RS1/10SR0R0J

R 136 RS1/10SR101J
 R 138 RS1/10SR220J
 R 145 RS1/10SR332J
 R 212 RS1/16SS2701F
 R 215 RS1/16SS3900F

R 255,306,524,525 RS1/10SR103J
 R 256,257 RS1/10SR221J
 R 301-304,340,720 RS1/10SR0R0J
 R 305,329 RS1/10SR470J
 R 309,319 RS1/10SR471J

R 310 RAB4CQ103J
 R 311,512 RS1/10SR100J
 R 313,314 RS1/16SS8201D
 R 315,316 RS1/16SS6801D
 R 317,318 RS1/16SS1601D

R 322-324,346,347 RS1/10SR104J
 R 336,337 RS1/16SS1001D
 R 338,339,501,502 RS1/16SS4701D
 R 341,342 RS1/10SR2401D
 R 343,344 RS1/10SR8200D

R 505-508 RS1/16SS3301D
 R 509,510 RS1/16SS3901D
 R 523,526-528 RS1/10SR102J
 R 718,719,752,765 RAB4CQ220J
 R 721 RAB4CQ470J

R 722-724,737,738 RAB4CQ221J
 R 741 RAB4CQ221J
 R 824 RAB4CQ220J
 R 1109-1111 RAB4CQ101J
 Other Resistors RS1/16SS###J

CAPACITORS

C 101 CCSRCH561J50
 C 102 CKSRYB332K50
 C 103 CCSRCH820J50
 C 104,113,149 CCG1205
 C 105,110-112,114 CKSRYB105K10

C 106,115,203,204 DCH1201
 C 108 CKSRYB222K50
 C 109 CCSRCH121J50
 C 117,141,144,335 CKSRYB103K50
 C 119,121,122,125 CKSRYB104K16

C 120,123,124,137 CKSRYB105K10
 C 126,227 CKSSYB222K50
 C 130-135,140,143 CKSRYB104K16
 C 139 CCSRCH221J50
 C 142,503,506 CCSRCH471J50

C 145,336,520 CCSRCH102J50
 C 147,225,312,313 CKSRYB104K16
 C 150 CKSRYB105K10
 C 205,206,211,213 CKSSYB104K16
 C 207,208,212 CCSSCH471J50

C 210,702,713,750 DCH1201
 C 214,228,229,714 CCSSCH220J50

5	6	7	8
Mark No. Description	Part No.	Mark No. Description	Part No.
C 215,219,221,226	CKSSYB104K16	SEMICONDUCTORS	
C 216,318,716	CKSSYB103K16	IC 3301	GP1S094HCZ0F
C 217,218	CCSSCH470J50	Q 3301	LSC4081UB
		D 3301	HSU119
C 220,715,718,719	CCSSCH101J50		
C 222,707,708,711	CCSSCH102J50	MISCELLANEOUS	
C 223,224	CCSSCH270J50	CN 3301 3PJUMPER CONNECTOR	52151-0310
C 231,232,701,703	CKSSYB104K16		
C 305-307,316,326	CEVW100M16	RESISTORS	
		All Resistors	RS1/10SR###J
C 308-311,328,329	CEVW470M16		
C 315,317,319,513	CKSRYB104K16	CAPACITORS	
C 320,321,504,505	CCSSCH681J50	C 3301	CKSRYB104K16
C 322,323	CCSRCH391J50		
C 327,331	CEVW100M16		
C 330	CEVW470M6R3	F JOGB ASSY	
C 332-334,337,338	CEVW470M16	MISCELLANEOUS	
C 340,342	CCSSCH821J50	CN 3201 CONNECTOR ASS'Y	PF04PG-B05
C 341,514	CEVW470M16		
C 509,510,554	CCH1565	RESISTORS	
		All Resistors	RS1/10SR###J
C 511,516,517,1019	CEVW101M16		
C 515,717,724	CKSRYB104K16	MISCELLANEOUS	
C 519	CKSRYB103K50	PC 3201 PHOTO INTERRUPTER	SEDS-7573
C 704,712,721,749	CKSSYB104K16		
C 705,706	CKSSYB471K50	CAPACITORS	
C 709,710	CCSSCH100D50	C 3201	CKSQYB225K10
C 720	CCSSCH220J50	C 3202,3203	CKSRYB103K50
C 725-748,760,1020	CKSSYB103K16		
C 752,759,762	CCSSCH102J50		
C 755,923-930	DCH1201	G LEDB ASSY	
C 756,1101,1110	CKSSYB104K16	SEMICONDUCTORS	
C 1013-1018	DCH1201	Q 6001-6004	RT1N241M
C 1021	CKSSYB103K16	Q 6005-6008	LSA1576UB
		Q 6009-6014	2SC4154-11
		D 6001-6024	SLI-343U3R(HJKL)
C CDCB 1 ASSY			
SEMICONDUCTORS		MISCELLANEOUS	
IC 2001	AD7147ACPZ500RL7	CN 6001 19P CONNECTOR	VKN1279
		CN 6002 L-PLUG (4P)	KM200NA4L
RESISTORS		JH 6001 3P CABLE HOLDER	51048-0300
All Resistors	RS1/16SS###J	JP 6001 3P JUMPER WIRE	D20PDY0310E
CAPACITORS			
C 2001	CKSRYB103K50	RESISTORS	
C 2003	CKSRYB104K16	R 6049-6051,6053,6056	RS1/8SQ0R0J
C 2005-2007	CCSSCH101J50	R 6072-6075,6077,6079	RS1/8SQ0R0J
C 2009	DCH1201	R 6088	RS1/8SQ472J
		R 6089,6096,6098,6100	RS1/8SQ0R0J
		R 6103,6105,6113	RS1/8SQ0R0J
		Other Resistors	RS1/10SR###J
D CDCB 2 ASSY			
SEMICONDUCTORS		CAPACITORS	
IC 2101	AD7147ACPZ500RL7	C 6001-6004	CKSRYB104K16
RESISTORS			
All Resistors	RS1/16SS###J	H CDJ1B ASSY	
CAPACITORS		SEMICONDUCTORS	
C 2101	CKSRYB103K50	Q 3030-3033	RT1N241M
C 2103	CKSRYB104K16	Q 3035,3045-3047	2SB1197K
C 2105-2107	CCSSCH101J50	Q 3038-3043	2SC4154-11
C 2109	DCH1201	D 3001-3008,3011-3029	HSU119
		D 3009,3010,3048-3050	SLI-343M8G(GHJ)
		D 3030-3047	SLI-343Y8Y(KLM)
		D 3051,3052	SLI-343U8R(HJK)
		D 3053	SLI-343M8G(GHJ)
E TCHB ASSY			

Mark	No.	Description	Part No.
	D	3056-3059	HSU119

Mark	No.	Description	Part No.
------	-----	-------------	----------

MISCELLANEOUS

A	VR 3001,3002,3004-3006	ROTARY VR	DCS1078
	VR 3003	VR	DCV1009
	S 3001,3002,3012	TACT SWITCH	DSG1079
	S 3003-3006,3009-3011	TACT SWITCH	DSG1089
	S 3013	TACT SWITCH	DSG1089
	S 3014-3026	TACT SWITCH	DSG1079
	S 3027,3028	TACT SWITCH	DSG1117
	S 3030	ENCODER	DSX1082
	CN 3001	19P CONNECTOR	VKN1250
	CN 3002	25P CONNECTOR	VKN1256
B	CN 3003	20P CONNECTOR	VKN1251

RESISTORS

R 3001,3002,3015	RS1/8SQ0R0J
R 3020-3022,3028,3067	RS1/8SQ0R0J
R 3076	RS1/8SQ472J
Other Resistors	RS1/10SR###J

CAPACITORS

C 3001-3003,3005-3008	CKSRYB103K50
C 3009,3010,3014,3017	CKSRYB104K16
C 3011	CEJQ101M16
C 3041,3042	CKSRYB103K50
C 3043,3046-3051	CKSRYB104K16

I CDJ2B ASSY SEMICONDUCTORS

Q 3530-3533	RT1N241M
Q 3538-3543	2SC4154-11
Q 3544-3547	2SB1197K
D 3501-3510,3512	HSU119
D 3511,3513,3548-3550	SLI-343M8G(GHJ)
D 3514-3529,3556-3559	HSU119
D 3530-3547	SLI-343Y8Y(KLM)
D 3551,3552	SLI-343U8R(HJK)
D 3553	SLI-343M8G(GHJ)

MISCELLANEOUS

VR 3501,3502,3504-3506	ROTARY VR	DCS1078
VR 3503	VR	DCV1009
S 3501,3503,3504	TACT SWITCH	DSG1079
S 3502,3505-3511	TACT SWITCH	DSG1089
S 3512-3524	TACT SWITCH	DSG1079
S 3525,3526	TACT SWITCH	DSG1117
S 3527	ENCODER	DSX1082
CN 3501	19P CONNECTOR	VKN1250
CN 3502	25P CONNECTOR	VKN1256
CN 3503	20P CONNECTOR	VKN1251

RESISTORS

R 3600	RS1/8SQ0R0J
Other Resistors	RS1/10SR###J

CAPACITORS

C 3501,3502,3504,3505	CKSRYB103K50
C 3520,3521,3541-3547	CKSRYB104K16
C 3535-3539	CKSRYB103K50
C 3540	CEJQ101M16
C 3550-3552	CKSRYB104K16

J DJMB ASSY SEMICONDUCTORS

IC 4001-4003	TC74HC4052AF
Q 4001-4008	RT1N241M
Q 4009-4016	LSA1576UB
Q 4017-4019	2SC4154-11
D 4001-4027	HSU119
D 4028-4034,4037	SLI-343Y8Y(KLM)
D 4035,4036,4038,4039	SLI-343U8R(HJK)
D 4040-4047	SLI-343Y8Y(KLM)

MISCELLANEOUS

VR 4001,4005,4009,4013	ROTARY VR	DCS1117
VR 4002-4004,4006-4008	ROTARY VR	DCS1078
VR 4010-4012,4014-4016	ROTARY VR	DCS1078
VR 4017,4019	ROTARY VR	DCS1117
VR 4018	ROTARY VR	DCS1116
S 4001,4003,4004,4007	TACT SWITCH	DSG1089
S 4002,4005,4006,4008	TACT SWITCH	DSG1079
S 4009,4011,4013-4018	TACT SWITCH	DSG1089
S 4010,4012,4019-4026	TACT SWITCH	DSG1079
S 4027	ROTARY SW	YSD5019
CN 4001	8P CONNECTOR	VKN1239
CN 4002	25P CONNECTOR	VKN1256

RESISTORS

All Resistors	RS1/10SR###J
---------------	--------------

CAPACITORS

C 4028,4029	CEJQ470M16
C 4030-4057	CKSRYB104K16
C 4058-4076	CKSRYB103K50

K MICB ASSY SEMICONDUCTORS

IC 4601	NJM4565MD
---------	-----------

MISCELLANEOUS

JA 4601	MIC JACK	DKN1614
KN 4601	SCREW PLATE	VNE1948
VR 4601	POTENTIOMETER	DCS1111
S 4601	SLIDE SWITCH	DSH1025
CN 4601	PLUG (6P)	KM200NA6
VA 4601	VARISTORS	EZJZ1V270RM

RESISTORS

R 4601	RS1/10SR2201D
R 4602	RS1/10SR1002D
R 4604	RS1/10SR1101D
R 4605	RS1/10SR6802D
Other Resistors	RS1/10SR###J

CAPACITORS

C 4601,4618	CCSRCH102J50
C 4602	CCSRCH561J50
C 4604,4612,4614	CEJQ100M35
C 4605	CCSRCH331J50
C 4606	CEJQ101M16
C 4609,4611	CEJQ470M16

5		6		7		8	
Mark	No. Description	Part No.	Mark	No. Description	Part No.		
	C 4613	CKSRYB103K50	Q	2509,2510,2512-2515	RT1N141M-11		
	C 4615	CFTLA103J50	Q	2516-2519,2526,2527	RT1P141M		
	C 4616	CKSRYB104K16	Q	2520,2521,2528,2531	RT1N141M-11		A
	C 4619,4620	CCSRCH101J50					
L CHFD ASSY			Q	2522-2525	RTQ040P02		
SEMICONDUCTORS			Q	2529,2530	RT1P141M		
	D 4201-4212	HSU119	D	2504	UDZS5R6(B)		
MISCELLANEOUS			D	2505,2507	RB160M-30		
	VR 4201-4204 VARIABLE RESISTOR	DCV1024	D	2511-2514	HSU119		
	S 4201-4204 SLIDE SWITCH	ASH1039					
	CN 4201 15P CONNECTOR	VKN1246	D	2515	UDZS3R6(B)		
	CN 4202 L-PLUG (3P)	KM200NA3L	MISCELLANEOUS				
RESISTORS			L	2503,2504 CHIP BEEDS FILTER	BTX1042		
	All Resistors	RS1/10SR###J	L	2506 COIL	DTH1197		
CAPACITORS			L	2507,2508 CHIP BEEDS FILTER	BTX1042		B
	C 4201	CEJQ101M16	JA	2501 DCIN JACK	DKN1523		
	C 4202-4205	CKSRYB103K50	JA	2502 USB CONNECTOR	DKN1237		
	C 4206-4210	CKSRYB104K16					
M CRFD ASSY			KN	4601 SCREW PLATE	VNE1948		
SEMICONDUCTORS			S	2502 SLIDE SWITCH	ASG1100		
	D 4301,4302	HSU119	CN	2501 L-PLUG (13P)	KM200NA13L		
MISCELLANEOUS			VA	2501,2502 VARISTORS	EZJZ1V270RM		
	VR 4301 VARIABLE RESISTOR	DCV1023	RESISTORS				
	CN 4301 L-PLUG (3P)	KM200NA3L	R	2510,2532	RS1/4SA0R0J		
CAPACITORS			Other Resistors		RS1/10SR###J		
	C 4301	CKSRYB103K50	CAPACITORS				C
	C 4302	CKSRYB104K16	C	2501,2503-2506,2514	CKSRYB103K50		
N HPJK ASSY			C	2502,2508	CEJQNP470M25		
SEMICONDUCTORS			C	2507	CEJQ100M35		
	IC 4801	NJM4556AD	C	2509,2533	CEHAZL121M10		
	Q 4801-4804	INC2002AC1	C	2515,2535	CKSRYB103K50		
MISCELLANEOUS			C	2516,2517	DCH1201		
	JA 4801 HEADPHONE JACK	DKN1622	C	2519	CKSRYB474K16		
	JA 4802 CONNECTOR	CKS4124	C	2520	CKSRYB224K16		
	KN 4801 SCREW PLATE	VNE1948	C	2521,2522,2534	CKSRYB105K16		
	CN 4801 PLUG (9P)	KM200NA9	C	2523,2528	CCSRCH102J50		
	VA 4801 VARISTORS	EZJZ1V270RM	C	2525,2529	CKSRYB104K16		D
RESISTORS							
	R 4807,4809	RS1/4SA270J					
	R 4813,4814	RS1/4SA130J					E
	Other Resistors	RS1/10SR###J					
CAPACITORS							
	C 4801-4803,4806	CEHAR470M16					
	C 4807,4808,4813,4814	CEHAR101M10					
	C 4809,4810,4815,4816	CKSRYB473K16					
	C 4811	CKSRYB103K50					
O USBB ASSY							F
SEMICONDUCTORS							
	Q 2506	2SC4154-11					
	Q 2507	LSA1576UB					