


Service Manual



ORDER NO.
RRV1397

STEREO TUNER AMPLIFIER

SX-J990

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Type	Model	Power Requirement	The voltage can be converted by the following method.
	SX-J990		
SD	○	AC110V/120-127V/220-230V/240V	With the voltage selector
S/DF	○	AC110V/120-127V/220-230V/240V	With the voltage selector
SD/TA	○	AC110V/120-127V/220-230V/240V	With the voltage selector

- This product is a component of a system.
For the system composition, packing, accessories, instruction manuals etc., refer to the service manual RRV 1396 for Z-AV990R.
- This product does not function properly when independent; to avoid malfunctions, be sure to connect it to the prescribed system component(s), otherwise damage may result.

CONTENTS

1. EXPLODED VIEWS AND PARTS LIST	2	5. IC INFORMATION	42
2. SCHEMATIC AND PCB CONNECTION DIAGRAMS	6	6. FL INFORMATION	46
3. PCB PARTS LIST	31	7. FOR S/DF AND SD/TA TYPES	47
4. ADJUSTMENTS	35	8. PANEL FACILITIES	52
		9. SPECIFICATIONS	54

PIONEER ELECTRONIC CORPORATION 4-1, Meguro 1-Chome, Meguro-ku, Tokyo 153, Japan

PIONEER ELECTRONICS SERVICE INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.

PIONEER ELECTRONIC [EUROPE] N.V. Haven 1087 Keetberglaan 1, 9120 Melsele, Belgium

PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 501 Orchard Road, #10-00 Lane Crawford Place, Singapore 0923

© **PIONEER ELECTRONIC CORPORATION** 1995

T-DFK OCT. 1995 Printed in Japan

1. EXPLODED VIEWS AND PARTS LIST


NOTES :

- Parts marked by “NSP” are generally unavailable because they are not in our Master Spare Parts List.
- The △ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- Parts marked by “⊙” are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.

1.1 EXTERIOR



Parts List

Mark	No.	Description	Parts No.	Mark	No.	Description	Parts No.
	1	MAIN ASSY	RWZ3664	46	FL PANEL SX	RAH2651	
	2	FUNC ASSY	RWZ3644	47	KNOB CAP A	RNK2169	
NSP	3	TRANS ASSY	RWZ3645	48	FUNCTION LENS	RNK2170	
NSP	4	PRIMARY ASSY	RWZ3684	49	SET LENS SX	RNK2171	
	5	VOL ASSY	RWZ3643	50	STAND-BY LENS	RNK2172	
	6	VOLTSEL ASSY	RWZ3647	51	KNOB CAP B	RNK2173	
	7	FRONT ASSY	RWZ3649	52	FRONT PANEL SX	RNT1228	
NSP	8	H.P. ASSY	RWZ3650	53	NAME PLATE	VAM1032	
	9	VIDEO ASSY	RWZ3651	54	SCREW	BBZ30P080FZK	
NSP	10	SP ASSY	RWZ3653	55	SCREW	BBZ30P140FMC	
	11	FM/AM TUNER MODULE	AXQ1012	56	SCREW	BBZ30P180FMC	
	12	POWER AMP MODULE	AXQ7023	57	BONNET	REA1222	
	13	STRAIN RELIEF	CM-22B	58	SCREW	BBZ30P080FMC	
	14	SCREW	VBZ35P080FMC	59	FLANGE NUT	ANB1006	
△	15	LEAD CARD 40P	RDD1346	60	BINDER	Z09-057	
△	16	FUSE (T1.6A, FU4, FU5)	AEK1056				
△	17	FUSE (T3.15A, FU6, FU7)	AEK1059				
△	18	FUSE (T4A, FU1, FU2)	AEK1060				
△	19	FUSE (T2A, FU3)	AEK1057				
△	20	POWER TRANSFORMAR (T)	RTT1302				
△	21	AC POWER CORD	VDG1058				
	22	SCREW	ABA1005				
	23	SCREW (4 × 8)	ABA1184				
NSP	24	PCB SPACER	AEC1188				
NSP	25	PCB SUPPORT	AEC1217				
NSP	26	PCB SPACER (3 × 8)	AEC1371				
NSP	27	PCB SPACER (3 × 12)	AEC1372				
NSP	28	PCB MOLD	AMR1525				
NSP	29	PCB MOLD	AMR2115				
NSP	30	CHASSIS	ANA1193				
NSP	31	CORD STOPPER	DNF1128				
	32	PLATE	PNM1158				
	33	INSULATOR	PNW1912				
	34	FOOT	REC1263				
	35	REAR PANEL SX	RNA1988				
	36	INSULATOR SPACER	RNK2174				
	37	BARRIER (PVC)	AEC7005				
	38	FUNCTION BUTTON	RAC2046				
	39	SET BUTTON SX	RAC2047				
	40	TIMER BUTTON	RAC2048				
	41	POWER BUTTON SX	RAC2049				
	42	VOLUME KNOB	RAC2050				
	43	JOG KNOB	RAC2051				
	44	MIC KNOB	RAC2052				
	45	-----					



Parts
Mark

1.2 POWER AMP MODULE



Parts List

Mark	No.	Description	Parts No.	Mark	No.	Description	Parts No.
	1	FRONT 100W ASSY	AWZ7927	▲	16	TRANSISTOR (Q7511)	2SA1264N
	2	REAR REGULATOR ASSY	AWZ7928	▲	17	TRANSISTOR (Q7512)	2SA1264N
	3	HEAT SINK (AL)	ANH7007	▲	18	TRANSISTOR (Q7513)	2SC3181N
	4	BRACKET	ANG1868	▲	19	TRANSISTOR (Q7514)	2SC3181N
	5	-----			20	TRANSISTOR (Q7503)	2SC4793
	6	MOLD A	AMR2594		21	TRANSISTOR (Q7504)	2SC4793
	7	MOLD B	AMR2595		22	TRANSISTOR (Q7509)	2SA1837
	8	SCREW (3 x 10)	ABA1021		23	TRANSISTOR (Q7510)	2SA1837
	9	SCREW	BBZ30P140FZK	▲	24	TRANSISTOR (Q7111)	2SB1274
	10	SCREW	BBZ30P350FZK	▲	25	TRANSISTOR (Q7112)	2SB1274
	11	FAN MOTOR	AXM1019	▲	26	TRANSISTOR (Q7113)	2SD1913
	12	REGULATOR IC (IC7401)	NJM7812FAS	▲	27	TRANSISTOR (Q7114)	2SD1913
	13	REGULATOR IC (IC7402)	NJM7912FA				
	14	REGULATOR IC (IC7403)	NJM7812FAS				
	15	REGULATOR IC (IC7404)	NJM7805FAS				

2. SCHEMATIC AND PCB CONNECTION DIAGRAMS


2.1 OVERALL SCHEMATIC DIAGRAM

A



B

C

D



MODEL	FU1	FU2	FU3	FU4, FU5	FU6, FU7
SX-J990/J	REK1085 (6.3A)	REK1086 (8A)	—	REK1079 (2.5A)	REK1083 (5A)
SX-J990/SD, SD/TA, S/DF	AEK1086 (T4A)	AEK1060 (T4A)	AEK1057 (T2A)	AEK1056 (T1.6A)	AEK1059 (T3.15A)



SCH-1

OVERALL SCHEMATIC DIAGRAM


2.2 FM/AM TUNER MODULE

A

B

C

D



N.C.
N.C.
CE
DA
CL
R CH
GND
L CH
MONO
MUTE
TUNE
+12V
+5V
STEREO

To MAIN assy CN607 (SCH-7)

SCH-2


FM/AM TUNER MODULE

SCH-2

FM/AM TUNER MODULE




- This diagram is viewed from the mounted parts side.



D

2. 3 FUNC ASSY AND VIDEO ASSY



SCH-3


FUNC ASSY, VIDEO ASSY

SCH-3

FUNC ASSY, VIDEO ASSY

The parts mounted
for several destinati
For further informati
to check with the sci

このPCB図にマウントし
各仕向地の情報は、回路書



SCH-3

SIGNAL ROUTE


▶: AUDIO SIGNAL ROUTE

◀: AUDIO SIGNAL ROUTE (REC)


◀: VIDEO SIGNAL ROUTE

TO MAIN ASSY CN601
(SCH-7)

TO MAIN ASSY CN602
(SCH-7)




	マイコン				4052				4066				
CONDITION	INH	B	A	I	B	A	A	B	A	B	A	B	CONDITION
DAT	H	L	L	L	L	L	+5V	-5V	VTR	OUT			
PHONO	H	L	H	L	L	H	+5V	+5V	VTR	DAT	OUT		
BS	H	H	L	L	H	L	+5V	+5V	VTR	DAT	OUT		
VTR	H	H	H	L	H	H	-5V	+5V	DAT	OUT			



TRUTH TABLE	SW1	SW2	MUTE1	MUTE2	OUT ① MONITOR	OUT ② VIDEO
① VIDEO	*	L	H	L	① VIDEO	GND
② BS	L	H	H	H	② BS	② BS
③ CLD	H	H	H	H	③ CLD	③ CLD
OTHER	*	*(L)	L	L	GND	GND


FUNC ASSY, VIDEO ASSY

SCH-3



IC1301

VIDEO ASSY



The parts mounted on this PCB include all necessary parts for several destinations. For further information for respective destinations, be sure to check with the schematic diagram.

このPCB図にマウントしている部品は複数の仕向けを含んでいます。各仕向けの情報は、回路図で確認するようにしてください。

• This diagram is viewed from the mounted parts side.

• この図は部品取付面側から見た図です。


2. 4 VOL ASSY

A

TO MAIN ASSY CN611
(SCH-7)

C


D



SCH-4

CN802
KP2001B11L

VOL UP
M. +12V
M. GND
REAR OUT
GND
CENTER OUT
+12V
-12V
L. OUT
GND
R. OUT



- This diagram is viewed from the mounted parts side.
- この図は部品取付面側から見た図です。

The parts mounted on this PCB include all necessary parts for several destinations. For further information for respective destinations, be sure to check with the schematic diagram.

このPCB図にマウントしている部品は複数の仕向地を含んでいます。各仕向地の情報は、回路図で確認するようにしてください。


SCH-4

VOL ASSY

VOL ASSY

SCH-4

2. 5 FRONT 100W ASSY




SCH-5

SCH-5

FRONT 100W ASSY

FRONT 100W ASSY

FRONT 100W ASSY



The parts mounted on this PCB include all necessary parts for several destinations.
For further information for respective destinations, be sure to check with the schematic diagram.

このPCB図にマウントしている部品は複数の仕向地を含んでいます。
各仕向地の情報は、回路図で確認するようにしてください。


● This diagram is viewed from the mounted parts side.

● この図は部品取付面側から見た図です。

2. 6 REAR REGULATOR ASSY

REAR REGULATOR ASSY

Q7103	Q7106
	Q7104
Q7105	IC7101
Q7111	Q7112
Q7101	Q7102
Q7113	Q7114
Q7107	
Q7109	Q7108
	Q7110
	Q7202
IC7401	IC7402
Q7301	Q7302
IC7404	IC7403
	IC7201
Q7201	
Q7203	



To MAIN assy J615

- To MAIN assy J616

· To FAN MOTOR

To FRONT 100W assy J7601


The parts mounted on this PCB include all necessary parts for several destinations.
For further information for respective destinations, be sure to check with the schematic diagram.

このPCB図にマウントしている部品は複数の仕向地を含んでいます。
各仕向地の情報は、回路図で確認するようにしてください。

- This diagram is viewed from the mounted parts side.

●この図は部品取付面側から見た図です。

2. 7 MAIN ASSY, TRANS ASSY, PRIMARY ASSY, H.P. ASSY, SP ASSY AND VOLTSEL ASSY




- This diagram is viewed from the mounted parts side.
- この図は部品取付面側から見た図です。


The parts mounted on this PCB include all necessary parts for several destinations. For further information for respective destinations, be sure to check with the schematic diagram.

このPCB図にマウントしている部品は複数の仕向地を含んでいます。各仕向地の情報は、回路図で確認するようにしてください。

PCB-6



2. 8 FRONT ASSY



- This dia mounted p
- この図は部

The parts mor
for several de
For further inf
to check with

このPCB図にマ
各仕向地の情報は

SCH-8

FRONT ASSY

SCH-8

FRONT ASSY

3. PCB PARTS LIST

NOTES :

- Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
- The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- Parts marked by "●" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.
- When ordering resistors, first convert resistance values into code form as shown in the following examples.

Ex. 1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47k ohm (tolerance is shown by J = 5%, and K = 10%).

560 Ω $\rightarrow$ $56 \times 10^1 = 561$ RD1/8PM $\begin{bmatrix} 5 & 6 & 1 \end{bmatrix} J$

47k Ω $\rightarrow$ $47 \times 10^3 = 473$ RD1/4PS $\begin{bmatrix} 4 & 7 & 3 \end{bmatrix} J$

0.5 Ω $\rightarrow$ 0R5 RN2H $\begin{bmatrix} 0 & R & 5 \end{bmatrix} K$

1 Ω $\rightarrow$ 010 RS1P $\begin{bmatrix} 0 & 1 & 0 \end{bmatrix} K$

Ex. 2 When there are 3 effective digits (such as in high precision metal film resistors).

5.62k Ω $\rightarrow$ $562 \times 10^1 = 5621$ RM1/4PC $\begin{bmatrix} 5 & 6 & 2 & 1 \end{bmatrix} F$

Mark	No.	Description	Parts No.	Mark	No.	Description	Parts No.
LIST OF ASSEMBLIES				TRANSFORMER			
NSP	SXAF ASSY	RWK1003		Δ	T601		RTT1298
	└MAIN ASSY	RWZ3664		CAPACITORS			
	└FUNC ASSY	RWZ3644		Δ	C652, C668 (10000pF/250V)		ACG7020
NSP	└TRANS ASSY	RWZ3645			C639, C640, C643, C644		CCSQSL391J50
NSP	└PRIMARY ASSY	RWZ3684			C725, C726		CEAS010M50
	└VOL ASSY	RWZ3643			C671		CEAS100M50
	└VOLTSEL ASSY	RWZ3647			C657, C658		CEAS101M10
NSP	SXDISP ASSY	RWM1853			C646		CEAS101M50
	└FRONT ASSY	RWZ3649			C670		CEAS102M25
NSP	└H. P. ASSY	RWZ3650			C645		CEAS2R2M50
	└VIDEO ASSY	RWZ3651			C650		CEAS331M50
NSP	└SP ASSY	RWZ3653			C648, C649		CEAS470M50
	FM/AM TUNER MODULE	AXQ1012			C659		CKCYF103Z50
	POWER AMP MODULE	AXQ7023			C641, C642		CKSQYB102K50
	└FRONT 100W ASSY	AWZ7927			C663, C664		CKSQYB103K50
	└REAR REGULATOR ASSY	AWZ7928			C655, C656		CKSQYB473K50
					C689-C693		CKSQYB561K50
MAIN ASSY					C1109, C1110		CKSQYF103Z50
SEMICONDUCTORS					C676-C683		CKSQYF104Z50
	IC601	BU4052BCF			C633		CQMA103J50
	IC603	BU4066BCF			C672, C673		CQMA104J50
	IC602, IC606, IC607, IC610	XRA4558F-P			C674, C675		CQMA223J50
	Q615	2SA1048			C631, C632 (3300 μ F/35V)		RCH1132
Δ	Q611	2SB1238X			C627, C628 (5600 μ F/63V)		RCH1143
	Q612, Q616	2SC2458		RESISTORS			
	Q614, Q617	DTC124ES			R660, R661		RD1/2VM221J
	D1103, D1114, D606, D614	1SS254			R665		RD1/2VM622J
Δ	D621	1SS254			R664		RD1/4VM4R7J
	D623-D628	1SS254			R615, R706		RD1/6PM103J
Δ	D629	1SS254			R666		RD1/6PM203J
	D641, D642	1SS254			R619, R620		RD1/6PM222J
Δ	D701, D702	1SS254			R682		RD1/6PM223J
Δ	D619	D3SBA20 (B)			R1407, R1408		RD1/6PM472J
Δ	D617	D5SB20F			R656		RD1/6PM623J
	D615	MTZJ33B			R721		RD1/6PM683J
	D609, D610	MTZJ5.1B			R662		RS1LMF272J
	D616	MTZJ8.2B			R653, R654		RS1LMFR22J
Δ	D611-D613, D622	S5688G			R684		RS3LMF151J
	D630, D631	S5688G			R651, R652		RS3LMFR22J
					Other Resistors		RS1/10SC11J
SWITCHES AND RELAYS							
Δ	S624 VOLTAGE SELECTOR	PSB1006					
Δ	RY601	ASR1036					

Mark No.	Description	Parts No.
OTHERS		
J615	CABLE HOLDER (8P)	51052-0800
J613	CABLE HOLDER (8P)	51052-1000
J602	CABLE HOLDER (8P)	51063-0605
J616	CABLE HOLDER (8P)	51063-1305
J601	CABLE HOLDER (8P)	51063-1505

	CN604	40P FFC CONNECTOR	9604S-40C
	CN607	PLUG 14P	AKM1110
	CN614	SOCKET (15P)	AKP1049
	CN612	SOCKET (9P)	AKP1072
△	CN622	AC SOCKET 1-P	AKP1078
	CN606	SOCKET (18P)	AKP1131
	CN609, CN611	PLUG 11P	KM200IB11
	CN605	SOCKET (8P)	KP250NA8
	CN608	JUMPER CONNECTOR 8P	KPC8
	CN601, CN602	PLUG (8P)	RKM1004
△	CN621	AC CODE SOCKET	RKP1751
	H101-H104, H107-H110	FUSE HOLDER	RKR1003
	KN601	EARTH METAL FITTING	RNF1002
		PCB BINDER	VEF1040

FUNC ASSY

SEMICONDUCTORS

IC901	BU4052BCF
IC902	BU4066BCF
IC903	UPC4570G2
Q902	DTA124ES

CAPACITORS

C935, C936	CEAS101M10
C909, C910	CEAS470M10
C903, C904	CEAS4R7M50
C905, C906	CKSQYB152K50
C907, C908	CKSQYB562K50
C939	CKSQYF104Z50

RESISTORS

All Resistors	RS1/10S□□□J
---------------	-------------

OTHERS

CN901, CN902	9133S-08A
	8P BOARD CONNECTOR
CN904	AKB7012
CN905	AKB7013
CN903	AKM1028
	VEF1040
	PCB BINDER

TRANS ASSY

OTHERS

J602	CABLE HOLDER (6P)	51063-0605
J601	CABLE HOLDER (15P)	51063-1505
H601-H604	FUSE HOLDER	RKR1003

PRIMARY ASSY

OTHERS

Y602	BOARD-IN READ WIRE	RDX1010
H105, H106	FUSE HOLDER	RKR1003

VOL ASSY

SEMICONDUCTORS

IC801	TA8409S
-------	---------

Mark No.	Description	Parts No.
	IC802, IC803	UPC4570G2
	Q801, Q802, Q805, Q806	2SD2144S
	Q803, Q804	DTA124ES

COILS AND FILTERS

L801	LAU221J
------	---------

CAPACITORS

C819, C820, C823, C824	CCSQCH470J50
C813, C814	CEAS100M50
C828	CEAS101M25
C811, C812, C815, C816	CEAS2R2M50
C807, C808	CEAS470M25
C801-C804	CEZA100M50
C805, C806	CEZA2R2M50
C851, C852	CKSQYB392K50
C831, C832	CKSQYB473K50
C821, C822	CKSQYB333K25
C809, C810	CKSQYF104Z50
C827	CKSQYF473Z50

RESISTORS

VR801 (100k Ω-4B×4)	RCX1056
R817	RD1/6PM272J
R818	RD1/6PM472J
Other Resistors	RS1/10S□□□J

OTHERS

CN801, CN802	11P SOCKET	KP200IB11L
--------------	------------	------------

VOLTSEL ASSY

OTHERS

Y606	BOARD-IN READ WIRE	ADX7039
Y605	BOARD-IN READ WIRE	ADX7043
Y601	BOARD-IN READ WIRE	RDX1011
Y603	BOARD-IN READ WIRE	RDX1012
Y604	BOARD-IN READ WIRE	RDX1013

△ S625	VOLTAGE SELECTOR	RSB1021
--------	------------------	---------

FRONT ASSY

SEMICONDUCTORS

IC1101	PDG155A
Q1101	2SC2458
Q1102	DTC124ES
Q1151, Q1152, Q1154-Q1162	DTC143ES
D1101, D1102, D1104, D1106-D1109	1SS254
D1115	1SS254
D1110	MTZ6.2B
D1152, D1154-D1159	SLR-342MCT31
D1151	SLR-342VCT31
D1160-D1162	SLR-342YCT31

COILS AND FILTERS

L1101	LAU220J
-------	---------

SWITCHES AND RELAYS

S1101-S1115	ASG1051
S941	RSX1006

CAPACITORS

C1101 (0.047F/5.5V)	ACH1246
C1106, C1115	CCCSL101J50
C1104, C1121	CEJA010M50
C1111	CEJA100M50
C1105	CEJA2R2M50

Mark No.	Description	Parts No.	Mark No.	Description	Parts No.
	C1103, C1114	CEJA470M16		Q6104	2SK302
	C1120	CKCYB102K50		Q6101	3SK194
	C1113	CKCYF223Z50		Q6204	XDA124EK
	C1102	CKCYF473Z50			
	C1107, C1108, C1112	CKPUYF103Z25		Q6217	XDC124EK
				D6101, D6102	1T33
RESISTORS			COILS AND FILTERS		
	VR1101 (100k Ω -B)	RCS1042		L6104	ATC1003
	Other Resistors	RD1/6PM□□□J		L6101	ATC1020
OTHERS				L6102	ATC1021
	J1101 CABLE HOLDER (3P)	51048-0300		L6207	ATE1013
	CN1101 40P FFC CONNCTOR	9607S-40F		F6203, F6204	ATF-119
	V1101 FL TUBE	AAV1186			
	FL HOLDER	AMR7038		F6101	ATF-155
	X1101 (8.00 MHz)	DSS1053		F6202	ATF1155
				L6103 (2.2 μ H)	ATH1043
	X1102 REMOTE RECEIVER UNIT	GP1U27X		L6202, L6203, L6208	LCTA2R2J3225
H. P. ASSY			TRANSFORMERS		
CAPACITORS				T6101	ATE-063
	C1051, C1052	CKCYF103Z50	CAPACITORS		
RESISTORS				C6202, C6234, C6236 (1 μ F/16V)	ACG1051
	R1051, R1052	RS2LMF331J		C6107	CCSCH010C50
OTHERS				C6229	CCSCH821J50
	J1051 CABLE HOLDER (8P)	51052-0800		C6110	CCSQCH020C50
	CN1052 HEADPHONE JACK	AKN1025		C6101	CCSQCH050C50
VIDEO ASSY					
SEMICONDUCTORS				C6108, C6203, C6268	CCSQCH101J50
	IC1301	NJM2279D		C6111, C6116, C6208, C6221, C6222	CCSQCH150J50
CAPACITORS				C6115	CCSQCH330J50
	C1304, C1305	CCCSL470J50		C6114	CCSQRH080D50
	C1308, C1309	CEAS331M6R3		C6113	CCSQRH180J50
	C1301-C1303	CEAS470M16			
	C1306, C1307	CKCYF473Z50		C6105	CCSQTH150J50
RESISTORS				C6261	CEAS010M50
	R1317, R1318	RD1/2VM180J		C6224, C6246, C6262	CEAS100M50
	Other Resistors	RD1/6PM□□□J		C6227	CEAS101M10
OTHERS				C6216, C6217	CEAS330M16
	JA1302 PIN JACK (2P)	AKB7016			
	JA1301 RCA PIN JACK (3P)	AKB7018		C6231, C6233	CEAS3R3M50
	CN1301 SOCKET 6-P	KP250NA6		C6219	CEAS470M10
SP ASSY				C6243-C6245	CEAS470M16
OTHERS				C6238	CEJA100M16
	JA1001 SPEAKER TERMINAL 4-P	AKE-109		C6249, C6250	CEJA4R7M35
	CN1001 8P PLUG	KM250NA8L			
	JA1002 PIN JACK (3P)	RKB1045		C6215	CFTXA103J50
FM/AM TUNER MODULE				C6214	CFTXA224J50
SEMICONDUCTORS				C6103, C6106, C6112, C6204	CKSQYB102K50
	IC6201	LA1836M		C6102, C6109, C6117, C6210, C6264	CKSQYB103K50
	IC6202	LM7001J		C6213	CKSQYB223K50
	Q6102	2SC2223			
	Q6203	2SC2235		C6230	CKSQYB333K50
	Q6202	2SC2712		C6228, C6252	CKSQYB472K50
				C6209, C6237, C6265, C6267	CKSQYB473K50
	Q6103, Q6214	2SC2714		C6212, C6218	CKSQYF103Z50
	Q6201	2SK208		C6220, C6226, C6239, C6242, C6255	CKSQYF223Z50
				C6235	CKSQYF224Z25
				C6225, C6241, C6266	CKSQYF473Z50
				C6232	CKSYB333K50
				C6251	CKSYB472K50
				C6223	CKSYF103Z50
				C6263	CKSYF473Z50
			RESISTORS		
				VR6201 (10k Ω)	ACP1056
				VR6202	VRTB6VS223
				R6299, R6300	RD1/8PM102J
				R6113, R6116, R6118, R6268-R6271	RS1/8S000J
				R6275, R6276, R6278, R6283, R6284	RS1/8S000J
				R6290, R6293, R6294, R6297	RS1/8S000J

Mark	No.	Description	Parts No.
	R6243, R6244		RS1/8S101J
	R6211		RS1/8S103J
	R6237		RS1/8S182J
	R6209		RS1/8S221J
	R6239		RS1/8S332J
	R6101		RS1/8S470J
	Other Resistors		RS1/10S□□□J

OTHERS

BN6201	ANNTENA TERMINAL 4-P	AKA1016
CN6201	14P SOCKET	KP2001A14L
X6203	(7.200 MHz)	ASS1042
X6201	(456 kHz)	ASS1066
X6202	(450 kHz)	ATF1027
	AM RF TUNING BLOCK	AXX1041

FRONT 100W ASSY

SEMICONDUCTORS

IC7501	UPC4570G2 (5)
Q7507, Q7508	2SA1182
Q7501, Q7502	2SC2240
Q7505, Q7506	2SC2859
D7505, D7506, D7517, D7518	1SS181
D7503, D7504, D7516	1SS184
D7535-D7538	1SS226
D7521-D7524	1SS244
D7519, D7520, D7525, D7526, D7531	HSS104-02
D7507-D7510	RD3.3ESB2

CAPACITORS

C7519-C7522, C7545-C7552	CCSQCH101J50
C7525-C7528	CCSQCH271J50
C7503, C7504	CCSQCH331J50
C7541, C7542	CCSQCH470J50
C7523, C7524	CEALR10M50
C7509, C7510	CEAS101M10
C7540	CEJA3R3M50
C7539	CEJA4R7M50
C7529-C7532	CKSQYB333K50
C7543, C7544	CKSQYB472K50
C7537	CKSQYF473Z50

RESISTORS

△ R7515, R7516 (1.8k Ω)	ACN1107
△ R7541, R7542	RD1/4PMF100J
△ R7519, R7520	RN1/10SE621D
△ R7547-R7550	RS1/10S2200F
R7753	RS1/8S000J
△ R7537-R7540	RS1/8S100J
△ R7553	RS1/8S101J
△ R7543, R7544	RS1/8S7R5J
Other Resistors	RS1/10S□□□J

REAR REGULATOR ASSY

SEMICONDUCTORS

IC7201	PAC006C
IC7101	UPC4570G2
Q7107, Q7108	2SA1162
Q7109, Q7110	2SB1115
Q7101, Q7102, Q7301, Q7302	2SC1815
Q7105, Q7106, Q7202	2SC2712
Q7103, Q7104	2SD1615
D7113, D7114	1SS181
D7111, D7112, D7204	1SS184

Mark	No.	Description	Parts No.
	D7115, D7116		1SS226
	D7205, D7208		HSS104-02
	D7210		RB441Q-40
	D7107-D7110		RD2.2ESB2
	D7206, D7211		RD4.7ESB
	D7207		RD5.6ESB2

CAPACITORS

C7402, C7406, C7408 (0.082 μF/25V)	ACG1050
C7204 (1 μF/16V)	ACG1051
C7401, C7405, C7407 (0.33 μF/50V)	ACG1053
C7409 (10 μF/35V)	ACH1150
C7109, C7110 (47 μF/16V)	ACH1151
C7119-C7122	CCSQCH101J50
C7133-C7136	CCSQCH221J50
C7125-C7128	CCSQCH271J50
C7103, C7104	CCSQCH331J50
C7142, C7143	CCSQCH470J50
C7202	CEANL4R7M50
C7140	CEAS010M50
C7205	CEJA101M10
C7203	CEJAR33M50
C7697	CKDYB103K50
C7144, C7145, C7201, C7208, C7219	CKSQYB103K50
C7301	CKSQYB332K50
C7129-C7132	CKSQYB333K50
C7206, C7215, C7216, C7404, C7698	CKSQYF104Z50
C7137, C7138	CKSQYF472Z50
C7139	CKSQYF473Z50

RESISTORS

△ VR7201 (22 k Ω)	RCP1103
△ R7403-R7405 (1 Ω)	ACN1104
△ R7119, R7120 (604 Ω)	ACN1105
△ R7115, R7116 (665 Ω)	ACN1109
△ R7252	RD1/6PM102J
△ R7253	RD1/6PM103J
△ R7137-R7140	RS1/10S0100F
△ R7303	RS1/10S1002F
△ R7147-R7150	RS1/10S2200F
△ R7304	RS1/10S8200F
△ R7141-R7144	RS1/8S100J
△ R7153	RS1/8S101J
Other Resistors	RS1/10S□□□J

OTHERS

CN7101	13P JUMPER CONNECTOR	KPE13
--------	----------------------	-------

4. ADJUSTMENTS

4.1 TUNER SECTION

■ FM Tuner Section

- Set the mode selector to FM BAND.
- Connect the wiring as shown in Fig. 1.

● For SD and SD/TA types (AXQ1012)

Step No.	Adjustment Title	FM SG (1kHz, ± 75 kHz dev.)		Reception Frequency Display	Adjustment Location	Specifications
		Frequency (MHz)	Level (dB μ V)			
1	Center Adjustment	98 Non modulation	80 or more	—	L6207	Adjust so that the DC voltage between IC6201-Pin 4 and Pin 28 (or $\oplus$ leads of C6224 and C6261) becomes $0V \pm 50mV$.
2	Front End Sencitivity	98	10-30	98MHz	L6102 T6101	Adjust so that the DC voltage between the IC6201-Pin 12 and GND (or $\oplus$ leads of C6238 and GND) becomes at maximum level.
3	Stereo Distortion	98	80	98MHz	T6101	Minimize the distortion with 1/8 rotation of the core.
4	TUNED IND. Lighting Level	98	15 ± 2	98MHz	VR6201	Adjust so that the indicator of TUNED IND. starts to light up.

Notes:

- Before adjusting, make sure there is no gap between L6101 and L6102. If there is a gap between them, bring them into contact with each other first, and then make adjustments.
- Make indicator adjustments in order of AM $\rightarrow$ FM.

● For S/DF type (AXQ1016)

Step No.	Adjustment Title	FM SG (1kHz, ± 75 kHz dev.)		Reception Frequency Display	Adjustment Location	Specifications
		Frequency (MHz)	Level (dB μ V)			
1	Center Adjustment	83 Non modulation	80 or more	83MHz	L6109	Adjust so that the DC voltage between Pin 4 and Pin 28 of IC6101 becomes $0V \pm 50mV$. (Both ends R6141)
2	Front End Sencitivity	83	10-30	83MHz	L6104 L6102 T6101	Adjust so that the DC voltage of the Pin12 of IC6101 (S-meter) becomes at maximum level.
3	TUNED IND. Lighting Level	83	15 ± 2	838MHz	VR6101	Adjust so that the indicator of TUNED IND. starts to light up.

Notes:

- Before adjusting, make sure there is no gap between L6101 and L6102 and between L6103 and L6104. If there is a gap between them, bring them into contact with each other first, and then make adjustments.
- Make indicator adjustments in order of AM $\rightarrow$ FM.

■ AM Tuner Section

- Set the mode selector to AM BAND.
- Connect the wiring as shown in Fig. 1.
- For SD and SD/TA types (AXQ1012)

Step No.	Adjustment Title	AM SG (400Hz, 30% Mod.)		Reception Frequency Display	Adjustment Location	Specifications
		Frequency (kHz)	Level (dBμV/m)			
1	TUNED IND. Lighting Level	999	47±2	999kHz*1	VR6202	Adjust so that the indicator of TUNED IND. starts to light up.

- For S/DF type (AXQ1016)

Step No.	Adjustment Title	AM SG (400Hz, 30% Mod.)		Reception Frequency Display	Adjustment Location	Specifications
		Frequency (kHz)	Level (dBμV/m)			
1	TUNED IND. Lighting Level	999	47±2	999kHz*1	VR6102	Adjust so that the indicator of TUNED IND. starts to light up.

*1 : For the area using 10kHz step, frequencies should be 1000kHz.





Fig. 1 AM and FM Adjustment Wiring Diagram

FM/AM TUNER MODULE (AXQ1012)



FM/AM TUNER MODULE (AXQ1016)




Fig. 2 Adjustment Point

4.2 POWER AMP MODULE SECTION (REFER TO FIG. 2-1.)

1. Handling Precautions

- Since the heat sink and transistor metallic parts are connected to the Front Amp output, make sure they do not contact the GND (chassis) or other circuits.
- Since there is residual high voltage in the Power Amp Module Assy ±B1 (FRONT ASSY FOR 100W) and ±B2 (REAR, PWR, PRTEC ASSY) even when the power is OFF, caution should be exercised. (If necessary, the voltage should be discharged).
- When handling the Power Amp Module Assy, make sure you do not touch the fan motor blade.

2. Adjustment and Confirmation of Idle Current

- Basically, the idle current needs to be confirmed when replacing a power transistor, driver transistor, or bias transistor, or when the entire split board Assy of the Power Amp Module Assy has been replaced.
- Make sure the heat sink has cooled sufficiently before measuring the idle current. (Temperature should be the same as room temperature; 25°C is ideal, if possible.)
- Idle current stipulated value: 3-100mA.

■ Front Amp Side (FRONT ASSY FOR 100W)

Step	Measurement	Item	Remarks
1	Lch side	Short both sides of C7144 (C7124) and C7145 (C7123) on the Rear Amp side.	Do not operate the Rear Amp side.
2		Insert a resistor (0.22 Ω, 3W or more) in series in the connector CN7502 +B1 (or-B1) line (terminal No. 5 or 6). (Refer to Fig. 2-2.)	For measuring voltage at both sides of resistor
3		Short both sides of C7524.	Do not operate Rch side.
4		Turn the power ON, wait 6 seconds, and then measure the resistance voltage in Step 2.	Lch Idle current I=V/0.22 (Ω)
5	Rch side	● Same as Steps 1 and 2 above. ● Short both sides of C7523.	Do not operate Lch side.
6		Turn the power ON under the above conditions, and after 6 seconds measure the resistance voltage in Step 2.	
7	——	If the measured idle current is greater than 100mA, perform the following procedure.	
8	Lch side	Short between the Point Ⓐ pattern in Fig. 2-4 using solder.	Connect R7517 to R7515 in a parallel circuit.
9	Rch side	Short between the Point Ⓑ pattern in Fig. 2-4 using solder.	Connect R7518 to R7516 in a parallel circuit.
10	——	After performing Steps 8 and 9, remeasure the idle current and confirm that it is below 100mA.	
11	——	If the idle current is below 3mA, perform the following procedure.	
12	Lch side	Short between the point Ⓒ pattern in Fig.2-4 using solder.	Connect R7551 to R7519 in a parallel circuit.
13	Rch side	Short between the point Ⓓ pattern in Fig.2-4 using solder.	Connect R7552 to R7520 in a parallel circuit.
14	——	After performing step 12 and 13, remeasure the idle current and confirm that it is greater than 3mA (within 3-100mA).	

■ Rear Amp Side (REAR REGULATOR ASSY)

Step	Measurement	Item	Remarks
1	Center amp side	Short both sides of C7523 and C7524 on the Front Amp side.	Do not operate the Front Amp side.
2		Insert a resistor (0.22 Ω, 2W or more) in series in the connector CN7102 +B2 (or -B2) line (terminal No. 5 or 6). (Refer to Fig. 2-3.)	For measuring voltage at both sides of resistor
3		Short both sides of C7145 (C7123) on the Surround Amp side.	Do not operate the Surround Amp.
4		Turn the power ON, wait 6 seconds, and then measure the resistance voltage in Step 2.	Idle current: $I = V/0.22 (\Omega)$
5	Surround amp side	● Same as Steps 1 and 2 above. ● Short both sides of C7144 (C7124) on Center Amp side.	Do not operate Center Amp.
6		Turn the power ON under the conditions in Steps 1 and 2, and after 6 seconds measure the resistance voltage in Step 2.	
7	—	If the measured idle current is greater than 100mA, perform the following procedure.	
8	Center amp side	Short between the Point ㊦ pattern in Fig. 2-5 using solder.	Connect R7117 to R7115 in a parallel circuit.
9	Surround amp side	Short between the Point ㊦ pattern in Fig. 2-5 using solder.	Connect R7118 to R7116 in a parallel circuit.
10	—	After performing Steps 8 and 9, remeasure the idle current and confirm that it is below 100mA.	
11	—	If the idle current is below 10mA, perform the following procedure.	
12	Center amp side	Short between the point ㊧ pattern in Fig.2-5 using solder.	Connect R7151 to R7119 in a parallel circuit.
13	Surround amp side	Short between the point ㊧ pattern in Fig.2-5 using solder.	Connect R7152 to R7120 in a parallel circuit.
14	—	After performing step 12 and 13 remeasure the idle current and confirm that it is greater than 10mA (within 10-100mA).	

FRONT ASSY FOR 100W (Front Amp Side)




Fig. 2-1 PCB Location of Power Amp Module




Fig. 2-2 FRONT 100W ASSY




Fig. 2-3 REAR REGULATOR ASSY





Fig. 2-5 REAR REGULATOR ASSY

3. Adjusting the Operating Temperature Setting of the Fan Motor (VR7201)

This adjustment is necessary when IC7401 (+12V regulator), Q7301 and Q7302 (temperature sensors), IC7201 (protection IC) or VR7201 has been replaced, or when the entire split board Assy of the Power Amp Module has been replaced.

■ Adjustment-Related Cautions

- Make sure the heat sink has sufficiently cooled (is the same as room temperature Ta.)
- Once the power has been turned ON, make measurements and adjustments as quickly as possible. (If too much time is taken, the heat sink temperature will rise, and the measurements will deviate from the Ta measurement point.)

■ Adjustment

1. Connect a voltmeter between VTEMP and VL (or between IC7201 terminals No.9 and 7). (Refer to Fig. 2-6.)
2. Determine the fan motor operating temperature setting by means of the following formula. (Tolerance is within $\pm 30\text{mV}$.)

Formula: $(75^\circ\text{C} - T_a) \times 19 \text{ (mV)}$

Ta: ambient temperature ($^\circ\text{C}$)

3. Adjust VR7201 so that the voltage between VTEMP and VL is the value obtained from the above formula.

For example:

when the room temperature is 25°C ,

set value = $(75 - 25) \times 19 \text{ (mV)}$

= 950mV (tolerance within $\pm 30\text{mV}$).




Fig. 2-6 Adjustment of Operating Temperature Setting of Fan Motor


5. IC INFORMATION

● The information shown in the list is basic information and may not correspond exactly to that shown in the schematic diagrams.


■ NJM2279D (IC1301 : VIDEO ASSY)

● VIDEO SWITCH IC

● Pin Assignment (Top View)



● BLOCK DIAGRAM



■ PDG155A (IC1101 : FRONT ASSY)

● System Control Micro-computer

● Pin Function

No.	Name	Function	I/O	Description
1	PE1/EC1/INT1	JOGA	I	Jog pulse input
2	PE2/INT2	JOGB	I	
3	PE3/INT3/NMI	COUNTRY 1	I	Dispatch switchover input H: JAPAN L: EX
4	PE4/RMC	REMOCON	I	Remote control signal input
5	PE5/CTL	WARNING	I	Power module WARNING input L: Normal H: Power OFF due to abnormal condition
6	PE6/PWM	NC	O	L
7	PE7/T0/ADJ	NC	O	L
8	PB0/CINT	H.P.IN	I	Headphone connection detection H: Undetected L: Detect/audio mute (REAR, CENTER)
9	PB1/CSO	PLL CLOCK	O	PLL IC LM7001 Serial clock
10	PB2/SCKO	PLL DATA	O	PLL IC LM7001 Serial Data
11	PB3/SI0	STEREO	I	Tuner stereo broadcast reception discrimination H: — L: STEREO
12	PB4/SO0	TUNED	I	Tuner tuning discrimination H: — L: TUNED
13	PB5/SCK1	MUTE	O	Tuner audio mute control H: MUTE L: —
14	PB6/SI1	MONO	O	Tuner forced monaural H: MONO L: AUTO STEREO
15	PB7/SO1	PLL CE	O	PLL IC LM7001 chip enable H: CE L: —
16 19	PC0/KR0 PC3/KR3	KEYIN 1 KEYIN 4	I	Key scan return input
20	PC4/KR4	NC	O	L
21	PC5/KR5	2279 S1	O	VIDEO SELECTOR NJM2279 Control
22	PC6/KR6	2279 M1	O	
23	PC7/KR7	2279 M2	O	
24	PH0	4052 A	O	AUDIO SELECTOR Control
25	PH1	4052 B	O	
26	PH2	4052 INH	O	
27	PH3	FAN	O	Power module control H: Fan On L: Fan Off
28	PH4	REAR MUTE	O	REAR, CENTER mute control H: — L: MUTE
29	PH5	FRONT MUTE	O	FRONT mute control H: — L: MUTE
30	PH6	POWER RY	O	Power relay control H: POWER ON L: POWER OFF
31	PH7	PROTECT	I	Machine connection detection (JAPAN model L fixed) L: OK H: Unconnected NG: POWER OFF

No.	Name	Function	I/O	Description					
32	PA0/AN0	VOL POSI	I	Volume location detection (ADC)					
33	PA1/AN1	VOL UP	O	Motor drive TA8409S control					
34	PA2/AN2	VOL DOWN	O						
35	PA3/AN3	CLD R/E	I/O	System bus CLD transmission request/approval I: Wait for request L: Approval					
36	PA4/AN4	DECK R/E	I/O	System bus DECK transmission request/approval I: Wait for request L: Approval					
37	PA5/AN5	GEQ R/E	I/O	System bus processor transmission request/approval I: Wait for request L: Approval					
38	RST	RESET	I	CPU RESET input L: RESET H: —					
39	EXTAL	OSC	I	8MHz ceramic oscillator connection					
40	XTAL	OSC	O						
41	VSS	D.GND	—	D.GND					
42	TX	NC	O	——					
43	TEX	D.GND	I	D.GND					
44	PA6/AN6	S.DATA	I/O	System bus serial data input and output					
45	PA7/AN7	S.CLOCK	O	System bus serial clock output					
46	AVref	+ 5V	I	AD standard voltage input					
47	AVss	D.GND	I	ADC GND					
48	PD0/S0	DIRECT B	O	DIRECT signal switchover control					
49	PD1/S1	DIRECT A	O						
50	PD2/S2	4066 B	O	VIDEO OUT switchover control	FUNCTION 4066 B 4066 A	VIDEO H L	DAT/MD L H	OTHER H H	H : + 5V L : - 5V
51	PD3/S3	4066 A	O						
52	PD4/S4	NC	O	L					
53	PD5/S5	JOG LED	O	JOG LED CONTROL		H: Illuminated		L: extinguished	
54	PD6/S6	SET LED	O	SET LED CONTROL		H: Illuminated		L: extinguished	
55	PD7/S7	STANDBY LED	O	STANDBY LED CONTROL		H: Illuminated		L: extinguished	
56	PF0/S8	DIRECT LED	O	DIRECT LED CONTROL		H: Illuminated		L: extinguished	
57	PF1/S9	CD/LD LED	O	CD/LD LED CONTROL		H: Illuminated		L: extinguished	
58	PF2/S10	VIDEO LED	O	VIDEO LED CONTROL		H: Illuminated		L: extinguished	
59	PF3/S11	AUX LED	O	AUX LED CONTROL		H: Illuminated		L: extinguished	
60 63	PF4/S12 PF7/S15	P1 P4	O	FDP CONTROL ANODE					
64 71	PI0/S16 PI7/S23	P5 P12	O						

No.	Name	Function	I/O	Description
72 75	T15/S24 T12/S27	P13 P16	O	FDP CONTROL ANODE
76 79	T11/S28 T8/S31	12G 9G	O	FDP CONTROL GRID
80 87	T7 T0	8G 1G	O	
88	Vfdp	- 28V	-	
89	VDD	+ 5V	-	FDP BLANKING VOLTAGE
90	NC	+ 5V	-	
91	VSS	D.GND	-	
92	PG0/RT00	NC	O	
93	PG1/RT01	PHONO LED	O	PHONO LED CONTROL H: Illuminated L: extinguished
94	PG2/RT02	TUNER LED	O	TUNER LED CONTROL H: Illuminated L: extinguished
95	PG3/RT03	TAPE LED	O	TAPE LED CONTROL H: Illuminated L: extinguished
96	PG4	DAT/MD LED	O	DAT/MD LED CONTROL H: Illuminated L: extinguished
97	PG5	NC	O	L
98	PG6	NC	O	L
99	PG7	NC	O	L
100	PE0/EC0/INT0	AC 50/60	I	AC PULSE INPUT (For Clock and Power monitoring)

7. FOR S/DF AND SD/TA TYPES

- NOTES :
- Parts marked by “ NSP ” are generally unavailable because they are not in our Master Spare Parts List.
 - The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
 - Parts marked by “ $\odot$ ” are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.
 - When ordering resistors, first convert resistance values into code form as shown in the following examples.
- Ex. 1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47k ohm (tolerance is shown by J = 5%, and K = 10%).
- $560\Omega \rightarrow 56 \times 10^1 = 561$ RD1/8PM $\begin{bmatrix} 5 & 6 & 1 \end{bmatrix}$ J
- $47k\Omega \rightarrow 47 \times 10^3 = 473$ RD1/4PS $\begin{bmatrix} 4 & 7 & 3 \end{bmatrix}$ J
- $0.5\Omega \rightarrow 0R5$ RN2H $\begin{bmatrix} 0 & R & 5 \end{bmatrix}$ K
- $1\Omega \rightarrow 010$ RS1P $\begin{bmatrix} 0 & 1 & 0 \end{bmatrix}$ K
- Ex. 2 When there are 3 effective digits (such as in high precision metal film resistors).
- $5.62k\Omega \rightarrow 562 \times 10^1 = 5621$ RM1/4PC $\begin{bmatrix} 5 & 6 & 2 & 1 \end{bmatrix}$ F

■ CONTRAST OF MISCELLANEOUS PARTS

SX-J990/S/DF, SD/TA and SD have the same construction except for the following :

Mark	Symbol & Description	Part No.			Remarks
		SD TYPE	S/DF TYPE	SD/TA TYPE	
NSP	SXAF assy	RWK1003	RWK1010	RWK1003	
	MAIN assy	RWZ3664	RWZ3878	RWZ3664	
	FM/AM TUNER MODULE	AXQ1012	AXQ1016	AXQ1012	
	Rear panel	RNA 1988	RNA 2000	RNA2061	


MAIN Assy

RWZ3878 and RWZ3664 have the same construvtion except for the following :

Mark	Symbol & Description	Part No.		Remarks
		RWZ3664	RWZ3878	
	R761	RS1/10S473J	Not used	
	R762	Not used	RS1/10S473J	

■ PCB PARTS LIST

Mark	No.	Description	Parts No.	Mark	No.	Description	Parts No.
FM/AM TUNER MODULE (AXQ1016)							
SEMICONDUCTORS							
	IC6101		LA1836M		C6135		CFTXA103J50
	IC6102		LM7001J		C6134		CFTXA394J50
	IC6103		MC13020M		C6132		CKCYX473M16
	Q6117		2SA1162		C6105, C6115, C6125, C6126, C6128		CKSQYB102K50
	Q6102		2SC2223		C6167, C6168		CKSQYB102K50
	Q6113		2SC2235		C6102, C6103, C6114, C6121, C6124		CKSQYB103K50
	Q6110, Q6115, Q6116, Q6121-Q6124		2SC2712		C6136, C6139, C6144, C6170, C6172		CKSQYB103K50
	Q6103, Q6107, Q6119, Q6120		2SC2714		C6182, C6184		CKSQYB103K50
	Q6111		2SK208		C6195, C6196		CKSQYB222K50
	Q6104, Q6105		2SK302		C6131, C6143		CKSQYB223K50
	Q6101		3SK194		C6173-C6175, C6180		CKSQYB332K50
	Q6106, Q6109		XDA124EK		C6158, C6159		CKSQYB333K50
	Q6112, Q6118		XDC124EK		C6156		CKSQYB472K50
	Q6108, Q6114		XDC143EK		C6201		CKSQYF104Z50
	D6106		1SS181		C6152		CKSQYF224Z25
	D6101, D6102, D6104		1SV228		C6138, C6146-C6150, C6171		CKSQYF473Z50
					C6123		CKSYB103K50
					C6207		CKSYF103Z50
COILS AND FILTERS				RESISTORS			
	T6102		ATB1010		VR6101 (10k Ω)		ACP1043
	L6106		ATC1008		VR6102 (22k Ω)		ACP1044
	L6101		ATC1025		R6115, R6119, R6123, R6127		RS1/8S000J
	L6102		ATC1026		R6217, R6218		RS1/8S000J
	L6103		ATC1027		R6137		RS1/8S331J
	L6104		ATC1028		R6112		RS1/8S473J
	T6101		ATE-063		R6141		RS1/8S563J
	L6109		ATE1013		Other Resistors		RS1/10S□□□J
	F6102		ATF-107				
	F6101		ATF-119				
	F6103		ATF1144				
	L6107		ATH1043				
	L6108, L6110		LCTA2R2J3225				
CAPACITORS							
	C6191-C6194		ACG1050		BN6101	4P ANTENNA TERMINAL	AKA1016
	(0.082 μ F/25V)		ACG1051			AG PCB	ANP1713
	C6129, C6153, C6154, C6199, C6200				X6102 (7.200MHz)		ASS1042
	(1 μ F/16V)				X6101 (456kHz)		ASS1066
	C6120		CCSCH150J50		X6104 (3.60MHz)		ASS1086
	C6111		CCSQCH010C50				
	C6112, C6122		CCSQCH020C50		X6103 (450kHz)		ATF1027
	C6113		CCSQCH101J50		AM RF TUNING BLOCK		AXX1044
	C6157, C6177		CCSQCH102J50		CN6101	14P PLUG	KP200IA14L
	C6141, C6142		CCSQCH150J50				
	C6183		CCSQCH470J50				
	C6119		CCSQUJ060D50				
	C6118		CCSQUJ080D50				
	C6101, C6116		CCSQUJ150J50				
	C6106		CCSQUJ270J50				
	C6107, C6117		CCSQUJ330J50				
	C6185, C6186		CEANLR47M50				
	C6165, C6166, C6190		CEAS010M50				
	C6137, C6145, C6169, C6205		CEAS100M50				
	C6155		CEAS101M10				
	C6164, C6197, C6198		CEAS101M25				
	C6179, C6188		CEAS2R2M50				
	C6206		CEAS330M16				
	C6140, C6162, C6163, C6178, C6187		CEAS470M25				
	C6189		CEAS4R7M50				
	C6160, C6161, C6176		CEJA100M16				
	C6181		CEJA470M16				



SCH-9

FM/AM TUNER MODULE

SCH-9

FM/AM TUNER MODULE


To MAIN assy CN607

- This diagram is viewed from the pink colored foil side.
- This PCB is double sided.

- This diagram is viewed from the gray colored foil side.
- This PCB is double sided.

8. PANEL FACILITIES

FRONT PANEL FACILITIES




This unit is provided with an illuminated guide function.

Easy Operation Illumination Guide

When performing operations on pages designated with this mark, lighted or flashing indicators show which buttons should be pressed next, or which indicators should be changed next.


- ① Input selector buttons (CD/LD, VIDEO, AUX, PHONO, TUNER, TAPE, DAT/MD)
- ② SET button
- ③ MULTI JOG dial
- ④ VOLUME control
- ⑤ BALANCE control
- ⑥ AUTO TUNING button
- ⑦ FM/AM/STATION button
- ⑧ STATION MEMORY button
- ⑨ REMOTE SENSOR
- ⑩ Display
- ⑪ TIMER ON/OFF button
TIMER MODE button
[CLOCK ADJ. (adjust) buttons]
- ⑫ Headphone jack (PHONES)
- ⑬ SYSTEM POWER STANDBY/ON switch/STANDBY indicator
This is the switch for electric power.
ON: When set to the ON position, power is supplied and the unit becomes operational.
STANDBY: When set to the STANDBY position, the main power flow is cut and the unit is no longer fully operational. A minute flow of power feeds the unit to maintain operation readiness.
When only the time is indicated in the display section, the unit is in STANDBY.
- ⑭ SOURCE DIRECT (DEMO) button

DISPLAY SECTION



- ① TIMER REC indicator
Lights during recording timer setting.
- ② SLEEP indicator
Lights when the sleep timer is ON.
- ③ WAKE UP 1, 2 indicator
Lights to indicate the selected timer during wake up timer setting.
- ④ Displays station frequencies and operating status.
- ⑤ TUNED indicator
Lights when a broadcast station is received.
- ⑥ AUTO indicator
Lights during automatic tuning.
- ⑦ STEREO indicator
Lights during FM stereo broadcast reception.
- ⑧ MONO indicator
Lights when the remote control unit's MONO button is ON during stereo FM broadcast reception.
- ⑨ Displays time and operating status.

REMOTE CONTROL UNIT



- ① **CD/LD-SYSTEM selector switch**
- ② **SYSTEM POWER button**
- ③ **FUNC. button (input selector button)**
The input function switches in the following order each time the button is pressed:



- ④ **AUDIO button**
- ⑤ **DISPLAY button**
- ⑥ **Last memory button (LAST MEMO.)**
- ⑦ **RANDOM button**
- ⑧ **REPEAT button**
- ⑨ **GRAPHICS buttons (ON/OFF, CH MODE, SCROLL) (CLD-J990G only.)**
- ⑩ **DIRECT ON/OFF button**
- ⑪ **BASS SYN. (synthe) ON/OFF button**
- ⑫ **SFC MODE button**
- ⑬ **BASS SYN. (synthe) LEVEL buttons (-, +)**
- ⑭ **SFC LEVEL/DELAY buttons (-, +)**
- ⑮ **SCENE SELECTOR button**
- ⑯ **SLEEP button**
- ⑰ **VOLUME control button (+/ -)**
- ⑱ **KARAOKE buttons (K. MODE, ECHO, KEY CONTROL)**
- ⑲ **Number buttons**

⑳ TUNER operation buttons

- **FM/AM button**
- **MONO button** (functions as chapter/time (CHP/TIME) button when CD/LD-SYSTEM selector switch is set to CD/LD).
- **SCAN button** (functions as program (PGM) button when CD/LD-SYSTEM selector switch is set to CD/LD).

㉑ TAPE I operation buttons

- ▶ : Play
- ⏸ : Pause
- ⏮ : Fast forward/rewind button (functions as still/frame advance button when CD/LD-SYSTEM selector switch is set to CD/LD).
- : Stop (functions as REPEAT A-B button when CD/LD-SYSTEM selector switch is set to CD/LD).

㉒ TAPE II operation buttons

- ▶ : Play
- ⏸ : Pause
- ⏮ : Fast forward/rewind button (functions as fast forward/reverse button when CD/LD-SYSTEM selector switch is set to CD/LD).
- : Stop (functions as ONCE button when CD/LD-SYSTEM selector switch is set to CD/LD).

㉓ CD/LD operating buttons

- ▶ : Play
- ⏸ : Pause
- ⏮ : Track search
- : Stop

㉔ DISC SIDE A/B buttons

㉕ TEST TONE button

㉖ CENTER MODE button

㉗ Surround adjust buttons

- CENTER LEVEL (-/+)
- REAR LEVEL (-/+)

㉘ Dolby MODE button

REAR PANEL FACILITIES

① FM/AM ANTENNA terminals

Antennas must be connected to these terminals: otherwise you will not be able to receive stations.

② Input/Output jacks

VIDEO IN: Connect to the video output jack of the CD CDV LD player.

PHONO IN: Connect the output cord of the turntable to these jacks.

AUX IN: Enables connection to the video and audio output jacks of video components such as an LD player.

VIDEO:
OUT: Connect to VCR video and audio input jacks.
IN: Connect to VCR video and audio output jacks.

DAT/MD:
OUT: Connect to the analog audio input jacks of the digital audio tape deck.
IN: Connect to the analog audio output jacks of the digital audio tape deck.

MONITOR OUT:
Connect to the VIDEO input jacks of your television or video deck.

③ CENTER SPEAKER jack

Connect to the center speaker.

NOTE:

Connect a speaker system having a nominal impedance ranging from 8 Ω to 16 Ω or more.

④ SURROUND SPEAKERS jacks

Connect to the Surround speaker system.

NOTE:

Connect a speaker system having a nominal impedance of 16 Ω or more.

⑤ TWO VOLTAGE SELECTORS

⑥ AC OUTLET (UNSWITCHED 100 W MAX)

Power supplied through this outlet is turned on and off by the tuner amplifier's POWER switch. Total electrical power consumption of connected equipment should not exceed 100 W. The CD CDV LD player's power cord can be connected.

NOTE:

Do not connect appliances with high power consumption such as heaters, irons, monitors, or television sets to the AC OUTLET in order to avoid overheating or fire risk.

⑦ Power cord

Connect the power cord to a household power outlet.

⑧ SPEAKERS terminals

NOTE:

Connect a speaker system having a nominal impedance ranging from 8 Ω to 16 Ω .

⑨ CASSETTE DECK jack

Connect the cassette deck system cable here.

⑩ CLD PLAYER jack


Connect the CD CDV LD player system cable here.

⑪ Ground terminal (GND)

Connect the ground lead of the turntable here.

⑫ SOUND FIELD PROCESSOR jack

Connect the sound field processor cable here.



9. SPECIFICATIONS

■ STEREO TUNER AMPLIFIER

FM Tuner Section

Frequency range

SD and HL models 87.5 MHz to 108 MHz

S/DF model 76.0 MHz to 108 MHz

Antenna Input 75 Ω unbalanced

MW (AM) Tuner Section

Frequency range

SD and HL models

9 kHz step 531 kHz to 1,602 kHz

10 kHz step 530 kHz to 1,700 kHz

S/DF model

9 kHz step 522 kHz to 1,629 kHz

10 kHz step 530 kHz to 1,700 kHz

Antenna Loop antenna

Amplifier Section

Continuous average power output of 67 watts* per channel, min., at 8 ohms, from 70 Hz to 20,000 Hz with no more than 0.9 %** total harmonic distortion.

Continuous Power Output (RMS)

Front 100 W + 100 W (1 kHz, T.H.D 10 %, 8 Ω)

Rear 25 W (1 kHz, T.H.D 10 %, 16 Ω x 2)

Center 25 W (1 kHz, T.H.D 10 %, 8 Ω)

Peak music power 1600 W

Total Harmonic Distortion (1 kHz, 50 W, 8 Ω) 0.1 %**

* Measured pursuant to the Federal Trade Commission's Trade Regulation rule on Power Output Claims for Amplifiers.

** Measured By Audio Spectrum Analyzer.

Power Supply/Miscellaneous

Power requirements

SD and S/DF models AC 110/120 – 127/220 – 230/240 V (switchable), 50/60 Hz

HL model AC 220 – 230/240 V (switchable), 50/60 Hz

Power consumption 240 W

AC outlets: unswitched (x 1) 100 W MAX

Dimensions 360 (W) x 366.5 (D) x 135 (H) mm

Weight 7.8 kg