


PIONEER®
The Art of Entertainment



Service Manual



ORDER NO.
ARP2139

STEREO TWIN CD CASSETTE DECK AMPLIFIER


XD-Z84T

MODEL XD-Z84T HAS FOLLOWING VERSIONS :

Type	Power requirement	Export destination
HE	AC220V, 240V (Switchable) *	European continent
HEWZIW	AC220V, 240V (Switchable) *	Germany and Italy

* Change the jumper wires of assembly board.

- This manual is applicable to the XD-Z84T/HE and HEWZIW types.
- As to the HEWZIW type, refer to pages 80 and 81.
- This product is a component of a system. As to the system composition, refer to the system manual.
- As to the MECHANISM DESCRIPTION, refer to the PD-Z74T service guide (ARP2144).
- For adjustment refer to ADJUSTMENTS FOR XD-Z54T, XD-Z84T, DC-Z94, DC-Z84 and DC-Z74 (ARP2140).



Free service manuals
Gratis schema's

Digitized by

www.freesevicemanuals.info

CONTENTS

1. SAFETY INFORMATION	2	4. P.C.B 's PARTS LIST	71
2. EXPLODED VIEWS, PACKING AND PARTS LIST	3	5. IC INFORMATION	78
3. SCHEMATIC DIAGRAM AND P.C.BOARDS CONNECTION DIAGRAM	23	6. FOR HEWZIW TYPE	80
		7. PANEL FACILITIES	82
		8. SPECIFICATIONS	88

PIONEER ELECTRONIC CORPORATION 4-1, Meguro 1-Chome, Meguro-ku, Tokyo 153, Japan

PIONEER ELECTRONICS SERVICE INC. P.O. Box 1760, Long Beach, California 90801 U.S.A.

PIONEER ELECTRONICS OF CANADA, INC. 505 Cochrane Drive, Markham, Ontario L3R 8E3 Canada

PIONEER ELECTRONIC [EUROPE] N.V. Keetberglaan 1, 2740 Beveren, Belgium

PIONEER ELECTRONICS AUSTRALIA PTY. LTD. 178-184 Boundary Road, Braeside, Victoria 3195, Australia TEL: [03] 580-9911

© **PIONEER ELECTRONIC CORPORATION 1991**

YV JAN. 1991 Printed in Japan.

1. SAFETY INFORMATION

(FOR EUROPEAN MODEL ONLY)

VARO!

AVATTAESSA JA SUOJALUKITUS
OHITETTAESSA OLET ALTTIINA
NÄKYMÄTTÖMÄLLE LASERSÄTEILYLLE.
ÄLÄ KATSO SÄTEESEEN.

ADVERSEL:

USYNLIG LASERSTRÅLING VED ÅBNING
NÅR SIKKERHEDSAFBRYDERE ER UDE AF
FUNKTION UNDGÅ UDSÆTTELSE FOR
STRÅLING.

VARNING!

OSYNLIG LASERSTRÅLNING NÅR DENNA
DEL ÄR ÖPPNAD OCH SPÄRREN
ÄR URKOPPLAD. BETRAKTA EJ STRÅLEN.



LASER
Kuva 1
Lasersäteilyn
varoituserkki

WARNING!

DEVICE INCLUDES LASER DIODE WHICH
EMITS INVISIBLE INFRARED RADIATION
WHICH IS DANGEROUS TO EYES. THERE IS
A WARNING SIGN ACCORDING TO PICTURE
1 INSIDE THE DEVICE CLOSE TO THE LASER
DIODE.



LASER
Picture 1
Warning sign for
laser radiation


IMPORTANT

THIS PIONEER APPARATUS CONTAINS
LASER OF HIGHER CLASS THAN 1.
SERVICING OPERATION OF THE APPARATUS
SHOULD BE DONE BY A SPECIALLY
INSTRUCTED PERSON.

LASER DIODE CHARACTERISTICS

MAXIMUM OUTPUT POWER: 5 mw
WAVELENGTH: 780-785 nm

LABEL CHECK (TWIN type)



HE, HEWZIW and HB types

Additional Laser Caution

1. Laser Interlock Mechanism

The ON/OFF (ON: low level/OFF: high level) status of the U (S601) and L (S603) switches for detecting the disc clamp state is detected by the system microprocessor, and the design prevents laser diode oscillation when both switches U and L are OFF (high level).

Thus, the interlock will no longer function if switches U (S601) and L (S603) are deliberately shorted.

Laser diode oscillation will continue if pins 2 and 3 of CXA1471S (IC101) are connected to ground or pin 20 is connected to high level (ON) or the terminals of Q101 are shorted to each other (fault condition).


2. When the cover is opened, close viewing of the objective lens with the naked eye will cause exposure to a Class 1 or higher laser beam.



HE and HEWZIW types



HB type




HE, HB and HEWZIW types

2. EXPLODED VIEWS, PACKING AND PARTS LIST


- NOTES:
- Parts without part number cannot be supplied.
 - The  mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
 - Parts marked by "⊙" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.

2.1 PACKING

Parts list of Packing			
Mark	No.	Description	Parts No.
	1	FRONT PAD L, R	AHA1406
	2	REAR PAD L, R	AHA1407
	3	PACKING CASE	AHD1968
	4	OPERATING INSTRUCTIONS (Duch, Swedish, Spanish, Portuguese)	ARC1242
	5	OPERATING INSTRUCTIONS (English, German, French, Italian)	ARE1173
	6	CAUTION CARD	ARM1003
	7	REMOTE CONTROL UNIT (CU-DC022)	AXD1183
	8	BATTERY COVER	AZN1846
101		BATTERY (R03, AAA)	
102		PACKING SHEET	



2.2 GENERAL BLOCK




Parts list of General block			
Mark	No.	Description	Parts No.
	1	SCREW	ABA-298
	2	SCREW (STEEL)	ABA1007
	3	SCREW (STEEL)	ABA1009
	4	SCREW	ABA1082
	5	AC POWER CORD	ADG1049
	6	STRAIN RELIEF	AEC-882
	7	TRANS CONNECT ASSEMBLY	
	8	TERMINAL SCREW	
	9	REAR PANEL	
	10	BONNET	ANE1275
	11	PLATE L	ANG1536
	12	PLATE R	ANG1537
	13	SUB TRANS ASSEMBLY	AWR1056
	14	SCREW	BBZ30P080FZK
	15	SCREW	VPZ30P080FMC
	16	SCREW	VPZ30P080FZK
	17	FUSE (T2A, FU101)	AEK-017
	18	FUSE (T1.6A, FU102)	AEK-405
	19	POWER TRANSFORMER (T2001)	ATS1321
	20	WASHER	ABE-052
	21	CUSHION RUBBER M	

2.3 DECK AMP BLOCK

Parts list of Deck amp block


Mark	No.	Description	Parts No.	Mark	No.	Description	Parts No.
	1	ROTARY KNOB	AAB1136		46	PRESSURE METAL	
	2	VOL KNOB	AAB1200		47	HEAT SINK HOLDER A	
	3	ROTARY KNOB	AAB1202		48	PCB HOLDER	
	4	POWER BUTTON	AAD1674		49	HOLDER	
	5	KIN BUTTON	AAD1682		50	HEAT SINK	
	6	FUNCTION BUTTON	AAD1894		51	SHIELD PLATE (MECHA)	
	7	REC. COPY BUTTON	AAD1895		52	SHIELD PLATE	
	8	DECK PLAY BUTTON	AAD1896		53	DISPLAY ASSEMBLY	AWZ3351
	9	EJECT BUTTON L	AAD1898		54	1 MECHA SW ASSEMBLY	
	10	GEQ BUTTON	AAD1899		55	2 MECHA SW ASSEMBLY	
	11	CURSOR BUTTON	AAD1900		56	MIC BALANCE ASSEMBLY	
	12	AI BUTTON	AAD1901		57	1 MECHA ASSEMBLY	
	13	EJECT BUTTON R	AAD1922		58	2 MECHA ASSEMBLY	
	14	LENS (POWER IND)	AAK1800		59	1 MECHA UNIT	EXK2020
	15	FILTER (REC)	AAK1812		60	2 MECHA UNIT	EXK2010
	16	DECORATIVE PLATE (DOOR)	AAK2065		61	DAMPER ASSEMBLY	AXA1008
	17	DECORATIVE PLATE A (DECK)	AAK2071		62	SCREW	BPZ26P080FMC
	18	DECORATIVE PLATE B (DECK)	AAK2072		63	NUT	NK90FUC
	19	AI DECORATIVE PLATE	AAK2073		64	SCREW	PCZ30P040FMC
	20	DECORATIVE PLATE (GEQ)	AAK2074		65	SCREW	VPZ30P080FMC
	21	INDICATOR LENS	AAK2075		66		
	22	AF ASSEMBLY	AWZ3336		67	FUSE (T1.6A, FU151)	AEK-405
	23	CASSETTE DOOR (R)	AAN1250		68	FUSE (T1.6A, FU152)	AEK-405
	24	CASSETTE DOOR (L)	AAN1251				
	25	COUNTER	AAW1009				
	26	GEQ ASSEMBLY	AWX1048				
	27	VR ASSEMBLY					
	28	FABEL (PAPER)	AAX1301				
	29	SCREW	ABA-298				
	30	SCREW (STEEL)	ABA1009				
	31	SCREW (STEEL)	ABA1011				
	32	SCREW	ABA1018				
	33	SCREW (STEEL)	ABA1095				
	34	DOOR SPRING L	ABH1068				
	35	DOOR SPRING R	ABH1069				
	36	KEEP PLATE	ABK1016				
	37	NUT	ABN1016				
	38	GROUND LEAD					
	39	GROUND LEAD					
	40	COUNTER BELT	AEB1161				
	41	HEAD PHONE ASSEMBLY					
	42	NYLON RIVET	AEC1160				
	43	FRONT PANEL	AMB1745				
	44	PACK HOLDER					
	45	HEAT SINK HOLDER B					



2.4 1 MECHA UNIT (EXK2020)

Parts list of 1 Mecha unit

Mark	No.	Description	Parts No.	Mark	No.	Description	Parts No.
	1	FLYWHEEL UNIT (FWD)	EXA1102		46	SCREW (M2×8)	ATZ20P080FMC
	2	FLYWHEEL UNIT (RVS)	EXA1103		47	SCREW	BSZ20P050FMC
	3	ROLLER UNIT (FWD)	EXA1104		48	SCREW	PMS26P025FUC
	4	ROLLER UNIT (RVS)	EXA1105		49	WASHER	EBF1008
	5	LIMITER UNIT	EXA1106		50	WASHER	EBF1009
	6	LEVER UNIT	EXA1107		51	WASHER	EBF1010
	7	ARM	AZN2063		52	WASHER	EBF1011
	8	NR LEVER	ENV1155		53		
	9	BRAKE	ENV1157		54	ARM UNIT	EXX1002
	10	CAM GEAR	ENV1158		55	ARM UNIT	EXX1003
	11	LOCK ARM	ENV1159		56	P HEAD ASSEMBLY	EXX1005
	12	NR ARM	ENV1163				
	13	REEL COLLAR	ENV1164				
	14	REEL	ENV1170				
	15	REEL BUSH	ENV1178				
	16	ARM	ENV1181		101	HEAD BASE	
	17	ARM	AZN2069		102	BRACKET	
	18	BUSH	ENV1184		103	PLATE	
	19	MAGNET	ENV1185		104	BRACKET	
	20	BELT	ENT1015		105	ARM	
	21	SPRING	EBH1201		106	HOLDER	
	22	SPRING	EBH1202		107	HOLDER	
	23	SPRING	EBH1203		108	GEAR	
	24	SPRING	EBH1204		109	P HEAD UNIT	
	25	SPRING	EBH1208		110	SCREW	
	26	SPRING	EBH1209		111	SCREW	
	27	SPRING	EBH1210		112	CHASSIS UNIT	
	28	SPRING	EBH1211				
	29	SPRING	EBH1255				
	30	SPRING	EBH1213				
	31	SPRING	EBH1220				
	32	SPRING	EBH1256				
	33	SPRING	EBL1013				
	34	SPRING	EBL1014				
	35	MOTOR UNIT	EXA1108				
	36	SWITCH (Detect)	ESN1003				
	37	SWITCH (Mode)	ESN1004				
	38	SOLENOID	EXP1005				
	39	HALL IC	DN6847SE				
	40	P.C.BOARD	ENX1002				
	41	CONNECTOR	EKS1013				
	42	LEAD WIRE	EDD1003				
	43	CONNECTOR	EDE1009				
	44	SCREW	EBA1020				
	45	SCREW	EBA1021				




2.5 2 MECHA UNIT (EXK2010)

Parts list of 2 Mecha unit

Mark	No.	Description	Parts No.	Mark	No.	Description	Parts No.
	1	FLYWHEEL UNIT (FWD)	EXA1102		46	SCREW (M2×8)	ATZ20P080FMC
	2	FLYWHEEL UNIT (RVS)	EXA1103		47	SCREW	BSZ20P050FMC
	3	ROLLER UNIT (FWD)	EXA1104		48	SCREW	PMS26P025FUC
	4	ROLLER UNIT (RVS)	EXA1105		49	WASHER	EBF1008
	5	LIMITER UNIT	EXA1106		50	WASHER	EBF1009
	6	LEVER UNIT	EXA1107		51	WASHER	EBF1010
	7	ARM	AZN2064		52	WASHER	EBF1011
	8	NR LEVER	ENV1155		53		
	9	BRAKE	ENV1157		54	ARM UNIT	EXX1002
	10	CAM GEAR	ENV1158		55	ARM UNIT	EXX1003
	11	LOCK ARM	ENV1159		56	R/P HEAD ASSEMBLY	EXX1004
	12	NR ARM	ENV1163				
	13	REEL COLLAR	ENV1164				
	14	REEL	ENV1170				
	15	REEL BUSH	ENV1178				
	16	ARM	ENV1181		101	HEAD BASE	
	17	ARM	AZN2070		102	BRACKET	
	18	BUSH	ENV1184		103	PLATE	
	19	MAGNET	ENV1185		104	BRACKET	
	20	BELT	ENT1015		105	ARM	
	21	SPRING	EBH1201		106	HOLDER	
	22	SPRING	EBH1202		107	HOLDER	
	23	SPRING	EBH1203		108	GEAR	
	24	SPRING	EBH1204		109	R/P HEAD UNIT	
	25	SPRING	EBH1208		110	SCREW	
	26	SPRING	EBH1209		111	SCREW	
	27	SPRING	EBH1210		112	CHASSIS UNIT	
	28	SPRING	EBH1211				
	29	SPRING	EBH1254				
	30	SPRING	EBH1213				
	31	SPRING	EBH1220				
	32	SPRING	EBH1256				
	33	SPRING	EBL1013				
	34	SPRING	EBL1014				
	35	MOTOR UNIT	EXA1108				
	36	SWITCH (Detect)	ESN1003				
	37	SWITCH (Mode)	ESN1004				
	38	SOLENOID	EXP1005				
	39	HALL IC	DN6847SE				
	40	P.C.BOARD	ENX1002				
	41	CONNECTOR	EKS1012				
	42	LEAD WIRE	EDD1003				
	43	CONNECTOR	EDE1008				
	44	SCREW	EBA1020				
	45	SCREW	EBA1021				


Note :
When removing the chassis unit to replace the arm unit (EXX1003), the chassis unit can be easily removed by cutting the (A) part of No.55 (1/2) with a nippers, etc. (see following illustration).



2.6 CD BLOCK

Parts list of CD block


Mark	No.	Description	Parts No.
A	1	SCREW	BBZ30P060FMC
	2	SCREW	BBZ30P080FZK
	3	SCREW	BBZ30P100FMC
	4	SCREW	BBZ30P120FMC
	5	SCREW	IBZ30P150FMC
	6	DISC BUTTON	PAC1522
	7	PLAY BUTTON	PAC1524
	8	WINDOW	PAM1454
	9	30P F·F·C/30V	PDD1049
	10	SCREW	PDZ30P050FMC
	11	SPACER	
	12		
	13	UNDER BASE	
	14	ANGLE	
	15	NAME PLATE 1	PNW1866
B	16	NAME PLATE 2	PNW1867
	17	FUNCTION PANEL	
	18	PCB SPACER	
	19	MOTHER BOARD ASSEMBLY	PWM1349
	20	SUB BOARD ASSEMBLY	PWX1143
	21	FOOT ASSEMBLY	PXA1201
	22	INSULATOR ASSEMBLY	PXA1343
	23	TWIN TORAY MECHA ASSEMBLY	



2.7 REMOVING AND MOUNTING EACH BLOCK

● REMOVAL OF TRAY I AND TRAY II

1. Open the tray I.
2. Insert the flat blade screwdriver into the slit in the left of tray I. Pull out the tray I by pushing the screwdriver.



* When remove the tray II, open it first, insert the flat blade screwdriver into the slit in the right of tray II, and pull out the tray by pushing the screwdriver.




Fig. 1

● MOUNTING OF TRAY I

1. Set the disc II to the clamp position and open the tray I.
2. Align the 1st tooth of tray I to ungrooved portion of gear I, and insert the tray I.





Fig. 2

● MOUNTING OF TRAY II

1. Set the disc I to the clamp position and open the tray II.
2. Align the 1st tooth of tray II to □ marked position of gear II, and insert the tray II.



Free service manuals
Gratis schema's
Fig. 3

Digitized by

www.freemove.com

● MOUNTING AND POSITIONING OF MAIN CAM, FOLLOW GEAR, GEAR I AND GEAR II

Set the following gears to the position as shown by arrows.




Fig. 4

● MOUNTING OF CLAMPER ASSEMBLY

Mount the clumper assembly by aligning the protrusion portion as shown in the figure.




Fig. 5

2.8 CD MECHA UNIT


Parts List of Mechanism Section

Mark	No.	Symbol & Description	Part No.	Mark	No.	Symbol & Description	Part No.
1	Clamp spring	PBH1103	101	Yoke	106	Servo mechanism assembly	
2	Lever spring	PBH1104	107	Connector assembly (6P)	109	Motor base	
3	Belt	PEB1106	108	Mechanism chassis	110	Mechanism base	
4	Motor pulley	PNW1634	109	Motor base	111	Actuator cover	
5	Tray 1	PNW1839	110	Mechanism base	112	Sub panel plate	
6	Tray 2	PNW1840					
7	Sub tray	PNW1841					
8	Loading base	PNW1842					
9	Main cam	PNW1843					
10	Follow gear	PNW1844					
11	Gear 1	PNW1845					
12	Gear 2	PNW1846					
13	Idler gear	PNW1847					
14	Clamper arm U	PNW1850					
15	Clamper arm B	PNW1851					
16	Clamp cam	PNW1852					
17	Float base	PNW1853					
18	Lock lever	PNW1854					
19	Motor	PXM1010					
20	Floating rubber	PEB1014					
21	Floating rubber	PEB1132					
22	Screw	PBA1048					
23	Screw	IPZ30P080FMC					
24	Screw	IPZ20P080FMC					
25	Chip capacitor	CKSYF105Z16					
26	Screw	JFZ20P025FMC					
27	Drive spring	PBH1084					
28	Plate spring	PBK1057					
29	Belt	PEB1072					
30	Drive screw	PLA1003					
31	Guide bar	PLA1071					
32	Half nut	PNW1605					
33	Disc table	PNW1608					
34	Pulley	PNW1634					
35	Earth spring	PBH1009					
36	Push switch	DSG1014					
37	Spindle motor assembly (with oil)	PEA1028					
38	Pick-up assembly	PEA1030					
39	Screw	BPZ20P080FZK					
40	Screw	PMZ20P030FMC					
41	Motor (CARRIAGE)	PXM1013					
42	Screw	PBZ30P080FMC					
43	Semi-fixed resistor	PCP1008					
44	Screw	PMZ26P040FMC					
45	Gear pulley	PNW1848					
46	Push spring	PBH1105					
47	Screw	IBZ30P200FMC					
48	Pulley	PNW1066					
49	Screw	IPZ30P120FMC					

• How to install the disc table


1 Use nippers or other tool to cut the two sections marked A in figure 1. Then remove the spacer.

2 While supporting the spindle motor shaft with the stopper, put spacer on top of the motor base (angled so it doesn't touch section B), and stick the disc table on top (takes about 9kg pressure). Take off the spacer.



3. SCHEMATIC DIAGRAM AND P.C.BOARDS CONNECTION DIAGRAM

3.1 OVER ALL SCHEMATIC DIAGRAM



Note:
Refer to page54 for
LINE VOLTAGE SELECTION.


- RESISTORS:**
Indicated in Ω , $\frac{1}{4}W$, $\frac{1}{2}W$, $\pm 5\%$ tolerance unless otherwise noted k:k Ω ,
M:M Ω , (F): $\pm 1\%$, (G): $\pm 2\%$, (K): $\pm 10\%$ (M): $\pm 20\%$ tolerance
- CAPACITORS:**
Indicated in capacity (μF)/voltage (V) unless otherwise noted p:pF
Indication without voltage is 50V except electrolytic capacitor.
- VOLTAGE, CURRENT:**
Signal voltage at (45 W + 45 W 8 Ω) output (1kHz)
DC voltage (V) at no input signal
Value in () is DC voltage at rated power.
mA: DC current at no input signal
- OTHERS:**
Signal route.
Adjusting point.
The mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
marked capacitors and resistors have parts numbers.

This is the basic schematic diagram, but the actual circuit may vary due to improvements in design.

SWITCHES:




DISPLAY assembly	1 MECHA SW assembly
S1504 POWER	S1551 1 REV
S1505 VIDEO	S1552 1 PLAY
S1506 CD DIRECT	S1553 1 STOP
S1507 FADE/FINE	S1554 1 REW
S1510 AI MEMO	S1555 1 FF
S1511 AI BGM	
S1512 PHONO	
S1513 2 REC MUTE	
S1514 DISCO	
S1516 SURR	
S1517 TAPE	
S1518 2 REC	
S1519 X2 COPY	
S1522 CD	
S1523 TX	
S1524 2 PAUSE	
S1525 X1 COPY	
S1528 DOLBY NR ON/OFF	
S1529 COM-A-B	
S1530 MILD	
S1531 VIVID	
S1532 FLAY	
S1533 /D	
S1534 /B	
S1535 MEMOLY	
S1537 EQ ON/OFF	
S1538 LEVEL UP	
S1539 F DOWN	
S1540 WARM	
S1541 SHARP	
S1542 /E	
S1543 /C	
S1544 /A	
S1546 PGM/PRESET	
S1547 F UP	
S1548 LEVEL DOWN	
S1549 ACTIVE LOUNNESS	

Free service manuals
Gratis schema's
Digitized by
www.freemove.com



DISPLAY assembly (AW53351)

(To page 47)
To AF assembly CMI



3.2 DISPLAY (AWZ3351), 1 MECHA SW, 2 MECHA SW assembly,
1 MECHA UNIT (EXK2020) and 2 MECHA UNIT (EXK2010)

A

- NOTE
- This P.C.B connection diagram is viewed from the parts mounted side.
 - The parts which have been mounted on the board can be replaced with those shown with the corresponding wiring symbols listed in the following Table.

P.C.B. pattern diagram indication	Corresponding part symbol	Part Name
		Transistor
		Radiator type transistor
		Diode
		Resistor
		Capacitor (Polarity)
		Capacitor (Non-polarity)

B


Others

P.C.B. pattern diagram indication	Part Name
IC	IC
S	Switch
RY	Relay
L	Coil
F	Filter
VR	Variable resistor or Semi-fixed resistor


- The capacitor terminal marked with (C) (double circles) shows negative terminal.
- The diode terminal marked with (C) (double circles) shows cathode side.
- The transistor terminal to which E is affixed shows the emitter.

C


2 MECHA SW assembly




1 MECHA SW assembly



D



30



To AF assembly CN12
(To page 47)

DISPLAY assembly (AWZ3351)


To AF assembly CN10
(To page 47)

To AF assembly CN11
(To page 47)

When the motor is activated 11.5V
When the motor is stop 0.6V

When the motor is stop 0V
When the motor is activated 4.7V

When the motor is stop 0.6V
When the motor is actd 11.5V



1 MECHA unit
(EXK2020) (1/2)

2 MECHA unit
(EXK2010) (1/2)

Free service manuals
Gratis schema's
Digitized by

www.freemove.com





3.3 GEQ (AWX1048), 1 MECHA and 2 MECHA assembly

A

B

C

D



GEQ assembly (AWX1048)

NOTE


1. This P.C.B. connection diagram is viewed from the parts mounted side.
2. The parts which have been mounted on the board can be replaced with those shown with the corresponding wiring symbols listed in the following Table.



P.C.B. pattern diagram indication	Corresponding part symbol	Part Name
		Transistor
		Radiator type transistor
		Diode
		Resistor
		Capacitor (Polarity)
		Capacitor (Non-polarity)

Others

P.C.B. pattern diagram indication	Part Name
	IC
	Switch
	Relay
	Coil
	Filter
	Variable resistor or Semi-fixed resistor

3. The capacitor terminal marked with ⊕ (double circles) shows negative terminal.
4. The diode terminal marked with ⊕ (double circles) shows cathode side.
5. The transistor terminal to which E is affixed shows the emitter.





Free service manuals
Gratis schema's
Digitized by
www.freeservicemanuals.info

Free service manuals
Gratis schema's

Digitized by

www.freecservicemanuals.info

3.4 AF (AWZ3336), HEAD PHONE, VR and MIC BALANCE assembly

A

NOTE

1. This P.C.B connection diagram is viewed from the parts mounted side.

2. The parts which have been mounted on the board can be replaced with those shown with the corresponding wiring symbols listed in the following Table.

P.C.B. pattern diagram indication	Corresponding part symbol	Part Name
EO 0504		Transistor
Q215		Radiator type transistor
D203		Diode
R237		Resistor
C513		Capacitor (Polarity)
C518		Capacitor (Non-polarity)

B



Others

P.C.B. pattern diagram indication	Part Name
IC	IC
S	Switch
RY	Relay
L	Coil
F	Filter
VR	Variable resistor or Semi-fixed resistor

3. The capacitor terminal marked with ⊖ (double circles) shows negative terminal.


4. The diode terminal marked with ⊕ (double circles) shows cathode side.

5. The transistor terminal to which E is affixed shows the emitter.






TRANS CONNECT assembly




Description	Part No.
220V label	AAX-193
240V label	AAX-192

 AC POWER CORD
AC 220V/240V
50/60Hz 




Free service manuals
Gratis schema's
Digitized by
www.freeservicemanuals.info



POWER TRANSFORMER




Free service manuals
Gratis schema's
Digitized by
www.freescvicemanuals.info



Note :
See pages 83,84 for the semiconductor's without
voltage indication.




MOTHER P.C.B assembly (PWX1343)
(To page 38)
To AF assembly 118





To Deck amplifier Block
AF assembly 113
(To page 38)

IC101
IC102
IC103
IC104
IC105
IC106
IC107
IC108
IC109
IC110
IC111
IC112
IC113
IC114
IC115
IC116
IC117
IC118
IC119
IC120
IC121
IC122
IC123
IC124
IC125
IC126
IC127
IC128
IC129
IC130
IC131
IC132
IC133
IC134
IC135
IC136
IC137
IC138
IC139
IC140
IC141
IC142
IC143
IC144
IC145
IC146
IC147
IC148
IC149
IC150
IC151
IC152
IC153
IC154
IC155
IC156
IC157
IC158
IC159
IC160
IC161
IC162
IC163
IC164
IC165
IC166
IC167
IC168
IC169
IC170
IC171
IC172
IC173
IC174
IC175
IC176
IC177
IC178
IC179
IC180
IC181
IC182
IC183
IC184
IC185
IC186
IC187
IC188
IC189
IC190
IC191
IC192
IC193
IC194
IC195
IC196
IC197
IC198
IC199
IC200
IC201
IC202
IC203
IC204
IC205
IC206
IC207
IC208
IC209
IC210
IC211
IC212
IC213
IC214
IC215
IC216
IC217
IC218
IC219
IC220
IC221
IC222
IC223
IC224
IC225
IC226
IC227
IC228
IC229
IC230
IC231
IC232
IC233
IC234
IC235
IC236
IC237
IC238
IC239
IC240
IC241
IC242
IC243
IC244
IC245
IC246
IC247
IC248
IC249
IC250
IC251
IC252
IC253
IC254
IC255
IC256
IC257
IC258
IC259
IC260
IC261
IC262
IC263
IC264
IC265
IC266
IC267
IC268
IC269
IC270
IC271
IC272
IC273
IC274
IC275
IC276
IC277
IC278
IC279
IC280
IC281
IC282
IC283
IC284
IC285
IC286
IC287
IC288
IC289
IC290
IC291
IC292
IC293
IC294
IC295
IC296
IC297
IC298
IC299
IC300
IC301
IC302
IC303
IC304
IC305
IC306
IC307
IC308
IC309
IC310
IC311
IC312
IC313
IC314
IC315
IC316
IC317
IC318
IC319
IC320
IC321
IC322
IC323
IC324
IC325
IC326
IC327
IC328
IC329
IC330
IC331
IC332
IC333
IC334
IC335
IC336
IC337
IC338
IC339
IC340
IC341
IC342
IC343
IC344
IC345
IC346
IC347
IC348
IC349
IC350
IC351
IC352
IC353
IC354
IC355
IC356
IC357
IC358
IC359
IC360
IC361
IC362
IC363
IC364
IC365
IC366
IC367
IC368
IC369
IC370
IC371
IC372
IC373
IC374
IC375
IC376
IC377
IC378
IC379
IC380
IC381
IC382
IC383
IC384
IC385
IC386
IC387
IC388
IC389
IC390
IC391
IC392
IC393
IC394
IC395
IC396
IC397
IC398
IC399
IC400
IC401
IC402
IC403
IC404
IC405
IC406
IC407
IC408
IC409
IC410
IC411
IC412
IC413
IC414
IC415
IC416
IC417
IC418
IC419
IC420
IC421
IC422
IC423
IC424
IC425
IC426
IC427
IC428
IC429
IC430
IC431
IC432
IC433
IC434
IC435
IC436
IC437
IC438
IC439
IC440
IC441
IC442
IC443
IC444
IC445
IC446
IC447
IC448
IC449
IC450
IC451
IC452
IC453
IC454
IC455
IC456
IC457
IC458
IC459
IC460
IC461
IC462
IC463
IC464
IC465
IC466
IC467
IC468
IC469
IC470
IC471
IC472
IC473
IC474
IC475
IC476
IC477
IC478
IC479
IC480
IC481
IC482
IC483
IC484
IC485
IC486
IC487
IC488
IC489
IC490
IC491
IC492
IC493
IC494
IC495
IC496
IC497
IC498
IC499
IC500
IC501
IC502
IC503
IC504
IC505
IC506
IC507
IC508
IC509
IC510
IC511
IC512
IC513
IC514
IC515
IC516
IC517
IC518
IC519
IC520
IC521
IC522
IC523
IC524
IC525
IC526
IC527
IC528
IC529
IC530
IC531
IC532
IC533
IC534
IC535
IC536
IC537
IC538
IC539
IC540
IC541
IC542
IC543
IC544
IC545
IC546
IC547
IC548
IC549
IC550
IC551
IC552
IC553
IC554
IC555
IC556
IC557
IC558
IC559
IC560
IC561
IC562
IC563
IC564
IC565
IC566
IC567
IC568
IC569
IC570
IC571
IC572
IC573
IC574
IC575
IC576
IC577
IC578
IC579
IC580
IC581
IC582
IC583
IC584
IC585
IC586
IC587
IC588
IC589
IC590
IC591
IC592
IC593
IC594
IC595
IC596
IC597
IC598
IC599
IC600
IC601
IC602
IC603
IC604
IC605
IC606
IC607
IC608
IC609
IC610
IC611
IC612
IC613
IC614
IC615
IC616
IC617
IC618
IC619
IC620
IC621
IC622
IC623
IC624
IC625
IC626
IC627
IC628
IC629
IC630
IC631
IC632
IC633
IC634
IC635
IC636
IC637
IC638
IC639
IC640
IC641
IC642
IC643
IC644
IC645
IC646
IC647
IC648
IC649
IC650
IC651
IC652
IC653
IC654
IC655
IC656
IC657
IC658
IC659
IC660
IC661
IC662
IC663
IC664
IC665
IC666
IC667
IC668
IC669
IC670
IC671
IC672
IC673
IC674
IC675
IC676
IC677
IC678
IC679
IC680
IC681
IC682
IC683
IC684
IC685
IC686
IC687
IC688
IC689
IC690
IC691
IC692
IC693
IC694
IC695
IC696
IC697
IC698
IC699
IC700
IC701
IC702
IC703
IC704
IC705
IC706
IC707
IC708
IC709
IC710
IC711
IC712
IC713
IC714
IC715
IC716
IC717
IC718
IC719
IC720
IC721
IC722
IC723
IC724
IC725
IC726
IC727
IC728
IC729
IC730
IC731
IC732
IC733
IC734
IC735
IC736
IC737
IC738
IC739
IC740
IC741
IC742
IC743
IC744
IC745
IC746
IC747
IC748
IC749
IC750
IC751
IC752
IC753
IC754
IC755
IC756
IC757
IC758
IC759
IC760
IC761
IC762
IC763
IC764
IC765
IC766
IC767
IC768
IC769
IC770
IC771
IC772
IC773
IC774
IC775
IC776
IC777
IC778
IC779
IC780
IC781
IC782
IC783
IC784
IC785
IC786
IC787
IC788
IC789
IC790
IC791
IC792
IC793
IC794
IC795
IC796
IC797
IC798
IC799
IC800
IC801
IC802
IC803
IC804
IC805
IC806
IC807
IC808
IC809
IC810
IC811
IC812
IC813
IC814
IC815
IC816
IC817
IC818
IC819
IC820
IC821
IC822
IC823
IC824
IC825
IC826
IC827
IC828
IC829
IC830
IC831
IC832
IC833
IC834
IC835
IC836
IC837
IC838
IC839
IC840
IC841
IC842
IC843
IC844
IC845
IC846
IC847
IC848
IC849
IC850
IC851
IC852
IC853
IC854
IC855
IC856
IC857
IC858
IC859
IC860
IC861
IC862
IC863
IC864
IC865
IC866
IC867
IC868
IC869
IC870
IC871
IC872
IC873
IC874
IC875
IC876
IC877
IC878
IC879
IC880
IC881
IC882
IC883
IC884
IC885
IC886
IC887
IC888
IC889
IC890
IC891
IC892
IC893
IC894
IC895
IC896
IC897
IC898
IC899
IC900
IC901
IC902
IC903
IC904
IC905
IC906
IC907
IC908
IC909
IC910
IC911
IC912
IC913
IC914
IC915
IC916
IC917
IC918
IC919
IC920
IC921
IC922
IC923
IC924
IC925
IC926
IC927
IC928
IC929
IC930
IC931
IC932
IC933
IC934
IC935
IC936
IC937
IC938
IC939
IC940
IC941
IC942
IC943
IC944
IC945
IC946
IC947
IC948
IC949
IC950
IC951
IC952
IC953
IC954
IC955
IC956
IC957
IC958
IC959
IC960
IC961
IC962
IC963
IC964
IC965
IC966
IC967
IC968
IC969
IC970
IC971
IC972
IC973
IC974
IC975
IC976
IC977
IC978
IC979
IC980
IC981
IC982
IC983
IC984
IC985
IC986
IC987
IC988
IC989
IC990
IC991
IC992
IC993
IC994
IC995
IC996
IC997
IC998
IC999
IC1000
IC1001
IC1002
IC1003
IC1004
IC1005
IC1006
IC1007
IC1008
IC1009
IC1010
IC1011
IC1012
IC1013
IC1014
IC1015
IC1016
IC1017
IC1018
IC1019
IC1020
IC1021
IC1022
IC1023
IC1024
IC1025
IC1026
IC1027
IC1028
IC1029
IC1030
IC1031
IC1032
IC1033
IC1034
IC1035
IC1036
IC1037
IC1038
IC1039
IC1040
IC1041
IC1042
IC1043
IC1044
IC1045
IC1046
IC1047
IC1048
IC1049
IC1050
IC1051
IC1052
IC1053
IC1054
IC1055
IC1056
IC1057
IC1058
IC1059
IC1060
IC1061
IC1062
IC1063
IC1064
IC1065
IC1066
IC1067
IC1068
IC1069
IC1070
IC1071
IC1072
IC1073
IC1074
IC1075
IC1076
IC1077
IC1078
IC1079
IC1080
IC1081
IC1082
IC1083
IC1084
IC1085
IC1086
IC1087
IC1088
IC1089
IC1090
IC1091
IC1092
IC1093
IC1094
IC1095
IC1096
IC1097
IC1098
IC1099
IC1100
IC1101
IC1102
IC1103
IC1104
IC1105
IC1106
IC1107
IC1108
IC1109
IC1110
IC1111
IC1112
IC1113
IC1114
IC1115
IC1116
IC1117
IC1118
IC1119
IC1120
IC1121
IC1122
IC1123
IC1124
IC1125
IC1126
IC1127
IC1128
IC1129
IC1130
IC1131
IC1132
IC1133
IC1134
IC1135
IC1136
IC1137
IC1138
IC1139
IC1140
IC1141
IC1142
IC1143
IC1144
IC1145
IC1146
IC1147
IC1148
IC1149
IC1150
IC1151
IC1152
IC1153
IC1154
IC1155
IC1156
IC1157
IC1158
IC1159
IC1160
IC1161
IC1162
IC1163
IC1164
IC1165
IC1166
IC1167
IC1168
IC1169
IC1170
IC1171
IC1172
IC1173
IC1174
IC1175
IC1176
IC1177
IC1178
IC1179
IC1180
IC1181
IC1182
IC1183
IC1184
IC1185
IC1186
IC1187
IC1188
IC1189
IC1190
IC1191
IC1192
IC1193
IC1194
IC1195
IC1196
IC1197
IC1198
IC1199
IC1200
IC1201
IC1202
IC1203
IC1204
IC1205
IC1206
IC1207
IC1208
IC1209
IC1210
IC1211
IC1212
IC1213
IC1214
IC1215
IC1216
IC1217
IC1218
IC1219
IC1220
IC1221
IC1222
IC1223
IC1224
IC1225
IC1226
IC1227
IC1228
IC1229
IC1230
IC1231
IC1232
IC1233
IC1234
IC1235
IC1236
IC1237
IC1238
IC1239
IC1240
IC1241
IC1242
IC1243
IC1244
IC1245
IC1246
IC1247
IC1248
IC1249
IC1250
IC1251
IC1252
IC1253
IC1254
IC1255
IC1256
IC1257
IC1258
IC1259
IC1260
IC1261
IC1262
IC1263
IC1264
IC1265
IC1266
IC1267
IC1268
IC1269
IC1270
IC1271
IC1272
IC1273
IC1274
IC1275
IC1276
IC1277
IC1278
IC1279
IC1280
IC1281
IC1282
IC1283
IC1284
IC1285
IC1286
IC1287
IC1288
IC1289
IC1290
IC1291
IC1292
IC1293
IC1294
IC1295
IC1296
IC1297
IC1298
IC1299
IC1300
IC1301
IC1302
IC1303
IC1304
IC1305
IC1306
IC1307
IC1308
IC1309
IC1310
IC1311
IC1312
IC1313
IC1314
IC1315
IC1316
IC1317
IC1318
IC1319
IC1320
IC1321
IC1322
IC1323
IC1324
IC1325
IC1326
IC1327
IC1328
IC1329
IC1330
IC1331
IC1332
IC1333
IC1334
IC1335
IC1336
IC1337
IC1338
IC1339
IC1340
IC1341
IC1342
IC1343
IC1344
IC1345
IC1346
IC1347
IC1348
IC1349
IC1350
IC1351
IC1352
IC1353
IC1354
IC1355
IC1356
IC1357
IC1358
IC1359
IC1360
IC1361
IC1362
IC1363
IC1364
IC1365
IC1366
IC1367
IC1368
IC1369
IC1370
IC1371
IC1372
IC1373
IC1374
IC1375
IC1376
IC1377
IC1378
IC1379
IC1380
IC1381
IC1382
IC1383
IC1384
IC1385
IC1386
IC1387
IC1388
IC1389
IC1390
IC1391
IC1392
IC1393
IC1394
IC1395
IC1396
IC1397
IC1398
IC1399
IC1400
IC1401
IC1402
IC1403
IC1404
IC1405
IC1406
IC1407
IC1408
IC1409
IC1410
IC1411
IC1412
IC1413
IC1414
IC1415
IC1416
IC1417
IC1418
IC1419
IC1420
IC1421
IC1422
IC1423
IC1424
IC1425
IC1426
IC1427
IC1428
IC1429
IC1430
IC1431
IC1432
IC1433
IC1434
IC1435
IC1436
IC1437
IC1438
IC1439
IC1440
IC1441
IC1442
IC1443
IC1444
IC1445
IC1446
IC1447
IC1448
IC1449
IC1450
IC1451
IC1452
IC1453
IC1454
IC1455
IC1456
IC1457
IC1458
IC1459
IC1460
IC1461
IC1462
IC1463
IC1464
IC1465
IC1466
IC1467
IC1468
IC1469
IC1470
IC1471
IC1472
IC1473
IC1474
IC1475
IC1476
IC1477
IC1478
IC1479
IC1480
IC1481
IC1482
IC1483
IC1484
IC1485
IC1486
IC1487
IC1488
IC1489
IC1490
IC1491
IC1492
IC1493
IC1494
IC1495
IC1496
IC1497
IC1498
IC1499
IC1500
IC1501
IC1502
IC1503
IC1504
IC1505
IC1506
IC1507
IC1508
IC1509
IC1510
IC1511
IC1512
IC1513
IC1514
IC1515
IC1516
IC1517
IC1518
IC1519
IC1520
IC1521
IC1522
IC1523
IC1524
IC1525
IC1526
IC1527
IC1528
IC1529
IC1530
IC1531
IC1532
IC1533
IC1534
IC1535
IC1536
IC1537
IC1538
IC1539
IC1540
IC1541
IC1542
IC1543
IC1544
IC1545
IC1546
IC1547
IC1548
IC1549
IC1550
IC1551
IC1552
IC1553
IC1554
IC1555
IC1556
IC1557
IC1558
IC1559
IC1560
IC1561
IC1562
IC1563
IC1564
IC1565
IC1566
IC1567
IC1568
IC1569
IC1570
IC1571
IC1572
IC1573
IC1574
IC1575
IC1576
IC1577
IC1578
IC1579
IC1580
IC1581
IC1582
IC1583
IC1584
IC1585
IC1586
IC1587
IC1588
IC1589
IC1590
IC1591
IC1592
IC1593
IC1594
IC1595
IC1596
IC1597
IC1598
IC1599
IC1600
IC1601
IC1602
IC1603
IC1604
IC1605
IC1606
IC1607
IC1608
IC1609
IC1610
IC1611
IC1612
IC1613
IC1614
IC1615
IC1616
IC1617
IC1618
IC1619
IC1620
IC1621
IC1622
IC1623
IC1624
IC1625
IC1626
IC1627
IC1628
IC1629
IC1630
IC1631
IC1632
IC1633
IC1634
IC1635
IC1636
IC1637
IC1638
IC1639
IC1640
IC1641
IC1642
IC1643
IC1644
IC1645
IC1646
IC1647
IC1648
IC1649
IC1650
IC1651
IC1652
IC1653
IC1654
IC1655
IC1656
IC1657
IC1658
IC1659
IC1660
IC1661
IC1662
IC1663
IC1664
IC1665
IC1666
IC1667
IC1668
IC1669
IC1670
IC1671
IC1672
IC1673
IC1674
IC1675
IC1676
IC1677
IC1678
IC1679
IC1680
IC1681
IC1682
IC1683
IC1684
IC1685
IC1686
IC1687
IC1688
IC1689
IC1690
IC1691
IC1692
IC1693
IC1694
IC1695
IC1696
IC1697
IC1698
IC1699
IC1700
IC1701
IC1702
IC1703
IC1704
IC1705
IC1706
IC1707
IC1708
IC1709
IC1710
IC1711
IC1712
IC1713
IC1714
IC1715
IC1716
IC1717
IC1718
IC1719
IC1720
IC1721
IC1722
IC1723
IC1724
IC1725
IC1726
IC1727
IC1728
IC1729
IC1730
IC1731
IC1732
IC1733
IC1734
IC1735
IC1736
IC1737
IC1738
IC1739
IC1740
IC1741
IC1742
IC1743
IC1744
IC1745
IC1746
IC1747
IC1748
IC1749
IC1750
IC1751
IC1752
IC1753
IC1754
IC1755
IC1756
IC1757
IC1758
IC1759
IC1760
IC1761
IC1762
IC1763
IC1764
IC1765
IC1766
IC1767
IC1768
IC1769
IC1770
IC1771
IC1772
IC1773
IC1774
IC1775
IC1776
IC1777
IC1778
IC1779
IC1780
IC1781
IC1782
IC1783
IC1784
IC1785
IC1786
IC1787
IC1788
IC1789
IC1790
IC1791
IC1792
IC1793
IC1794
IC1795
IC1796
IC1797
IC1798
IC1799
IC1800
IC1801
IC1802
IC1803
IC1804
IC1805
IC1806
IC1807
IC1808
IC1809
IC1810
IC1811
IC1812
IC1813
IC1814
IC1815
IC1816
IC1817
IC1818
IC1819
IC1820
IC1821
IC1822
IC1823
IC1824
IC1825
IC1826
IC1827
IC1828
IC1829
IC1830
IC1831
IC1832
IC1833
IC1834
IC1835
IC1836
IC1837
IC1838
IC1839
IC1840
IC1841
IC1842
IC1843
IC1844
IC1845
IC1846
IC1847
IC1848
IC1849
IC1850
IC1851
IC1852
IC1853
IC1854
IC1855
IC1856
IC1857
IC1858
IC1859
IC1860
IC1861
IC1862
IC1863
IC1864
IC1865
IC1866
IC1867
IC1868
IC1869
IC1870
IC1871
IC1872
IC1873
IC1874
IC1875
IC1876
IC1877
IC1878
IC1879
IC1880
IC1881
IC1882
IC1883
IC1884
IC1885
IC1886
IC1887
IC1888
IC1889
IC1890
IC1891
IC1892
IC1893
IC1894
IC1895
IC189

3.6 SCHEMATIC AND P.C.BOARDS CONNECTION DIAGRAM (CD BLOCK)




Note :
See pages 63,64 for the semiconductors without
voltage indication.



Free service manuals
Gratis schema's
Digitized by
www.freeservicemanuals.info

To AF assembly J18
(To page 39)

MOTHER P.C.B assembly (PWM1349)



To Deck amplifier Block
AF assembly J19
(To page 39)

P.C.B. pattern diagram indication	Corresponding part symbol	Part name
		Transistor
		FET
		Diode
		Zener diode
		LED
		Varactor
		Tact switch
		Inductor
		Coil
		Transformer
		Filter
		Ceramic capacitor
		Mylar capacitor
		Styrol capacitor
		Electrolytic capacitor (Non polarized)
		Electrolytic capacitor (Noiseless)
		Electrolytic capacitor (Polarized)
		Electrolytic capacitor (Polarized)
		Power capacitor
		Semi-fixed resistor
		Resistor array
		Resistor
		Resonator
		Thermistor

- This P.C.B. connection diagram is viewed from the parts mounted side.
- The parts which have been mounted on the board can be replaced with those shown with the corresponding wiring symbols listed in the above Table.
- The capacitor terminal marked with shows negative terminal.
- The diode marked with shows cathode side.
- The transistor terminal marked with shows emitter.

1. RESISTORS:

Indicated in Ω , $\frac{1}{4}W$, $\frac{1}{2}W$, $\pm 5\%$ tolerance unless otherwise noted k : k Ω ,
M : M Ω , (F) : $\pm 1\%$, (G) : $\pm 2\%$, (K) : $\pm 10\%$ (M) : $\pm 20\%$ tolerance

2. CAPACITORS:

Indicated in capacity (μF)/voltage (V) unless otherwise noted p : pF
Indication without voltage is 50V except electrolytic capacitor.

3. VOLTAGE, CURRENT:

 : DC voltage (V) at play state.
Value in () is DC voltage at rated power.

 mA : DC current at no input signal

4. OTHERS:

 : Signal route.

 : Adjusting point.

The  mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.

※ marked capacitors and resistors have parts numbers.

This is the basic schematic diagram, but the actual circuit may vary due to improvements in design.

List of semiconductor terminal voltage

Note: All terminal voltages are measured in the PLAY mode.

IC151

CXA1372S

Pin No.	Volts	Pin No.	Volts
1	0	25	-5
2	0	26	5
3	0	27	5
4	0	28	5
5	0	29	5
6	0	30	5
7	0	31	5
8	0	32	0
9	0	33	5
10	0	34	0
11	-1	35	0
12	0	36	N. C
13	0.2	37	2.5
14	0	38	2.5
15	0	39	5
16	5	40	-1.5
17	0	41	-1.7
18	0	42	5
19	0	43	-0.7
20	0.2~0.8	44	-1.6
21	0	45	0
22	-4	46	0.8
23	1.3	47	-5
24	0	48	0

IC101

CXA1471S

Pin No.	Volts	Pin No.	Volts
1	N. C	16	0
2	2.9	17	0
3	-4.7	18	0.8
4	0	19	0
5	0	20	5
6	-5	21	5
7	0	22	N. C
8	0		
9	N. C		
10	0		
11	N. C		
12	N. C		
13	-0.9		
14	-0.7		
15	0		

5. SWITCH**MECHA PCB Assembly**

S601 U

S602 S

S603 L

SUB PCB Assembly

S701 O/C D1

S702 O/C D2

S703 D1

S704 D2

S705  ()

S706 COMPU

S707 PGM

S708  ()S709 

S710 TIME/CALENDER

S711 REP

S712 AUTO EJECT

S713 HI LITE

S714 RND

S715 STOP

S716 PAUSE

IC20
M5298P

Pin No.	Volts
1	-8.2
2	N. C
3	-5
4	0
5	-8.2
6	N. C
7	N. C
8	N. C
9	5
10	N. C
11	0.7
12	5
13	8
14	5
15	1.2
16	8

IC201
LA6520

Pin No.	Volts
1	0
2	0
3	-0.7
4	0
5	0
6	0
7	1.7
8	1.7
9	0.7
10	0
11	0
12	8
FIN	-8.2

IC351
PD4305A

Pin No.	Volts	Pin No.	Volts	Pin No.	Volts	Pin No.	Volts
1	-10	17	1.8	33	0	49	-22
2	-13.5	18	0	34	5	50	0
3	-5.5	19	5	35	0	51	5
4	-10.5	20	0.5	36	0	52	0
5	2.1	21	5	37	0	53	0
6	4.8	22	0	38	0	54	-26
7	4.5	23	0	39	5	55	-26
8	3.9	24	0	40	-22	56	-26
9	2.3	25	5	41	-22	57	-5
10	0	26	5	42	-22	58	-9
11	5	27	5	43	-22	59	-11
12	2.5	28	5	44	-22	60	5
13	5	29	5	45	-22	61	-2.5
14	5	30	2.5	46	-22	62	2
15	5	31	2.5	47	-22	63	-2.5
16	0	32	0	48	-22	64	5

IC404
NJM4558D-D


Pin No.	Volts
1	-0.2
2	1
3	1
4	-5
5	1
6	1
7	-0.2
8	5

IC401
TC9237N





Pin No.	Volts
1	5
2	0
3	5
4	5.5
5	2.5
6	2.5
7	0
8	0
9	2.5
10	2.5
11	5
12	0
13	N. C
14	0
15	0
16	1.9
17	1.9
18	5
19	2
20	0
21	0
22	0
23	0
24	5
25	2.5
26	2.5
27	2.5
28	5

IC301
CXD2500Q

Pin No.	Volts	Pin No.	Volts	Pin No.	Volts
1	5	31	N. C	61	N. C
2	N. C	32	2.5	62	N. C
3	5	33	5	63	0
4	2.6	34	2.5	64	N. C
5	N. C	35	2.5	65	0
6	5	36	N. C	66	3.3~4.6
7	N. C	37	N. C	67	5
8	N. C	38	N. C	68	0
9	0	39	N. C	69	2.1~3
10	0	40	N. C	70	5
11	N. C	41	N. C	71	5
12	0	42	5	72	5
13	N. C	43	N. C	73	5
14	N. C	44	N. C	74	5
15	N. C	45	N. C	75	5
16	N. C	46	4.4	76	0
17	0	47	0	77	5
18	2.5	48	0	78	5
19	2.4	49	0~0.3	79	5
20	2.4	50	N. C	80	0
21	0	51	N. C		
22	2.5	52	0		
23	5	53	2.5		
24	2.5	54	N. C		
25	N. C	55	0		
26	0	56	N. C		
27	2.5	57	N. C		
28	0	58	N. C		
29	N. C	59	0		
30	0	60	N. C		





• IC BLOCK



Wave Forms

Note: The encircled numbers denote measuring points in the schematic diagram.

*1 50T-JUMP: After switching to the pause mode, press the manual search key.
*2 FOCUS-IN: Press the key without loading a disc.




4. P.C.B 's PARTS LIST

NOTES:

- Parts without part number cannot be supplied.
- Parts marked by "●" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.
- The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- When ordering resistors, first convert resistance values into code form as shown in the following examples.

Ex. 1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47k ohm (tolerance is shown by J = 5%, and K = 10%).

560 Ω	56×10^1	561.....	RD1/4PS $\begin{smallmatrix} 5 & 6 & 1 & J \end{smallmatrix}$
47k Ω	47×10^3	473.....	RD1/4PS $\begin{smallmatrix} 4 & 7 & 3 & J \end{smallmatrix}$
0.5 Ω	0R5.....		RN2H $\begin{smallmatrix} 0 & 5 & K \end{smallmatrix}$
1 Ω	010.....		RS1P $\begin{smallmatrix} 0 & 1 & 0 & K \end{smallmatrix}$



Free service manuals
Gratis schema's

Digitized by

www.freesevicemanuals.info

Ex. 2 When there are 3 effective digits (such as in high precision metal film resistors).

5.62k Ω	562×10^1	5621.....	RN1/4SR $\begin{smallmatrix} 5 & 6 & 2 & 1 & F \end{smallmatrix}$
----------------	-------------------	-----------	---

Mark No.	Description	Parts No.	Mark No.	Description	Parts No.
AF assembly (AWZ3336)					
SEMICONDUCTORS					
IC1001	OP-AMP IC	RC4558DXP	Q404	TRANSISTOR	RN1203
IC151	REGULATOR IC	NJM78M05FA	Q405	TRANSISTOR	2SC2458
IC152	REGULATOR IC	NJM79M05FA	Q406	TRANSISTOR	2SA1048
IC153, 154	REGULATOR IC	UPC7812AHF	Q601	TRANSISTOR	RN2203
IC155	IC PROTECTOR	ICP-N75	Q602	N-FET	2SK246
IC2001	OP-AMP IC	RC4558DXP	Q801	TRANSISTOR	RN2203
IC2002	LOGIC IC	TC4066BP	Q802	TRANSISTOR	RN1203
IC2201	OP-AMP IC	RC4558DXP	Q803	TRANSISTOR	RN2203
IC2202	LOGIC IC	SN74LS05N			
IC2302	DOLBY-B IC	CXA1100P	D151	DIODE	D3SBA20 (A)
IC2451	OP-AMP IC	RC4558DXP	D152-159	DIODE	1SR139-400
IC301	AUDIO IC	STK4162-2GP	D161	ZENER DIODE	RD6.2ESB2
IC601	OP-AMP IC	RC4558DXP	D162	DIODE	1SS252
IC801	LOGIC IC	MC14052BCP	D163-166	DIODE	1SR139-400
IC802	LOGIC IC	TC4066BP			
IC803, 833	OP-AMP IC	RC4558DXP	D168, 170	DIODE	1SR139-400
Q2001-2204	TRANSISTOR	2SC2458	D2301, 2302	DIODE	1SS252
Q2005, 2006	TRANSISTOR	2SC2878	D2401	ZENER DIODE	RD6.8ESB
Q2007	TRANSISTOR	RN2203	D2402	DIODE	1SS252
Q2008	TRANSISTOR	RN2201	D2451, 2452	DIODE	1SS252
Q2009, 2201	TRANSISTOR	RN1201			
Q2202	TRANSISTOR	RN2203	D401	ZENER DIODE	RD22EB
Q2203, 2204	TRANSISTOR	2SC2878	D403	DIODE	1SR139-400
Q2301-2304	TRANSISTOR	2SC2458	D404	DIODE	1SS252
Q2351	TRANSISTOR	RN2203	D405	ZENER DIODE	RD6.8ESB2
Q2401	TRANSISTOR	DTC124ES	D406, 601	DIODE	1SS252
Q2402	TRANSISTOR	DTA124ES			
Q2403, 2404	TRANSISTOR	2SC2603	RELAY		
Q2405	TRANSISTOR	2SA1115	RY401	RELAY	ASR1035
Q2406	TRANSISTOR	2SC2458	COILS		
Q401-403	TRANSISTOR	2SC2458	F2351, 2352	DOLBY FILTER	ATF1064
			L151	AXIAL INDUCTOR	LAU2R2K
			L2201, 2202	INDUCTOR	LTA392J
			L501, 502	COIL	ATH-133

Mark No.	Description	Parts No.
CAPACITORS		
C1001-1004	CERAMIC CAPACITOR	CCCSL101J50
C1005	CERAMIC CAPACITOR	CKSQYB152K50
C1006	CERAMIC CAPACITOR	CKDYB152K50
C1007, 1008	CERAMIC CAPACITOR	CKDYB562K50
C1009-1012	ELECTR.CAPACITOR	CEAS2R2M50
C1015, 1016	ELECTR.CAPACITOR	CEAS470M16
C151, 152	ELECTROLYTIC CAPACIT (3300/50)	ACH1017
C153	ELECTR.CAPACITOR	CEAS222M16
C154	ELECTR.CAPACITOR	CEAS102M16
C155, 156	ELECTR.CAPACITOR	CEAS220M16
C157	ELECTR.CAPACITOR	CEAS222M25
C158, 159	ELECTR.CAPACITOR	CEAS220M25
C160	ELECTR.CAPACITOR	CEAS100M25
C161	CERAMIC CAPACITOR	CKDYB103K500
C162	CKA (0.01/AC250V)	ACG1005
C2007, 2008	MYLOR FILM CAPACITOR	CQMA273J50
C2009, 2010	MYLOR FILM CAPACITOR	CQMA183J50
C2011, 2012	CERAMIC CAPACITOR	CKSQYB152K50
C2201-2204	ELECTR.CAPACITOR	CEAS010M50
C2205, 2206	CHIP CAPACITOR	CKSQYB222K50
C2207, 2208	AUDIO FILM CAPACITOR	CFTXA104J50
C2209, 2210	ELECTR.CAPACITOR	CEAS330M16
C2211, 2212	CERAMIC CAPACITOR	CKCYX183M25
C2213, 2214	MYLOR FILM CAPACITOR	CQMA752J50
C2215, 2216	CERAMIC CAPACITOR	CKSQYB562K50
C2217, 2218	MYLOR FILM CAPACITOR	CQMA273J50
C2221, 2222	ELECTR.CAPACITOR	CEAS2R2M50
C2225, 2226	ELECTR.CAPACITOR	CEAS470M16
C2303, 2304	ELECTR.CAPACITOR	CEAS010M50
C2305	ELECTR.CAPACITOR	CEAS220M16
C2306	ELECTR.CAPACITOR	CEAS220M25
C2351, 2352	ELECTR.CAPACITOR	CEAS100M50
C2353, 2354	ELECTR.CAPACITOR	CEASR22M50
C2355	ELECTR.CAPACITOR	CEAS101M10
C2356-2359	ELECTR.CAPACITOR	CEAS100M50
C2401	ELECTR.CAPACITOR	CEAS331M16
C2402	ELECTR.CAPACITOR	CEAS100M25
C2451	CERAMIC CAPACITOR	CKSQYB473K50
C2452	CERAMIC CAPACITOR	CCSQCH560J50
C2453	ELECTR.CAPACITOR	CEAS010M50
C2454	ELECTR.CAPACITOR	CEAS0R1M50
C301, 302	ELECTR.CAPACITOR	CEAS2R2M50
C303, 304	CERAMIC CAPACITOR	CKMYB331K50
C305, 306	ELECTR.CAPACITOR	CEAS220M50
C307, 308	ELECTR.CAPACITOR	CEAS101M25

Mark No.	Description	Parts No.
C309	ELECTR.CAPACITOR	CEANP220M50
C310	ELECTR.CAPACITOR	CEANP100M50
C311, 312	ELECTR.CAPACITOR	CEAS100M50
C313	ELECTROLYTIC CAPACIT (47/50)	ACH1143
C401-404	CERAMIC CAPACITOR	CKCYF473Z50
C405	ELECTR.CAPACITOR	CEAS221M16
C406	ELECTR.CAPACITOR	CEAS330M25
C407	ELECTR.CAPACITOR	CEAS221M16
C408	ELECTR.CAPACITOR	CEAS100M50
C501	ELECTR.CAPACITOR (10/100)	ACH1144
C601, 602	CERAMIC CAPACITOR	CKMYB471K50
C603, 604	ELECTR.CAPACITOR	CEAS2R2M50
C605	CERAMIC CAPACITOR	CKSQYB681K50
C606	CERAMIC CAPACITOR	CKCYF473Z50
C831, 832	CERAMIC CAPACITOR	CCCSL101J50
C856-858	CERAMIC CAPACITOR	CKDYB471K50
RESISTORS		
VR2201, 2202	VR	VRTB6VS222
R1013	CHIP RESISTOR	RS1/10S104J
R157, 158	CARBON FILM RESISTOR	RD1/2PM8R2J
R159-162	CARBON FILM RESISTOR	RD1/4PM100J
R163, 164	METAL OXIDE RESISTOR	RS2LMFR22J
R2001, 2002	CHIP RESISTOR	RS1/10S103J
R2003, 2004	CHIP RESISTOR	RS1/10S122J
R2005, 2006	CHIP RESISTOR	RS1/10S105J
R2007, 2008	CHIP RESISTOR	RS1/10S332J
R2009, 2010	CHIP RESISTOR	RS1/10S105J
R2011, 2014	CHIP RESISTOR	RS1/10S472J
R2016	CHIP RESISTOR	RS1/10S472J
R2019, 2020	CHIP RESISTOR	RS1/10S154J
R2021, 2022	CHIP RESISTOR	RS1/10S222J
R2207, 2208	CHIP RESISTOR	RS1/10S104J
R2209, 2210	CHIP RESISTOR	RS1/10S683J
R2211, 2212	CHIP RESISTOR	RS1/10S223J
R2213, 2214	CHIP RESISTOR	RS1/10S333J
R2223, 2224	CHIP RESISTOR	RS1/10S471J
R2226	CHIP RESISTOR	RS1/10S681J
R2233, 2234	CHIP RESISTOR	RS1/10S102J
R2301, 2302	CHIP RESISTOR	RS1/10S273J
R2303, 2304	CHIP RESISTOR	RS1/10S362J
R2305, 2306	CHIP RESISTOR	RS1/10S103J
R2317, 2318	CHIP RESISTOR	RS1/10S222J
R2351, 2352	CHIP RESISTOR	RS1/10S242J
R2355, 2356	CHIP RESISTOR	RS1/10S682J
R2357	CHIP RESISTOR	RS1/10S433J
R2361, 2362	CHIP RESISTOR	RS1/10S222J
R2363, 2364	CHIP RESISTOR	RS1/10S273J
R2366	CHIP RESISTOR	RS1/10S103J

Mark No.	Description	Parts No.
R2451	CHIP RESISTOR	RS1/10S224J
R2452	CHIP RESISTOR	RS1/10S154J
R2454	CHIP RESISTOR	RS1/10S223J
R2457	CHIP RESISTOR	RS1/10S123J
R305, 306	CARBON FILM RESISTOR	RD1/4PM104J
R309–312	CARBON FILM RESISTOR	RD1/4PM222J
R313	CARBON FILM RESISTOR	RD1/4PMFL471J
R314	CARBON FILM RESISTOR	RD1/4PMFL101J
R315	CARBON FILM RESISTOR	RD1/4PM102J
R316, 317	CARBON FILM RESISTOR	RD1/4PMFL222J
R318	CARBON FILM RESISTOR	RD1/4PMFL101J
R401, 402	CARBON FILM RESISTOR	RD1/4PM100J
R409	CARBON FILM RESISTOR	RD1/2PM182J
R416	METAL OXIDE RESISTOR	RS2LMF331J
R417	METAL OXIDE RESISTOR	RS2LMF391J
R501, 502	CARBON FILM RESISTOR	RD1/4PMFL100J
R805, 806	CHIP RESISTOR	RS1/10S273J
R843, 844	CHIP RESISTOR	RS1/10S223J
R855, 856	CHIP RESISTOR	RS1/10S332J
R857	CHIP RESISTOR	RS1/10S104J
R858	CHIP RESISTOR	RS1/10S000J
	Other resistors	RD1/8PM□□□J
OTHERS		
CN10	CONNECTOR (14P)	KPE14
CN11	CONNECTOR (15P)	KPE15
CN12	CONNECTOR (13P)	KPE13
CN16	CONNECTOR (7P)	KPE7
CN4	CONNECTOR (13P)	KPE13
CN5	CONNECTOR (5P)	KPE5
CN6	CONNECTOR (4P)	KPC4
	PIN JACK (4P)	AKB1124
	PIN JACK (2P)	AKB1146
	SPEAKER TERMINAL 4–P	AKE–109
	JACK	AKN–203
	SOCKET (14P)	AKP1048
	GEQ assembly	AWX1048

Mark No.	Description	Parts No.
© GEQ assembly (AWX1048)		
The GEQ assembly (AWX1048) is a part of AF assembly (AWZ3336).		
SEMICONDUCTORS		
IC701, 702	GEQ IC	LA3607
IC703	GEQ EVR IC	LC7522
CAPACITORS		
C701, 702	CERAMIC CAPACITOR	CCSQL331J50
C703–706	ELECTR.CAPACITOR	CEAS2R2M50
C707, 708	ELECTROLYTIC CAPACIT	CEASR15M50
C709, 710	ELECTR.CAPACITOR	CEASR47M50
C711, 712	CERAMIC CAPACITOR	CKCYX683M16
C713, 714	ELECTROLYTIC CAPACIT	CEASR15M50
C715, 716	CERAMIC CAPACITOR	CKCYX273M16
C717, 718	CERAMIC CAPACITOR	CKCYX683M16
C719, 720	CERAMIC CAPACITOR	CKSQYB103K50
C721, 722	CERAMIC CAPACITOR	CKCYX273M16
C723, 724	CERAMIC CAPACITOR	CKSQYB472K50
C725, 726	CERAMIC CAPACITOR	CKSQYB103K50
C727, 728	CERAMIC CAPACITOR	CKSQYB182K50
C729, 730	CERAMIC CAPACITOR	CKSQYB472K50
C731, 732	CERAMIC CAPACITOR	CKSQYB681K50
C733, 734	CERAMIC CAPACITOR	CKSQYB182K50
C735, 736	ELECTR.CAPACITOR	CEAS101M10
C737, 738	CERAMIC CAPACITOR	CKSQYB473K50
RESISTORS		
R701	CARBONFILM RESISTOR	RD1/8PM103J
R703, 704	CARBONFILM RESISTOR	RD1/8PM223J
R710	RESISTOR ARRAY (1M)	RA8T105J
R711, 712	CARBON FILM RESISTOR	RD1/4PM390J
R726, 727	CARBONFILM RESISTOR	RD1/8PM103J
	Other resistors	RS1/10S□□□J
VR assembly		
SEMICONDUCTORS		
IC551	OP–AMP IC	RC4558DXP
IC552	MECHANISM DRIVER IC	TA7291S
Q551, 552	TRANSISTOR	2SC2878
Q553	TRANSISTOR	RN2203



Mark No.	Description	Parts No.
CAPACITORS		
C551, 552	ELECTR.CAPACITOR	CEAS4R7M50
C553, 554	CHIP CAPACITOR	CCSQCH101J50
C555, 556	ELECTR.CAPACITOR	CEAS101M16
C557	ELECTR.CAPACITOR	CEAS220M25
C558	CERAMIC CAPACITOR	CKSQYF104Z50
C559	CERAMIC CAPACITOR	CKCYF473Z50
RESISTORS		
VR551	VARIABLE RESISTOR	ACX1051
R554	CHIP RESISTOR	RS1/10S000J
R555, 556	CHIP RESISTOR	RS1/10S104J
R561	CHIP RESISTOR	RS1/10S000J
R565, 566	CHIP RESISTOR	RS1/10S102J
	Other resistors	RD1/8PM□□□J

HEAD PHONE assembly

CAPACITOR		
C453	CERAMIC CAPACITOR	CKDYF473Z50

RESISTORS		
R451, 452	METAL OXIDE RESISTOR	RS2LMF331J
R453	CARBONFILM RESISTOR	RD1/8PM100J

OTHERS		
CN1	JACK (HEAD PHONE) CONNECTOR (5P)	AKN1010 KPC5

TRANS CONNECT assembly

No parts are supplied with the TRANS CONNECT assembly.

◎ DISPLAY assembly (AWZ3351)

SEMICONDUCTORS		
IC1501	LOGIC IC	SN74LS05N
IC1502	LOGIC IC	SN74LS03N
IC1503	GEQ-BPF IC	BA3826S
IC1504	OP-AMP IC	RC4558DXP
IC1505	SPECTRUM ANALYZER CONTROL μ -COM	PD3174A
IC1651	SYSTEM CONTROL μ -COM	PD5147B
IC1652	RESET IC	M51951BSL

Mark No.	Description	Parts No.
Q1501-1504	TRANSISTOR	RN1201
Q1505-1507	TRANSISTOR	RN1203
Q1508, 1509	TRANSISTOR	RN2201
Q1510	TRANSISTOR	RN1203
Q1601	TRANSISTOR	RN2204
Q1602	TRANSISTOR	RN1203
Q1603	TRANSISTOR	RN2204
Q1604	TRANSISTOR	2SA1515
Q1605	TRANSISTOR	RN1203
Q1606	TRANSISTOR	2SA1515
Q1607	TRANSISTOR	RN1203
Q1608	TRANSISTOR	2SA1515
Q1609	TRANSISTOR	RN1203
Q1610	TRANSISTOR	2SA1515
Q1611	TRANSISTOR	RN1203
D1501-1504	LED (GREEN)	AEL1130
D1505	LED (RED)	AEL1119
D1506, 1507	LED (RED)	AEL1126
D1508, 1509	LED	AEL1128
D1510	LED (RED)	AEL1065
D1511-1516	LED (RED)	AEL1108
D1517-1531	DIODE	1SS252
D1535-1543	DIODE	1SS252
D1544, 1545	LED (GREEN)	AEL1129
D1546	LED (RED)	AEL1065
D1547, 1548	DIODE	1SS252
D1601-1617	DIODE	1SS252
D1651-1664	DIODE	1SS252
SWITCHES		
S1504-1507	SWITCH	ASG1034
S1510-1514	SWITCH	ASG1034
S1516-1519	SWITCH	ASG1034
S1522-1525	SWITCH	ASG1034
S1528	SWITCH	ASD1012
S1529	ROTARY ENCODER	ASX1009
S1530-1535	SWITCH	ASG1034
S1537-1544	SWITCH	ASG1034
S1546-1549	SWITCH	ASG1034

COILS

L1501	AXIAL INDUCTOR	LAU221K
L1651	AXIAL INDUCTOR	LAU220K

CAPACITORS

C1501	CERAMIC CAPACITOR	CKDYX473M16
C1504	ELECTR.CAPACITOR	CEJA470M10
C1505	CEA (47000/5.5V)	ACH1070
C1506	CERAMIC CAPACITOR (0.022)	ACG1022
C1507	CERAMIC CAPACITOR	CCDSL100D50

Mark No.	Description	Parts No.
C1508	CERAMIC CAPACITOR	ACG1022
C1509	CERAMIC CAPACITOR	CKMYB102K50
C1510	CERAMIC CAPACITOR	CKDYX473M16
C1601	ELECTR.CAPACITOR	CEAS470M10
C1602	ELECTR.CAPACITOR	CEASR33M50
C1651	CERAMIC CAPACITOR	CKCYF473Z50
C1652	ELECTR.CAPACITOR	CEAS101M16
C1653	CERAMIC CAPACITOR	CKCYF473Z50
C1654 – 1658	CERAMIC CAPACITOR (1000p)	ACG1020
C1659	ELECTR.CAPACITOR	CEAS010M50

RESISTORS

VR1601, 1602	VR	VRTM6V203
VR1603	VR	VRTM6V103
R1543	RESISTOR ARRAY (100k)	RA13S104J
R1544	RESISTOR ARRAY (100k)	RA15T104J
R1662	RESISTOR ARRAY (3.3K)	RA8T332J
	Other resistors	RD1/8PM□□□J

OTHERS

V1501	FL TUBE	AAV1116
X1502	CERAMIC RESONATOR	ASS1018
X1651	CERAMIC RESONATOR	ASS1025
	REMOTE RECEIVER UNIT	AXX1010
CN8	CONNECTOR (15P)	KPE15

1 MECHA SW assembly**SWITCHES**

S1551 – 1555	SWITCH	ASG1034
--------------	--------	---------

2 MECHA SW assembly**SWITCHES**

S1556 – 1560	SWITCH	ASG1034
--------------	--------	---------

MIC BALANCE assembly**SEMICONDUCTORS**

IC901	OP – AMP IC	NJM4558S – X
-------	-------------	--------------

Mark No.	Description	Parts No.
CAPACITORS		
C901	CERAMIC CAPACITOR	CKMYB681K50
C902	ELECTR.CAPACITOR	CEAS010M50
C903	CERAMIC CAPACITOR	CKMYB471K50
C904, 905	ELECTR.CAPACITOR	CEAS100M25
C906, 907	CERAMIC CAPACITOR	CKDYX473M16
C908	CERAMIC CAPACITOR	CKDYF473Z50

RESISTORS

VR552	VARIABLE RESISTOR	ACS1066
VR901	VARIABLE (10K – X1)	ACS1065

Other resistors	RD1/8PM□□□J
-----------------	-------------

OTHERS

CN3	JUMPER CONNECTOR JACK (MIC)	KPC6 AKN1017
-----	--------------------------------	-----------------

◎ SUB TRANS assembly (AWR1056)**SEMICONDUCTORS**

IC101	REGULATOR IC	NJM78M56FA
IC102	REGULATOR IC	UPC78M12AHF
Q101	TRANSISTOR	2SC2458
Q102	TRANSISTOR	2SB560
D101	ZENER DIODE	RD10ESB2
D102	ZENER DIODE	RD30ESB2
D103 – 106	DIODE	1SR139 – 400
D107, 109	DIODE	1SS252

RELAY

RY101	RELAY	ASR1027
-------	-------	---------

TRANSFORMER

T101	POWER TRANSFORMER	ATT1149
------	----------------------	---------

CAPACITORS

C101	ELECTR.CAPACITOR	CEAS222M25
C102	ELECTR.CAPACITOR	CEAS221M50
C103, 104	ELECTR.CAPACITOR	CEAS470M16
C105	ELECTR.CAPACITOR	CEAS470M50
C106	ELECTR.CAPACITOR	CEAS220M50
C107	ELECTR.CAPACITOR	CEAS470M16

RESISTORS

R101	METAL OXIDE RESISTOR	RS3LMF392J
------	-------------------------	------------

Other resistors	RD1/8PM□□□J
-----------------	-------------

Mark No.	Description	Parts No.
----------	-------------	-----------

1 MECHA assembly

CAPACITORS

C2001, 2002	CERAMIC CAPACITOR	CKMYB391K50
C2005, 2006	AUDIO FILM CAPACITOR	CFTXA223J50
C2007, 2008	ELECTR.CAPACITOR	CEAS4R7M50
C2009, 2010	ELECTR.CAPACITOR	CEAS470M10

RESISTORS

VR2001, 2002	VR	VRTM6H202
	Other resistors	RD1/8PM□□□J

2 MECHA assembly

SEMICONDUCTORS

IC2001, 2021	OP-AMP IC	RC4558DXP
Q2021, 2022	N-FET	2SK373
Q2251	TRANSISTOR	RN1201
Q2252	TRANSISTOR	2SA1515
Q2253, 2254	TRANSISTOR	2SC3377
Q2255	TRANSISTOR	2SC2458

D2021-2026	DIODE	1SS252
------------	-------	--------

COILS & TRANSFORMERS

L2204, 2205	INDUCTOR	LTA822J
T2251	OSC TRANSFORMER	ATX-043

CAPACITORS

C2021, 2022	CERAMIC CAPACITOR	CCMSL100D50
C2023, 2024	CERAMIC CAPACITOR	CKMYB391K50
C2027, 2028	AUDIO FILM CAPACITOR	CFTXA223J50
C2029, 2030	ELECTR.CAPACITOR	CEAS4R7M50
C2031, 2032	ELECTR.CAPACITOR	CEAS470M10

C2219, 2220	CERAMIC CAPACITOR	CCDSL271K500
C2223, 2224	CERAMIC CAPACITOR	CKDYB681K50
C2251	ELECTR.CAPACITOR	CEAS470M16
C2252, 2253	CERAMIC CAPACITOR	CGMYX103M16
C2254	CERAMIC CAPACITOR	CKMYB221K50

C2255	MYLOR FILM CAPACITOR	CQMA153K50
C2256	CERAMIC CAPACITOR	CKMYB681K50
C2257	MYLOR FILM CAPACITOR	CQMA123K250
C2258	ELECTR.CAPACITOR	CEAS4R7M50
C2259, 2260	CERAMIC CAPACITOR	CCCSL101K500

C2261	MYLOR FILM CAPACITOR	CQMA562K400
C2262	CQPA (2000P/630V)	ACE1020
C2263	ELECTR.CAPACITOR	CEAS100M50

Mark No.	Description	Parts No.
----------	-------------	-----------

RESISTORS

VR2021, 2022	VR	VRTM6V202
VR2251, 2252	VR	VRTM6H204
R2253	CARBON FILM RESISTOR	RD1/2PM360J
	Other resistors	RD1/8PM□□□J

◎ MOTHER P.C.B ASSEMBLY (PWM1349)

SEMICONDUCTORS

IC101	PRE AMP IC	CXA1471S
IC151	SERVO IC	CXA1372S
△ IC20	REGULATOR IC	M5298P
△ IC201	POWER OP-AMP, IC	LA6520
△ IC30	IC PROTECTOR	ICP-N10

IC301	EFM DEMODULATION IC	CXD2500Q
IC351	MICROCOMPUTER	PD4305B
IC401	8FS DF DA CONVERTER IC	TC9237N

IC404	OP-AMP IC	NJM4558D-D
-------	-----------	------------

Q101	TRANSISTOR	2SA854S
Q201	TRANSISTOR	2SC3581
Q202	TRANSISTOR	2SA1399
Q203	TRANSISTOR	2SC3581
Q204	TRANSISTOR	2SA1399

Q381, 382	TRANSISTOR	2SC1740S
Q403, 404	TRANSISTOR	2SD2144S
Q405	TRANSISTOR	DTC124ES
Q62	TRANSISTOR	2SC1740S

△ D1, 2	DIODE	11ES2
D211	ZENNER DIODE	MTZJ6.2B/C
D381-385	DIODE	1SS254

COILS

L381	AXIAL INDUCTOR	LAU010K
L401	AXIAL COIL	LAUR22K
L402, 403	AXIAL INDUCTOR	LAU010K

CAPACITORS

C101	ELECTROLYTIC CAPACIT	CEAS471M6R3
C102	ELECTR.CAPACITOR	CEAS101M10
C103	CERAMIC CAPACITOR	CCCCH180J50
C104	ELECTR.CAPACITOR	CEAS101M10
C11, 110	CERAMIC CAPACITOR	CKCYF103Z50

C12-14	CERAMIC CAPACITOR	CKCYF103Z50
C153	ELECTR.CAPACITOR	CEAS101M10
C155	MYLOR FILM CAPACITOR	CQMA182J50
C156	MYLOR FILM CAPACITOR	CQMA333K50

Mark No.	Description	Parts No.
C157	MYLOR FILM CAPACITOR	CQMA103K50
C158, 159	MYLOR FILM CAPACITOR	CQMA104K50
C160	ELECTR.CAPACITOR	CEAS4R7M50
C161	MYLOR FILM CAPACITOR	CQMA104K50
C162	ELECTR.CAPACITOR	CEAS010M50
C163	MYLOR FILM CAPACITOR	CQMA104K50
C164	MYLOR FILM CAPACITOR	CQMA103K50
C167	CERAMIC CAPACITOR	CKCYF103Z50
C168	MYLOR FILM CAPACITOR	CQMA333K50
C169	MYLOR FILM CAPACITOR	CQMA103K50
C170	MYLOR FILM CAPACITOR	CQMA332J50
C171	MYLOR FILM CAPACITOR	CQMA472J50
C172	MYLOR FILM CAPACITOR	CQMA472K50
C202	CERAMIC CAPACITOR	CKCYF103Z50
C212	MYLOR FILM CAPACITOR	CQMA103K50
C216, 217	ELECTR.CAPACITOR	CEAS330M16
C27	ELECTROLYTIC CAPACIT	CEAS471M6R3
C28	ELECTR.CAPACITOR	CEAS101M10
C301	MYLOR FILM CAPACITOR	CQMA104K50
C306	CERAMIC CAPACITOR	CKCYB152K50
C307	MYLOR FILM CAPACITOR	CQMA473J50
C308	MYLOR FILM CAPACITOR	CQMA103K50
C309	ELECTR.CAPACITOR	CEASR47M50
C351	ELECTROLYTIC CAPACIT	CEAS471M6R3
C353, 355	CERAMIC CAPACITOR	CKCYF103Z50
C361	CERAMIC CAPACITOR	CKCYF103Z50
C383, 384	CERAMIC CAPACITOR	CKCYF103Z50
C401	CERAMIC CAPACITOR	CKCYF103Z50
C403, 404	CERAMIC CAPACITOR	CCCCH470J50
C410, 411	CERAMIC CAPACITOR	CCCSL560J50
C412-415	CERAMIC CAPACITOR	CCCCH390J50
C420	ELECTR.CAPACITOR	CEAS330M16
C421	CERAMIC CAPACITOR	CKCYF473Z50
C422	CERAMIC CAPACITOR	CKCYF103Z50
C429, 430	ELECTR.CAPACITOR	CEAS220M25
C431, 432	MYLOR FILM CAPACITOR	CQMA104K50

Mark No.	Description	Parts No.
C433, 434	MYLOR FILM CAPACITOR	CQMA103K50
C435	CERAMIC CAPACITOR	CKCYF103Z50
C60	ELECTR.CAPACITOR	CEAS010M50
RESISTORS		
VR102	VR	RCP1046
VR103	VR	RCP1044
VR151, 152	VR	RCP1046
Other resistors		RD1/6PM□□□J
OTHERS		
CN1	CONNECTOR (6P)	KPE6
CN101	CONNECTOR	52045-1610
CN351	CONNECTOR	HLEM30S-1
CN381	CONNECTOR (7P)	KPE7
X351	CERAMIC RESONATOR	VSS1014
X401	XTAL RES (OSC)	PSS1006

◎ SUB P.C.B ASSEMBLY (PWX1143)

SEMICONDUCTORS

D701-704	DIODE	1SS254
D708	DIODE	1SS254

SWITCHES

S701-716	SWITCH	PSG1006
----------	--------	---------

OTHERS

CN701	CONNECTOR	HLEM30R-1
V701	FL INDICATOR TUBE	PEL1050

MECHA P.C.B ASSEMBLY

SWITCHES

S601-603	SWITCH	SDSG1017
----------	--------	----------

5. IC INFORMATION

• PD3174A

• Pin Function

No.	Pin name	I/O	Description
1	S5/KO5	DP	FL SEGMENT Output (S5), KEY SCAN Output (KO5)
2	S4/KO4	DP	FL SEGMENT Output (S4), KEY SCAN Output (KO4)
3	S3/KO3	DP	FL SEGMENT Output (S3), KEY SCAN Output (KO3)
4	S2/KO2	DP	FL SEGMENT Output (S2), KEY SCAN Output (KO2)
5	S1/KO1	DP	FL SEGMENT Output (S1), KEY SCAN Output (KO1)
6	1G	DP	FL DIGIT Output (1G)
7	2G	DP	FL DIGIT Output (2G)
8	3G	DP	FL DIGIT Output (3G)
9	4G	DP	FL DIGIT Output (4G)
10	5G	DP	FL DIGIT Output (5G)
11	6G	DP	FL DIGIT Output (6G)
12	7G	DP	FL DIGIT Output (7G)
13	8G	DP	FL DIGIT Output (8G)
14	9G	DP	FL DIGIT Output (9G)
15	10G	DP	FL DIGIT Output (10G)
16	11G	DP	FL DIGIT Output (11G)
17	12G	DP	FL DIGIT Output (12G)
18	POWER	I	When AC power supply ceases, the backup mode is activated.
19	-27V	I	Vfdp (-27V)
20	13G	DP	FL DIGIT Output (13G)
21	14G/ MODE 1	DP	FL DIGIT Output (14G)
22	15G/ MODE 2	DP	FL DIGIT Output (15G)

No.	Pin name	I/O	Description
23	N.C.	DP	Not used
24	DEL 1	O	Not used
25	DEL 2	O	Not used
26	DEL 3	O	Not used
27	DATA	O	LC7522 DATA Output
28	CLOCK	O	LC7522 CLOCK Output
29	S. DATA	I	SYSTEM BUS DATA Input
		O	SYSTEM BUS DATA Output
30	S. CLOCK	I	SYSTEM BUS CLOCK Input
31	REQ/EN	I	SYSTEM BUS TALKER ENABLE Input
		O	SYSTEM BUS TAKER REQUEST Output
32	Vcc		Connected to Power supply (+5V)
33	CTR	O	BA3826 L/R Switching Output
34	A	O	BA3826 A Output
35	B	O	BA3826 B Output
36	C	O	BA3826 C Output
37	DA0	O	A/D Converter Output
38	DA1	O	A/D Converter Output
39	DA2	O	A/D Converter Output
40	DA3	O	A/D Converter Output
41	DA4	O	A/D Converter Output
42	CMP IN	I	A/D converter Input
43	KI1	I	KEY SCAN Input
44	KI2	I	KEY SCAN Input
45	ENC B	I	Rotary pulse encoder B Input
46	ENC A	I	Rotary pulse encoder A Input

No.	Pin name	I/O	Description
47	RESET	I/O	RESET Input
48	OSC 2	O	Connected to ceramic oscillator (4.19MHz).
49	OSC 1	I	
50	GND		GND
51	CL 1	I	Not used (+5V)
52	CL 2	O	Not used (OPEN)
53	TEST	I	Not used (+5V)
54	S16	DP	FL SEGMENT Output (S16)
55	S15	DP	FL SEGMENT Output (S15)
56	S14	DP	FL SEGMENT Output (S14)
57	S13	DP	FL SEGMENT Output (S13)
58	S12	DP	FL SEGMENT Output (S12)
59	S11	DP	FL SEGMENT Output (S11)
60	S10/K10	DP	FL SEGMENT Output (S10), KEY SCAN Output (K10)
61	S9/K09	DP	FL SEGMENT Output (S9), KEY SCAN Output (K09)
62	S8/K08	DP	FL SEGMENT Output (S8), KEY SCAN Output (K08)
63	S7/K07	DP	FL SEGMENT Output (S7), KEY SCAN Output (K07)
64	S6/K06	DP	FL SEGMENT Output (S6), KEY SCAN Output (K06)

I : CMOS input

O : CMOS output

N : N ch open drain output

P : P ch open drain output

UN : N ch open drain output with pull-up resistor

DP : P ch open drain output with pull-down resistor

UI : CMOS input with pull-up resistor

DI : CMOS input with pull-down resistor

6. FOR HEWZIW TYPE

NOTES:

- Parts without part number cannot be supplied.
- The  mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- Parts marked by "●" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.

6.1 CONTRAST OF MISCELLANEOUS PARTS

The XD-Z84T/HEWZIW type is the same as the XD-Z84T/HE type with the exception of the following sections.

Mark	Symbol & Description	Part No.		Remarks
		HE type	HEWZIW type	
	AF assembly	AWZ3336	AWZ3337	
	VR assembly	Non supply	Non supply	
	HEAD PHONE assembly	Non supply	Non supply	
	MIC BALANCE assembly	Non supply	Non supply	
	SUB TRANS assembly	AWR1056	AWR1057	
	Screw (EARTH)		ABA1047	
	Operating instructions (Dutch, Swedish, Spanish, Portuguese)	ARC1242		
	Operating instructions (English, German, French, Italian)	ARE1173		
	Operating instructions (German, Italian)		ARC1236	

6.2 VR assembly (HEWZIW type)

The VR assembly (HEWZIW type) is the same as the VR assembly (HE type) with the exception of the following sections.

Mark	Symbol & Description	Part No.		Remarks
		HE type	HEWZIW type	
	C561, C562		CKMYB221K50	

6.3 SUB TRANS assembly (AWR1057)

The SUB TRANS assembly (AWR1057) is the same as the SUB TRANS assembly (AWR1056) with the exception of the following sections.

Mark	Symbol & Description	Part No.		Remarks
		HE type	HEWZIW type	
	L101		ATF-151	
	T101 Power transformer	ATT1149	ATT1144	
	C109 (0.01 μ F/AC400V)		ACG1002	

6.4 AF assembly (AWZ3337)

The AF assembly (AWZ3337) is the same as the AF assembly (AWZ3336) with the exception of the following sections.

Mark	Symbol & Description	Part No.		Remarks
		AWZ3336	AWZ3337	
	L501, L502 L503, L504	ATH-133	ATH-059 ATH-059	
	C162 (0.01 μ F/AC250V) C162	ACG1005	 CQMA473K250	
	C321, C322		CCDCH101J50	
	C502, C503, C513, C514		CKDYB103K50	
	C511, C512		CKDYB102K50	
	C607, C608		CCMSL101J50	
	C801-C804 (390p)		ACG1026	
	C805-C808		CKMYB391K50	
	C831, C832, C1003, C1004	CCCSL101J50	CCMSL101J50	
	C851-C853, C855		CKDYF473Z50	
	C854		CQMA224K50	
	C856-C858	CKDYB471K50	CKMYB471K50	
	C1001, C1002	CCMSL101J50	CKMYB391K50	
	C1013, C1014		CKDYB471K50	
	R351, R352		RD1/8PM222J	
	R501, R502	RD1/4PMFL100J	RD1/4PMFL101J	
	R807, R808		RD1/8PM221J	
	R1001, R1002	RD1/8PM102J	RD1/8PM222J	

6.5 HEAD PHONE assembly (HEWZIW type)

The HEAD PHONE assembly (HEWZIW type) is the same as the HEAD PHONE assembly (HE type) with the exception of the following sections.

Mark	Symbol & Description	Part No.		Remarks
		.HE type	HEWZIW type	
	C451, C452		CKDYF473Z50	
	C453	CKDYF473Z50		
	R453	RD1/8PM100J		


6.6 MIC BALANCE assembly (HEWZIW type)

The MIC BALANCE assembly (HEWZIW type) is the same as the MIC BALANCE assembly (HE type) with the exception of the following sections.

Mark	Symbol & Description	Part No.		Remarks
		HE type	HEWZIW type	
	C909, C910		CCDSL101J50	
	C911, C912		CKDYB102K50	
	C913		CKDYB472K50	
	R909		RD1/8PM222J	
	R910		RD1/8PM100J	

7. PANEL FACILITIES

REAR PANEL FACILITIES



① Ground terminal (GND)

Connect this to the ground terminal on the turntable (except for PL-Z94).

② PHONO input jacks

Connect the audio cord of the turntable to these jacks.

③ LD/VCR jacks

Connect to audio output jacks of LD player or VCR, etc.

④ TUNER jacks

Connect the tuner cord here.

⑤ TURNTABLE (DC 12 V OUTPUT) jack

This jack supplies power to the turntable PL-Z94.

Connect the power supply cord of the turntable to this jack.

⑥ SPEAKERS terminals

L: Connect the left speaker system as seen from the listening position.

R: Connect the right speaker system as seen from the listening position.

NOTE:

Connect a speaker system having a nominal impedance ranging from 8 Ω to 16 Ω .

⑦ SURROUND SPEAKERS jacks

Connect the surround speaker systems.

NOTE:


Connect a speaker system having a nominal impedance of 16 Ω or more.

⑧ Power cord


Connect this to the household electrical outlet.

FRONT PANEL FACILITIES


Amplifier section




Sound image controller section





XD-Z84T



Cassette deck section



Compact disc player section



- This unit has an automatic tape type selector.
- Tapes can be played back on deck I; tapes can be played back and recorded on deck II.
- Sound can be recorded as adjusted by the sound image controller.
- Use a normal or chrome position tape.

Amplifier section

① POWER STANDBY/ON switch /STANDBY indicator

This is the switch for electric power.

ON: When set to the ON position, power is supplied and the unit becomes operational.

STANDBY: When set to the STANDBY position, the main power flow is cut and the unit is no longer fully operational. A minute flow of power feeds the unit to maintain operation readiness.

When the STANDBY indicator is on, the unit is in STANDBY.

② REMOTE SENSOR window

③ SMART OPER. (OPERATION) indicator

This lights when smart operation is on.

It goes out after about 30 seconds.

④ CD DIRECT indicator

This lights when CD DIRECT is on.

⑤ SURROUND indicator

This lights when SURROUND & STEREO WIDE is on.

⑥ SMART OPERATION buttons

[START/SET]

Use when programming memory and operating SMART OPERATION.

[MEMORY]

Use when programming SMART OPERATION into memory.

⑦ CD DIRECT button

Press this button to listen to a CD without passing the signal through sound quality adjustment circuits.

⑧ SURROUND & STEREO WIDE button

By turning this switch ON, you can enjoy surround reproduction when rear speakers are used.

By turning this switch ON, you can enjoy STEREO WIDE reproduction with greater left-right spread when rear speakers are not used.

NOTE:

- In the case of monaural source, SURROUND & STEREO WIDE effects cannot be obtained.
- SURROUND & STEREO WIDE functions do not operate if CD DIRECT is on.

⑨ VOLUME control

⑩ PHONES (Headphones) jack

For stereo headphones.

NOTE:

There is no output from the speakers when headphones are plugged into PHONES jack.

⑪ Input selector buttons

[PHONO]

Press to play records on a turntable connected to the PHONO jacks.

[TUNER]

Press to listen to radio broadcast.

[TAPE]

Press to listen to cassette tape.

[CD]

Press to listen to a CD.

[LD/VCR]

Press for playback on an LD player or VCR connected to the LD/VCR jacks.

⑫ ACTIVE LOUDNESS button

This switches the active loudness function ON and OFF. Depending on the volume setting on the amplifier, this function automatically boosts bass and treble response.

⑬ BALANCE control

Used for changing the balance between left and right channels. Usually set this control to the center position.

⑭ MIC (Microphone) jack

This is a standard jack for connecting a microphone.

⑮ MIC LEVEL control

Used for adjusting the volume of microphone.

Sound image controller section

① SOUND CONTROL ON/OFF button

This switches the sound image controller on/off. When it's on, the SOUND CONTROL indicator in the display section lights.

During playback with CD DIRECT on, sound control is not possible.

② FLAT button

Press to reset the equalizer to flat response (no equalization).

③ MEMORY button


Use this to program your desired equalization setting into the memory recall buttons (A to E).

④ PRESET/PGM (PROGRAM) button

Use to switch between recall of PRESET memory settings and your own original memory settings (PROGRAM) with the memory recall buttons. The memory being recalled is indicated by the lit indicator in the display section.

⑤ Display section

- Ⓐ Visual display of spectrum analyzer and graphic equalizer.
- Ⓑ This lights when the sound control is on.
- Ⓒ This indicates the recalled image effect. A lit bar under the letters indicates the one selected.
- Ⓓ This indicates the memory (PRESET and PROGRAM) that can be recalled with the memory recall buttons.
- Ⓔ This lights when active loudness is on.
- Ⓕ Display of the memory being recalled with the memory recall buttons. A lit bar under A to E indicates the one selected.



⑥ CURSOR EQUALIZER buttons

Use to adjust graphic equalizer settings.

[◀, ▶]: Use these to change the frequency range to be adjusted.

[UP, DOWN]: Use these to adjust the degree of equalization.

⑦ Image effect buttons

These buttons let you select the effect mode most suitable for a particular genre of music. Adjust the effect level with the SOUND JOG.

⑧ Memory (PRESET/PROGRAM) recall buttons

Use to recall preset equalization settings. Also use to program into memory and recall desired sound settings.

⑨ SOUND JOG

Use to adjust image effect level.

■ Cassette Deck Section

① Deck I cassette door

② Operation indicators


A Direction (◀, ▶): Indicates direction of tape travel during recording or playback. Flashes slowly in Pause mode. Flashes rapidly during Music Search (MS).

B REC: Lights when recording. It flashes during tape copying.

C ASES mode

FADE: Fade edit in progress.

DISCO: Disco edit in progress.



③ DECK II COUNTER and RESET button

Press the RESET button to reset the tape counter display to 000.

④ SYNCHRO COPY I ▶ II buttons

Used for tape copying.

NORMAL: Copying from the Deck I tape to the Deck II tape at normal recording/playback speed.

HIGH: Copying at about twice normal tape speed. (Copies can be made in about half the NORMAL time.)

⑤ Deck II cassette door

⑥ Deck I EJECT button

⑦ Deck I operation buttons

▶ (PLAY: FWD) For playing back a tape in the forward mode.

◀ (PLAY: REV) For playing back a tape in the reverse mode.

■ (STOP) For stopping the tape.

▶▶ (FAST) Fast forward in forward mode, rewind in reverse mode.

Music search (MS) starts if this is pressed during playback.

◀◀ (FAST) Rewind in forward mode, fast forward in reverse mode.

Music search (MS) starts if this is pressed during playback.

⑧ DOLBY* NR switch

Set this switch to the ON position to activate the DOLBY NR system.

- Tapes recorded using Dolby noise reduction should always be played back with the noise reduction system on. Sound quality will be adversely affected if played back with the system off, or if tapes recorded using a different noise reduction system are played back with the Dolby NR system on.

- It is recommended that tapes recorded with Dolby B type NR be so marked on the label. This will help prevent incorrect setting of the noise reduction switch during playback.

*

Dolby noise reduction manufactured under license from Dolby Laboratories Licensing Corporation.

"DOLBY" and the double-D symbol  are trademarks of Dolby Laboratories Licensing Corporation.

⑨ A.S.E.S. buttons

Used for automatically recording a CD on cassette tape.

FADE (FINE): The sound fades out at the end of the tape.

DISCO: This cross-fades between songs during recording.

NOTE:

- FINE is the mode when performing CD player COMPU PGM EDIT (Computer Allocated Program Editing).*

- The FADE (FINE) modes provide a blank space of about five seconds between songs.*

⑩ DECK II CONTROL buttons

● (REC) To set to recording standby mode. The REC indicator lights and the direction indicators (◀ and ▶) flash. Recording begins when you press the PLAY button (▶ or ▶▶).

II (PAUSE) Temporarily stops tape travel. Cancels pause mode when pressed again or press the PLAY button.

● (MUTE) Used for creating a blank space between songs.

⑪ Deck II operation buttons

Same as Deck I operation buttons ⑦.

⑫ Deck II EJECT button

CD player section

① DISC (I, II)

This is where the disc is set. When power is switched ON and the OPEN/CLOSE button is pressed, the tray is ejected forward.

To insert the tray, press the OPEN/CLOSE button, or lightly push the tray in with your finger. With the disc tray open, press the PLAY button to close the disc tray and start playback.

② OPEN/CLOSE button (I, II)

Press when you wish to eject or load a disc. Each time the buttons is pressed, the tray is alternately pushed out or pulled in.

I: Opens and closes DISC I.

II: Opens and closes DISC II.

③ Indicators

COMPU PGM: Display when COMPU PGM editing is set or used.

AUTO EJECT: Lights during auto eject playback.

PGM: Lights after programming (after program has been memorized).

RND: Lights during random playback.

SCAN: Lights during HI-LITE scan playback.

I, II: Displays the disc number (I or II) of the disc to be played.

▶ : Lights during playback.

II: Lights during temporarily interrupted playback.

1 ▶ REP: Lights during repeat playback of one track.

REP: Lights during repeat play.

TRACK (figure): Displays the current track number and index number (during normal playback and programmed playback) or the track being programmed (during programmed operation).

MINUTES (figure): Displays the minutes of the elapsed time, total playback time, and remaining time.

SECOND (figure): Displays the seconds of the elapsed time, total playback time, and remaining time.

= = Display change = =

Changes each time the TIME (CALENDER) button is pressed.

• **TIME:** Displays the track number of the track being played (TRACK) and the elapsed time (minutes and seconds).

• **REMAIN:** Displays the remaining time on the track being played. When the TIME (CALENDER) button is pressed again, the remaining time on the disc being played will be displayed.

• **TOTAL:** Displays the total number of tracks on the disc (TRACK) and the overall playback time of disc II will be displayed. During playback, the display goes on for about 5 seconds before changing to the TIME display.

• **I/II (music calender):** Only the numbers of the track recorded on DISC I (DISC II) will light.

When inputing a program and when playing, only the programmed track number will light.

The track number will go out one by one after the tracks are played.

Music calender changes DISC I to DISC II (DISC II to DISC I) by holding down TIME (CALENDER) button.

• **A/B (music calender):**

TAPE SIDE A/TAPE SIDE B

After editing, the track numbers that can be recorded on the A (B) side of the tape will light.

Music calender changes A to B (B to A) by holding down TIME (CALENDER) button.

NOTE:

The music calendar section only indicates the tracks on a single disc, but manual switching between Disc I and Disc II is possible. Switching is not automatic.

④ PLAY button (▶)

Press to begin playback, and to cancel the pause mode.

⑤ PGM button (PROGRAM)

Use to program a sequence of tracks.

• Press this button after selecting a desired disc and track with DISC SELECT and track search button. Tunes will be added to the program in the order in which they are specified.

⑥ COMPU PGM button

Press this button, and with the MANUAL/TRACK SEARCH buttons (I◀◀ ◀◀, ▶▶ ▶▶I) specify the length of tape you want to use for recording. Before recording, the CD player automatically programs the order of tracks to minimize the amount of unused tape at the end of a selected tape length.

⑦ MANUAL/TRACK SEARCH buttons

(I◀◀ ◀◀, ▶▶ ▶▶I)

Use these buttons to perform track search during regular playback, programmed playback, or during pause.

Press a button to skip to the previous or the next track. You will continue moving to the next track in the direction of the button you pressed as long as you continue pressing the button.

⑧ DISC SELECT buttons

DISC I: Use to select DISC I for playback or programming.

DISC II: Use to select DISC II for playback or programming.

• During playback, when the disc select button for the disc not being played is pressed, the current playback will stop and playback of that disc will begin.

⑨ AUTO EJECT button

Press to perform auto eject playback.

When a disc is finished playing, the disc's disc tray will automatically eject. The other disc tray will close and playback will start. By replacing discs, continuous playback can be maintained.

⑩ REPEAT button

Press this button for repeat playback. Pressing the button once, twice, or three times will change the repeat mode from single track repeat, all tracks repeat, and repeat playback cancellation.

⑪ TIME (CALENDER) button

This button selects the display mode. Each time the button is pressed, the indication changes from Time, Remain, to Total in that order. Calendar display can be switched by pressing this button. (For details concerning the display contents, refer to the explanation about the indicators.)

⑫ PAUSE button (II)

Press to temporarily interrupt playback. When pressed again, the pause mode is canceled and playback resumes.

⑬ RANDOM PLAY button

Press to begin random playback.

⑭ HI-LITE SCAN button

10 second passages are played starting from the first minute of each track on the CD, in sequence, beginning with the first track.

To set the point in the tracks you want to scan, press this button during playback. The elapsed time is memorized, and then ten second passages of all the remaining tracks are played at the memorized time.

⑮ STOP button (■)

Press to stop playback. When pressed, the player goes into stop mode and all operations stop.

Press to clear a program. When pressed during stop mode, the program stored in memory is cleared.

PRECAUTIONS DURING TRANSPORTATION

- Before transporting, press the OPEN/CLOSE button (II) and open Disc II tray, then press the OPEN/CLOSE button again and close Disc II tray.
- When the track number display goes from "II-01" to "II-00," turn the power off.

NOTE:

Always remove the discs when moving the unit.

Remote control unit**① POWER button****② Function buttons**

LD/VCR Sets function to LD/VCR.
 PHONO Sets function to PHONO.
 CD DIRECT Sets function to CD DIRECT.

③ DECK I operation buttons:

Same as Deck I operation buttons on the CD cassette deck amplifier.

④ TUNER STATION button

- Before operation, memorize broadcast stations in the STATION CALL buttons.
- + Stations change in order in the upward direction.
- Stations change in order in the downward direction.

⑤ SOUND CONTROL operation buttons

ON/OFF: Turns the sound image controller on and off.

CALL: Recalls the preset equalizing curves (PRESET) and memorized sound control (PROGRAM) in sequence.

⑥ VOLUME + (UP)/- (DOWN) button

When pressed, VOLUME on the amplifier is actually moved by a motor.

⑦ SURROUND button

Turns SURROUND & STEREO WIDE on and off.

⑧ Deck II operation button:

Same as Deck II operation buttons and DECK II CONTROL buttons on the cassette deck amplifier (except MUTE).

⑨ CD operation buttons

► Play
 DISC DISC selection
 ■ Stop
 II Pause
 ◀▶ Track search


⑩ Timer operation buttons

SLEEP: Sets the sleep timer.

WAKE-UP: Timer playback setting/cancellation can be performed when the timer playback time has been set. This is shown in the tuner display section.

SNOOZE: Turns off power if pressed after timer playback begins. Timer playback begins again approx. 5 minutes later.

The amplifier input selector automatically switches to the music source being operated when you press the CD playback (►), cassette deck playback (◀▶), or tuner station controls.

Range of remote control

When the remote control unit is pointed at the remote sensor window on the amplifier section and any of its buttons is pressed, the tuner and other components can be operated by remote control. Distance: Within a range of approx. 7 meters from the remote sensor window.

Angle: Within approx. 30 degrees from the center of the remote sensor window.

Remote control will not be possible if there is an obstacle between the remote control unit itself and the remote sensor window.

Performance of the remote control unit is adversely affected in the presence of strong fluorescent light. Keep such lights away, especially from the sensor window.

8. SPECIFICATIONS

Twin CD cassette deck amplifier: XD-Z84T

Amplifier Section

Music power (DIN) 80 W + 80 W (1 kHz, T.H.D. 1 %, 8 Ω)
 Continuous Power Output (DIN) 45 W + 45 W
 (1 kHz, T.H.D. 1 %, 8 Ω)
 Graphic equalizer frequency band..... 60 Hz, 150 Hz,
 400 Hz, 1 kHz, 2.4 kHz, 6 kHz, 15 kHz, ± 5.5 dB
 Total Harmonic Distortion (40 Hz to 20,000 Hz, 22.5 W, 8 Ω)**
 No more than 0.2 %

Cassette Deck Section

Systems 4 track, 2-channel stereo
 Heads Recording/playback head x 1
 Erasing head x 1
 Playback head x 1
 Motor..... DC servo 2 speed motor x 2
 Wow and Flutter..... No more than 0.09 % (WRMS)
 Fast Winding Time Approximately 105 seconds
 (C-60 tape)
 Frequency Response (– 20 dB recording):
 Normal tape 35 Hz to 14,000 Hz ± 6 dB
 CrO₂ tape 35 Hz to 15,000 Hz ± 6 dB
 Signal-to-Noise ratio
 Dolby NR OFF..... 56 dB
 Noise Reduction Effect
 Dolby B type NR ON More than 10 dB (at 5 kHz)

CD Section

Type Compact disc digital audio system
 Operating temperature..... + 5°C – + 35°C
 Frequency response 2 Hz – 20 kHz
 S/N 100 dB or more (EIAJ)
 Wow and flutter Limit of measurement
 (± 0.001 % W.PEAK) or less (EIAJ)
 Number of channels 2 channels (stereo)

Furnished Parts

Operating Instructions 1
 Remote Control Unit 1
 Dry Cell Batteries..... 2

Miscellaneous

Power requirements a.c. 220 Volts ~ , 50/60 Hz
 Power Consumption 310 W
 Dimensions 360 (W) x 375.5 (H) x 309 (D) mm
 Weight (without package) 10 kg

Accessories

EP Adapter 1

- Specifications and design subject to possible modification without notice due to improvement.

** Measured By Audio Spectrum Analyzer.