


Service Manual

PIONEER®
The Art of Entertainment



ORDER NO.
ARP2428

STEREO CD CASSETTE DECK RECEIVER

XR-P320

XR-P320 HAS FOLLOWING VERSIONS:

Type	Power Requirement	Remarks
HEXK	AC220V-230V, 240V (switchable)*	
HBXK	AC220V-230V, 240V (switchable)*	
SD	AC110V, 120V-127V, 220V, 240V (switchable)	
YPW	AC240V only	
HEWZIXK	AC220V-230V, 240V (switchable)*	
KUC	AC120V only	
KUC/CA	AC120V only	

*Change the connection with power transformer primary taps.

- This manual is applicable to HEXK, HBXK, SD and YPW types.
- As to HBXK, SD and YPW types, refer to page 132.
- As to the other types, refer to the applicable service manuals.
- As to IC INFORMATION and DISASSEMBLY, refer to XR-P310/HE service manual ARP2185 or XR-P310/KUC service manual ARP2186.
- Ce manuel pour le service comprend les explications de réglage en français.
- Este manual de servicio trata del método ajuste escrito en español.

CONTENTS

1. SAFETY INFORMATION	2	6. ADJUSTMENT	72
2. EXPLODED VIEWS, PACKING AND PARTS LIST	4	6. REGLAGES	92
3. SCHEMATIC AND PCB CONNECTIONS DIAGRAMS	18	6. AJUSTES	112
4. LINE VOLTAGE SELECTION	65	7. FOR HBXK, SD AND YPW TYPES	132
5. P.C.B PARTS LIST	66	8. SPECIFICATIONS	160
		9. PANEL FACILITIES	161

PIONEER ELECTRONIC CORPORATION 4-1, Meguro 1-Chome, Meguro-ku, Tokyo 153, Japan
PIONEER ELECTRONICS SERVICE INC. P.O. Box 1760, Long Beach, California 90801 U.S.A.
PIONEER ELECTRONICS OF CANADA, INC. 300 Allstate Parkway Markham, Ontario L3R 0P2 Canada
PIONEER ELECTRONIC [EUROPE] N.V. Haven 1087 Keetberglaan 1, 9120 Melsele, Belgium
PIONEER ELECTRONICS AUSTRALIA PTY. LTD. 178-184 Boundary Road, Braeside, Victoria 3195, Australia TEL: [03] 580-9911
© PIONEER ELECTRONIC CORPORATION 1992

AV FEB. 1992 Printed in Japan

3682

This service manual is intended for qualified service technicians; it is not meant for the casual do-it-yourselfer. Qualified technicians have the necessary test equipment and tools, and have been trained to properly and safely repair complex products such as those covered by this manual. Improperly performed repairs can adversely affect the safety and reliability of the product and may void the warranty. If you are not qualified to perform the repair of this product properly and safely, you should not risk trying to do so and refer the repair to a qualified service technician.

WARNING
Lead in solder used in this product is listed by the California Health and Welfare agency as a known reproductive toxicant which may cause birth defects or other reproductive harm (California Health & Safety Code, Section 25249.5).
When servicing or handling circuit boards and other components which contain lead in solder, avoid unprotected skin contact with the solder. Also, when soldering do not inhale any smoke or fumes produced.

1. SAFETY INFORMATION


(FOR USA MODEL ONLY)

1. SAFETY PRECAUTIONS

The following check should be performed for the continued protection of the customer and service technician.

LEAKAGE CURRENT CHECK

Measure leakage current to a known earth ground (water pipe, conduit, etc.) by connecting a leakage current tester such as Simpson Model 229-2 or equivalent between the earth ground and all exposed metal parts of the appliance (input/output terminals, screwheads, metal overlays, control shaft, etc.). Plug the AC line cord of the appliance directly into a 120V AC 60Hz outlet and turn the AC power switch on. Any current measured must not exceed 0.5mA.



AC Leakage Test

ANY MEASUREMENTS NOT WITHIN THE LIMITS OUTLINED ABOVE ARE INDICATIVE OF A POTENTIAL SHOCK HAZARD AND MUST BE CORRECTED BEFORE RETURNING THE APPLIANCE TO THE CUSTOMER.

2. PRODUCT SAFETY NOTICE

Many electrical and mechanical parts in the appliance have special safety related characteristics. These are often not evident from visual inspection nor the protection afforded by them necessarily can be obtained by using replacement components rated for voltage, wattage, etc. Replacement parts which have these special safety characteristics are identified in this Service Manual.

Electrical components having such features are identified by marking with a Δ on the schematics and on the parts list in this Service Manual. The use of a substitute replacement component which does not have the same safety characteristics as the PIONEER recommended replacement one, shown in the parts list in this Service Manual, may create shock, fire, or other hazards.

Product Safety is continuously under review and new instructions are issued from time to time. For the latest information, always consult the current PIONEER Service Manual. A subscription to, or additional copies of, PIONEER Service Manual may be obtained at a nominal charge from PIONEER.

(FOR EUROPEAN MODEL ONLY)

VARO!

AVATTAESSA JA SUOJALUKITUS
OHITETTAESSA OLET ALTTIINA
NÄKYMÄTTÖMÄLLE LASERSÄTEILYLLE.
ÄLÄ KATSO SÄTEESEEN.

ADVERSEL:

USYNLIG LASERSTRÅLING VED ÅBNING
NÅR SIKKERHEDSAFBRYDERE ER UDE AF
FUNKTION UNDGÅ UDSÆTTELSE FOR
STRÅLING.

VARNING!

OSYNLIG LASERSTRÅLING NÅR DENNA
DEL ÄR ÖPPNAD OCH SPÄRREN
ÄR URKOPPLAD. BETRakta EJ STRÅLEN.



LASER
Kuva 1
Lasersäteilyn
varoituserkki

WARNING!

DEVICE INCLUDES LASER DIODE WHICH
EMITS INVISIBLE INFRARED RADIATION
WHICH IS DANGEROUS TO EYES. THERE IS
A WARNING SIGN ACCORDING TO PICTURE
1 INSIDE THE DEVICE CLOSE TO THE LASER
DIODE.



LASER
Picture 1
Warning sign for
laser radiation

IMPORTANT

THIS PIONEER APPARATUS CONTAINS
LASER OF CLASS 1.
SERVICING OPERATION OF THE APPARATUS
SHOULD BE DONE BY A SPECIALLY
INSTRUCTED PERSON.

LASER DIODE CHARACTERISTICS

MAXIMUM OUTPUT POWER: 5 mw
WAVELENGTH: 780-785 nm


LABEL CHECK

HEWZIXK type

CLASS 1
LASER PRODUCT
ARW1046

HEWZIXK type

ADVARSEL
USYNLIG LASERSTRÅLING VED ÅBNING NÅR SIKKERHEDSAF-
BRYDERE ER UDE AF FUNKTION.
UNDGÅ UDSÆTTELSE FOR STRÅLING.
VORSICHT!
UNSICHTBARE LASER-STRÅHLUNG TRITZT AUS, WEENN DECKEL-
ODDER KLAPPE GEÖFFNET IST! NICHT DEM STRAHLE AUSSETZEN!
ARW1046



Additional Laser Caution

1. Laser Interlock Mechanism

The position of the switch (S601) for detecting loading completion is detected by the system microprocessor, and the design prevents laser diode oscillation when the switch (S601) is not in CLMP terminal side (when the mechanism is not clamped and CLMP signal is high level).

Thus, the interlock will no longer function if the switch (S601) is deliberately set to CLMP terminal side (if CLMP signal is low level).

In the test mode *, the interlock mechanism will not function.

Laser diode oscillation will continue if pins 2 and 3 of CXA1471S(IC2101) are connected to ground or pin 20 is connected to high level (ON) or the terminals of Q2101 are shorted to each other (fault condition).

2. When the cover is opened, close viewing of the objective lens with the naked eye will cause exposure to a Class 1 laser beam.

* Refer to page 79.



ADVARSEL
USYNLIG LASERSTRÅLING VED
ÅBNING NÅR SIKKERHEDSAF-
BRYDERE ER UDE AF FUNKTION.
UNDGÅ UDSÆTTELSE FOR
STRÅLING.
VARO!
Avatattaessa ja suojalukitus ohitettaessa olet alttiina näkymättömälle lasersäteilylle. Älä katso säteeseen.
VORSICHT!
UNSICHTBARE LASER-STRÅHLUNG TRITZT AUS, WEENN DECKEL-
ODDER KLAPPE GEÖFFNET IST! NICHT DEM STRAHLE AUSSETZEN!
VARNING!
Osynlig laserstrålning när denna del är öppnad och spärren är urkopplad. Betrakta ej strålen.
ARW 1047

HEXK type

CAUTION
INVISIBLE LASER
RADIATION WHEN OPEN,
AVOID EXPOSURE
TO BEAM
ARW1050

HBXK type

CLASS 1
LASER PRODUCT
ARW1046

HEXK and HBXK types

2. EXPLODED VIEWS, PACKING AND PARTS LIST

2.1 EXTERIOR, FRONT PANEL SECTION and PACKING


NOTES:

- The parts with an encircled number are generally unavailable because they are not in our Master Spare Parts List.
- The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- Parts marked by "⊙" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.


• Parts List of Exterior, Front Panel Section and Packing

Mark	No.	Description	Part No.	Mark	No.	Description	Part No.
	1	VR.KNOB (ABS)	AAB1278		53	CD SUB CHASSIS	ANG1636
	2	WAKE UP BUTTON	AAD2180		54	HEAT SINK	ANH1244
	3	TIMER BUTTON	AAD2181		55	SHIELD PLATE OF MECHANISM	ANK1157
	4	POWER BUTTON	AAD2183				
	5	AUDITION BUTTON	AAD2185		56	OPE. INSTRUCTIONS (Dutch, Swedish, Spanish, Portuguese)	ARC1330
	6	DECK BUTTON Ass'y	AAD2191		57	OPE. INSTRUCTIONS (English, French, German, Italian)	ARE1226
	7	CD-TUNER BUTTON (OPEN/CLOSE)	AAD2192		58		
	8	CD-TUNER BUTTON (BAND)	AAD2193		59		
	9	S.F.C. BUTTON	AAD2194		60		
	10	EJECT BUTTON (L)	AAD2195		61		
	11	EJECT BUTTON (R)	AAD2196	⊙	62	SPACER Ass'y	AWZ3923
	12	FUNCTION BUTTON	AAD2208	⊙	63	AF-TUNER Ass'y	AWZ3914
	13	WAKE UP BUTTON	AAD2215	⊙	64	VOLUME Ass'y	AWZ3919
	14	SLIDE KNOB	AAE1158	⊙	65	DECK SW Ass'y	AWZ3921
	15	REMOTE CONTROL FILTER	AAK2010	⊙	66	DECK-1 Ass'y	AWZ3212
	16	INDICATOR LENS	AAK2101	⊙	67	DECK-2 Ass'y	AWZ3213
	17	DOOR PANEL (L)	AAK2265	⊙	68	TRANS Ass'y	AWZ3214
	18	DOOR PANEL (R)	AAK2266	⊙	69	REGULATOR Ass'y	AWZ3215
	19	TRAY CAP	AAK2267	⊙	70	POWER Ass'y	AWZ3230
	20	TUNER DISPLAY WINDOW	AAK2268	⊙	71	TX-CD SW Ass'y	AWZ3925
	21	DOOR WINDOW PLATE (L)	AAK2269	⊙	72	AMP SW Ass'y	AWZ3926
	22	DOOR WINDOW PLATE (R)	AAK2270		73		
	23	HALF-POCKET (L)	AAN1316		74	DUMPER Ass'y	AXA1011
	24	HALF-POCKET (R)	AAN1317		75	REMOTE CONTROL UNIT (CU-SX039)	AXD1273
	25	INSULATING SPACER	AAX-444		76	BATTERY COVER	AZN2176
	26				77	SCREW	BBZ30P080FMC
	27	SCREW (STEEL)	ABA1095		78	SCREW	BBZ30P080FZK
	28	DOOR SPRING (L)	ABH1070		79	SCREW	BBZ30P180FMC
	29	DOOR SPRING (R)	ABH1071		80	SCREW	BCZ30P060FZK
	30	KEEP PLATE	ABK1017		81	SCREW	BPZ226P080FMC
Δ	31	AC POWER CORD	ADG1049		82	SCREW	BPZ30P100FMC
	32	FM ANTENNA	ADH1005	⊙	83	SCREW	CBZ30P080FMC
	33	RUBBER SHEET	AEB1111	⊙	84	2 MECHA UNIT	EKK2015
	34	NYLON BINDER	AEC-093		85	1 MECHA UNIT	EKK2025
	35	BINDER	AEC-826		86	NUT	NK90FUC
	36	STRAIN RELIEF	AEC-882		87		
	37	NYLON RIVET	AEC1160		88	FOOT (RUBBER)	REC-434
	38	BINDER	AEP-215		89	SCREW	VBZ30P060FMC
	39	DRY CELL (R03,AAA)	AEX-021		90	SCREW	VBZ35P080FMC
	40	FRONT PAD (L,R)	AHA1485		91	SCREW	VPZ30P080FMC
	41	REAR PAD (L,R)	AHA1486		92	SCREW	VPZ30P080FZK
	42	PACKING CASE	AHD2237	Δ	93	SCREW	VPZ30P200FMC
	43	PACKING SHEET	AHG1090	Δ	94	FU701 FUSE (T800mA/250V)	AEK-507
	44	LITERATURE BAG	AHG1091		95	FU702 FUSE (T2A/250V)	AEK-511
	45	FRONT PANEL	AMB1942	Δ	96	FU703 FUSE (T1A/250V)	AEK-508
	46	MECHANISM BEARING MOLD	AMR2257	Δ	97	FU704 FUSE (T500mA/250V)	AEK-505
	47	CHASSIS	ANA1164		98	LOOP ANTENNA	ATB1006
	48	REAR PANEL	ANC1855	Δ	99	T1 POWER TRANSFORMER	ATS1404
	49	BONNET	ANE1337				
	50	PACK HOLDER	ANG1428				
	51	HEAT SINK HOLDER	ANG1542				
	52	P.C.B. SUPPORT METAL	ANG1543				


- **Exterior**




• Front Panel Section (Rear View)



• Front Panel Section (Front View)



• Packing



A

B

C

D

2.2 1 MECHA UNIT (EXK2025)

• Parts list of 1 Mecha unit

Mark	No.	Description	Parts No.
	1	FLYWHEEL UNIT (FWD)	EXA1222
	2	FLYWHEEL UNIT (RVS)	EXA1223
	3	ROLLER UNIT (FWD)	EXA1224
	4	ROLLER UNIT (RVS)	EXA1225
	5	LIMITER UNIT	EXA1226
	6	LEVER UNIT	EXA1227
	7	EJECT LEVER L2	AZN2063
	8	LEVER	ENV1155
	9	BRAKE	ENV1317
	10	CAM GEAR	ENV1158
	11	LOCK ARM	ENV1159
	12	NR ARM	ENV1163
	13		
	14	REEL	ENV1335
	15	REEL BUSH	ENV1338
	16	ARM	ENV1330
	17	EJECT LEVER L1	AZN2108
	18	BUSH	ENV1184
	19	MAGNET	ENV1336
	20	BELT	ENT1023
	21	SPRING	EBH1424
	22	SPRING	EBH1401
	23	SPRING	EBH1203
	24	SPRING	EBH1402
	25	SPRING	EBH1405
	26	SPRING	EBH1406
	27	SPRING	EBH1407
	28	SPRING	EBH1408
	29	SPRING	EBH1413
	30	SPRING	EBH1409
	31	SPRING	EBH1410
	32	SPRING	EBH1256
	33	SPRING	EBL1013
	34	SPRING	EBL1014
	35	MOTOR UNIT	EXA1241
	36	SWITCH (Detect)	ESN1003
	37	SWITCH (Mode)	ESN1004
	38	SOLENOID	EXP1005
	39	HALL IC	DN6847SE
	40	COMPLEX PCB	ENX1007
	41	CONNECTOR (10P)	EKS1013
	42	LEAD WIRE (4P)	EDD1003
	43	CONNECTOR (3P)	EDE1009
	44	SCREW (AZIMUTH)	EBA1020
	45		

Mark	No.	Description	Parts No.
	46	SCREW (M2×8)	ATZ20P080FMC
	47	SCREW	BSZ20P050FMC
	48	SCREW	PMS26P025FUC
	49	WASHER	EBF1008
	50	WASHER	EBF1009
	51	WASHER	EBF1010
	52	WASHER	EBF1011
	53		
	54	ARM UNIT	EXX1006
	55	ARM UNIT	EXX1003
	56	P HEAD ASSEMBLY	EXX1008
	101	HEAD BASE	ENC1281
	102	BRACKET	ENC1194
	103	PLATE	ENC1285
	104	BRACKET	ENC1199
	105	ARM	ENC1188
	106	HOLDER	ENV1161
	107	HOLDER	ENV1301
	108	GEAR	ENV1177
	109	P HEAD UNIT	EXA1110
	110	SCREW	JGZ14P085FNI
	111	SCREW	JGZ14P040FNI
	112	CHASSIS UNIT	

• 1 Mecha unit

Note :


When removing the chassis unit to replace the arm unit (EXX1003), the chassis unit can be easily removed by cutting the (A) part of No.55 (1/2) with a nippers, etc. (see following illustration).

A

B

C


D



• 1 Mecha unit

Note :
When removing the chassis unit to replace the arm unit (EXX1003), the chassis unit can be easily removed by cutting the (A) part of No.55 (1/2) with a nippers, etc. (see following illustration).

Parts No.
ATZ20P080FMC
BSZ20P050FMC
PMS26P025FUC
EBF1008
EBF1009
EBF1010
EBF1011
EXX1006
EXX1003
EXX1008
ENC1281
ENC1194
ENC1285
ENC1199
ENC1188
ENV1161
ENV1301
ENV1177
EXA1110
JGZ14P085FNI
JGZ14P040FNI
.....



2.3 2 MECHA UNIT (EXK2015)


• Parts list of 2 Mecha unit

Mark	No.	Description	Parts No.
	1	FLYWHEEL UNIT (FWD)	EXA1222
	2	FLYWHEEL UNIT (RVS)	EXA1223
	3	ROLLER UNIT (FWD)	EXA1224
	4	ROLLER UNIT (RVS)	EXA1225
	5	LIMITER UNIT	EXA1226
	6	LEVER UNIT	EXA1227
	7	EJECT LEVER R2	AZN2064
	8	NR LEVER	ENV1155
	9	BRAKE	ENV1317
	10	CAM GEAR	ENV1158
	11	LOCK ARM	ENV1159
	12	NR ARM	ENV1163
	13		
	14	REEL	ENV1335
	15	REEL BUSH	ENV1338
	16	ARM	ENV1330
	17	EJECT LEVER R1	AZN2109
	18	BUSH	ENV1184
	19	MAGNET	ENV1336
	20	BELT	ENT1023
	21	SPRING	EBH1424
	22	SPRING	EBH1401
	23	SPRING	EBH1203
	24	SPRING	EBH1402
	25	SPRING	EBH1405
	26	SPRING	EBH1406
	27	SPRING	EBH1407
	28	SPRING	EBH1408
	29	SPRING	EBH1412
	30	SPRING	EBH1409
	31	SPRING	EBH1410
	32	SPRING	EBH1256
	33	SPRING	EBL1013
	34	SPRING	EBL1014
	35	MOTOR UNIT	EXA1241
	36	SWITCH (Detect)	ESN1003
	37	SWITCH (Mode)	ESN1004
	38	SOLENOID	EXP1005
	39	HALL IC	DN6847SE
	40	COMPLEX PCB	ENX1012
	41	CONNECTOR (15P)	EKS1012
	42	LEAD WIRE (4P)	EDD1003
	43	CONNECTOR (5P)	EDE1008
	44	SCREW (AZIMUTH)	EBA1020
	45		

Mark	No.	Description	Parts No.
	46	SCREW (M2×8)	ATZ20P080FMC
	47	SCREW	BSZ20P050FMC
	48	SCREW	PMS26P025FUC
	49	WASHER	EBF1008
	50	WASHER	EBF1009
	51	WASHER	EBF1010
	52	WASHER	EBF1011
	53		
	54	ARM UNIT	EXX1006
	55	ARM UNIT	EXX1003
	56	R/P HEAD ASSEMBLY	EXX1007
	101	HEAD BASE	ENC1281
	102	BRACKET	ENC1194
	103	PLATE	ENC1285
	104	BRACKET	ENC1199
	105	ARM	ENC1189
	106	HOLDER	ENV1161
	107	HOLDER	ENV1301
	108	GEAR	ENV1177
	109	R/P HEAD UNIT	EXA1109
	110	SCREW	JGZ14P085FNI
	111	SCREW	JGZ14P040FNI
	112	CHASSIS UNIT	

• 2 Mecha unit

Note :
When removing the chassis unit to replace the arm unit (EXX1003), the chassis unit can be easily removed by cutting the (A) part of No.55 (1/2) with a nippers, etc. (see following illustration).



• 2 Mecha unit

Note :
When removing the chassis unit to replace the arm unit (EXX1003), the chassis unit can be easily removed by cutting the (A) part of No.55 (1/2) with a nippers, etc. (see following illustration).

s No.

20P080FMC
20P050FMC
26P025FUC
1008
1009

1010
1011

1006
1003

1007

1281
1194
1285
1199
1189

1161
1301
1177
1109

4P085FNI

4P040FNI

.....

A

B

C


D

A

B

C

D





• Parts List of CD Player Section

Mark	No.	Description	Part No.
	51	Semi – fixed VR	PCP1008
	52	Chip capacitor	CKSYF105Z16
	53	Screw	PMZ26P040FMC
	54	Washer	WT26D060D013
	55	Washer	WA62D095D013
	56	Screw	PBZ30P080FMC
	57	Mechanism chassis	
	58	Screw	PPZ30P100FMC
	59	Screw	ZMK20H040FBT
	60	Screw	PPZ30P100FMC
	61	Tray	PNW2172

This diagram is an exploded view of a mechanical assembly, likely a pump or motor component. It shows various parts numbered 1 through 61, along with callouts A and B. The parts include a main housing (20), a base plate (25), a motor unit (21), a pump head (19), a drive shaft (14), a gear (15), a pulley (10), a belt (3), a cover (11), a bracket (7), a plate (8), a flange (6), a nut (5), a screw (1), a pin (4), a bush (2), a washer (18), a nut (18), a pin (23), a screw (23), a pin (49), a screw (49), a pin (17), a screw (22), a pin (24), a nut (48), a pin (13), a screw (55), a nut (15), a pin (16), a screw (54), a pin (53), a screw (59), a pin (14), a pin (58), a pin (46), a screw (46), a pin (42), a screw (26), and a pin (38). The diagram illustrates the assembly sequence and the relative positions of the components.

• CD Player Section

Part No.
PCP1008
CKSYF105Z16
PMZ26P040FMC
WT26D060D013
WA62D095D013
PBZ30P080FMC
PPZ30P100FMC
ZMK20H040FBT
PPZ30P100FMC
PNW2172



• How to install the disc table

1 Use nippers or other tool to cut the two sections marked **A** in figure **1**. Then remove the spacer.

2 While supporting the spindle motor shaft with the stopper, put spacer on top of the motor base (angled so it doesn't touch section **B**), and stick the disc table on top (takes about 9kg pressure). Take off the spacer.

Spindle motor mounting position

Chassis

Spacer

Spacer setting position

Disc table

Motor base

Spindle motor

Stopper

7.3mm

3.5mm ± 0.05mm


MS

5. SWITCHES (The underlined indicates the switch position)

AF-TUNER Ass'y	TX-CD SW Ass'y	AMP SW Ass'y
S301:BEAT CUT 1-2	S1201:CLOCK ADJ.	S1301:MEMORY
	S1202:TIMER SET	S1302:START/SET
	S1203:WAKE UP	S1303:MODE
	S1204:REC	S1304:POWER
DECK SW Ass'y	S1205:DISPLAY	S1305:B. G. M. /TREBLE EQ
S1401:DOLBY NR ON-OFF	S1206:AUTO PRE-MEMORY	S1306:HALL/S. ST./WIDE
S1402:DECK2 STOP	S1207:AM-NR/FM-MONO	S1307:DISCO./P. BASS EQ
S1403:DECK2 FWD	S1208:BAND	S1308:SFC CLEAR
S1404:DECK2 FF	S1209:TUNING +	S1309:CD
S1405:ASES	S1210:TUNING -	S1310:TUNER
S1406:DECK2 REV	S1211:FREQ./STATION	S1311:TAPE
S1407:DECK2 REW	S1221:PLAY	S1312:PHONO
S1409:DECK1 STOP	S1222:TRACK -	
S1410:REC/PAUSE	S1223:TRACK +	
S1411:DECK1 FF	S1224:OPEN/CLOSE	
S1412:DECK1 FWD	S1225:STOP	
S1413:COPY	S1226:PAUSE	
S1414:DECK1 REW	S1227:PROGRAM	
S1415:DECK1 REV	S1228:HI-LITE SCAN	
	S1229:REPEAT	

is indicates the
Therefore, when
ignation.
numbers.

actual circuit may




A

B

C

D

3.2 POWER Ass'y, TRANS Ass'y, REGULATOR Ass'y and SPACER Ass'y



IC801	IC802	IC803	IC804	IC805	IC806	IC807	IC808	IC809	IC810	IC811	IC812	IC813	IC814	IC815	IC816	IC817	IC818	IC819	IC820	IC821	IC822	IC823	IC824	IC825	IC826	IC827	IC828	IC829	IC830	IC831	IC832	IC833	IC834	IC835	IC836	IC837	IC838	IC839	IC840	IC841	IC842	IC843	IC844	IC845	IC846	IC847	IC848	IC849	IC850	IC851	IC852	IC853	IC854	IC855	IC856	IC857	IC858	IC859	IC860	IC861	IC862	IC863	IC864	IC865	IC866	IC867	IC868	IC869	IC870	IC871	IC872	IC873	IC874	IC875	IC876	IC877	IC878	IC879	IC880	IC881	IC882	IC883	IC884	IC885	IC886	IC887	IC888	IC889	IC890	IC891	IC892	IC893	IC894	IC895	IC896	IC897	IC898	IC899	IC900	IC901	IC902	IC903	IC904	IC905	IC906	IC907	IC908	IC909	IC910	IC911	IC912	IC913	IC914	IC915	IC916	IC917	IC918	IC919	IC920	IC921	IC922	IC923	IC924	IC925	IC926	IC927	IC928	IC929	IC930	IC931	IC932	IC933	IC934	IC935	IC936	IC937	IC938	IC939	IC940	IC941	IC942	IC943	IC944	IC945	IC946	IC947	IC948	IC949	IC950	IC951	IC952	IC953	IC954	IC955	IC956	IC957	IC958	IC959	IC960	IC961	IC962	IC963	IC964	IC965	IC966	IC967	IC968	IC969	IC970	IC971	IC972	IC973	IC974	IC975	IC976	IC977	IC978	IC979	IC980	IC981	IC982	IC983	IC984	IC985	IC986	IC987	IC988	IC989	IC990	IC991	IC992	IC993	IC994	IC995	IC996	IC997	IC998	IC999	IC1000
-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	--------



This PCB connection diagram is viewed from the foil side.

POWER Ass'y (AWS 3530)

PHONES

OT
TX-CD SW
Y'ssA
EPL

OT
MIAM
Y'22A
100501

TO
DECK-1
Ass'y
JH

OT
VOLUME
A22Y
J17

TO
AF-TUNER
Ass'y
J16

TO
DECK-S
Ass'y
JIS

20801

1080

8080

5080

0722

4270

428

2280

1280 2

8070

100

8 510

2

NC 708

IC 103

NOTE

1. This P.C.B connection diagram is viewed from the parts mounted side.
2. The parts which have been mounted on the board can be replaced with those shown with the corresponding wiring symbols listed in the following Table.

P.C.B. pattern diagram indication	Corresponding part symbol	Part Name
		Transistor
		Radiator type transistor
		Diode
		Resistor
		Capacitor (Polarity)
		Capacitor (Non-polarity)


Others

P.C.B. pattern diagram indication	Part Name
IC	IC
S	Switch
RY	Relay
L	Coil
F	Filter
VR	Variable resistor or Semi-fixed resistor

3. The capacitor terminal marked with⊙(double circles) shows negative terminal.
4. The diode terminal marked with⊙(double circles) shows cathode side.
5. The transistor terminal to which E is affixed shows the emitter.

This PCB connection diagram is viewed from the parts mounted side.


POWER Ass'y (AWZ 3230)





- IC805
- IC801
- IC803
- IC802
- Q12
- Q854
- Q11
- Q853
- Q852
- Q851
- IC709
- Q741
- Q22
- Q23
- IC701
- IC705
- IC702
- IC703
- Q702
- Q701
- Q708
- Q707
- Q709
- Q703
- Q710
- Q742
- Q743
- Q751
- Q752
- Q753
- Q754
- Q755
- Q756
- Q757
- Q758
- Q759
- Q760
- Q761
- Q762
- Q763
- Q764
- Q765
- Q766
- Q767
- Q768
- Q769
- Q770
- Q771
- Q772
- Q773
- Q774
- Q775
- Q776
- Q777
- Q778
- Q779
- Q780
- Q781
- Q782
- Q783
- Q784
- Q785
- Q786
- Q787
- Q788
- Q789
- Q790
- Q791
- Q792
- Q793
- Q794
- Q795
- Q796
- Q797
- Q798
- Q799
- Q800


POWER Ass'y (AWZ3230)

- (P51) To DECK-1 Assy J11
 - +5V
 - PB 1 L
 - GND
 - PB 1 R
 - 5V
- (P52) To DECK-2 Assy J12
 - +5V
 - PB 2 L
 - GND
 - PB 2 R
 - 5V
 - PB 1/2
 - REC L
 - BIAS GND
 - REC R
 - BIAS
 - BIAS CONT
 - REC CrO2
 - BEAT CUT
- (P32) To AF-TUNER Assy J16
 - W DE 2
 - W DE 1
 - BASS 2
 - BASS 1
 - TREBLE 2
 - TREBLE 1
 - MUTE 2
 - L+R/VOL LEVEL
 - VOL UP
 - VOL DOWN
 - MUTE 1
 - ASP IN R
 - ASP GND
 - ASP IN L
 - SUPER BASS
- (P39) TO VOLUME Assy J17
 - VOL OUT L
 - GND
 - VOL OUT R
 - +5V
 - 5V
 - MUTE 1
 - VOL IN R
 - GND
 - VOL IN L
 - L+R IN
 - L+R OUT/LEVEL
 - VOL DOWN
 - VOL UP
 - M. +12V
 - M. GND
- (P30) TO AF-TUNER Assy CN14
 - MIC(SD)
 - REC CrO2
 - SP RELAY
 - STANDBY
 - BEAT CUT
 - BIAS GND
 - REF GND
 - VT
 - +5V
 - 5V
 - +12V
 - M. +12V
 - M. GND
 - u. +5.6V
 - D. GND
- (P30) TO AF-TUNER Assy CN15
 - PB 1/2
 - BIAS
 - BIAS CONT
 - REC R
 - MIC GND
 - REC L
 - PB R
 - GND
 - PB L
 - CD R
 - GND
 - CD L
 - TX GND
 - CD ON/OFF
- (P58) TO MOTHER BOARD Assy CN2001
 - CD L
 - GND
 - CD R
 - ON/OFF
 - CD -7.5V
 - CD +7.5V
 - GND
- (P50) TO TX-CD Assy J19
 - D. GND
 - u. +5.6V
 - VFPD
 - FL AC2
 - FL AC1
 - RESET











3.3 AF-TUNER Ass'y (1/2), (2/2), 1 MECHA unit (1/2) and 2 MECHA unit (1/2)






To TX-CD SW Ass'y
J23 (→P49)

DUAL
STEREO
REND-CON
TUNE
RESET
LOCAL
TX MUTE
FM MONO
PLL CLK
PLL DE
CD RED/EN
TX RED/EN
S. DATA
S. CLK

IC305 (CXA1100P)



Q327, Q328
INVERTER BUFFER

SUPER BASS

SFC L IN
GND
SFC R IN
MUTE 1
VOL DOWN
VOL UP
L+R/VOL LEVEL
MUTE 2
TREBLE 1
TREBLE 2
BASS 1
BASS 2
WIDE 1
WIDE 2

To POWER Ass'y CN16
(→P27)


1 REV
1 FWD
K14
K13
K12
K04
K03
K02
DOLBY

To DECK SW Ass'y J25
(→P40)


2 REC
AUDITION
+5V
K01
K00
2 REV
2 FWD

To DECK SW Ass'y J24
(→P40)

1 MECHA unit (EXK2025)(1/2)



2 MECHA unit (EXK2015)(1/2)



A

B


C

D


E

F

This PCB connection diagram is viewed from the parts mounted side.




AF-TUNER As'y
(AWΣ 3914)

[illegible]


This PCB connection diagram is viewed from the parts mounted side.

VOLUME Ass'y (AWZ 3919)




To POWER Ass'y
CN17

DECK SW Ass'y (AWZ3921)



3.5 TX-CD SW Ass'y and AMP SW Ass'y

This PCB connection diagram is viewed from the foil side.




TX-CD SW Ass'y (AWZ3925)

To POWER Ass'y
CN19 (→P27)
RESET
FL AC1
FL AC2
VFDP
u+5.6V
D. GND


To AF-TUNER
Ass'y
CN 23 (→P32)

AMP SW Ass'y (AWZ 3926)





5


DECK-2 A




F



Ass'y (AWZ3213)




To POWER Ass'y
CN12



**1 MECHA unit
(EXK2025)(2/2)**

A




**2 MECHA unit
(EXK2015)(2/2)**

7


0

DECK-1 As2 γ (AW53515)



CNN
To POWER Assy


AF-TUNER Ass'y (2/2) (AWZ3914)



To AF-TUNER Ass'y (1/2) (P31)

3.7 MOTHER BOARD Ass'y and SERVO MECHA Ass'y

MOTHER BOARD Ass'y (PWM1556)

IC2301
CXD2500AQ

Pin No.	Volts	Pin No.	Volts	Pin No.	Volts	Pin No.	Volts
1	5.0	21	0.0	41	NC	61	NC
2	NC	22	2.5	42	5.0	62	NC
3	5.0	23	5.0	43	NC	63	0.0
4	2.6	24	2.5	44	NC	64	NC
5	NC	25	NC	45	NC	65	0.0
6	5.0	26	0.0	46	4.4	66	1.1~1.5
7	NC	27	2.5	47	0.0	67	5.0
8	NC	28	0.0	48	0.0	68	0.0
9	0.0	29	NC	49	1.1~1.5	69	2.1~2.5
10	0.0	30	0.0	50	NC	70	5.0
11	NC	31	NC	51	NC	71	5.0
12	0.0	32	2.5	52	0.0	72	5.0
13	NC	33	5.0	53	2.5	73	5.0
14	NC	34	2.5	54	NC	74	5.0
15	NC	35	2.5	55	0.0	75	5.0
16	NC	36	NC	56	NC	76	0.0
17	0.0	37	NC	57	NC	77	5.0
18	2.5	38	NC	58	NC	78	5.0
19	2.4	39	NC	59	0.0	79	5.0
20	2.4	40	NC	60	NC	80	0.0

IC2101
CX1471S

Pin No.	Volts	Pin No.	Volts
1	NC	12	NC
2	2.9	13	-0.9
3	-4.7	14	-0.7
4	0.0	15	0.0
5	0.0	16	0.0
6	-5.0	17	0.0
7	0.0	18	0.8
8	0.0	19	0.0
9	NC	20	5.0
10	0.0	21	5.0
11	NC	22	NC

IC2404
NJM4558D-D

Pin No.	Volts
1	-0.2
2	1.0
3	1.0
4	-5.0
5	1.0
6	1.0
7	-0.2
8	5.0

IC2202
LA6517


Pin No.	Volts
1	0.0
2	6.5
3	0.0
4	-6.5
5	0.0
6	0.0
7	0.0
8	0.0



IC2020
MS298P

Pin No.	Volts
1	-6.5
2	NC
3	-5.0
4	0.0
5	-6.5
6	-5.7
7	3.3
8	1.1
9	5.0
10	1.1
11	0.6
12	5.0
13	6.5
14	5.0
15	1.2
16	6.5

IC2201
LA6520


Pin No.	Volts
1	1.1~1.5
2	1.1~1.5
3	1.1~1.5
4	-0.7
5	1.7
6	1.7
7	0.0
8	0.0
9	0.0
10	NC
11	NC
12	6.5
13	-6.5





IC2151
 CXA1372S

Pin No.	Volts	Pin No.	Volts
1	0.0	25	-5.0
2	0.0	26	5.0
3	0.0	27	5.0
4	0.0	28	5.0
5	0.0	29	5.0
6	0.0	30	5.0
7	0.0	31	5.0
8	0.0	32	0.0
9	0.0	33	5.0
10	0.0	34	0.0
11	-1.0	35	0.0
12	0.0	36	NC
13	0.2	37	2.5
14	0.0	38	2.5
15	0.0	39	5.0
16	5.0	40	-1.5
17	0.0	41	-1.7
18	0.0	42	5.0
19	0.0	43	-0.7
20	1.2	44	-1.6
21	0.0	45	0.0
22	-4.0	46	0.8
23	1.3	47	-5.0
24	0.0	48	0.0

















Waveforms


Note: The encircled numbers denote measuring points in the schematic diagram.

*1 50T-JUMP: After switching to the pause mode, press the manual search key.

*2 FOCUS-IN: Press the key without loading a disc.


② TP1-Pin 1: PLAY MODE (RF) 500mV/div 500nsec/div  - GND	⑤ IC2202-Pin 1: FOCUS-IN (*2) MODE (FODR) 1V/div 200msec/div  - GND	⑦ IC2201-Pin 4: TRACK SEARCH MODE (SPDR) 2V/div 50msec/div  - GND
② TP1-Pin 1: TRACK SEARCH MODE (RF) 500mV/div 200μsec/div  - GND	⑤ IC2202-Pin 1: PLAY MODE (FODR) 1V/div 1msec/div  - GND	⑧ IC2201-Pin 3: PLAY MODE (CADR) 1V/div 2S/div  - GND
③ TP1-Pin 6: PLAY MODE (FOER) 100mV/div 10msec/div  - GND	⑥ IC2202-Pin 3: PLAY MODE (TRDR) 500mV/div 1msec/div  - GND	⑧ IC2201-Pin 3: TRACK SEARCH MODE (CADR) 2V/div 200msec/div  - GND
④ TP1-Pin 2: PLAY MODE (TRER) 1V/div 10msec/div  - GND	⑥ IC2202-Pin 3: 50T-JUMP (*1) MODE (TRDR) 500mV/div 1msec/div  - GND	⑨ IC2151-Pin 38: PLAY MODE (EFM) 2V/div 500nsec/div  - GND
④ TP1-Pin 2: 50T-JUMP (*1) MODE (TRER) 1V/div 1msec/div  - GND	⑦ IC2201-Pin 4: PLAY MODE (SPDR) 1V/div 50msec/div  - GND	

This PCB connection diagram is viewed from the parts mounted side.




1. This P.C.B. connection diagram is viewed from the parts mounted side.
2. The parts which have been mounted on the board can be replaced with those shown with the corresponding wiring symbols listed in the above table.
3. The capacitor terminal marked with  shows negative terminal.
4. The diode marked with  shows cathode side.
5. The transistor terminal marked with  shows emitter.

Pin No.	Volts	Pin No.	Volts	Pin No.	Volts
1	5	31	N. C	61	N. C
2	N. C	32	2. 5	62	N. C
3	5	33	5	63	0
4	2. 6	34	2. 5	64	N. C
5	N. C	35	2. 5	65	0
6	5	36	N. C	66	3.3~4.6
7	N. C	37	N. C	67	5
8	N. C	38	N. C	68	0
9	0	39	N. C	69	2.1~3
10	0	40	N. C	70	5
11	N. C	41	N. C	71	5
12	0	42	5	72	5
13	N. C	43	N. C	73	5
14	N. C	44	N. C	74	5
15	N. C	45	N. C	75	5
16	N. C	46	4. 4	76	0
17	0	47	0	77	5
18	2. 5	48	0	78	5
19	2. 4	49	0~0.3	79	5
20	2. 4	50	N. C	80	0
21	0	51	N. C		
22	2. 5	52	0		
23	5	53	2. 5		
24	2. 5	54	N. C		
25	N. C	55	0		
26	0	56	N. C		
27	2. 5	57	N. C		
28	0	58	N. C		
29	N. C	59	0		
30	0	60	N. C		




VR2102 VR2103 VR2152 VR2151

IC2301		IC2151
IC2401	Q2401	IC2201
IC2404	IC2020	IC2351
	Q2062	Q2381 Q2382



MOTHER BOARD Ass'y (PWM 1556)




4. LINE VOLTAGE SELECTION

Line voltage can be changed with the following steps.

1. Disconnect the AC power cord.
2. Remove the bonnet.
3. Change the connection with the power transformer primary taps.
4. Stick the line voltage label on the rear panel.

Part No.	Description
AAX-193	220V label
AAX-192	240V label



5. P.C.B PARTS LIST

NOTES:

- Part without part number cannot be supplied.
- Parts marked by "⊙" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.
- The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- When ordering resistors, first convert resistance values into code form as shown in the following examples.

Ex. 1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47k ohm (tolerance is shown by J = 5%, and K = 10%).

560Ω	56×10^1	561.....	RD1/8PM	Ⓜ	Ⓜ	Ⓜ	J
47kΩ	47×10^3	473.....	RD1/4PS	Ⓜ	Ⓜ	Ⓜ	J
0.5Ω	0R5.....		RN2H	Ⓜ	Ⓜ	Ⓜ	K
1Ω	010.....		RS1P	Ⓜ	Ⓜ	Ⓜ	K

Ex. 2 When there are 3 effective digits (such as in high precision metal film resistors).

5.62kΩ	562×10^1	5621.....	RN1/4SR	Ⓜ	Ⓜ	Ⓜ	F
--------	-------------------	-----------	---------	---	---	---	---

Mark	No.	Description	Part No.	Mark	No.	Description	Part No.
------	-----	-------------	----------	------	-----	-------------	----------

LIST OF ASSEMBLIES

⊙	SPACER Ass'y	
⊙	AF-TUNER Ass'y	AWZ3914
⊙	VOLUME Ass'y	AWZ3919
⊙	DECK SW Ass'y	AWZ3921
⊙	DECK-1 Ass'y	AWZ3212
⊙	DECK-2 Ass'y	AWZ3213
⊙	TRANS Ass'y	AWZ3214
⊙	REGULATOR Ass'y	AWZ3215
⊙	POWER Ass'y	AWZ3230
⊙	TX-CD SW Ass'y	AWZ3925
⊙	AMP SW Ass'y	AWZ3926
⊙	MOTHER BOARD Ass'y	PWM1556

SPACER Ass'y

There is no supply part in this unit.

⊙DECK-1 Ass'y (AWZ3212) SEMICONDUCTORS

IC1001	OP-AMP IC	RC4558DXP
--------	-----------	-----------

CAPACITORS

C1001,1002	CERAMIC CAPACITOR	CKCYB681K50
C1003,1004	CERAMIC CAPACITOR	CCCSL101J50
C1005,1006	AUDIO FILM CAPACITOR	CFTXA223J50
C1007,1008	ELECTR.CAPACITOR	CEAS2R2M50
C1009,1010	ELECTR.CAPACITOR	CEAS470M10
C1011,1012	ELECTR.CAPACITOR	CEAS101M10

RESISTORS

VR1001	VR	VRTM6H202
VR1002	VR	VRTM6H202
	OTHER RESISTORS	RD1/8PM

⊙DECK-2 Ass'y (AWZ3213) SEMICONDUCTORS

IC1101	OP-AMP	RC4558DXP
--------	--------	-----------

Q1101,1102	N-FET	2SK373
Q1103	TRANSISTOR	XDC143ES
Q1104	TRANSISTOR	2SA1515
Q1105,1106	TRANSISTOR	2SC3377
Q1107,1108	TRANSISTOR	2SC2458

D1101-1106	DIODE	1SS252
------------	-------	--------

COILS and TRANSFORMERS

L1101,1102	INDUCTOR	LTA822J
T1101	OSC TRANSFORMER	ATX-043

CAPACITORS

C1101,1102	CERAMIC CAPACITOR	CCMSL100D50
C1103,1104	CERAMIC CAPACITOR	CKCYB681K50
C1105,1106	CERAMIC CAPACITOR	CCCSL101J50
C1107,1108	AUDIO FILM CAPACITOR	CFTXA223J50
C1109,1110	ELECTR.CAPACITOR	CEAS2R2M50
C1111,1112	ELECTR.CAPACITOR	CEAS470M10
C1113,1114	CERAMIC CAPACITOR	CKDYB681K50
C1115,1116	CERAMIC CAPACITOR	CCDSL271K500
C1117,1118	CERAMIC CAPACITOR	CCCSL101K500
C1119	MYLAR FILM CAPACITOR	CQMA562K400
C1120	ELECTR.CAPACITOR	CEAS4R7M50
C1121	MYLAR FILM CAPACITOR	CQMA123K250
C1122	MYLAR FILM CAPACITOR	CQMA153K50
C1123,1124	MYLAR FILM CAPACITOR	CQMA103K50
C1125	CERAMIC CAPACITOR	CCDSL221J50
C1127	COPA (2000P/630V)	ACE1020
C1128	CERAMIC CAPACITOR	CKDYB472K500
C1129	CERAMIC CAPACITOR	CKDYB681K50
C1131,1132	ELECTR.CAPACITOR	CEAS101M10

RESISTORS

R1116	CARBON FILM RESISTOR	RD1/4PM102J
R1117	CARBON FILM RESISTOR	RD1/2PM360J
VR1101	VR	VRTM6H202
VR1102	VR	VRTM6H202
VR1103	VR	VRTM6H204
VR1104	VR	VRTM6H204
	OTHER RESISTORS	RD1/8M

Mark No.	Description	Part No.
----------	-------------	----------

⊙TRANS Ass'y (AWZ3214)

There is no supply part in this unit.

**⊙REGULATOR Ass'y (AWZ3215)
SEMICONDUCTORS**

IC704	REGULATOR IC	NJM7812FA
-------	--------------	-----------

CAPACITORS

C747	ELECTR. CAPACITOR	CEAS100M25
C748	ELECTR. CAPACITOR	CEAS100M50

**⊙POWER Ass'y (AWZ3230)
SEMICONDUCTORS**

IC701,702	REGULATOR IC	NJM7805FA
IC703	REGULATOR IC	NJM7812FA
IC705	REGULATOR IC	NJM78M56FAS
IC709	IC PROTECTOR	ICP-N38
IC751	LOGIC IC	TC4066BP

IC753	OP-AMP IC	RC4558DXP
IC801	SOUND PROCESSOR IC	PA0049
IC802,803	OP-AMP IC	RC4558DXP
IC805	GEQ IC	LA3607
IC851	AUDIO IC	STK4142-2GP

Q11	TRANSISTOR	2SA1048
Q12	TRANSISTOR	2SC2458
Q21,22	TRANSISTOR	2SC2458
Q23	TRANSISTOR	XDA143ES
Q701	TRANSISTOR	2SC3377

Q702,708	TRANSISTOR	XDA124ES
Q706	TRANSISTOR	2SB560
Q707	TRANSISTOR	2SC2603
Q703,709	TRANSISTOR	XDC124ES
Q710	TRANSISTOR	2SA933S

Q741	TRANSISTOR	2SA1515
Q742,752	TRANSISTOR	XDC143ES
Q744	TRANSISTOR	XDC124ES
Q751,743	TRANSISTOR	XDA143ES
Q753,754	TRANSISTOR	2SC2458

Q851-854	TRANSISTOR	2SC2458
----------	------------	---------

D11	DIODE	HSS104-02
D701	DIODE	RBV402
D702-709	DIODE	S5566
D712,714	DIODE	S5566
D716	ZENER DIODE	RD30ESB
D717	ZENER DIODE	RD7.5ESB

D718,719	DIODE	HSS104-02
D740	DIODE	HSS104-02
D741	ZENER DIODE	RD6.8ESB3
D742-744	DIODE	HSS104-02
D745	ZENER DIODE	RD2.7ESB

D746,799	DIODE	HSS104-02
D851,852	ZENER DIODE	RD12ESB
D853	DIODE	HSS104-02

COILS and RELAY

L751,752	INDUCTOR	LTA392J
L851,852	COIL	ATH-133
RY851	RELAY	ASR-111

Mark No.	Description	Part No.
----------	-------------	----------

CAPACITORS

C11	ELECTR. CAPACITOR	CEAS100M50
C701,702	ELECTR. CAPACITOR (2200 μ F/42V)	ACH1109
C703,704	ELECTR. CAPACITOR	CEAS222M16
C705,706	ELECTR. CAPACITOR	CEAS100M25
C707	ELECTR. CAPACITOR	CEAS332M35
C708,709	ELECTR. CAPACITOR	CEAS100M25
C716	CERAMIC CAPACITOR	ACG-009

C718	ELECTR. CAPACITOR	CEAS101M35
C720	ELECTR. CAPACITOR	CEAS220M100
C723	ELECTR. CAPACITOR	CEAS470M50
C724	ELECTR. CAPACITOR	CEAS100M50
C730	ELECTR. CAPACITOR	CEAS101M16

C731	ELECTR. CAPACITOR	CEAS470M10
C732	ELECTR. CAPACITOR	CEAS331M10
C733	ELECTR. CAPACITOR	CEAS470M50
C741,742	ELECTR. CAPACITOR	CEAS010M50
C753,754	AUDIO FILM CAPACITOR	CFTXA683J50

C755,756	MYLAR FILM CAPACITOR	CQMA182J50
C757,758	ELECTR. CAPACITOR	CEAS330M16
C759,760	AUDIO FILM CAPACITOR	CFTXA273J50
C761,762	AUDIO FILM CAPACITOR	CFTXA473J50

C765,766	ELECTR. CAPACITOR	CEAS470M10
C771	ELECTR. CAPACITOR	CEAS3R3M50
C803,804	CERAMIC CAPACITOR	CKDYB682K50
C805,806	MYLAR FILM CAPACITOR	CQMA102J50
C807,808	MYLAR FILM CAPACITOR	CQMA562J50

C809	ELECTR. CAPACITOR	CEASR47M50
C810	ELECTR. CAPACITOR	CEAS6R8M50
C811	MYLAR FILM CAPACITOR	CQMA223J50
C812	CERAMIC CAPACITOR	CKCYX104M25
C819,820	ELECTR. CAPACITOR	CEAS3R3M50

C823	CERAMIC CAPACITOR	CKDYB561K50
C824	CERAMIC CAPACITOR	CKDYB822K50
C825	CERAMIC CAPACITOR	CKDYB561K50
C826,829	CERAMIC CAPACITOR	CKDYB272K50
C830	CERAMIC CAPACITOR	CKDYX393M25

C831	CERAMIC CAPACITOR	CKDYB472K50
C832	CERAMIC CAPACITOR	CKDYX683M25
C833	CERAMIC CAPACITOR	CKDYB102K50
C834	CERAMIC CAPACITOR	CKDYX153M25
C835	CERAMIC CAPACITOR	CKDYB182K50

C836	CERAMIC CAPACITOR	CKDYX273M25
C837	AUDIO FILM CAPACITOR	CFTXA474J50
C851,852	ELECTR. CAPACITOR	CEAS2R2M50
C855,856	ELECTR. CAPACITOR	CEAS470M25
C857,858	ELECTR. CAPACITOR	CEAS101M25

C859	ELECTR. CAPACITOR	CEANP220M35
C860	ELECTR. CAPACITOR	CEAS100M50
C863	ELECTR. CAPACITOR	CEAS470M35
C865-868	CERAMIC CAPACITOR	CKDYX104M25
C869	CERAMIC CAPACITOR	CKDYF473Z50

C870	ELECTR. CAPACITOR	CEAS220M25
C873	ELECTR. CAPACITOR	CEAS221M10
C874	CERAMIC CAPACITOR	CKCYF473Z50

RESISTORS

R11,12	METAL OXIDE RESISTOR	RS2LMFR22J
R705,706	CARBON FILM RESISTOR	RD1/4PM681J
R714	CARBON FILM RESISTOR	RD1/2PM223J
R715	METAL OXIDE RESISTOR	RS2LMF331J
R716	CARBON FILM RESISTOR	RD1/4PM223J

R859-862	CARBON FILM RESISTOR	RD1/4PM222J
----------	----------------------	-------------

Mark No.	Description	Part No.
R863	CARBON FILM RESISTOR	RD1/4PMFL471J
R864	CARBON FILM RESISTOR	RD1/4PM101J
R865	CARBON FILM RESISTOR	RD1/4PM102J
R866	CARBON FILM RESISTOR	RD1/4PMFL222J
R867	CARBON FILM RESISTOR	RD1/4PM222J
R868	CARBON FILM RESISTOR	RD1/4PMFL101J
R869,870	CARBON FILM RESISTOR	RD1/4PM100J
R871,872	METAL OXIDE RESISTOR	RS1LMF331J
R873,874	CARBON FILM RESISTOR	RD1/4PMFL100J
R881	METAL OXIDE RESISTOR OTHER RESISTORS	RS2LMF471J RD1/8PM□□□

OTHERS

CN	JACK	AKN1027
CN10	CONNECTOR (3P)	KPE3
CN11	CONNECTOR (5P)	KPE5
CN12	CONNECTOR (13P)	KPE13
CN16,17	CONNECTOR (15P)	KPE15
CN19	CONNECTOR (6P)	KPE6
	SPEAKER TERMINAL 4-P	AKE1012
	SOCKET 15-P	AKP-048
	SOCKET 14-P	AKP1056

⊙AF-TUNER Ass'y (AWZ3914)

SEMICONDUCTORS

IC101	PLL IC	LM7001
IC201	AM/FM IC	LA1265S
IC203	MPX IC	AN7470P
IC301	OP-AMP IC	RC4558DXP
IC302	LOGIC IC	MC14052BCP
IC303	OP-AMP IC	RC4558DXP
IC305	DOLBY-B IC	CXA1100P
IC307	OP-AMP IC	RC4558DXP
IC308	SYSTEM CONTROL IC	PD5147C
Q101	TRANSISTOR	2SC2668
Q204	N-FET	2SK246
Q205	TRANSISTOR	XDA143ES
Q206	TRANSISTOR	2SC1740SLN
Q207	TRANSISTOR	XDA143ES
Q208	TRANSISTOR	XDC124ES
Q301-308	TRANSISTOR	2SC2458
Q309	TRANSISTOR	XDA124ES
Q316	TRANSISTOR	XDC124ES
Q317	TRANSISTOR	2SA1515
Q318	TRANSISTOR	XDC124ES
Q319	TRANSISTOR	2SA1515
Q320	TRANSISTOR	XDC124ES
Q321	TRANSISTOR	2SA1515
Q322-326	TRANSISTOR	XDC124ES
Q328,335	TRANSISTOR	XDC143ES
D203-206	DIODE	HSS104-02
D301,302	DIODE	HSS104-02
D307-318	DIODE	HSS104-02
D320-325	DIODE	HSS104-02
D327	DIODE	HSS104-02
D490-493	DIODE	HSS104-02

SWITCHES

S301	SLIDE SWITCH (BEAT CUT)	ASH1031
------	----------------------------	---------

COILS and FILTERS

L202	COIL	ATE-079
------	------	---------

Mark No.	Description	Part No.
L203,204	AXIAL INDUCTOR	LAU2R2M
L303	AXIAL INDUCTOR	LAU220K
F101,202	CERAMIC FILTER	ATF-107
F203	CERAMIC FILTER	ATF-208
F301,302	DOLBY FILTER	ATF1064

CAPACITORS

C101,107	CHIP CAPACITOR	CKSQYF223Z50
C201,204	CHIP CERAMIC C.	CCSQCH150J50
C205	CHIP CAPACITOR	CKSQYF103Z50
C206	ELECTR.CAPACITOR	CEAS470M10
C207	CHIP CAPACITOR	CKSQYF223Z50
C208	CERAMIC CAPACITOR	CKDYX103M25
C209	AUDIO FILM CAPACITOR	CFTXA224J50
C210	CHIP CAPACITOR	CKSQYF223Z50
C211	CERAMIC CAPACITOR	CKSQYF473Z50
C212	CHIP CAPACITOR	CKSQYF223Z50
C215	CERAMIC CAPACITOR	CKSQYB103K50
C216	CERAMIC CAPACITOR	CCSQCH470J50
C217	ELECTR.CAPACITOR	CEAS470M16
C218	ELECTR.CAPACITOR	CEAS330M16
C219	CHIP CAPACITOR	CKSQYF103Z50
C220	CERAMIC CAPACITOR	CKSQYF473Z50
C221,222	CHIP CAPACITOR	CKSQYF223Z50
C223	ELECTR.CAPACITOR	CEAS330M16
C224	ELECTR.CAPACITOR	CEAS4R7M50
C225	CHIP CAPACITOR	CKSQYF103Z50
C226	ELECTR.CAPACITOR	CEAS010M50
C227	CERAMIC CAPACITOR	CKSQYB471K50
C228	CHIP CAPACITOR	CKSQYB222K50
C230	CERAMIC CAPACITOR	CKDYX473M25
C231	ELECTR.CAPACITOR	CEAS010M50
C232	ELECTR.CAPACITOR	CEAS2R2M50
C233	ELECTR.CAPACITOR	CEAS100M50
C234	ELECTR.CAPACITOR	CEANP100M35
C235	ELECTR.CAPACITOR	CEAS100M50
C236	CERAMIC CAPACITOR	CKSQYF473Z50
C237	ELECTR.CAPACITOR	CEAS101M16
C238	CAPACITOR	ACE1039
C240	ELECTR.CAPACITOR	CEAS1R5M50
C241	ELECTR.CAPACITOR	CEAS3R3M50
C242	ELECTR.CAPACITOR	CEAS470M16
C243,244	CHIP CAPACITOR	CKSQYB102K50
C246	ELECTR.CAPACITOR	CEASR22M50
C248	CHIP CAPACITOR	CKSQYF103Z50
C255,256	CERAMIC CAPACITOR	CKDYB682K50
C265,266	ELECTR.CAPACITOR	CEAS100M50
C267	CERAMIC CAPACITOR	CKDYX223M25
C288	CERAMIC CAPACITOR	CCDSL101J50
C295,296	CERAMIC CAPACITOR	CKPUYB102K50
C298	CERAMIC CAPACITOR	CCDSL820J50
C299	CERAMIC CAPACITOR	CKDYF102Z50
C303-306	CHIP CAPACITOR	CCSQCH101J50
C307,308	ELECTR.CAPACITOR	CEAS2R2M50
C309,310	CERAMIC CAPACITOR	CKCYB152K50
C311,312	CERAMIC CAPACITOR	CKCYB562K50
C315,316	ELECTR.CAPACITOR	CEAS470M10
C317,318	CHIP CAPACITOR	CCSQCH101J50
C325,326	C. CERAMIC CAPACITOR	CKSQYB273K50
C327,328	ELECTR.CAPACITOR	CEAS010M50
C329	ELECTR.CAPACITOR	CEAS100M50
C330	ELECTR.CAPACITOR	CEAS220M25
C331,332	ELECTR.CAPACITOR	CEASOR1M50
C333	ELECTR.CAPACITOR	CEAS470M16
C334	CERAMIC CAPACITOR	CKSQYB473K50
C335	ELECTR.CAPACITOR	CEASR68M50

Mark	No.	Description	Part No.
	C336	ELECTR. CAPACITOR	CEAS101M10
	C337	ELECTR. CAPACITOR	CEASR68M50
	C338	ELECTR. CAPACITOR	CEAS220M16
	C339,340	ELECTR. CAPACITOR	CEAS2R2M50
	C341-344	ELECTR. CAPACITOR	CEAS010M50
	C345,346	CERAMIC CAPACITOR	CKCYB152K50
	C347	CERAMIC CAPACITOR	CKCYB102K50
	C350,351	CERAMIC CAPACITOR	CKCYF473Z50
	C352	ELECTR. CAPACITOR	CEAS100M50
	C353,354	CERAMIC CAPACITOR	CKDYF473Z50
	C363	CERAMIC CAPACITOR	CKCYB102K50
	C364	ELECTR. CAPACITOR	CEAS100M50
	C365,366	CERAMIC CAPACITOR	CKSQYB152K50
	C367,368	CERAMIC CAPACITOR	CKSQYF473Z50
	C369,370	CHIP CAPACITOR	CKSQYF223Z50

RESISTORS

R122,212	CARBONFILM RESISTOR	RD1/8PM221J
R214	CARBONFILM RESISTOR	RD1/8PM471J
R220	CARBONFILM RESISTOR	RD1/8PM223J
R305,306	CARBONFILM RESISTOR	RD1/8PM122J
R307,308	CARBONFILM RESISTOR	RD1/8PM473J
R309,310	CARBONFILM RESISTOR	RD1/8PM474J
R315,316	CARBONFILM RESISTOR	RD1/8PM820J
R323,324	CARBONFILM RESISTOR	RD1/8PM472J
R325,326	CARBONFILM RESISTOR	RD1/8PM332J
R327,328	CARBONFILM RESISTOR	RD1/8PM682J
R336	CARBONFILM RESISTOR	RD1/8PM222J
R338	CARBONFILM RESISTOR	RD1/8PM332J
R340	CARBONFILM RESISTOR	RD1/8PM105J
R341,342	CARBONFILM RESISTOR	RD1/8PM472J
R343,344	CARBONFILM RESISTOR	RD1/8PM242J
R353,362	CARBONFILM RESISTOR	RD1/8PM103J
R367,368	CARBONFILM RESISTOR	RD1/8PM683J
R369,370	CARBONFILM RESISTOR	RD1/8PM101J
R385-387	CARBONFILM RESISTOR	RD1/8PM103J
R388-389	CARBONFILM RESISTOR	RD1/8PM223J
R401-406	CARBONFILM RESISTOR	RD1/8PM103J
R407-409	CARBONFILM RESISTOR	RD1/8PM473J
R410	CARBONFILM RESISTOR	RD1/8PM152J
R411	CARBONFILM RESISTOR	RD1/8PM103J
R419	CARBONFILM RESISTOR	RD1/8PM105J
R422,430	CARBONFILM RESISTOR	RD1/8PM102J
R431	CARBONFILM RESISTOR	RD1/8PM473J
R455-457	CARBONFILM RESISTOR	RD1/8PM103J
R458	CARBONFILM RESISTOR	RD1/8PM222J
R491	CARBONFILM RESISTOR	RD1/8PM102J
R492,496	CARBONFILM RESISTOR	RD1/8PM182J
VR201	VR	VRTB6VS223
VR202,203	VR	VRTB6VS472
VR301-304	VR (20k)	ACP1004
	OTHER RESISTORS	RS1/10S□□□□

OTHERS

CN	PIN JACK (2P)	AKB1171
CN21	CONNECTOR (10P)	KPE10
CN22	CONNECTOR (12P)	KPE12
CN23	CONNECTOR (15P)	KPE15
CN24	CONNECTOR (7P)	KPE7
CN25	CONNECTOR (9P)	KPE9
X201	CRYSTAL RESONATOR (7,200MHz)	ASS1042
X202	CERAMIC RESONATOR (450kHz)	ATF1027
X301	CERAMIC OSCILLATOR (4.19MHz)	ASS1022
	ANTENNA TERMINAL4-P	AKA1010

Mark	No.	Description	Part No.
		PLUG 15-P	AKM-080
		PLUG 14-P	AKM1048
		2 SERIAL F.E. MODULE Ass'y	AXQ1002
		AM RF TUNING BLOCK	AXX1011

NOTE: Since the 2 serial F.E. Module Ass'y (AXQ1002) is replaced during the service, the parts in the Ass'y are not designated as the service parts.

**①VOLUME Ass'y (AWZ3919)
SEMICONDUCTORS**

IC601	OP-AMP IC	RC4558DXP
IC602	MECHANISM DRIVER IC	TA7291S

CAPACITORS

C601,602	ELECTR. CAPACITOR	CEAS4R7M50
C605,606	ELECTR. CAPACITOR	CEAS470M10
C607	CERAMIC CAPACITOR	CKCYF473Z50

RESISTORS

VR601	VR (VOLUME CONTROL) OPTHER RESISTOR	ACX1053 RS1/8PM□□□□
-------	--	------------------------

**①DECK SW Ass'y (AWZ3921)
SEMICONDUCTORS**

D1401	LED (GREEN) (DECK1 REV)	AEL1132
D1402	LED (GREEN) (DECK1 FWD)	AEL1132
D1403	LED (GREEN) (DECK2 REV)	AEL1132
D1404	LED (GREEN) (DECK2 FWD)	AEL1132
D1405	LED (RED) (REC/PAUSE)	AEL1131

SWITCHS

S1401	SLIDE SWITCH (DOLBY NR)	ASH1039
S1402	SWITCH (DECK2 STOP)	ASG1034
S1403	SWITCH (DECK2 FWD)	ASG1034
S1404	SWITCH (DECK2 FF)	ASG1034
S1405	SWITCH (ASES)	ASG1034
S1406	SWITCH (DECK2 REV)	ASG1034
S1407	SWITCH (DECK2 REW)	ASG1034
S1409	SWITCH (DECK1 STOP)	ASG1034
S1410	SWITCH (REC/PAUSE)	ASG1034
S1411	SWITCH (DECK1 FF)	ASG1034
S1412	SWITCH (DECK1 FWD)	ASG1034
S1413	SWITCH (COPY)	ASG1034
S1414	SWITCH (DECK1 REW)	ASG1034
S1415	SWITCH (DECK1 REV)	ASG1034

**①TX-CD SW Ass'y (AWZ3925)
SEMICONDUCTORS**

IC1201	IC	PDG065C
Q1201	TRANSISTOR	XDC143ES
Q1202	TRANSISTOR	2SC2458
D1212-1217	DIODE	HSS104-02
D1218	ZENER DIODE	RD6.2ESB

SWITCHS

S1201	SWITCH (CLOCK ADJ.)	ASG1034
S1202	SWITCH (TIMER SET)	ASG1034

Mark No.	Description	Part No.
S1203	SWITCH (WAKE UP)	ASG1034
S1204	SWITCH (REC)	ASG1034
S1205	SWITCH (DISPLAY)	ASG1034
S1206	SWITCH (AUTO PRE.MEMORY)	ASG1034
S1207	SWITCH (AM-NR/FM-MONO)	ASG1034
S1208	SWITCH (BAND)	ASG1034
S1209	SWITCH (TUNING +)	ASG1034
S1210	SWITCH (TUNING -)	ASG1034
S1211	SWITCH (FREQ./STATION)	ASG1034
S1221	SWITCH (PLAY)	ASG1034
S1222	SWITCH (TRACK -)	ASG1034
S1223	SWITCH (TRACK +)	ASG1034
S1224	SWITCH (OPEN/CLOSE)	ASG1034
S1225	SWITCH (STOP)	ASG1034
S1226	SWITCH (PAUSE)	ASG1034
S1227	SWITCH (PROGRAM)	ASG1034
S1228	SWITCH (HI-LITE SCAN)	ASG1034
S1229	SWITCH (REPEAT)	ASG1034

COLIS

L1201	AXIAL INDUCTOR	LAU220K
-------	----------------	---------

CAPACITORS

C1201	CERAMIC CAPACITOR	CKDYX473M25
C1202	ELECTR.CAPACITOR	CEJA010M50
C1203	AUDIO FILM CAPACITOR	CFTXA224J50
C1204	CERAMIC CAPACITOR	CKDYB102K50
C1205	ELECTR.CAPACITOR	CEJA470M10
C1206	CERAMIC CAPACITOR	CKDYF473Z50
C1207	ELECTR.CAPACITOR	CEJA470M10
C1208	CAPACITOR (0.047F/5.5V)	ACH1135
C1209	CERAMIC CAPACITOR	CKDYF223Z50
C1211	ELECTR.CAPACITOR	CEJA2R2M50

RESISTORS

ALL RESISTORS	RS1/8PM□□□J
---------------	-------------

OTHERS

V1201	FL TUBE	AAV1127
X1202	CRYSTAL RESONATOR (8MHz)	ASS1015
	REMOTE RECEIVER UNIT	AXX1010

AMP SW Ass'y (AWZ3926) SEMICONDUCTORS

D1305	LED (RED) (PRESET)	AEL1108
D1306	LED (RED) (MANUAL)	AEL1108

SWITCHES

S1301	SWITCH (MEMORY)	ASG1034
S1302	SWITCH (START/SET)	ASG1034
S1303	SWITCH (MODE)	ASG1034
S1304	SWITCH (POWER)	ASG1034
S1305	SWITCH (B.G.M./TREBLE EQ)	ASG1034
S1306	SWITCH (HALL/S.ST./WIDE)	ASG1034
S1307	SWITCH (DISCO./P.BASS EQ)	ASG1034
S1308	SWITCH (SFC CLEAR)	ASG1034
S1309	SWITCH (CD)	ASG1034
S1310	SWITCH (TUNER)	ASG1034

Mark No.	Description	Part No.
S1311	SWITCH (TAPE)	ASG1034
S1312	SWITCH (PHONO)	ASG1034

RESISTORS

R1301	CARBONFILM RESISTOR	RD1/8PM331J
-------	---------------------	-------------

MOTHER BOARD Ass'y (PWM1556) SEMICONDUCTORS

△ IC2020	REGULATOR IC	M5298P
IC2101	PRE AMP IC	CXA1471S
IC2151	SERVO IC	CXA1372S
△ IC2201	POWER OP-AMP,IC	LA6520
△ IC2202	POWER OP-AMP,IC	LA6517
IC2301	EFM DEMODULATION IC	CXD2500AQ
IC2351	MICROCOMPUTER,IC	PD4401A
IC2401	8FS DF DA CONVERTER IC	TC9237BN
IC2404	OP-AMP IC	NJM4558D-D
Q2062	TRANSISTOR	2SC1740S
Q2101	TRANSISTOR	2SA854S
Q2381,2382	TRANSISTOR	2SC1740S
Q2401	N-FET	2SK246
D2211	ZENNER DIODE	MTZJ6.2B/C
D2301	DIODE	1SS254
D2381-2383	DIODE	1SS254
D2401	DIODE	1SS254
D2701-2703	DIODE	1SS254

COILS

L2401	AXIAL INDUCTOR	LAU100K
L2403,2404	AXIAL INDUCTOR	LAU100K

CAPACITORS

C2025-2028	ELECTR.CAPACITOR	CEAS101M10
C2060	ELECTR.CAPACITOR	CEAS010M50
C2101	ELECTROLYTIC CAPACIT	CEAS471M6R3
C2102	ELECTR.CAPACITOR	CEAS101M10
C2103	CERAMIC CAPACITOR	CCCCH180J50
C2104	ELECTR.CAPACITOR	CEAS101M10
C2110	CERAMIC CAPACITOR	CKCYF103Z50
C2153	ELECTR.CAPACITOR	CEAS101M10
C2155	MYLAR FILM CAPACITOR	QOMA182J50
C2156	CERAMIC CAPACITOR	CGCYX333K25
C2157	CERAMIC CAPACITOR	CGCYX103K25
C2158,2159	CERAMIC CAPACITOR	CGCYX104K25
C2160	ELECTR.CAPACITOR	CEAS4R7M50
C2161	CERAMIC CAPACITOR	CGCYX104K25
C2162	ELECTR.CAPACITOR	CEAS010M50
C2163	CERAMIC CAPACITOR	CGCYX104K25
C2164	CERAMIC CAPACITOR	CGCYX103K25
C2167	CERAMIC CAPACITOR	CKCYF103Z50
C2168	CERAMIC CAPACITOR	CGCYX333K25
C2169	CERAMIC CAPACITOR	CGCYX103K25
C2170	CERAMIC CAPACITOR	CKCYB332K50
C2171,2172	CERAMIC CAPACITOR	CKCYB472K50
C2202,2204	CERAMIC CAPACITOR	CKCYF103Z50
C2212	MYLAR FILM CAPACITOR	QOMA103K50
C2216,2217	ELECTR.CAPACITOR	CEAS330M16
C2301	CERAMIC CAPACITOR	CGCYX104K25
C2302	ELECTROLYTIC CAPACIT	CEAS331M6R3
C2303	ELECTR.CAPACITOR	CEAS101M10
C2306	CERAMIC CAPACITOR	CKCYB152K50
C2307	CERAMIC CAPACITOR	CGCYX473K25
C2308	CERAMIC CAPACITOR	CGCYX103K25
C2309	ELECTR.CAPACITOR	CEASR47M50

Mark	No.	Description	Part No.
	C2351	ELECTR. CAPACITOR	CEAS330M16
	C2353,2361	CERAMIC CAPACITOR	CKCYF103Z50
	C2403,2404	CERAMIC CAPACITOR	CCCCH470J50
	C2413	ELECTR. CAPACITOR	CEAS101M10
	C2414	MYLAR FILM CAPACITOR	CQMA103K50
	C2415,2416	MYLAR FILM CAPACITOR	CQMA104K50
	C2421	CERAMIC CAPACITOR	CKCYF473Z50
	C2427,2428	CERAMIC CAPACITOR	CCDSL101J50
	C2429,2430	CERAMIC CAPACITOR	CCCCH560J50
	C2433,2434	ELECTR. CAPACITOR	CEANP2R2M50
	C2435-2438	CERAMIC CAPACITOR	CCCCH390J50
	C2441,2442	MYLAR FILM CAPACITOR	CQMA152J50

RESISTORS

VR2102	VR (22k)	RCP1035
VR2103	VR (1k)	RCP1027
VR2151	VR (22k)	RCP1035
VR2152	VR (22k)	RCP1035
	OTHER RESISTORS	RS1/6PM□□□J

OTHERS

CN2001	CONNECTOR (7P)	KPE7
CN2002	CONNECTOR (12P)	KPE12
CN2101	CONNECTOR	S2045-1610
X2351	CERAMIC RESONATOR (4.19MHz)	VSS1014
X2401	XTAL RES (16.9344MHz)	PSS1006

6. ADJUSTMENTS

6.1 TUNER SECTION

Preparations

- Set the VOLUME control to minimum.
- Set the input selector to TUNER.
- Refer to Fig. 6-3. for adjustment test points and controls.

FM tuner section adjustment

- Select the FM mode with the BAND selector switch.
- Connect as shown in Fig. 6-1.

Step	Adjustment name	FM SG (1 kHz $\pm$ 75 kHz dev.)		Reception frequency indication	Adjustment	
		Frequency (MHz)	Level (dB μ)		Adjusting point	Specification
1	Center meter adjustment	98	60	98 MHz	L202	Adjust so that the voltage of both side of R220 becomes $0V \pm 50$ mV.
2	FM VCO free-run frequency adjustment	98	60 (No modulation)	98 MHz	VR203	Adjust so that the frequency between TP MPX VCO and GND becomes 76 ± 0.5 kHz.
3	Tuning indicator level adjustment	98	17 (± 3 dB)	98 MHz	VR201	Adjust to the point where the tuning indicator just lights down.

AM tuner section adjustment

- AM SG level (dB μ /m) indicates the electric field strength of the loop antenna.
- Select the AM mode with the BAND selector switch.
- Connect as shown in Fig. 6-2.

Step	Adjustment name	AM SG (400 Hz, 30% modulation)		Reception frequency indication	Adjustment	
		Frequency (kHz)	Level (dB μ /m)		Adjusting point	Specification
1	Tracking adjustment *1	603 *2	55	*2 603 kHz	ANT coil of AM RF turning block	Adjust so that the DC voltage between TP S-METER and GND becomes maximum.
2		1395 *3	55	*3 1395 kHz	TC101	Adjust so that the DC voltage between TP S-METER and GND becomes maximum.
3	Repeat steps 1 and 2 so that both steps are satisfied. *1					
4	IFT adjustment *1	603 *2	55	*2 603 kHz	F203	Adjust so that the DC voltage between TP S-METER and GND becomes maximum.
5	Tuning indicator level adjustment	999 *4	55 (± 5 dB)	*4 999 kHz	VR202	Adjust to the point where the tuning indicator just lights down.

*1: HEWZIXK only

*2-*4: The frequencies in the above table are for the 9 kHz area.

(For the 9 kHz area of SD, KUC, HEXK, HBXK, HEWZIXK and YPW types)

The frequencies in the case of the 10 kHz area are as follows (The 10 kHz area of SD and KUC types):

*2: 600 kHz

*3: 1400 kHz

*4: 1000 kHz




Fig. 6-1. FM Adjustment Connection Diagram




Fig. 6-2. AM Adjustment Connection Diagram




Fig. 6-3. Adjustment Points and Test Points

6.2 TAPE DECK SECTION

- Adjustment points and test points are shown in Fig. 6-3.

● Mechanical Adjustment

- Set the TAPE function.
- Test tape: STD-301 (3 kHz, 30 min.)

1. Tape Speed Adjustment							
No.	Mode	Test tape	Adjusting points		Measurement points	Adjustment procedure	Remarks
1	PLAY	STD-301 (playback 3 kHz)	Deck I	AF-TUNER Ass'y VR304	TP303 (Rich)	Press the PLAY SW and adjust so that the reading becomes 3010 ± 10 Hz. Confirm that wow & flutter level is below 0.2% (in the reverse direction, confirm that the reading is within 3010 ± 55 Hz).	
2	PLAY		Deck II	AF-TUNER Ass'y VR303	TP303 (Rich)	Press the PLAY SW and adjust so that the reading becomes 3010 ± 10 Hz. Confirm that wow & flutter level is below 0.2% (in the reverse direction, confirm that the reading is within 3010 ± 55 Hz).	

● Electrical Adjustment

Check the following before starting.

1. Confirm that tape speed adjustment has been completed.
2. Clean the heads and demagnetize them using a head eraser.
3. Set the measurement level to 0 dBV=1 Vrms.
4. Use the specified tape for adjustment. Use the labeled (A) side of the test tape.
STD-331B: for playback adjustment
STD-630: normal blank tape
5. Provide yourself with the following measuring devices:
AC millivoltmeter, low-frequency oscillator, attenuator, oscilloscope
6. Adjust both right and left channels unless otherwise specified.
7. Turn the DOLBY NR switch off unless otherwise specified.
8. Warm up the unit for several minutes before adjustment. In particular, be sure to warm up the unit in the REC/PLAY mode for 3 to 5 minutes before starting recording/playback frequency characteristics adjustment.

9. Always follow the indicated adjustment order. Otherwise, a complete adjustment may not be achieved.

Playback Adjustment (decks I, II)

1. Head angle adjustment
2. Playback level adjustment

Recording Adjustment (deck II)

1. Bias oscillation frequency check
2. Recording/playback frequency characteristics adjustment
3. Recording level adjustment
4. ALC operation check




Fig. 6-4. STD-331B Test Tape




Fig. 6-5. Head Angle Adjustment




Fig. 6-6. Frequency Characteristics

● Playback Adjustment

1. Head Angle Adjustment

- This unit is equipped with auto tape selector.
- Do not switch between forward and reverse operation with the screwdriver inserted.

Step	Tape selector (AUTO)	Mode	Input signal/ test tape	Adjusting points		Measurement points	Adjustment value	Remarks
1	NORMAL	PLAY	STD-331B test tape (playback 10 kHz, -20 dB)	Deck I	Head angle adjustment screw (Fig. 6-5)	TP301 (Lch) TP303 (Rch) (DOLBY TP)	Max. playback signal level	After adjustment, apply lock paint to the head angle adjustment screw.
				Deck II				

2. Playback Level Adjustment

- Since this adjustment determines playback Dolby NR level, perform it carefully.

Step	Tape selector (AUTO)	Mode	Input signal/ test tape	Adjusting points		Measurement points	Adjustment value	Remarks
1	NORMAL	PLAY	STD-331B test tape (playback 315 kHz, 0 dB)	Deck I	VR1001 (Lch) VR1002 (Rch)	TP301 (Lch) TP303 (Rch) (DOLBY TP)	-5.2 dBV	
				Deck II	VR1101 (Lch) VR1102 (Rch)			

Note: Deck II level also changes when deck I level is adjusted.
Therefore, adjust deck I level first.

● Recording Adjustment

Note: To make frequency response of the phone equalizer flat, perform the following adjustment items 2 to 4 with connecting B1 to B2 and C1 to C2 in Fig. 6-3 respectively.

1. Bias Oscillation Frequency Check

Step	Tape selector (AUTO)	Mode	Input signal/ test tape	Adjusting points	Measurement points	Adjustment value	Remarks
1	NORMAL	REC	Load the STD-830 test tape and set the recording mode.	Deck I		Oscillation frequency to be 108.5 ± 2 kHz with the rear panel beat-cut switch in the "1" position.	Frequency is 2 to 3 kHz lower with the rear panel beat-cut switch in the "2" position.
				Deck II	Between the ② point in Fig. 6-3 and GND		

2. Recording/Playback Frequency Characteristics Adjustment

• Since this adjustment affects recording bias, prevent distortion from increasing due to underbias.

Step	Tape selector (AUTO)	Mode	Input signal/ test tape	Adjusting points	Measurement points	Adjustment value	Remarks
1	NORMAL	REC	Input a 315 Hz signal to the phono terminal and set the input selector to PHONO.	Deck I	TP301 (Lch) TP303 (Rch) (DOLBY TP)	-25.2 dBV	
				Deck II	Input signal level		
2	NORMAL	REC/PLAY	Load the STD-830 test tape and record/playback the 315 Hz and 10 kHz signals (see the Note below).	Deck I	TP301 (Lch) TP303 (Rch) (DOLBY TP)	Repeat adjustment until playback level of the 10 kHz signal is within 0 ± 0.5 dB from that of the 315 Hz signal.	
				Deck II	VR1103 (Lch) VR1104 (Rch)		

Note: Set to the same level used for the 315 Hz input signal at step 1.

3. Recording Level Adjustment

Step	Tape selector (AUTO)	Mode	Input signal/ test tape	Adjusting points	Measurement points	Adjustment value	Remarks
1	NORMAL	REC	Input a 315 Hz signal to the phono terminal and set the input selector to PHONO.	Deck I	TP301 (Lch) TP303 (Rch) (DOLBY TP)	-5.2 dBV	
				Deck II	Input signal level		
2	NORMAL	REC/PLAY	STD-830 test tape and record/playback the 315 Hz signal.	Deck I	TP301 (Lch) TP303 (Rch) (DOLBY TP)	Repeat recording, playback and adjustment until playback level of the 315 Hz signal becomes -5.2 dBV.	
				Deck II	VR301 (Lch) VR302 (Rch)		

4. ALC Operation Check

Step	Tape selector (AUTO)	Mode	Input signal/ test tape	Adjusting points	Measurement points	Adjustment value	Remarks
1	NORMAL	REC-PAUSE	Input a 315 Hz signal to the PHONO terminal and set the input selector to PHONO.	Input signal level		-5.2 dBV	
2				Set to a level +10 dB above the input level at step 1.		-1.2 ± 2.5 dBV	

6.3 CD PLAYER SECTION

Adjustment Methods

If a disc player is adjusted incorrectly or inadequately, it may malfunction or not work at all even though there is nothing at all wrong with the pickup or the circuitry. Adjust correctly following the adjustment procedure.

● Adjustment items/verification items and order

Step	Item	Test point	Adjustment location
1	Focus offset adjustment	TP1, Pin 6 (FCS. ERR)	VR2103 (FCS. OFS)
2	Grating adjustment	TP1, Pin 2 (TRK. ERR)	Grating adjustment slit
3	Tracking error balance adjustment	TP1, Pin 2 (TRK. ERR)	VR2102 (TRK. BAL)
4	Pickup radial/ tangential direction tilt adjustment	TP1, Pin 1 (RF)	Radial tilt adjustment screw, Tangential tilt adjustment screw
5	RF level adjustment	TP1, Pin 1 (RF)	VR1 (RF level)
6	Focus servo loop gain adjustment	TP1, Pin 5 (FCS. IN) TP1, Pin 6 (FCS. ERR)	VR2152 (FCS. GAN)
7	Tracking servo loop gain adjustment	TP1, Pin 3 (TRK. IN) TP1, Pin 2 (TRK. ERR)	VR2151 (TRK. GAN)
8	Focus error signal verification	TP1, Pin 6 (FCS. ERR)	——

[Abbreviation table]

FCS. ERR	: Focus Error
FCS. OFS	: Focus Offset
TRK. ERR	: Tracking Error
TRK. BAL	: Tracking Balance
FCS. IN	: Focus In
TRK. IN	: Tracking In

● Measuring instruments and tools

1. Dual trace oscilloscope (10:1 probe)
2. Low-frequency oscillator
3. Test disc (YEDS-7)
4. 12-cm disc (with at least about 70 minutes of recording)
5. Low-pass filter ($39\text{ k}\Omega + 0.001\text{ }\mu\text{F}$)
6. Resistor ($100\text{ k}\Omega$)
7. Hexagonal wrench (M3 mm)
8. Standard tools

● Test point and adjustment variable resistor positions




Fig. 6-7 Adjustment Locations

● Notes

1. Use a 10:1 probe for the oscilloscope.
2. All the knob positions (settings) for the oscilloscope in the adjustment procedures are for when a 10:1 probe is used.

● Test mode

These models have a test mode so that the adjustments and checks required for service can be carried out easily. When these models are in test mode, the keys on the front panel work differently from normal. Adjustments and checks can be carried out by operating these keys with the correct procedure. For these models, all adjustments are carried out in test mode.

[Setting these models to test mode]

How to set this model into test mode.

1. Turn off the power switch.
2. Short the test mode jumper wires. (See Fig. 6-7.)
3. Turn on the power switch.

When the test mode is set correctly, the display is different from what it usually is when the power is turned on. If the display is still the same as usual, test mode has not been set correctly, so repeat Steps 1-3.

[Release from test mode]

Here is the procedure for releasing the test mode:

1. Press the STOP key and stop all operations.
2. Turn off the power switch on the front panel.


[Operations of the keys in test mode]

Code	Key name	Function in test mode	Explanation
	PROGRAM	Focus servo close	The laser diode is lit up and the focus actuator is lowered, then raised slowly and the focus servo is closed at the point where the objective lens is focused on the disc. With the player in this state, if you lightly rotate the stopped disc by hand, you can hear the sound the focus servo. If you can hear this sound, the focus servo is operating correctly. If you press this key with no disc mounted, the laser diode lights up, the focus actuator is pulled down, then the actuator is raised and lowered twice and returned to its original position.
▶	PLAY	Spindle servo ON	Starts the spindle motor in the clockwise direction and when the disc rotation reaches the prescribed speed (about 500 rpm at the inner periphery), sets the spindle servo in a closed loop. Be careful. Pressing this key when there is no disc mounted makes the spindle motor run at the maximum speed. If the focus servo does not go correctly into a closed loop or the laser light shines on the mirror section at the outermost periphery of the disc, the same symptom is occurred.
⏸	PAUSE	Tracking servo close/open	Pressing this key when the focus servo and spindle servo are operating correctly in closed loops puts the tracking servo into a closed loop, displays the track number being played back and the elapsed time on the front panel, and outputs the playback signal. If the elapsed time is not displayed or not counted correctly or the audio is not played back correctly, it may be that the laser is shining on the section with no sound recorded at the outer edge of the disc, that something is out of adjustment, or that there is some other problem. This key is a toggle key and open/close the tracking servo alternately. This key has no effect if no disc is mounted.
⏮ / ⏪	TRACK/ MANUAL SEARCH REV	Carriage reverse (inwards)	Moves the pickup position toward the inner periphery of the disc. When this key is pressed with the tracking servo in a closed loop, the tracking servo automatically goes into an open loop. Since the pickup does not automatically stop at the mechanical end point in test mode, be careful with this operation.
⏭ / ⏮	TRACK/ MANUAL SEARCH FWD	Carriage forward (outwards)	Moves the pickup position toward the outer periphery of the disc. When this key is pressed with the tracking servo in a closed loop, the tracking servo automatically goes into an open loop. Since the pickup does not automatically stop at the mechanical end point in test mode, be careful with this operation.
■	STOP	Stop	Switches off all the servos and initializes. The pickup remains where it was when this key was pressed.
▲	OPEN/CLOSE	Disc tray open/close	Opens/closes the disc tray. This key is a toggle key and open/close tray alternately. Pressing this key when the disc is turning stops the disc, then opens the tray. This key operation does not affect the position of the pickup.

[How to play back a disc in test mode]

In test mode, since the servos operate independently, playing back a disc requires that you operate the keys in the correct order to close the servos.

Here is the key operation sequence for playing back a disc in test mode.



Wait at least 2-3 seconds between each of these operations.

1. Focus offset adjustment

● Objective	Sets the DC offset for the focus error amp.		
● Symptom when out of adjustment	The player does not focus in and the RF signal is dirty.		
● Measurement instrument connections	Connect the oscilloscope to TP1, Pin 6 (FCS ERR). [Settings] 5 mV/division 10 ms/division DC mode	● Player state	Test mode, stopped (just the Power switch on)
		● Adjustment location	VR2103 (FCS OFS)
		● Disc	None needed

[Procedure]

Adjust VR2103 (FCS OFS) so that the DC voltage at TP1, Pin 6 (FCS ERR) is -50 ± 50 mV.

2. Grating adjustment

● Objective	To align the tracking error generation laser beam spots to the optimum angle on the track		
● Symptom when out of adjustment	Play does not start, track search is impossible, tracks are skipped.		
● Measurement instrument connections	Connect the oscilloscope to TP1, Pin 2 (TRK ERR) via a low pass filter. (See Fig. 6-8)	● Player state	Test mode, focus and spindle servos closed and tracking servo open
	[Settings] 50 mV/division 5 ms/division DC mode	● Adjustment location	Pickup grating adjustment slit
		● Disc	12 cm disc. (YEDS-7 can not be used.)

[Procedure]

1. Move the pickup to the outer edge of the disc with the TRACK/MANUAL SEARCH FWD ►►/►► or ◀◀/◀◀ key so that the grating adjustment slit is at the outer edge of the disc where it can be adjusted.
2. Press the PROGRAM key, then the PLAY ► key in that order to close the focus servo then the spindle servo.
3. Insert an ordinary screwdriver into the grating adjustment slit and adjust the grating to find the null point. For more details, see the next page.
4. If you slowly turn the screwdriver counterclockwise from the null point, the amplitude of the wave gradually increases, then if you continue turning the screwdriver, the amplitude of the wave becomes smaller again. Turn the screwdriver counterclockwise from the null point and set the grating to the first point where the wave amplitude reaches its maximum.

Reference: Fig. 6-9 shows the relation between the angle of the tracking beam with the track and the wave form.

Note: The amplitude of the tracking error signal is about 3 Vp-p (when a 39 k Ω + 0.001 μ F low pass filter is used). If this amplitude is extremely small (2 Vp-p or less), the objective lens or the pickup malfunction may be the case. If the difference between the amplitude of the error signal at the innermost edge and outermost edge of the disc is more than 10%, the grating is not adjusted to the optimum point, so adjust it again.

5. Return the pickup to more or less midway across the disc with the TRACK/MANUAL SEARCH REV ◀◀/◀◀ key, press the PAUSE ■■ key and check that the track number and elapsed time are displayed on the front panel. If they are not displayed at this time or the elapsed time changes irregularly, check the null point and adjust the grating again.





Fig. 6-8



[How to find the null point]

When you insert the regular screwdriver into the slit for the grating adjustment and change the grating angle, the amplitude of the tracking error signal at TP1 Pin 2 changes. Within the range for the grating, there are five or six locations where the amplitude of the wave reaches a minimum. Of these five or six locations, there is only one at which the envelope of the wave form is smooth. This location is where the three laser beams divided by the grating are all right above the same track. (See Fig. 6-9.)

This point is called the null point. When adjusting the grating, this null point is found and used as the reference position.





Fig. 6-9




3. Tracking error balance adjustment

● Objective	To correct for the variation in the sensitivity of the tracking photodiode		
● Symptom when out of adjustment	Play does not start or track search is impossible		
● Measurement instrument connections	Connect the oscilloscope to TP1, Pin 2 (TRK ERR). This connection may be via a low pass filter. [Settings] 50 mV/division 5 ms/division DC mode	● Player state ● Adjustment location ● Disc	Test mode, focus and spindle servos closed and tracking servo open VR2102 (TRK BAL) YEDS-7

[Procedure]

1. Move the pickup to midway across the disc (R = 35 mm) with the TRACK/MANUAL SEARCH FWD ►► / ►► or ◀◀ / ◀◀ key.
2. Press the PROGRAM key, then the PLAY ► key in that order to close the focus servo then the spindle servo.
3. Line up the bright line (ground) at the center of the oscilloscope screen and put the oscilloscope into DC mode.
4. Adjust VR2102 (TRK BAL) so that positive amplitude and negative amplitude of the tracking error signal at TP1 Pin 2 (TRK ERR) are the same (in other words, so that there is no DC component).



4. Pickup radial/tangential tilt adjustment

● Objective	To adjust the angle of the pickup relative to the disc so that the laser beams are shone straight down into the disc for the best read out of the RF signals.		
● Symptom when out of adjustment	Sound broken; some discs can be played but not others.		
● Measurement instrument connections	Connect the oscilloscope to TP1, Pin 1 (RF). [Settings] 20 mV/division 200 ns/division AC mode	● Player state ● Adjustment location ● Disc	Test mode, play Pickup radial tilt adjustment screw and tangential tilt adjustment screw 12 cm disc. (YEDS-7 can not be used.)

[Procedure]

1. Move the pickup to the outer edge of the disc with the TRACK/MANUAL SEARCH FWD ►► / ►►► or ►►► / ►►► key so that the radial/tangential tilt screws can be adjusted.
Press the PROGRAM key, the PLAY ► key, then the PAUSE ■■■ key in that order to close the focus servo then the spindle servo and put the player into play mode.
2. First, adjust the radial tilt adjustment screw with an M3 mm hexagonal wrench so that the eye pattern (the diamond shape at the center of the RF signal) can be seen the most clearly.
3. Next, adjust the tangential tilt adjustment screw with an M3 mm hexagonal wrench so that the eye pattern (the diamond shape at the center of the RF signal) can be seen the most clearly (Fig. 6-11).
4. Adjust the radial tilt adjustment screw and the tangential tilt adjustment screw again so that the eye pattern can be seen the most clearly. As necessary, adjust the two screws alternately so that the eye pattern can be seen the most clearly.

Note: Radial and tangential mean the directions relative to the disc shown in Fig. 6-10.





Fig. 6-10



Adjustment Locations




Fig. 6-11 Eye Pattern

5. RF level adjustment

● Objective	To optimize the playback RF signal amplitude		
● Symptom when out of adjustment	No play or no search		
● Measurement instrument connections	Connect the oscilloscope to TP1, Pin 1 (RF). [Settings] 50 mV/division 10 ms/division AC mode	● Player state ● Adjustment location ● Disc	Test mode, play VR1 (laser power) YEDS-7

[Procedure]

1. Move the pickup to midway across the disc ($R = 35 \text{ mm}$) with the TRACK/MANUAL SEARCH FWD $\blacktriangleright\blacktriangleright\blacktriangleright / \blacktriangleright\blacktriangleright\blacktriangleright$ or $\blacktriangleleft\blacktriangleleft\blacktriangleleft / \blacktriangleleft\blacktriangleleft\blacktriangleleft$ key, then press the PROGRAM key, then the PLAY $\blacktriangleright$ key in that order to close the respective servos and put the player into play mode.
2. Adjust VR1 (laser power) so that the RF signal amplitude is $1.2 \text{ Vp-p} \pm 0.1 \text{ V}$.

6. Focus servo loop gain adjustment

● Objective	To optimize the focus servo loop gain		
● Symptom when out of adjustment	Playback does not start or focus actuator noisy		
● Measurement instrument connections	See Fig. 6-12. [Settings] CH1 CH2 20 mV/division 5 mV/division X-Y mode	● Player state ● Adjustment location ● Disc	Test mode, play VR2152 (FCS GAN) YEDS-7

[Procedure]

1. Set the AF generator output to 1.2 kHz and 1 Vp-p.
2. Press the TRACK/MANUAL SEARCH FWD ►►/►► or ◀◀/◀◀ key to move the pickup to halfway across the disc (R = 35 mm), then press the PROGRAM key, the PLAY ► key, then the PAUSE ■■ key in that order to close the corresponding servos and put the player into play mode.
3. Adjust VR2152 (FCS GAN) so that the Lissajous wave form is symmetrical about the X axis and the Y axis.





Fig. 6-12

Focus Gain Adjustment



Higher gain

Optimum gain

Lower gain

7. Tracking servo loop gain adjustment

● Objective	To optimize the tracking servo loop gain		
● Symptom when out of adjustment	Playback does not start, during searches the actuator is noisy, or tracks are skipped.		
● Measurement instrument connections	See Fig. 6-13.	● Player state	Test mode, play
	[Settings] CH1 CH2 50 mV/division 50 mV/division X-Y mode	● Adjustment location	VR2151 (TRK GAN)
		● Disc	YEDS-7

[Procedure]

1. Set the AF generator output to 1.2 kHz and 2 Vp-p.
2. Press the TRACK/MANUAL SEARCH FWD ►►/►► or ◀◀/◀◀ key to move the pickup to halfway across the disc (R = 35 mm), then press the PROGRAM key, the PLAY ► key, then the PAUSE ■■ key in that order to close the corresponding servos and put the player into play mode.
3. Adjust VR2151 (TRK GAN) so that the Lissajous wave form is symmetrical about the X axis and the Y axis.





Fig. 6-13

Tracking Gain Adjustment



8. Focus error signal (focus S curve) verification

● Objective	To judge whether the pickup is ok or not by observing the focus error signal. The pickup is judged from the amplitude of the tracking error signal (as discussed in the section on adjusting the tracking error balance) and the wave form for the focus error signal.		
● Symptom when out of adjustment			
● Measurement instrument connections	Connect the oscilloscope to TP1, Pin 6 (FCS ERR). [Settings] 100 mV/division 5 ms/division DC mode	● Player state ● Adjustment location ● Disc	Test mode, stop None YEDS-7

[Procedure]

1. Connect TP1 Pin 5 to ground.
2. Mount the disc.
3. While watching the oscilloscope screen, press the PROGRAM key and observe the wave form in Fig. 6-14 for a moment. Verify that the amplitude is at least 2.5 Vp-p and that the positive and negative amplitude are about equal. Since the wave form is only output for a moment when the PROGRAM key is pressed, press this key over and over until you have checked the wave form.




Fig. 6-14

[Judging the pickup]

Do not judge the pickup until all the adjustments have been made correctly. In the following cases, there may be something wrong with the pickup.

1. The tracking error signal amplitude is extremely small (less than 2 Vp-p).
2. The focus error signal amplitude is extremely small (less than 2.5 Vp-p).
3. The positive and negative amplitudes of the focus error signal are extremely asymmetrical (2:1 ratio or more).
4. The RF signal is too small (less than 0.8 Vp-p) and even if VR1 is adjusted (laser power), the RF signal can not be brought up to the standard level.

7. FOR HBXK, SD AND YPW TYPES

7.1 CONTRAST OF MISCELLANEOUS PARTS

NOTES:

- Part without part number cannot be supplied.
- The $\triangle$ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- Parts marked by "©" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.

The XR-P320/HBXK, SD and YPW types are the same as the XR-P320/HEXK type with the exception of the following sections.

Mark	Symbol & Description	Parts No.				Remarks
		XR-P320/ HEXK type	XR-P320/ HBXK type	XR-P320/ SD type	XR-P320/ YPW type	
©	AF-TUNER Ass'y	AWZ3914	AWZ3914	AWZ3916	AWZ3917	
©	DECK SW Ass'y	AWZ3921	AWZ3921	AWZ3922	AWZ3922	
©	POWER Ass'y	AWZ3230	AWZ3230	AWZ3233	AWZ3234	
©	AUDITION Ass'y			AWZ3924	AWZ3924	
	Front Panel	AMB1942	AMB1942	AMB1943	AMB1943	
	VR. Knob			AAB1253	AAB1253	
	APSS Knob (ABS)			RAC1526	RAC1526	
	Function Button	AAD2208	AAD2208	AAD2209	AAD2209	
	Bonnet	ANE1337	ANE1337	ANE1330	ANE1330	
	Front Pad(L,R)	AHA1485	AHA1485	AHA1427	AHA1427	
	Rear Pad(L,R)	AHA1486	AHA1486	AHA1428	AHA1428	
	Packing Case	AHD2237	AHD2237	AHD2232	AHD2232	
	OPE. Instructions (Dutch, Swedish, Spanish, Portuguese)	ARC1330				
	OPE. Instructions (English, French, German, Italian)	ARE1226				
	OPE. Instructions(English)		ARB1356	ARB1356	ARB1356	
	OPE. Instructions(Spanish)			ARC1331		
$\triangle$	Fuse (FU705, T800mA/250V)			AEK-507		
$\triangle$	AC Power Cord	ADG1049	ADG1087	ADG1051	ADG1050	
$\triangle$	Power Transformer(T1)	ATS1404	ATS1404	ATS1405	ATS1417	
$\triangle$	Voltage Selector (S1, 110/120-127/220/240V)			AKX-507		
	Screw(3X14B)			ABA1024	ABA1024	For AUDITION Ass'y

© DECK SW Ass'y (AWZ3922)

The DECK SW Ass'y (AWZ3922) is the same as the DECK SW Ass'y (AWZ3921) with the exception of the following sections.

Mark	Symbol & Description	Parts No.		Remarks
		AWZ3921	AWZ3922	
	D1406-D1408		AEL1131	
	R1404-R1406		RD1/8PM271J	
	S1416		ASG1034	

◎ AF-TUNER Ass'y (AWZ3916 and AWZ3917)

The AF-TUNER Ass'y (AWZ3916 and AWZ3917) is the same as the AF-TUNER Ass'y (AWZ3914) with the exception of the following sections.

Mark	Symbol & Description	Parts No.			Remarks
		AWZ3914	AWZ3916	AWZ3917	
	IC301	RC4558DXP			
	IC310		RC4558DXP	RC4558DXP	
	Q332		XDC124ES	XDC124ES	
	Q333		XDA143ESA	XDA143ESA	
	Q334		2SC2458	2SC2458	
	C197		CCDSL101J50	CCDSL101J50	
	C198		CKDYF102Z50	CKDYF102Z50	
	C199		CCDSL050C50	CCDSL050C50	
	C243, C244	CKSQYB102K50	CKSQYB122K50	CKSQYB102K50	
	C255, C256	CKDYB682K50	CKDYB822K50	CKDYB682K50	
	C288	CCDSL101J50			
	C298	CCDSL820J50	CCDSL101J50	CCDSL101J50	
	C303-C306	CCSQCH101J50			
	C307, C308	CEAS2R2M50			
	C309, C310	CKCYB152K50			
	C311, C312	CKCYB562K50			
	C315, C316	CEAS470M10			
	R301, R302	RS1/10S000J			
	R303, R304	RS1/10S473J			
	R305, R306	RD1/8PM122J			
	R307, R308	RD1/8PM473J			
	R309, R310	RD1/8PM474J			
	R315, R316	RD1/8PM820J			
	R317		RD1/8PM682J	RD1/8PM682J	
	R318	RS1/10S000J	RS1/10S682J	RS1/10S682J	
	R417		RS1/10S102J	RS1/10S102J	
	R418		RD1/8PM102J	RD1/8PM102J	
	R437-R439		RS1/10S682J	RS1/10S682J	
	R440		RD1/8PM682J	RD1/8PM682J	
	R441, R442		RS1/10S682J	RS1/10S682J	
	R443, R444		RS1/10S392J	RS1/10S392J	
	R445		RD1/8PM473J	RD1/8PM473J	
	R446	RS1/10S473J			
	R447		RS1/10S473J	RS1/10S473J	
	R449, R450	RS1/10S000J			
	R494, R495	RS1/10S102J	RS1/10S000J	RS1/10S000J	
	S101		ASH1027		
	CN26		KPE8	KPE8	
	Antenna Terminal 4-P	AKA1010	AKA1009	AKA1009	

◎ POWER Ass'y (AWZ3233 and AWZ3234)

The POWER Ass'y (AWZ3233 and AWZ3234) is the same as the POWER Ass'y (AWZ3230) with the exception of the following sections.

Mark	Symbol & Description	Parts No.			Remarks
		AWZ3230	AWZ3233	AWZ3234	
	IC791		RC4558DXP	RC4558DXP	
	C718	CEAS101M35	CEAS101M50	CEAS101M50	
	C791		CKDYF103Z50	CKDYF103Z50	
	C792		CEAS010M50	CEAS010M50	
	C793		CCDSL680J50	CCDSL680J50	
	C794		CEAS100M25	CEAS100M25	
	C795		CEAS0R1M50	CEAS0R1M50	
	C796-C798		CKDYF473Z50	CKDYF473Z50	
	C863	CEAS470M35	CEAS470M50	CEAS470M35	
	R791		RD1/8PM222J	RD1/8PM222J	
	R792		RD1/8PM104J	RD1/8PM104J	
	R793		RD1/8PM103J	RD1/8PM103J	
	R794		RD1/8PM681J	RD1/8PM681J	
	R795		RD1/8PM224J	RD1/8PM224J	
	R796		RD1/8PM102J	RD1/8PM102J	
	R797		RD1/8PM104J	RD1/8PM104J	
	R798		RD1/8PM100J	RD1/8PM100J	
	VR791		ACS1064	ACS1064	
	Maic Jack		AKN1017	AKN1017	

7.2 PCB PARTS LIST
◎ AUDITION Ass'y (AWZ3924)

Mark No.	Symbol & Description	Parts No.
SEMICONDUCTORS		
IC1501-1505	OP-AMP IC	RC4558DXP
IC1506	LOGIC IC	XRU4066B
Q1501	TRANSISTOR	XDA143ES
Q1502	TRANSISTOR	XDC143ES












CAPACITORS

C1501, 1502	CHIP CAPACITOR	CKSQYF683Z50
C1503, 1504	ELECTR. CAPACITOR	CEASR33M50
C1505, 1506	CHIP CAPACITOR	CKSQYB272K50
C1507-1512	CHIP CAPACITOR	CKSQYB561K50
C1513, 1514	CHIP CAPACITOR	CKSQYB681K50
C1515, 1516	C.CERAMIC CAPACITOR	CCSQCH221J50
C1517	CHIP CAPACITOR	CCSQCH101J50
C1518-1520	CHIP CAPACITOR	CKSQYB183K50
C1521-1524	ELECTR. CAPACITOR	CEAS4R7M50
C1525, 1526	ELECTR. CAPACITOR	CEAS470M10

Mark No.	Symbol & Description	Parts No.
RESISTORS		
R1513, 1515	RESISTOR	RD1/8PM223J
R1517, 1527	RESISTOR	RD1/8PM223J
R1523	RESISTOR	RD1/8PM433J
R1534	RESISTOR	RD1/8PM473J
R1535-1538	RESISTOR	RD1/8PM104J
R1539, 1540	RESISTOR	RD1/8PM330J
	OTHER RESISTORS	RS1/10S□□□J

NOTE

- 1. This P.C.B connection diagram is viewed from the parts mounted side.
- 2. The parts which have been mounted on the board can be replaced with those shown with the corresponding wiring symbols listed in the following Table.

P.C.B. pattern diagram indication	Corresponding part symbol	Part Name
		Transistor
		Radiator type transistor
		Diode
		Resistor
		Capacitor (Polarity)
		Capacitor (Non-polarity)


Others

P.C.B. pattern diagram indication	Part Name
IC	IC
S	Switch
RY	Relay
L	Coil
F	Filter
VR	Variable resistor or Semi-fixed resistor

- 3. The capacitor terminal marked with @ (double circles) shows negative terminal.
- 4. The diode terminal marked with @ (double circles) shows cathode side.
- 5. The transistor terminal to which E is affixed shows the emitter.


This PCB connection diagram is viewed from the parts mounted side.

POWER Ass'y (SD: AWZ3233) (YPW: AWZ3234)



IC805 Q12 Q854
Q752 Q801 IC803 Q11 Q853
Q751 IC791 IC802 Q852 Q851
IC751 IC753 Q753 Q754 IC709 Q741 Q22 Q23 IC701 IC705
Q742 Q21 Q702 Q701 IC702 IC703
Q743 Q709 Q708 Q707 Q703 Q710

POWER Ass'y (SD: AWZ3233) (YPW: AWZ3234)




FU705 (SD Type Only)

FU701

AC POWER CORD

AC110V/120-127V/220V/240V,
50/60Hz: For SD Type
AC240V, 50/60Hz: For YPW Type


TRANS Ass'y (AWZ 3214)



T1
POWER
TRANSFORMER

For YPW Type


SPACER Ass'y




POWER Supply Section for SD Type.

- | | | | | |
|-------|-------|------|------|-------|
| IC805 | Q12 | Q854 | | |
| Q752 | Q11 | Q853 | | |
| Q751 | Q852 | Q851 | | |
| IC751 | IC709 | | | |
| IC753 | | | | |
| Q753 | | | | |
| Q754 | | | | |
| | Q741 | Q22 | Q23 | IC701 |
| | Q742 | Q21 | | IC702 |
| | Q743 | | Q702 | IC703 |
| | Q709 | | Q701 | |
| | Q708 | | | |
| | Q707 | Q703 | Q710 | |

7.3.1 POWER Ass'y, TRANS Ass'y, REGULATOR Ass'y and SPACER Ass'y



for SD and YPW Types)
CER Ass'y



This PCB connection diagram is viewed from the foil side.

- IC801
- IC802
- IC803
- IC804
- IC805
- IC806
- IC807
- IC808
- IC809
- IC810
- IC811
- IC812
- IC813
- IC814
- IC815
- IC816
- IC817
- IC818
- IC819
- IC820
- IC821
- IC822
- IC823
- IC824
- IC825
- IC826
- IC827
- IC828
- IC829
- IC830
- IC831
- IC832
- IC833
- IC834
- IC835
- IC836
- IC837
- IC838
- IC839
- IC840
- IC841
- IC842
- IC843
- IC844
- IC845
- IC846
- IC847
- IC848
- IC849
- IC850
- IC851
- IC852
- IC853
- IC854
- IC855
- IC856
- IC857
- IC858
- IC859
- IC860
- IC861
- IC862
- IC863
- IC864
- IC865
- IC866
- IC867
- IC868
- IC869
- IC870
- IC871
- IC872
- IC873
- IC874
- IC875
- IC876
- IC877
- IC878
- IC879
- IC880
- IC881
- IC882
- IC883
- IC884
- IC885
- IC886
- IC887
- IC888
- IC889
- IC890
- IC891
- IC892
- IC893
- IC894
- IC895
- IC896
- IC897
- IC898
- IC899
- IC900
- IC901
- IC902
- IC903
- IC904
- IC905
- IC906
- IC907
- IC908
- IC909
- IC910
- IC911
- IC912
- IC913
- IC914
- IC915
- IC916
- IC917
- IC918
- IC919
- IC920
- IC921
- IC922
- IC923
- IC924
- IC925
- IC926
- IC927
- IC928
- IC929
- IC930
- IC931
- IC932
- IC933
- IC934
- IC935
- IC936
- IC937
- IC938
- IC939
- IC940
- IC941
- IC942
- IC943
- IC944
- IC945
- IC946
- IC947
- IC948
- IC949
- IC950
- IC951
- IC952
- IC953
- IC954
- IC955
- IC956
- IC957
- IC958
- IC959
- IC960
- IC961
- IC962
- IC963
- IC964
- IC965
- IC966
- IC967
- IC968
- IC969
- IC970
- IC971
- IC972
- IC973
- IC974
- IC975
- IC976
- IC977
- IC978
- IC979
- IC980
- IC981
- IC982
- IC983
- IC984
- IC985
- IC986
- IC987
- IC988
- IC989
- IC990
- IC991
- IC992
- IC993
- IC994
- IC995
- IC996
- IC997
- IC998
- IC999
- IC1000

To TX, CD TUNER Ass'y
J19

D. GND
u. +5. 6V
VFDP
FL AC2
FL AC1
RESET

AWZ3215

1. RESISTORS:
Indicated in Ω , 1/8W, $\pm 5\%$ tolerance unless otherwise noted
k; k Ω , M; M Ω , (F); $\pm 1\%$, (G); $\pm 2\%$, (K); $\pm 10\%$, (M); $\pm 20\%$ tolerance.
2. CAPACITORS:
Indicated in capacity (μ F) /voltage (V) unless otherwise noted
p; pF. Indication without voltage is 50V except electrolytic capacitor.
3. VOLTAGE CURRENT:
V: Signal voltage at 22W/22W/8 Ω output (1kHz).
: DC voltage (V) at no input signal.
Value in () is DC voltage at rated power.

4. OTHERS

► (RED): Measurement point.

→: Signal route.

⊙: Adjusting point.

The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
*marked capacitors and resistors have parts numbers.

This is the basic schematic diagram, but the actual circuit may

5. SWITCHES (The under


AF-TUNER Ass'y
S101: CANNEL STEP FM/AM
(50/9kHz-100/10kHz)
S301: BEAT CUT 1-2

DECK SW Ass'y
S1401: DOLBY NR ON-OFF
S1402: DECK2 STOP
S1403: DECK2 FWD
S1404: DECK2 REV
S1405: DECK2 FF
S1406: DECK2 REW
S1407: DECK2 STOP
S1408: DECK1 STOP
S1410: REC/PAUSE
S1411: DECK1 FWD
S1412: DECK1 FF
S1413: COPY
S1414: DECK1 REW
S1415: DECK1 REV
S1416: VOCAL CANCEL


POWER Supply

T1
POWER
TRANSFORMER
AT15405

S1
VOLUME
SELECTOR
AKX-507



7.3.2 AF-TUNER Ass'y (1/2,2/2)




VER Ass'y
→P141)

To AUDITION Ass'y
J20 (→P153)

To AF-TUNER Ass'y (2/2)
(→P151, 152)

To TX-CD SW Ass'y
J23




SUPER BASS
SFC L IN
GND
SFC R IN
MUTE 1
VOL DOWN
VOL UP
L+R/VOL LEVEL
MUTE 2
TREBLE 1
TREBLE 2
BASS 1
BASS 2
WIDE 1
WIDE 2

To P
CN1


To DECK
J25 (→P1

To DECK
J24 (→P


IC305




AF-TUNER Ass'y
(SD: AWZ3916)
(YPW: AWZ3917)




2 Serial F.E. Module Ass'y (AXQ1002)




This PCB connection diagram is viewed from the parts mounted side.






This PCB connection diagram is viewed from the foil side.

AF-TUNER Ass'y (2/2) (SD:AWZ3916)(YPW:AWZ3917)




7.3.3 AUDITION Ass'y


AUDITION Ass'y (AWZ3924)



This PCB connection diagram is viewed from the parts mounted side.




This PCB connection diagram is viewed from the foil side.




7.3.4 DECK SW Ass'y

This PCB connection diagram is viewed from the parts mounted side.

DECK SW Ass'y (AWZ3922)



This PCB connection diagram is viewed from the foil side.



8. SPECIFICATIONS

Amplifier section

Music Power (DIN)	37 W + 37 W
Continuous Power Output (DIN)	22 W + 22 W
	(1 kHz, T.H.D. 1%, 8 Ω)
Continuous Power Output (RMS)	28 W + 28 W
	(1 kHz, T.H.D. 5%, 8 Ω)
Hum & Noise	
(DIN, Continuous Power/50 mW)	68 dB/60 dB
Total Harmonic Distortion	
(40 Hz to 20,000 Hz, 11 W, 8 ohms)	
*PHONO	No more than 0.2%

FM/AM tuner section

FM Tuner Section

Frequency Range	87.5 MHz to 108 MHz
Usable Sensitivity	Mono: 12.8 dBf, IHF
	(1.2 μ V/75 ohms)
Sensitivity (DIN)	Mono S/N 26 dB: 1 μ V/75 Ω
	Stereo S/N 46 dB: 50 μ V/75 Ω
Signal-to-Noise Ratio (IHF, 85 dBf Input)	Mono: 77 dB
	Stereo: 73 dB
Signal-to-Noise Ratio (DIN)	Mono: 66 dB
	Stereo: 60 dB
Distortion	Stereo: 0.5 % (1 kHz)
Antenna Input	75 ohms unbalanced

MW (AM) Tuner Section

Frequency Range	531 kHz to 1,602 kHz
Sensitivity (IHF, Loop antenna)	350 μ V/m
Antenna	Loop Antenna

CD Section

Type	Compact disc digital audio system
Signal-to-Noise Ratio	98 dB or more (EIAJ)
Dynamic Range	92 dB or more (EIAJ)
Wow and Flutter	Limit of measurement
	($\pm$ 0.001% W.PEAK) or less (EIAJ)

Dolby noise reduction manufactured under license from
Dolby Laboratories Licensing Corporation.
"DOLBY" and the double-D symbol  are trademarks
of Dolby Laboratories Licensing Corporation.

Cassette deck section

Systems	4 track, 2-channel stereo
Heads	Recording/playback head x 1
	Playback head x 1
	Erasing head x 1
Motor	DC servo motor x 2
Wow and Flutter	No more than 0.09 % (WRMS)
Frequency Response (-20 dB recording):	
TYPE II (HIGH/CrO ₂) tape	35 Hz to 15,000 Hz $\pm$ 6 dB
TYPE I (Normal) tape	35 Hz to 14,000 Hz $\pm$ 6 dB
Signal-to-Noise Ratio	
Dolby NR OFF	56 dB
Noise Reduction Effect	
Dolby B type NR ON	More than 10 dB (at 5 kHz)

Miscellaneous

Power Requirements	AC. 220 - 230 Volt, 50/60 Hz
Power Consumption	160 W
Dimensions	260 (W) x 310 (H) x 295 (D) mm
Weight (without package)	8.1 kg

Accessories


Operating Instructions	1
Remote Control Unit	1
Dry Cell Batteries (AAA/R03)	2
FM T-type Antenna	1
AM Loop Antenna	1

NOTE:


*Specifications and design subject to possible modification
without notice due to improvements.*

* Measured by audio spectrum analyzer.

DECK SW Ass'y (AWZ3922)




9. PANEL FACILITIES




CD PLAYER

- | | |
|---------------------------------|---|
| ① Remote sensor window (SENSOR) | ⑦ HI-LITE SCAN button |
| ② Disc tray | ⑧ PROGRAM button |
| ③ OPEN/CLOSE button | ⑨ Manual/Track search buttons
(◀◀, ▶▶) |
| ④ Play button (▶) | ⑩ Pause button () |
| ⑤ Stop button (■) | |
| ⑥ REPEAT button | |



TUNER

- | | |
|-----------------------|----------------------------------|
| ① TIMER SET button | ⑦ - (tuner down) button |
| ② DISPLAY button | ⑧ TIMER CONTROL WAKE UP/- button |
| ③ CLOCK ADJ. button | ⑨ TIMER CONTROL REC/+ button |
| ④ Display | ⑩ FREQ./STATION button |
| ⑤ BAND button | ⑪ AM-NR/FM-MONO button |
| ⑥ + (tuner up) button | ⑫ AUTO PRE. MEMORY button |



AMPLIFIER

① POWER STANDBY/ON switch

This is the switch for electric power.

ON: When set to the ON position, power is supplied and the unit becomes operational.

STANDBY: When set to the STANDBY position, the main power flow is cut and the unit is no longer fully operational. A minute flow of power feeds the unit to maintain operation readiness. (The display shows only the time.)


- ② **SMART OPERATION MEMORY button**
- ③ **SMART OPERATION START/SET button**
- ④ **SFC CLEAR (DEMO) button**
- ⑤ **SOUND FIELD CONTROL buttons**
(DISCO/P.BASS EQ, HALL/S.ST./WIDE, B.G.M./TREBLE EQ)
- ⑥ **PRESET mode indicator**
- ⑦ **MANUAL mode indicator**
- ⑧ **MODE button**
- ⑨ **VOLUME control**
- ⑩ **Headphones jack (PHONES)**
- ⑪ **Input selector buttons (TUNER/TAPE/CD/PHONO)**

Auto Function

This model is equipped with "Auto Function" operation, so when the switch for CD PLAY, RANDOM, PLAY (tape), +/- (tuner up/down) or BAND is pressed, the function switches automatically. Use the PHONO function button to select the component connected to the PHONO jacks, since Auto Function is not effective for this.

NOTE:

The function cannot be switched during recording except for tape copying. (Auto Function does not operate either.)



REMOTE CONTROL UNIT

① POWER button

② FUNCTION button

Each time this button is pressed, the function changes in the following sequence: TUNER → TAPE → CD → PHONO → TUNER.

③ SCAN button

In TUNER mode: This button is used for scanning preset stations.

In CD mode: This button is used for Hi-Lite Scan.

④ DECK operation buttons

(◀▶ DECK Play, ■ Stop, ◀◀ ▶▶ Fast, ● II Rec pause)

⑤ SHIFT DECK II button

To operate Deck II, press the desired deck operation button while pressing this button.

⑥ SLEEP button

⑦ SNOOZE button

⑧ VOLUME -/+ button

⑨ SFC PRESET button


Each time this button is pressed, the SOUND FIELD CONTROL setting changes in the following sequence: DISCO → HALL → B.G.M. → CLEAR (SFC clear).

⑩ SMART OPE. button

⑪ TUNER STATION -/+ button

⑫ CD operation buttons


(▶ Play, ■ Stop, II Pause, ◀◀ ▶▶ Track search, RND)



CASSETTE DECK

- ① DECK I cassette door
- ② DECK II cassette door
- ③ DECK I EJECT button (▲)
- ④ DECK I operation buttons
(Play ◀▶, Stop ■, Fast ◀◀▶▶)
- ⑤ ASES (Auto Synchro Editing System) button
- ⑥ COPY button
- ⑦ DOLBY* NR switch
- ⑧ DECK II operation buttons
(Play ◀▶, Stop ■, Fast ◀◀▶▶, REC PAUSE ● II)
- ⑨ DECK II EJECT button (▲)

* Dolby noise reduction manufactured under license from Dolby Laboratories Licensing Corporation. "DOLBY" and the double D symbol are trademarks of Dolby Laboratories Licensing Corporation.



DISPLAY

- ① **Sound field control indicators**
Display the SOUND FIELD CONTROL settings.
- ② **Tuner indicators**
Indicate the tuning mode.
- ③ **Timer indicators**
Display timer settings.
- ④ **ASES (Auto Synchro Editing System) indicator.**
Lights when A.S.E.S. is performed.
- ⑤ **Music calendar**
- ⑥ **Function display**
Displays the selected function. In the TUNER mode, this displays the station No., and when playing a CD it displays the track No.
When you change the setting of the SOUND FIELD CONTROL buttons, the corresponding mode is displayed.
- ⑦ **Random indicator**
- ⑧ **Repeat indicator**
- ⑨ **Program indicator**
- ⑩ **Frequency/Time display**
In TUNER mode, frequency is displayed. In any other mode it displays the time.
- ⑪ **REMAIN/TOTAL indicator**
In CD mode, "REMAIN" shows the remaining play time and "TOTAL" shows the total play time.