

Pioneer

Service Manual

ORDER NO.
RRV2214

STEREO CD/VCD CASSETTE DECK RECEIVER

XR-VS88 XR-VS66

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Type	Model		Power Requirement	The voltage can be converted by the following method.
	XR-VS88	XR-VS66		
DBDXJ	○	○	AC110-127V/220-230V/240V	With the voltage selector
DXJN/NC	○	○	AC110-127V/220-230V/240V	With the voltage selector
DLXJ/NC	○	○	AC110-127V/220-230V/240V	With the voltage selector

● This service manual should be used together with the following manual(s):

Model No.	Order No.	Remarks
XR-A670/KUCXJ	RRV2188	

CONTENTS

1. SAFETY INFORMATION	2
2. CONTRAST OF MISCELLANEOUS PARTS	3
3. SCHEMATIC DIAGRAM	12
4. PCB CONNECTION DIAGRAM	28
5. ADJUSTMENT	30

PIONEER CORPORATION 4-1, Meguro 1-chome, Meguro-ku, Tokyo 153-8654, Japan
PIONEER ELECTRONICS SERVICE, INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.
PIONEER ELECTRONIC (EUROPE) N.V. Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium
PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 253 Alexandra Road, #04-01, Singapore 159936
©PIONEER CORPORATION 1999

T – ZZK OCT. 1999 Printed in Japan

1. SAFETY INFORMATION


LABEL CHECK (for DLXJ/NC and DXJN/NC types)

IMPORTANT

THIS PIONEER APPARATUS CONTAINS
LASER OF CLASS 1.
SERVICING OPERATION OF THE APPARATUS
SHOULD BE DONE BY A SPECIALLY
INSTRUCTED PERSON.

LASER DIODE CHARACTERISTICS

MAXIMUM OUTPUT POWER: 1.3 mW
WAVELENGTH: 790nm $\pm$ 25 nm



CAUTION

INVISIBLE LASER
RADIATION WHEN OPEN,
AVOID EXPOSURE
TO BEAM

PRW1018

CLASS 1
LASER PRODUCT

Printed on the Rear Panel

Additional Laser Caution

1. Laser Interlock Mechanism

The position of the switch (S9501) for detecting loading state is detected by the system microprocessor, and the design prevents laser diode oscillation when the switch (S9501) is pressed physically.

Thus, the interlock will no longer function if the switch (S9501) is released physically and deliberately.

The interlock also does not function in the test mode *. Laser diode oscillation will continue, if pin 62 of L9240ML (IC1101) on the CD ASSY mounted on the \$M Loading Mechanism assembly is connected to GND, or else the terminals of Q1101 are shorted to each other (fault condition).

2. When the cover is opened, close viewing of the objective lens with the naked eye will cause exposure to a Class 1 laser beam.

* : Refer to page 66 on the service manual RRV2188.

2. CONTRAST OF MISCELLANEOUS PARTS

NOTES: ● Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.

● The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.

● Screws adjacent to ∇ mark on product are used for disassembly.

● Reference Nos. indicate the pages and Nos. in the service manual for the base model.

● When ordering resistors, first convert resistance values into code form as shown in the following examples.

Ex.1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47k ohm (tolerance is shown by J=5%, and K=10%).

560 $\rightarrow$ 56 $\times 10^1 \rightarrow$ 561 RD1/4PU561J

47k $\rightarrow$ 47 $\times 10^3 \rightarrow$ 473 RD1/4PU473J

0.5 $\rightarrow$ R50 RN2H[R]50K

1 $\rightarrow$ 1R0 RS1P1R0K

Ex.2 When there are 3 effective digits (such as in high precision metal film resistors).

5.62k $\rightarrow$ 562 $\times 10^1 \rightarrow$ 5621 RN1/4PC5621F

■ CONTRAST TABLE

XR-VS88/DBDXJ, DXJN/NC, DLXJ/NC and XR-A670/KUCXJ are constructed the same except for the following :

Ref. No.	Mark	Symbol and Description	Part No.				Remarks	
			XR-A670 /KUCXJ	XR-VS88 /DBDXJ	XR-VS88 /DXJN/NC	XR-VS88 /DLXJ/NC		
P6- 1		PCB ASSEMBLIES MAIN ASSY └ AF ASSY	XWM3100 XWZ3199	XWM3102 XWZ3201	XWM3102 XWZ3201	XWM3102 XWZ3201		
P6- 2		COMPLEX ASSY └ PRIMARY ASSY	XWM3113 XWZ3224	XWM3115 XWZ3222	XWM3115 XWZ3222	XWM3115 XWZ3222		
P6- 3		└ SUB TRANS ASSY	XWZ3227	XWZ3226	XWZ3226	XWZ3226		
P9- 1		└ DISPLAY ASSY	XWZ3214	XWZ3216	XWZ3216	XWZ3216		
P4- 1	⚠	PACKING SECTION Power Cord	ADG7022	ADG1158	ADG1154	ADG1154		
P4- 4		Remote Control Unit (CU-XR060)	XZN3067	Not used	Not used	Not used		
P4- 4		Remote Control Unit (CU-XR061)	Not used	XZN3068	XZN3068	XZN3068		
P4- 5		Battery Cover	XZN3065	XZN3066	XZN3066	XZN3066		
P4-10		Packing Case	XHD3091	XHD3096	XHD3113	XHD3097		
P4-11	NSP	Warranty Card	ARY7033	Not used	Not used	Not used		
P4-13		Operating Instructions (English/French)	XRE3024	Not used	Not used	Not used		
		Operating Instructions (English/Chinese/Spanish)	Not used	XRE3026	Not used	XRE3026		
		Operating Instructions (Thai)	Not used	Not used	XRC3019	Not used		
		Video Cord (L=1.5m/Yellow)	Not used	VDE1034	VDE1034	VDE1034		Accessories
		EXTERIOR SECTION						
P6- 6	NSP	\$M Mechanism CD-2	XXA3012	Not used	Not used	Not used		
P6- 6	NSP	\$M Mechanism VCD	Not used	XXA3007	XXA3007	XXA3007		
P6- 7	⚠	Power Transformer (AC120V)	XTS3032	Not used	Not used	Not used		
P6- 7	⚠	Power Transformer (AC110-127V/220-230V/240V)	Not used	XTS3031	XTS3031	XTS3031		
P6- 8	⚠ NSP	Fuse (FU1 : 6.3A)	REK1085	Not used	Not used	Not used		
P6- 8		Fuse (FU1 : T5A)	Not used	AEK1061	AEK1061	AEK1061		
P6- 9		Fuse Caution Label	XAX3157	Not used	Not used	Not used		
P6-12		25P 120 Flexible Cable/60V	XDD3034	Not used	Not used	Not used		
P6-12		30P 120 Flexible Cable/60V	Not used	XDD3035	XDD3035	XDD3035		
P6-13	NSP	19P 190 Flexible Cable/30V	XDD3038	Not used	Not used	Not used		
P6-14		8P 230 Flexible Cable/30V	XDD3039	Not used	Not used	Not used		
P6-14		16P Flexible Cable/30V	Not used	XDD3006	XDD3006	XDD3006		
P6-19		Chassis	XNA3004	XNA3003	XNA3003	XNA3003		
P6-20		Rear Panel	XNC3040	XNC3043	XNC3043	XNC3043		
P6-35	NSP	Fuse Label	AAX2374	AAX7098	AAX7098	AAX7098		
P6-39	NSP	Cushion Leg B	XEB3009	Not used	Not used	Not used		
P6-43		Getter	XAX3143	XAX3146	XAX3146	XAX3146		
P6-44		Caution Label	Not used	Not used	PRW1018	PRW1018		
P6-45		65 Label	ORW1069	Not used	Not used	Not used		

XR-VS88, XR-VS66

Ref. No.	Mark	Symbol and Description	Part No.				Remarks
			XR-A670 /KUCXJ	XR-VS88 /DBDXJ	XR-VS88 /DXJN/NC	XR-VS88 /DLXJ/NC	
P6-56 P6-57	△ NSP	Cusion Leg A	XEB3008	Not used	Not used	Not used	*1 *2 *3
		Leg	XMR3012	Not used	Not used	Not used	
		Fuse (FU2, FU3 : T3.15A)	Not used	AEK1059	AEK1059	AEK1059	
		Fuse Label	Not used	AAX7493	AAX7493	AAX7493	
		Name Label	Not used	XAL3036	Not used	Not used	No.1
		Mic Knob	Not used	XAB3007	XAB3007	XAB3007	
		Cord Clamper	RNH1005	Not used	Not used	Not used	
		FRONT PANEL SECTION					
P9- 3		Earth Plate B	XNG3023	XNG3023	XNG3023	Not used	
P9-13		V button A	XAD3034	XAD3035	XAD3035	XAD3035	
P9-14		V button B	XAD3039	XAD3040	XAD3040	XAD3040	
P9-17		Display Panel	XAK3113	XAK3119	XAK3119	XAK3119	
P9-19		FL Cover	XAK3088	XAK3124	XAK3124	XAK3124	
P9-23		S.C. button	XAD3026	XAD3029	XAD3029	XAD3029	
P9-27		JOG Lens	XAK3084	XAK3096	XAK3096	XAK3096	
P9-30		Sub Panel	XAK3106	XAK3107	XAK3107	XAK3107	
P9-37		Cusion Leg A	XEB3008	Not used	Not used	Not used	No.2
		Earth Plate A	Not used	XNG3018	XNG3018	XNG3018	

Notes : ●The numbers in the remarks column correspond to the numbers on the “ EXPLODED VIEWS ”.
 ● For PCB ASSEMBLIES, Refer to “CONTRAST OF PCB ASSEMBLIES” and “3. SCHEMATIC DIAGRAM”.
 *1 : Refer to “3. SCHEMATIC DIAGRAM”.
 *2 : Stick Fuse Card on PRIMARY Assy.
 *3 : Stick Name Label on Rear Panel.

XR-VS66/DBDXJ, DXJN/NC, DLXJ/NC and XR-A370/KUCXJ are constructed the same except for the following :

Ref. No.	Mark	Symbol and Description	Part No.				Remarks
			XR-A370 /KUCXJ	XR-VS66 /DBDXJ	XR-VS66 /DXJN/NC	XR-VS66 /DLXJ/NC	
P6- 1	△ NSP	PCB ASSEMBLIES					
		MAIN ASSY	XWM3097	XWM3099	XWM3099	XWM3099	
		└ AF ASSY	XWZ3196	XWZ3198	XWZ3198	XWZ3198	
		COMPLEX ASSY	XWM3108	XWM3118	XWM3110	XWM3110	
P6- 2		└ PRIMARY ASSY	XWZ3224	XWZ3222	XWZ3222	XWZ3222	
P6- 3		└ SUB TRANS ASSY	XWZ3227	XWZ3226	XWZ3226	XWZ3226	
P9- 1		└ DISPLAY ASSY	XWZ3209	XWZ3219	XWZ3211	XWZ3211	
		PACKING SECTION					
P4- 1		Power Cord	ADG7022	ADG1158	ADG1154	ADG1154	
P4- 4		Remote Control Unit (CU-XR060)	XZN3067	Not used	Not used	Not used	
P4- 4		Remote Control Unit (CU-XR061)	Not used	XZN3068	XZN3068	XZN3068	
P4- 5		Battery Cover	XZN3065	XZN3066	XZN3066	XZN3066	
P4-10		Packing Case	XHD3082	XHD3088	XHD3112	XHD3089	
P4-11		Warranty Card	ARY7033	Not used	Not used	Not used	
P4-13		Operating Instructions (English/French)	XRE3024	Not used	Not used	Not used	
		Operating Instructions (English/Chinese/Spanish)	Not used	XRE3026	Not used	XRE3026	
		Operating Instructions (Thai)	Not used	Not used	XRC3019	Not used	
		Video Cord (L=1.5m/Yellow)	Not used	VDE1034	VDE1034	VDE1034	
		SW Antenna	Not used	ADH7006	Not used	Not used	
							Accessories

Ref. No.	Mark	Symbol and Description	Part No.				Remarks
			XR-A370 /KUCXJ	XR-VS66 /DBDXJ	XR-VS66 /DXJN/NC	XR-VS66 /DLXJ/NC	
		EXTERIOR SECTION					
P6- 5		FM/AM TUNER Module	AXQ7065	AXQ7062	AXQ7065	AXQ7065	
P6- 6	NSP	\$M Mechanism CD-2	XXA3009	Not used	Not used	Not used	
P6- 6	NSP	\$M Mechanism VCD	Not used	XXA3007	XXA3007	XXA3007	
P6- 7	⚠	Power Transformer (AC120V)	XTS3017	Not used	Not used	Not used	
P6- 7	⚠	Power Transformer (AC110-127V/220-230V/240V)	Not used	XTS3015	XTS3015	XTS3015	
P6- 8	⚠	Fuse (FU1 : 5A)	REK1083	Not used	Not used	Not used	
P6- 8	⚠	Fuse (FU1 : T4A)	Not used	AEK1060	AEK1060	AEK1060	
P6- 9	NSP	Fuse Caution Label	XAX3122	Not used	Not used	Not used	
P6-12		25P 120 Flexible Cable/60V	XDD3034	Not used	Not used	Not used	
P6-12		30P 120 Flexible Cable/60V	Not used	XDD3035	XDD3035	XDD3035	
P6-13		19P 190 Flexible Cable/30V	XDD3038	Not used	Not used	Not used	
P6-14		8P 230 Flexible Cable/30V	XDD3039	Not used	Not used	Not used	
P6-14		16P Flexible Cable/30V	Not used	XDD3006	XDD3006	XDD3006	
P6-19	NSP	Chassis	XNA3004	XNA3003	XNA3003	XNA3003	
P6-20		Rear Panel	XNC3035	XNC3038	XNC3038	XNC3038	
P6-35	NSP	Fuse Label	AAX7097	Not used	Not used	Not used	
P6-39		Cushion Leg B	XEB3009	Not used	Not used	Not used	
P6-43	NSP	Getter	XAX3138	XAX3141	XAX3141	XAX3141	
P6-44		Caution Label	Not used	Not used	PRW1018	PRW1018	
P6-45		65 Label	ORW1069	Not used	Not used	Not used	
P6-56		Cusion Leg A	XEB3008	Not used	Not used	Not used	
P6-57	⚠	Leg	XMR3012	Not used	Not used	Not used	
	NSP	Fuse (FU2, FU3 : T2A)	Not used	AEK1057	AEK1057	AEK1057	*1
		Name Label	Not used	XAL3031	Not used	Not used	*2
		Mic Knob	Not used	XAB3007	XAB3007	XAB3007	No.1
		FRONT PANEL SECTION					
P9-13		V button A	XAD3034	XAD3035	XAD3035	XAD3035	
P9-14		V button B	XAD3039	XAD3040	XAD3040	XAD3040	
P9-17		Display Panel	XAK3108	XAK3110	XAK3110	XAK3110	
P9-19		FL Cover	XAK3088	XAK3124	XAK3124	XAK3124	
P9-23		S.C. button	XAD3026	XAD3029	XAD3029	XAD3029	
P9-24		POWER button	XAD3027	XAD3033	XAD3033	XAD3033	
P9-27		JOG Lens	XAK3084	XAK3096	XAK3096	XAK3096	
P9-30		Sub Panel	XAK3080	XAK3103	XAK3103	XAK3103	
P9-37		Cusion Leg A	XEB3008	Not used	Not used	Not used	
		Earth Plate A	Not used	XNG3018	XNG3018	XNG3018	No.2

Notes : ●The numbers in the remarks column correspond to the numbers on the “EXPLODED VIEWS”.


● For PCB ASSEMBLIES, Refer to “CONTRAST OF PCB ASSEMBLIES” and “3. SCHEMATIC DIAGRAM”.

*1 : Refer to “3. SCHEMATIC DIAGRAM”.


*2 : Stick Name Label on Rear Panel.

■ EXPLODED VIEWS

● EXTERIOR SECTION



● FRONT PANEL SECTION



■ CONTRAST OF \$M MECHANISM

XXA3007 and XXA3012 are constructed the same except for the following :


Ref. No.	Mark	Symbol and Description	Part No.		Remarks
			XXA3012 (XR-A670)	XXA3007 (XR-VS88, XR-VS66)	
P11- 1		\$M SERVO MECHA ASSY	XWX3008	Not used	
P11- 2		— MOTOR ASSY	XWZ3230	Not used	
P11- 3		— SW ASSY	XWZ3231	Not used	
P11- 4		— CD ASSY	XWZ3233	Not used	
P11- 4		— TRADE ASSY	XWZ3232	Not used	
P11- 3		\$M VCD SURVO ASSY	Not used	XWX3003	
P11- 1		\$M MECHA PCB ASSY	Not used	XWX3004	
P11- 2		— MOTOR ASSY	Not used	XWZ3080	
P11- 2		— SW ASSY	Not used	XWZ3081	
P11- 4		— TRADE ASSY	Not used	XWZ3082	
P11-11		Traverse Base	XNW3006	XNW3010	
P11-12		Rotary Tray	ANW7124	ANW7113	
P11-13		Clamper	XNW3007	ANW7091	
P11-21		16P 200 Flexible Cable/60V	XDD3036	Not used	
P11-21		15P Flexible Cable/30V	Not used	XDD3007	
P11-25		Servo Mechanism Assy	XXA3010	AXA7039 *1	
P11-31		11P 185 Flexible Cable/30V	XDD3037	Not used	
P11-31		13P Flexible Cable/30V	Not used	XDD3008	
P11-32		Cushion Rubber	XEB3007	Not used	

Notes : For PCB ASSEMBLIES, Refer to “ ”, “3. SCHEMATIC DIAGRAM” and “4. PCB CONNECTION DIAGRAM”.

*1 : Refer to “ EXPLODED VIEWS ”.

■ EXPLODED VIEWS

● SERVO MECHANISM ASSY



● SERVO MECHANISM ASSY PARTS LIST

Mark	No.	Description	Part No.
	1	Servo Mechanism	AXA7039
	2	SPINDLE MOTOR Assy	AEA7009
	3	SLEAD MOTOR Assy	AEA7010
	4	Gear A	AEA7013
	5	Gear B	AEA7014
	6	Screw	AEA7015
	7	Screw	AEA7016
	8	Screw	AEA7017
	9	Screw	AEA7018
	10	Leaf Switch	AEA7011

■ CONTRAST OF PCB ASSEMBLIES

F AF ASSY

XWZ3201 and XWZ3199 are constructed the same except for the following :

Mark	Symbol and Description	Part No.		Remarks
		XWZ3199	XWZ3201	
⚠	IC51	Not used	NJM7805FA	
	IC3951	Not used	BA4558F	
	Q51, Q52	Not used	2SB1237X	
	Q53	Not used	2SC2412K	
	D46	1SS133	Not used	
	D51, D52	S5688G	Not used	
	D53	Not used	MTZJ6.8C	
	D63, D64	1SS355	Not used	
	C52, C3953	Not used	CEAT100M50	
	C53	Not used	CEAT220M50	
	C1992, C1993	Not used	CKSQYB104K25	
	C3011, C3012	CEATR47M50	Not used	
	C3038	CEJA2R2M50	CEAT2R2M50	
	C3041, C3042	Not used	CEAT2R2M50	
	R51, R53, R56	Not used	RS1/10S473J	
⚠	R52	Not used	RD1/2PM221J	
	R54	Not used	RD1/2PM101J	
	R55, R3951~R3956	Not used	RS1/10S472J	
	R63, R64	Not used	RS1/10S0R0J	
	R1999	Not used	RS1/10S102J	
	R3957, R3958	Not used	RS1/10S101J	
	CN1052	52045-0845	Not used	
	CN1053	Not used	52045-1645	
	CN5102	52045-2545	52045-3045	

XWZ3198 and XWZ3196 are constructed the same except for the following :

Mark	Symbol and Description	Part No.		Remarks
		XWZ3196	XWZ3198	
⚠	IC51	Not used	NJM7805FA	
	IC3951	Not used	BA4558F	
	Q51, Q52	Not used	2SB1237X	
	Q53	Not used	2SC2412K	
	D46	1SS133	Not used	
	D51, D52	S5688G	Not used	
	D53	Not used	MTZJ6.8C	
	D63, D64	1SS355	Not used	
	C52, C3953	Not used	CEAT100M50	
	C53	Not used	CEAT220M50	
	C1992, C1993	Not used	CKSQYB104K25	
	C3011, C3012	CEATR47M50	Not used	
	C3038	CEJA2R2M50	CEAT2R2M50	
	C3041, C3042	Not used	CEAT2R2M50	
	R51, R53, R56	Not used	RS1/10S473J	
⚠	R52	Not used	RD1/2PM221J	
	R54	Not used	RD1/2PM101J	
	R55, R3951~R3956	Not used	RS1/10S472J	
	R63, R64	Not used	RS1/10S0R0J	
	R1999	Not used	RS1/10S102J	
	R2212, R2213	RS1/10S0R0J	RS1/10S102J	
	R3957, R3958	Not used	RS1/10S101J	
	CN1052	52045-0845	Not used	
	CN1053	Not used	52045-1645	
	CN5102	52045-2545	52045-3045	

HF PRIMARY ASSY

XWZ3222 and XWZ3224 are constructed the same except for the following :

Mark	Symbol and Description	Part No.		Remarks
		XWZ3224	XWZ3222	
△	S1 VOLTAGE SELECTOR	Not used	XKX3001	
	H3-H6 FUSE CLIP	Not used	AKR7001	
NSP	Y4 JUMPER WIRE	Not used	XDX3009	

JF DISPLAY ASSY

XWZ3216 and XWZ3214 are constructed the same except for the following :

Mark	Symbol and Description	Part No.		Remarks
		XWZ3214	XWZ3216	
	IC3901	Not used	BA4558F	
	IC3931	Not used	M65855FP	
	D3931	Not used	MTZJ5.1B	
	D5551-D5554	1SS181	Not used	
	D5591	Not used	1SS133	
	D5597	1SS355	Not used	
	D5613-D5616	MBG5064X	MAA5064X	
	D5617, D5618	SLP7118C51H	SLP6118C51H	
	F3903, F3904	Not used	DTF1069	
	L3931	Not used	LCTB100K2125	
	C3901, C3902, C3904, C3906	Not used	CEJA2R2M50	
	C3903	Not used	CCSQSL331J50	
	C3905	Not used	CEJA470M16	
	C3907, C3948	Not used	CKSQYB472K50	
	C3910	Not used	CKSQYB104K25	
	C3911, C3931, C3934, C3940	Not used	CKSQYB103K50	
	C3932	Not used	CEJAR47M50	
	C3933	Not used	CEJA220M16	
	C3935	Not used	CKSQYB473K50	
	C3936, C3937	Not used	CEJA4R7M50	
	C3938	Not used	CKSQYB472K50	
	C3939	Not used	CKSQYB123K50	
	C3942	Not used	CKSQYF104K50	
	C3943	Not used	CEJA101M16	
	R3901, R3902, R3907, R3911, R3912	Not used	RS1/10S332J	
	R3903, R3936	Not used	RS1/10S103J	
	R3904	Not used	RS1/10S104J	
	R3905	Not used	RS1/10S473J	
	R3906	Not used	RS1/10S681J	
	R3908	Not used	RS1/10S101J	
	R3922	Not used	RS1/10S0R0J	
	R3931	Not used	RS1/10S472J	
	R3932, R3937, R3938	Not used	RS1/10S123J	
	R3933	Not used	RS1/10S154J	
	R3934	Not used	RS1/10S124J	
	R3935	Not used	RS1/10S822J	
	R3940	Not used	RD1/4PU331J	
	R5554 (1.5kΩ)	ACN7062	Not used	
	R5558 (47kΩ)	ACN7077	Not used	
	R5605, R5606	RD1/4PU301J	RD1/4PU391J	
	VR3901, VR3931	Not used	XCS3002	
	JA3901, JA3902	Not used	XKN3003	
	CN5501	52492-1920	Not used	
	CN5502	Not used	52045-3045	
	CN5503	52045-2545	Not used	

XR-VS88, XR-VS66

XWZ3219, XWZ3211 and XWZ3209 are constructed the same except for the following :

Mark	Symbol and Description	Part No.			Remarks
		XWZ3209	XWZ3219	XWZ3211	
	IC3901	Not used	BA4558F	BA4558F	
	IC3931	Not used	M65855FP	M65855FP	
	D3931	Not used	MTZJ5.1B	MTZJ5.1B	
	D5551–D5554	1SS181	Not used	Not used	
	D5591	Not used	1SS133	1SS133	
	D5594	Not used	1SS133	Not used	
	D5597	1SS355	Not used	Not used	
	F3903, F3904	Not used	DTF1069	DTF1069	
	L3931	Not used	LCTB100K2125	LCTB100K2125	
	C3901, C3902, C3904, C3906	Not used	CEJA2R2M50	CEJA2R2M50	
	C3903	Not used	CCSQSL331J50	CCSQSL331J50	
	C3905	Not used	CEJA470M16	CEJA470M16	
	C3907, C3948	Not used	CKSQYB472K50	CKSQYB472K50	
	C3910	Not used	CKSQYB104K25	CKSQYB104K25	
	C3911, C3931, C3934, C3940	Not used	CKSQYB103K50	CKSQYB103K50	
	C3932	Not used	CEJAR47M50	CEJAR47M50	
	C3933	Not used	CEJA220M16	CEJA220M16	
	C3935	Not used	CKSQYB473K50	CKSQYB473K50	
	C3936, C3937	Not used	CEJA4R7M50	CEJA4R7M50	
	C3938	Not used	CKSQYB472K50	CKSQYB472K50	
	C3939	Not used	CKSQYB123K50	CKSQYB123K50	
	C3942	Not used	CKSQYF104K50	CKSQYF104K50	
	C3943	Not used	CEJA101M16	CEJA101M16	
	R3901, R3902, R3907, R3911, R3912	Not used	RS1/10S332J	RS1/10S332J	
	R3903, R3936	Not used	RS1/10S103J	RS1/10S103J	
	R3904	Not used	RS1/10S104J	RS1/10S104J	
	R3905	Not used	RS1/10S473J	RS1/10S473J	
	R3906	Not used	RS1/10S681J	RS1/10S681J	
	R3908	Not used	RS1/10S101J	RS1/10S101J	
	R3922	Not used	RS1/10S0R0J	RS1/10S0R0J	
	R3931	Not used	RS1/10S472J	RS1/10S472J	
	R3932, R3937, R3938	Not used	RS1/10S123J	RS1/10S123J	
	R3933	Not used	RS1/10S154J	RS1/10S154J	
	R3934	Not used	RS1/10S124J	RS1/10S124J	
	R3935	Not used	RS1/10S822J	RS1/10S822J	
	R3940	Not used	RD1/4PU331J	RD1/4PU331J	
	R5554 (1.5kΩ)	ACN7062	Not used	Not used	
	R5558 (47kΩ)	ACN7077	Not used	Not used	
	VR3901, VR3931	Not used	XCS3002	XCS3002	
	JA3901, JA3902	Not used	XKN3003	XKN3003	
	CN5501	52492-1920	Not used	Not used	
	CN5502	Not used	52045-3045	52045-3045	
	CN5503	52045-2545	Not used	Not used	

IF SUB TRANS ASSY

XWZ3226 and XWZ3227 are constructed the same except for the following :

Mark	Symbol and Description	Part No.		Remarks
		XWZ3227	XWZ3226	
⚠	R1 (2.2MΩ/ 1/2) AN1 1P AC INLET	RCN1080 XKP3042	Not used XKP3041	

Mark	No.	Description	Part No.
------	-----	-------------	----------

PCB PARTS LIST

B F VCD SURVO ASSY

SEMICONDUCTORS

△	IC1001	BA033FP
	IC1401	BA4558F-HT
	IC1301	BA5923FP
	IC1701	CL680T-D1
	IC1101	LA9240ML
	IC1201	LC78632RE
	IC1752	MB814260-70PJ
	IC1501	PDC051A
	IC1751	PDK032A
	IC1754	TC7W14F
	IC1753	TC7WU04F
	Q1101	2SA1048
	Q1351, Q1352	2SB1237X
	Q1353, Q1354	2SD1858X
	D1351-D1354	1SS355

COILS AND FILTERS

F1501	DTF1064
F1201	DTF1066
F1202	DTF1067
F1705, F1706	DTF1069
L1702	LCTB1R8K2125
L1701	LCTB2R7K2125
L1201	LFA100J
L1001	LFA220J

CAPACITORS

C1129, C1205, C1208, C1213, C1353	CCSQCH101J50
C1706, C1722	CCSQCH101J50
C1133, C1755, C1756	CCSQCH120J50
C1720	CCSQCH121J50
C1216	CCSQCH150J50
C1708	CCSQCH151J50
C1217	CCSQCH180J50
C1705	CCSQCH271J50
C1132	CCSQCH300J50
C1707	CCSQCH331J50
C1130	CCSQCH3R0C50
C1715, C1717	CCSQCH470J50
C1138	CEAT100M50
C1003, C1108, C1144, C1207, C1214	CEAT101M10
C1301, C1351, C1501	CEAT101M10
C1127	CEAT1R0M50
C1005, C1007, C1126, C1141, C1409	CEAT470M16
C1411	CEAT470M16
C1718	CEAT471M6R3
C1136	CEAT4R7M50
C1109	CEATR22M50
C1124	CEATR47M50
C1101	CEJA3R3M50
C1105	CEJA470M10
C1106, C1119, C1134	CKSQYB102K50

Mark	No.	Description	Part No.
------	-----	-------------	----------

C1102, C1122, C1123, C1139, C1140	CKSQYB103K50
C1209, C1215, C1218, C1231, C1302	CKSQYB103K50
C1354, C1502-C1506, C1703, C9002	CKSQYB103K50
C9005, C9013, C9015	CKSQYB103K50
C1001, C1002, C1004, C1008, C1135	CKSQYB104K25

C1151, C1202, C1203, C1511	CKSQYB104K25
C1701, C1702, C1704, C1710-C1714	CKSQYB104K25
C1716, C1751-C1754, C1757, C9004	CKSQYB104K25
C9006, C9008, C9017, C9019	CKSQYB104K25
C1405, C1406	CKSQYB152K50

C1111	CKSQYB153K25
C1114, C1117, C1120, C1121	CKSQYB154K16
C1125	CKSQYB221K50
C1131	CKSQYB222K50
C1107	CKSQYB223K50

C1110, C1403, C1404, C1407, C1408	CKSQYB331K50
C1115, C1128	CKSQYB332K50
C1113	CKSQYB333K25
C1112, C1143	CKSQYB334K16
C1212	CKSQYB471K50

C1507	CKSQYB472K50
C1116, C1142	CKSQYB473K50
C1401, C1402	CKSQYB561K50
C1118, C1201, C1204, C1206	CKSQYF104Z25

RESISTORS

R1704	RS1/10S2001F
Other Resistors	RS1/10S□□□J

OTHERS

CN1004	16P FFC CONNECTOR	52044-1645
CN1003	3P SIDE POST	B3P-SHF-1AA
CN1002	13P FFC CONNECTOR	SLW13R-1C7
CN1001	15P FFC CONNECTOR	SLW15R-1C7
JA1701	1P PIN JACK	VKB1063

X1201	CRYSTAL RESONATOR (16.9344MHz)	PSS1008
-------	--------------------------------	---------

X1501	CERAMIC RESONATOR (6MHz)	RSS1050
-------	--------------------------	---------

X1751	CRYSTAL RESONATOR (27MHz)	VSS1086
-------	---------------------------	---------

C F MOTOR ASSY

SWITCHES AND RELAYS

S9503	ASG7009
-------	---------

OTHERS

J9502	JUMPER WIRE 4P	D20PWW0405E
	MOTOR PULLEY	PNW1634
	CARRIAGE MOTOR	VXM1033

XR-VS88, XR-VS66


Mark	No.	Description	Part No.
D F SW ASSY			
SWITCHES AND RELAYS			
	S9502		ASG7009
	S9501		DSG1017
OTHERS			
	J9501	JUMPER WIRE 6P	D20PWY0610E
E F TRADE ASSY			
OTHERS			
	CN9501	6P JUMPER CONNECTOR	52147-0610
	CN9001	CONNECTOR	S6B-PH-K-S
	CN9002	13P CONNECTOR	SLW13R-1C7
A F FM/AM TUNER MODULE (AXQ7062)			
SEMICONDUCTORS			
	IC6201		LA1832ML
	IC6202		LC72131MD
	Q6402		2SC2223
	Q6203		2SC2705
	Q6201, Q6202		2SC2712
	Q6214, Q6403		2SC2714
	Q6304, Q6306		2SD2114K
	Q6404		2SK302
	Q6401		3SK194
	Q6301–Q6303		DTA124EK
	Q6204		DTA124ES
	Q6205		DTC124EK
	D6202, D6303–D6308, D6310–D6312		1SS254
	D6314, D6315		1SS254
	D6302, D6309		1SS85
	D6401, D6402		1T363
	D6313		KV1561A-2
COILS AND FILTERS			
	L6303		ATA7001
	L6304		ATA7002
	L6404		ATC1003
	L6401		ATC1020
	L6402		ATC1021
	F6204		ATF-107
	F6203		ATF-119
	F6401		ATF-155
	F6206		ATF7008
	F6202		ATF7017
	L6206, L6208, L6403		LAU2R2J
	L6301, L6302		LTA393J
TRANSFORMERS			
	T6201		ATB7008
	T6401		ATE7002

Mark	No.	Description	Part No.
CAPACITORS			
	C6208		CCSQCH100D50
	C6212, C6274, C6275, C6408		CCSQCH101J50
	C6412		CCSQCH102J50
	C6221, C6222, C6416		CCSQCH150J50
	C6271		CCSQCH200J50
	C6415		CCSQCH330J50
	C6401, C6419		CCSQCH5R0C50
	C6304		CCSQCH7R0D50
	C6407		CCSQCK1R0C50
	C6320, C6410		CCSQCK2R0C50
	C6413		CCSQPH220J50
	C6414		CCSQPH8R0D50
	C6405		CCSQTH180J50
	C6234, C6235		CEAL1R0M50
	C6245		CEAL470M16
	C6224		CEAS100M50
	C6243		CEAS101M16
	C6231		CEAS1R0M50
	C6227		CEAS220M16
	C6236		CEAS2R2M50
	C6216		CEAS330M16
	C6262		CEAS3R3M50
	C6219		CEAS470M10
	C6244		CEAS470M16
	C6249, C6250, C6265, C6266		CEAS4R7M50
	C6258		CEJA470M16
	C6215		CFTLA103J50
	C6214		CFTLA224J50
	C6211, C6254, C6403, C6406		CKSQYB102K50
	C6201, C6205, C6210, C6213, C6237		CKSQYB103K50
	C6276, C6278, C6280, C6281, C6302		CKSQYB103K50
	C6308, C6312, C6314, C6318, C6319		CKSQYB103K50
	C6402, C6409, C6417, C6418		CKSQYB103K50
	C6251, C6252		CKSQYB153K50
	C6303		CKSQYB222K50
	C6203, C6259, C6301, C6305, C6306		CKSQYB223K50
	C6311, C6315		CKSQYB223K50
	C6228		CKSQYB472K50
	C6209		CKSQYB473K50
	C6310		CKSQYB562K50
	C6230		CKSQYB821K50
	C6218, C6223, C6255		CKSQYF103Z50
	C6316		CKSQYF105Z16
	C6220, C6226, C6242, C6256		CKSQYF223Z50
	C6225		CKSQYF473Z50
RESISTORS			
	R6280		RD1/4PU101J
	R6311, R6318, R6413, R6416, R6418		RS1/8S0R0J
	R6906, R6909		RS1/8S0R0J
	R6304		RS1/8S103J
	R6401		RS1/8S470J
	VR6201 (2.2kΩ/0.1W)		RCP1046
	Other Resistors		RS1/10S□□□J

Mark	No.	Description	Part No.
OTHERS			
	BN6202	TERMINAL 4-P	AKE7051
	X6202	CERAMIC RESONATOR (456kHz)	ASS1066
	X6201	CRYSTAL RESONATOR (7.2MHz)	ASS1093
	CN6201	14P SOCKET	KP200IA14L
		AM RF TUNING BLOCK	AXX7039
		AM RF TUNING BLOCK	AXX7040

3. SCHEMATIC DIAGRAM

3.1 FM/AM TUNER MODULE (FOR XR-VS66/DBDXJ)



Note : When ordering service parts, be sure to refer to "EXPLODED VIEWS and PARTS LIST" or "PCB PARTS LIST"

SIGNAL ROUTE

(AM)

□ : AM SIGNAL ROUTE

(FM)

□ : FM SIGNAL ROUTE

(TA)

◆ : TUNER AUDIO SIGNAL ROUTE

Notes

1.RESISTORS


Indicated in Ω , 1/10W $\pm$ 5% Tolerance unless otherwise noted K:K Ω , M:M Ω .

2.CAPACITORS


Indicated in Capacity (μ F)/VOLTAGE (V) unless otherwise noted P:PF.

3.DIODES

No mark diode is 1SS254.



F23 F CN3051



A

B

C


D

3.3 VCD SURVO ASSY (2/2)



B 2/2F



A F CN6201 (XR-VS66/DBDX.J)**AB** CN6201 (EXCEPT XR-VS66/DBDX.J)

F3/3F

AF ASSY

(XR-VS88 : XWZ3201)


(XR-VS66 : XWZ3198)

CAUTION : FOR CONTINUED PROTECTION AGAINST RISK OF FIRE. REPLACE ONLY WITH SAME TYPE NO. 4911.25 MFD, BY LITTELFUSE INK. FOR IC71 (AEK7010).


CAUTION : FOR CONTINUED PROTECTION AGAINST RISK OF FIRE. REPLACE ONLY WITH SAME TYPE NO. 491003 MFD, BY LITTELFUSE INK. FOR IC41 (AEK7050).

CAUTION : FOR CONTINUED PROTECTION AGAINST RISK OF FIRE. REPLACE ONLY WITH SAME TYPE NO. 491004 MFD, BY LITTELFUSE INK. FOR IC31 (AEK7053: XR-VS88).

CAUTION : FOR CONTINUED PROTECTION AGAINST RISK OF FIRE. REPLACE ONLY WITH SAME TYPE NO. 491003 MFD, BY LITTELFUSE INK. FOR IC31 (AEK7050: XR-VS66).



3.6 PRIMARY and SUB TRANS ASSYS



H_F
PRIMARY ASSY
(XWZ3222)

• NOTE FOR FUSE REPLACEMENT


CAUTION - FOR CONTINUED PROTECTION AGAINST RISK OF FIRE.
REPLACE WITH SAME TYPE AND RATINGS ONLY.

Y3 BLUE XDX3007
Y1 BROWN XDX3008
Y4 ORANGE XDX3009
Y2 GREY XDX3010
Y5 WHITE XDX3011

I_F
SUB TRANS ASSY
(XWZ3226)

XR-VS88 : AEK1061 (T5A)
XR-VS66 : AEK1060 (T4A)


XKP3041
LIVE
NEUTRAL




AC POWER CORD
DBDXJ TYPE : ADG1158
DLXJ/NC TYPE : ADG1154
DXJN/NC TYPE : ADG1154

3.7 DISPLAY ASSY

JF DISPLAY ASSY
 (XR-VS88 : XWZ3216)
 (XR-VS66/DBDXJ : XWZ3219)
 (XR-VS66/DLXJ/NC, DXJN/NC : XWZ3211)







4. PCB CONNECTION DIAGRAM

4.1 VCD SURVO, MOTOR, SW and TRADE ASSYS

A




B



C

D

BF VCD SURVO ASSY



(XNP3010-A)

SIDE B

5. ADJUSTMENT (FOR XR-VS66/DBDXJ)

Note : Adjustment of XR-VS66/DBDXJ are the same as those of XR-A370/KUCXJ except for the following:

■ AM Tuner SW Section

- Set the mode selector to SW2.
- Connect the wiring as shown in Fig. 1.

Step No.	Adjustment Title	AM SG (400Hz, 30% Mod.)		Reception Frequency Display	Adjustment Location	Specifications
		Frequency (MHz)	Input Level (dBμV/EMF)			
1	AM Front End Sensitivity Adjustment	14	25-35	14MHz	L6303	Adjust so that the DC voltage between the IC6201-Pin 20 and GND becomes at maximum level.

Befor adjustment, connect AM-ANT. and IEC-dummy ANT.. Signal input is through IEC-dummy ANT.. Connecting AM-ANT. follows Fig. 1.




Fig. 1 SW adjustment wiring diagram




Fig. 2 Adjustment points