

Service Manual

Direct Drive Automatic Turntable System

SL-1700MK2

(XG), (XGF), (XGB),
(E), (XA), (XGE)

SL-1700MK2A

(XA), (XG), (E)

SL-1710MK2

(XG), (E)

SL-1710MK2A

(XG), (E)



- The model SL-1700MK2 (XG), SL-1700MK2A (XG), SL-1710MK2 (XG) and SL-1710MK2A (XG) are available in European only.
- The model SL-1700MK2 (XGF) is available in France only.
- The model SL-1700MK2 (XGB) is available in Belgium only.
- The model SL-1700MK2 (E), SL-1700MK2A (E), SL-1710MK2 (E) and SL-1710MK2A (E) are available in Scandinavia only.
- The model SL-1700MK2 (XA) and SL-1700MK2A (XA) are available in Asia, Latin America, Middle East and Africa only.
- The model SL-1700MK2 (XGE) is available in United Kingdom only.
- SL-1700MK2 and SL-1700MK2A are of silver finish.
- SL-1710MK2 and SL-1710MK2A are of black finish.

SPECIFICATIONS (Specifications are subject to change without notice.)

General

Power supply: ~110-120/220-240V, AC 50 or 60 Hz
 Power consumption: 17.5W
 Dimensions: 45.3 x 14.9 x 39.9 cm
 (W x H x D)
 Weight: 10 kg (22 lb.)

Turntable section

Type: Quartz direct drive
 Automatic turntable
 Auto return
 Auto stop
 Drive method: Direct drive
 Motor: Brushless DC motor
 Turntable platter: Aluminum die-cast
 Diameter 33.2 cm (13-5/16")
 Weight 2 kg (4.4 lb.)
 Turntable speeds: 33-1/3 rpm and 45 rpm
 Pitch control: $\pm 6\%$ range
 Starting torque: 1.5 kg-cm (1.3 lb-in)
 Build-up characteristics: 0.7 sec. from standstill to 33-1/3 rpm
 Braking system: Electronic brake
 Speed change due to load torque: 0% within 1.0 kg-cm (0.87 lb-in)
 Wow and flutter: 0.01% WRMS*
 0.025% WRMS (JIS C5521)
 $\pm 0.035\%$ peak (IEC 98A Weighted)

*This rating refers to turntable assembly alone, excluding effects of record, cartridge or tonearm, but including platter.
 Measured by obtaining signal from built-in frequency generator of motor assembly.

Rumble: -56 dB (IEC 98A Unweighted)
 -78 dB (IEC 98A Weighted)

Tonearm section

Type: Universal
 Effective length: 230 mm (9-1/16")
 Arm height adjustment range:

Overhang: 15 mm (19/32")
 Effective mass: 12 g (without cartridge)
 Tracking error angle: Within $2^\circ 32'$ at the outer groove of 30 cm (12") record
 Within $0^\circ 32'$ at the inner groove of 30 cm (12") record
 Offset angle: 22°
 Friction: Less than 7 mg (lateral, vertical)

Stylus pressure adjustment range: 0-2.5 g
 Applicable cartridge weight range: 6-10 g
 13.5-17.5 g (including headshell)
 (with auxiliary weight): 9.5-13 g
 17-20.5 g (including headshell)
 (with shell weight): 3.5-6.5 g
 11-14 g (including headshell)
 Headshell weight: 7.5 g

Cartridge section

Model No.: EPC-207C
 Type: Moving magnet
 Frequency response: 20 Hz to 25 kHz
 20 Hz to 15 kHz ± 2 dB
 Output voltage: 3 mV at 1 kHz
 5 cm/s. zero to peak lateral velocity
 [8.5 mV at 1 kHz 10 cm/s. zero to peak 45° velocity (DIN 45500)]
 Channel separation: 25 dB at 1 kHz
 Channel balance: Within 2 dB at 1 kHz
 Compliance (dynamic): 10×10^6 cm/dyne at 100 Hz
 Stylus pressure: 1.75 ± 0.25 g (17.5 ± 2.5 mN)
 Load impedance: 47 k Ω to 100 k Ω
 Weight: 5.6 g (cartridge only)
 Replacement stylus: EPS-207ED
 (Elliptical stylus)

TECHNISCHE DATEN (Änderungen der technischen Daten vorbehalten.)

Allgemeine Daten

Stromversorgung:	~110-120/220-240 V, 50/60 Hz Wechselstrom
Leistungsaufnahme:	17,5 W
Abmessungen (B x H x T):	45,3 x 14,9 x 29,9 cm
Gewicht:	10 kg

Plattenspieler

Typ:	Automatischer Plattenspieler Rückführautomatik Stopautomatik Manueller Betrieb Direktantrieb
Antrieb:	Kollektorloser Gleichstrommotor
Motor:	Aluminium-Spritzguß
Plattenteller:	Durchmesser 33,2 cm Gewicht 2 kg
Plattenteller-Drehzahlen:	33-1/3 und 45 U/min
Drehzahl-Feinregulierung:	±6% Einstellbereich
Anlaufdrehmoment:	1,5 kg-cm
Drehzahl-Hochlaufzeit:	0,7 sec vom Stillstand auf 33-1/3 U/min
Bremssystem:	Elektronische Bremse

Drehzahl-Abweichung aufgrund von Lastschwankungen:	0% innerhalb 1,0 kg-cm
Gleichlaufschwankungen:	0,01% WRMS* 0,025% WRMS (JIS C5521) ±0,035% Spitze (IEC 98A bewertet)

*Diese Nennleistung bezieht sich auf das Laufwerk-Bauteil allein, ausschließlich Einflüsse von Schallplatte, Tonabnehmer oder Tonarm, aber einschließlich Plattenteller. Gemessen anhand von Signalen vom eingebauten Frequenzgenerator des Motorbauteils.

Rumpel-Geräuschspannungsabstand:	-56 dB (IEC 98A unbewertet) -78 dB (IEC 98A bewertet)
----------------------------------	--

Tonarm

Typ:	Universal-Tonarm
------	------------------

Effektive Länge:	230 mm
Tonarmhöhe-Einstellbereich:	Schraubteil: 6mm
Überhang:	15 mm
Effektive Masse:	12 g (ohne Tonabnehmer)
Spurfehlwinkel:	2°32' bei der Einlaufrille einer 30 cm-Platte 0°32' bei der Auslaufrille einer 30 cm-Platte 22°
Kröpfungswinkel:	22°
Lagerreibung:	Weniger als 7 mg (horizontal, vertikal)
Auflagekraft-Einstellbereich:	0-2,5 g
Zulässiger Tonabnehmer-Gewichtsbereich:	6-10 g 13,5-17 g (einschließlich Tonarmkopf)
(mit Ersatz-Gegengewicht):	9,5-13 g 17-20,5 g (einschließlich Tonarmkopf)
Gewichtsbereich:	3,5-6,5 g
(mit Zusatzgewicht):	11-14 g (einschließlich Tonarmkopf)
Tonarmkopf-Gewicht:	7,5 g

Tonabnehmer

Modell-Nummer:	EPC-207C
Typ:	Magnetischer Tonabnehmer
Frequenzgang:	20 Hz bis 25 kHz 20 Hz bis 15 kHz ±2 dB 3 mV bei 1 kHz 5 cm/s. Null-zu-Spitze, Lateral [8,5 mV bei 1 kHz 10 cm/s. Null-zu-Spitze, 45° (DIN 45500)]
Ausgangsspannung:	25 dB bei 1 kHz Innerhalb 2 dB bei 1 kHz
Kanaltrennung:	10 x 10 ⁶ cm/dyn bei 100 Hz
Kanalabweichung:	1,75 ±0,25 g (17,5 ±2,5 mN)
Nachgiebigkeit (dynamisch):	47 kΩ bis 100 kΩ
Auflagekraft:	5,6 g (ohne Tonarmkopf)
Impedanz:	EPS-207ED (Elliptische Nadel)
Gewicht:	
Ersatznadel:	

SPECIFICATIONS (Les spécifications sont susceptibles d'être modifiées sans préavis.)

Généralités

Alimentation:	Alternatif 110-120/220-240V, 50 ou 60 Hz
Consommation:	17,5 W
Dimensions (L x H x P):	45,3 x 14,9 x 39,3 cm
Poids:	10 kg

Platine de lecture

Type:	Platine automatique Retour automatique Arrêt automatique
Système d'entraînement:	Entraînement direct
Moteur:	Moteur C.C. sans balai
Plateau de lecture:	Aluminium moulé sous pression Diamètre 33,2 cm Poids 2 kg
Vitesses de rotation:	33-1/3 et 45 t/p.m
Réglage d'écart:	Plage de réglage de ±6%
Couple de démarrage:	1,5 kg-cm

Caractéristiques d'augmentation:	0,7 sec. de l'arrêt à 33-1/3 t/p.m.
Système de freinage:	Frein électronique
Variation de vitesse due au couple de charge:	0% en deçà de 1,9 kg-cm
Pleurage et scintillement:	0,01% de valeur efficace* 0,025% de valeur efficace (JIS C5521) ±0,035% de crête (IEC 98A Pondéré)

*Ce régime nominal se rapporte à l'ensemble du tournedisque seul, excluant les effets du disque, de la cellule pick-up ou de bras de lecture, mais comprenant le plateau. Mesuré par l'obtention d'un signal provenant du générateur de fréquences incorporé de l'ensemble du moteur.

Ronflement:	-56 dB (IEC 98A Non pondéré) -78 dB (IEC 98A Pondéré)
-------------	--

Bras de lecture

Type:	Bras de lecture universel
Longueur effective:	230 mm
Portée du réglage de la hauteur du bras:	Partie hélicoïdale 6 mm

Porte-à-faux:	15 mm
Masse réelle:	12 g (sans la cellule pick-up)
Angle d'erreur de piste:	En deçà de 2°32' au sillon extérieur d'un disque de 30 cm En deçà de 0°32' au sillon intérieur d'un disque de 30 cm
Angle de décalage:	22°
Frottement:	Moins de 7 mg (latéral et vertical)
Plage de réglage de la pression d'appui:	0-2,5 g
Gamme du poids de la cellule pick-up utilisable:	6-10 g 13,5-17 g (y compris la coque porte-cellule)
(avec contrepoids de réserve):	9,5-13 g 17-20,5 g (y compris la coque porte-cellule)
(avec contrepoids de la cellule):	3,5-6,5 g 11-14 g (y compris la coque porte-cellule)
Poids de la cellule:	7,5 g


Cellule pick-up

No. du modèle:	EPC-207C
Type:	Aimant mobile
Réponse en fréquence:	20 Hz à 25 kHz 20 Hz à 15 kHz ±2 dB 3 mV à 1 kHz; 5 cm/s. zéro à vitesse latérale de crête (8,5 mV à 1 kHz 10 cm/s., zéro à vitesse 45° de crête [DIN 45500])
Tension de sortie:	25 dB à 1 kHz En deçà de 2 dB à 1 kHz
Séparation de canal:	10 x 10 ⁶ cm/dyne à 100 Hz
Équilibrage des canaux:	1,75 ±0,25 g (17,5 ±2,5 mN)
Elasticité (dynamique):	47 kΩ to 100 kΩ
Pression de la pointe de lecture:	5,6 grammes (cellule seule)
Impédance de charge:	
Poids:	
Pointe de lecture de remplacement:	EPS-207ED (Forme elliptique)



■ CONTENTS

LOCATION OF CONTROLS	3 ~ 4	CONTROL CIRCUIT BOARD	21, 22
TECHNICAL GUIDE	4 ~ 6	DRIVE CIRCUIT BOARD	23
TROUBLE SHOOTING OF ARM DRIVE CIRCUIT	7	SCHEMATIC DIAGRAM 1 (Control Circuit Board)	24 ~ 26
DISASSEMBLY PROCEDURE	7 ~ 11	SCHEMATIC DIAGRAM 2 (Drive Circuit Board)	27, 28
ADJUSTMENTS (Electrical)	11 ~ 12	TONE ARM DRIVE CIRCUIT BOARD	29, 30
ADJUSTMENT POINTS	12	SCHEMATIC DIAGRAM 3 (Tone arm Drive Circuit Board)	31
REGLAGES (Electricité)	13	REPLACEMENT PARTS LIST (Electric Parts)	32
ABGLEICHUNG (Elektrisch)	14	EXPLODED VIEW (Main Base)	33, 34
ADJUSTMENTS (Tone arm)	15	REPLACEMENT PARTS LIST (Main Base and Bottom Base Parts)	35
REGLAGES (Bras acoustique)	16	EXPLODED VIEW (Bottom Base)	36, 37
JUSTIERUNG (Tonarm)	17	EXPLODED VIEW (Tone Arm and Arm Base)	38, 39
BLOCK DIAGRAM (Drive Circuit)	18	REPLACEMENT PARTS LIST (Tone Arm and Arm Base Parts)	40
BLOCK DIAGRAM (Control Circuit, Arm Control Circuit and Pitch Control Circuit)	19		
REFERENCE VOLTAGE AND WAVEFORM AT EACH IC ...	20		

■ LOCATION OF CONTROLS



SL-1700MK2/ SL-1710MK2



■ TECHNICAL GUIDE

Arm control circuit

This circuit includes a circuit to control the cueing and returning operation of the arm by using a DC motor, a rest detection circuit which gives a start/stop instruction to the turntable, and a circuit to electrically detect the return position the same as in SL-1300MK2.

1. Cueing operation

Arm switches A and B are turned ON and OFF by the cam interlocked with the cueing mechanism of the arm. Whether the arm is cued up or down with the cueing switch depressed depends on the positions of these two switches.

● Cueing down

When the arm switch A is OFF, while B is ON or OFF, depressing the cueing switch results in cueing down.

As the arm switch A is OFF, ④ is "H" and ③ is "L". The output of ③ is applied to D terminals (pin 5 and 9 of IC460) of the D flip-flop circuit* of IC460. Then, depressing the cueing switch generates clock pulses which are applied to CK terminals (pins 3 and 11) of IC460, thus the outputs X="L" and Y="H" come out of X (pin 1 of IC460) and Y (pin 12 of IC460). The outputs enter the motor driving circuit to operate the DC motor. Outputs X and Y, motor rotating direction, and arm operation are shown in the Fig. 1.

With the above operations completed, the arm is cued down by the drive motor. However, the motor will continue rotating if the conditions are left unchanged. Therefore, the outputs of arm switches A and B pass through the Exclusive -OR circuit* and generate motor stopping pulses at the next pulse generating circuit in order to apply pulses to S (pin 6 of IC460) and R (pin 10 of IC460) terminals of the flip-flop circuit of IC460 to reset the outputs at X and Y (X="H", Y="L", thus stopping the rotation of the motor.

• Cueing up

When the arm switch A is ON, while B is ON or OFF, depressing the cueing switch results in cueing up. As the arm switch A is ON, ④ is "L" and ③ is "H".

The output of ③ is put into D terminals (pins 5 and 9) of IC460. Then, depressing the cueing switch generates clock pulses as in cueing down operation, causing X and Y to become "H" and "L" respectively. Thus, the motor rotates in the direction of cueing up operation as shown in Table 1. After that, reset pulses are applied to the flip-flop circuit of IC460, then outputs at both X and Y become "H" causing the motor to stop.

Note:

Cueing up is possible during cueing down, but cueing down is not possible during cueing up.

2. Rest position detection

When the arm moves off the arm rest, the turntable rotates. Structurally, a coupler using an LED and photo-transistor is located under the arm base; when the arm is on the rest, the LED and photo-transistor are interrupted by the slit, turning the photo-transistor (PH402) off; when the arm is off the rest, the photo-transistor turns on, causing ⑥ to become "L", then Q455 turns off and a voltage is applied to pin 19 of IC201 to rotate the turntable. Input "L" is applied to pin 9 of IC456 in order to inhibit the operation of the gate so that depressing the stop switch does not cause the arm to operate when the arm is on the rest.

3. Stop operation

If desired to stop the performance, push the stop switch, then the arm returns to the arm rest.

Depressing the stop switch generates $\square$ pulse at ⑤.

① is "L" when the arm is on the rest, inhibiting the pulse from the stop switch, and it is "H" when the arm is off the rest.

Depressing the stop switch, when ① is "H", generates $\square$ pulse at ⑤. The pulse causes the R-S flip-flop circuit of IC457 and IC458 to reverse, then ⑥ and ④ respectively becomes "H" and "L", while S (pin 8 of IC460) and S (pin 6 of IC460) terminals of D flip-flop circuit of IC460 become "H" resulting in X="H" and Y="L". The output causes the arm to return. Also, about 0.9 sec. after rest position detection to stop the turntable, $\square$ pulse is applied to ① of R-S flip-flop circuit of IC457 and IC458, thus resetting the R-S flip-flop (⑥="L", ④="L").


* D flip-flop circuit

This circuit includes a D input, a clock input (ck), and two outputs Q and $\bar{Q}$. The outputs of this flip-flop remain unchanged even with D input "L" or "H" added.

However, if a clock pulse is applied to this circuit while it is supplied with a D input, the D input is transmitted to output Q. Therefore, output Q causes the circuit operation to delay by clock pulse equivalence.

The flip-flop circuit and the truth table are shown below.

a) Circuit



b) Truth table


tu		tu+1
D	Qu	Qu+1
L	L	L
L	H	L
H	L	H
H	H	H

Output X	Output Y	Rotating direction	Arm Operation
H	H	Stop	Stop
H	L	Reverse	Cueing up, return
L	H	Normal	Cueing down


[Fig. 1]

* Exclusive -OR circuit

In this circuit, output Y is "H" only when outputs A and B are not equal.



a) Logic circuit



Actual circuit

Input		Output
A	B	Y
L	L	L
L	H	H
H	L	H
H	H	L

b) Truth table

When the ❶ is H pressing the stop switch causes the arm to start returning irrespective of its position. When the arm is in return operation, the cueing switch does not work because of priority given to the stop operation.

4. Auto return operation

The detection of record end is performed with the optical sensor output, same as in SL-1300MK2; then the arm is returned in the same way as in the above-mentioned stop operation.


If the arm is in up position (arm switch A is OFF), no pulse is generated at ❸ for end detection, therefore auto return operation can not be achieved by shifting the arm.

* R-S flip-flop circuit

This circuit includes two inputs S(set), R(Reset), and two outputs Q and $\bar{Q}$.


If input S="H", R="L", then Q="L". If S="L", R="H", then Q="H". After determination of the output, changing the input to "H" does not cause the output to change.

a) Circuit




b) Truth table

S	R	Q _{n+1}
L	L	H
L	H	H
H	L	L
H	H	Q _n




■ TROUBLE SHOOTING OF ARM DRIVE CIRCUIT




■ DISASSEMBLY PROCEDURE

How to remove main base ass'y and bottom base ass'y


1. Clamp tone arm to the arm rest.
2. Remove head shell and turntable platter.
3. Close dust cover.
4. Turn unit upside down taking special care not to damage or scratch the dust cover.
5. Remove 6 screws **A** of the audio insulator and 2 screws **E** of the phono cord clamber as shown in Photo 1.
6. Holding the player firmly with both hands, to prevent separation of upper section (bottom base ass'y) from lower section (main base ass'y), turn it carefully upwards.
7. Remove dust cover.
8. Remove 5 screws **C** of the panel cover as shown in Photo 2.
9. Remove 3 connectors **D** and 2 read wires **B** from power transformer as shown in Photo 3.
10. To remove the main base ass'y from the bottom base ass'y, turn cueing lever upward and move tone arm towards center of spindle. The main base ass'y can be lifted up easily. (See Photo 4).




[Photo 1]



[Photo 2]




[Photo 3]




[Photo 4]

How to remove drive circuit p.c.b. and stator frame coil

1. Remove main base ass'y and bottom base ass'y.
2. Remove 3 screws ⑦ of the drive circuit p.c.b. and 3 screws ⑥ of the stator frame cover as shown in Photo 5.
3. Disconnect 18 soldered parts ④ of the stator frame coil and 4 soldered parts ⑤ of the F.G detector coil as shown in Fig. 2.
4. Remove 3 screws ① of the stator frame ass'y as shown in Fig. 2.




[Photo 5]




[Fig. 2]

How to remove control circuit p.c.b. and stylus-illuminator lamp


1. Remove main base ass'y and bottom base ass'y.
2. Remove 10 screws ⑩ of the control circuit p.c.b. as shown in Fig. 3.
3. Remove 2 screws ⑪ of the power switch bracket as shown in Fig. 3.
4. Set up the control circuit board as shown in Fig. 4. Then remove the 2 screws ⑭ of the stylus illuminator mounting plate. (Fig. 4).
5. To replace the stylus illuminating lamp, remove the setscrew of the lamp case (Fig. 5) and detach the lamp case, then the stylus illuminating lamp can be replaced.



[Fig. 3]




[Fig. 5]



[Fig. 4]

How to remove arm drive motor


1. Remove head shell and turntable platter.
2. Clamp tone arm to the arm rest.
3. Remove 5 screws (C) of the panel cover as shown in Photo 2.
4. Remove arm drive belt.
5. Turn the muting switch adjusting screw so that the arm drive motor setscrew can be removed. (See Photo. 7).
6. Remove 1 screw (P) of the arm drive motor ass'y as shown in Photo 7.
7. When adjusting the muting switch, refer to Muting Switch Adjustment.




[Photo 7]

How to remove tone arm


1. Remove 4 screws (A) of the tone arm base ass'y as shown in Photo 8.
2. Remove 1 screw (R) of the shilde plate as shown in Photo 9.
3. Disconnect soldered of the phono cord reads.
4. Remove 2 screws (S) of the arm drive motor plate as shown in Photo 9.
5. Remove 2 screws (T) of the tone arm fixing plate ass'y as shown in Photo 10.
6. Remove 3 screws (U) of the movable base assembly and 1 screw (V) of the ground wire as shown in Photo 11.
7. Remove 2 screws (W) of the tone arm as shown in Photo 12.
8. To remove the pick-up base plate, remove the arm lift height adjusting screw and the arm lift.
9. Remove 1 screws (X) and 1 circlip (Y) of the position fix plate as shown in Photo 12.
10. Remove 2 screws (Z) of the pick-up base plate as shown in Photo 12.




[Photo 8]




[Photo 9]



[Photo 10]




[Photo 11]




[Photo 12]

Arm Base Assembling Procedure


1. Attach the control ring to the arm base seat.
(The control ring should be rotated counterclockwise.)
 2. Completely tighten the control ring, and then loosen it 1.5 ~ 2.5 turns to set the scale to "3". (See photo 13.)
 3. Hold the arm base and set the red line mark on the arm base to the scale near "2", then turn the arm base clockwise. (See photo 14.)
- Note) Take care not to allow deflection of the predetermined positions of the control ring and arm base seat.



[Photo 13]




[Photo 14]




[Photo 15]

4. Adjust the arm base so that the red line mark on the arm base is set to the scale "3" of the control ring. (See photo 15). Next, secure the position fix plate with two setscrews. (See photo 12.)
5. Rotate the control ring and make sure that the arm base shifts within the range of 0 ~ 6mm.
(See photo 16 A, B.) If it does not shift within the specified range, the arm base position is deflected. In that case, disassemble the parts and check as specified in step 3.



(A)

[Photo 16]




(B)

Adjustment of Cancellor Spring Position

If the arm body or PU base plate is replaced, be sure to set the canceller knob to "0.5" and make sure that the canceller spring is in contact with the arm shaft. (See photo 17.)

If the canceller spring is deflected, adjust it as follows:

1. Clamp the arm on the rest.
2. Set the canceller knob to "0.5".
3. Remove the PU base plate, adjust gear A so that the canceller spring is in the position of photo 17.
4. Mount the PU base plate onto the arm base and check the spring position.




[Photo 17]

How to install the drive circuit board assembly

The circuit board assembly can be detached by removing the 4 setscrews ① shown in Photo. 1. When installing it onto the bottom base assembly after adjustment and repair, follow the procedure mentioned below.


1. Temporarily tighten the 4 setscrews ①.
(Refer to Photo 1.)
2. Adjust so that the center spindle is aligned to the center of the turntable provided with equal clearances ② as in Fig. 11.
3. Completely tighten the 4 setscrews ①, taking care not to allow deflection of the center spindle.



[Fig. 6]


■ ADJUSTMENTS (Electrical)

- Notes:
- Make the following adjustments after replacing parts such as IC's, transistors, diodes, etc.
 - Condition of the set
 1. Power switch ON
 2. Pitch control Center position
 3. Speed selector switch 33 r.p.m.
 - Instruments to be used
 1. Oscilloscope
 2. Frequency counter


	Adjustment	connection Points	Adjustment Points	Adjustment Method
A	Adjustment of pitch control $\pm 0\%$ (PITCH)	Frequency counter + $\rightarrow$ TP27 - $\rightarrow$ GROUND	VR301	1. Pitch control switch to center position. 2. Adjust VR301 for 262.08 kHz ± 0.05 kHz of frequency.
B	Adjustment of pitch control LED (GAIN)	Frequency counter + $\rightarrow$ TP27 - $\rightarrow$ GROUND	VR425	1. Adjust pitch control switch for 269.94 kHz of frequency. 2. Adjust VR425 so that the LED (pitch indicator plus 3%) lights up.
C	Braking adjustment (BRAKE)	—	VR201	 Adjust VR201 for complete stop within $120^\circ \sim 270^\circ$ after stop signal initiated. (turntable becomes free a few seconds after stop.)

D	Optical sensor gain adjustment (GAIN)	Oscilloscope + → TP32 - → GROUND	VR501	TP32 waveform With arm near center spindle, manually move with uniform motion, and adjust VR501 as that the (a) and (b) pitch of the waveform of TP32 is equal.
E	Auto-Return time adjustment (TIME)	Oscilloscope + → TP38 - → GROUND	VR502	TP38 waveform Turn power switch on, and adjust VR502 so that the time (T_0) from power on until the voltage of TP38 inverts is 1.5 second at 33 r.p.m. (1.1 second at 45 r.p.m.)

■ ADJUSTMENT POINTS






VR301 Adjustment of pitch control $\pm 0\%$
VR201 Braking adjustment



Auto-return
time adjustment
VR502
Optical sensor
gain adjustment
VR501
Adjustment of
pitch control LED
VR425

■ REGLAGES (Electricité)

- Notes:
- Effectuer les réglages suivants après avoir remplacé des éléments tels que les C.I., transistors, diodes, et autres.
 - Etat de l'appareil
 - 1. Commutateur d'alimentation Marche
 - 2. Commande d'alignement de la vitesse Position centrale
 - 3. Commutateur de sélecteur de vitesse 33-1/3 trs/mn
 - Appareils à utiliser
 - 1. Oscilloscope
 - 2. Fréquencemètre

	Réglage	Points de connexion	Points de réglage	Méthode de réglage
A	Réglage de la commande d'alignement de la vitesse, $\pm 0\%$ (PITCH)	Fréquencemètre + $\longrightarrow$ TR27 - $\longrightarrow$ TERE	VR301	1. Commutateur de commande d'alignement de la vitesse en position centrale. 2. Régler la VR301 sur une fréquence de 262,08 kHz $\pm 0,05$ kHz.
B	Réglage la LED de la commande d'alignement de la vitesse (GAIN)	Fréquencemètre + $\longrightarrow$ TP27 - $\longrightarrow$ TERE	VR425	1. Régler la commutateur de commande d'alignement de la vitesse sur la fréquence de 269,94 kHz. 2. Régler la VR425 de telle sorte que LED (plus 3% du témoin d'alignement de la vitesse) s'allume.
C	Réglage du frein (BRAKE)	—	VR201	SIGNAL D'ARRÊT  Régler la VR201 sur l'arrêt complet entre 120° et 270° après la début de l'envoi du signal d'arrêt. (Le plateau devient libre quelques secondes après l'arrêt.)
D	Réglage du Senseur optique (GAIN)	Oscilloscope + $\longrightarrow$ TP32 - $\longrightarrow$ TERE	VR501	Forme d'onde du TP32  Quand le bras est proche du mandrin central, le déplacer à la main dans un mouvement uniforme et régler la VR501 de telle sorte que les longueurs (a) et (b) de la forme d'onde du TP32, soient égales.
E	Réglage du temps de retour automatique (TIME)	Oscilloscope + $\longrightarrow$ TP38 - $\longrightarrow$ TERE	VR502	Forme d'onde du TP38  Allumer la commutateur d'alimentation et régler la VR502 de telle sorte que la temps (T_0) écoulé entre l'allumage de l'alimentation et l'inversion de la tension du TP38, soit d'une seconde et demie à 33 tours. (1,1 seconde à 45 tours) Commutateur d'alimentation allumé

■ ABGLEICHUNG (Elektrisch)




Anmerkung: • Nach Teilerneuerung von z.B. IC, Transistor, Diode usw, die folgenden Abgleichungen vornehmen.

• Einstellung des Gerätes

1. Netzschalter ON
2. Tonhöhekontrolle Mittlers Stellung
3. Drehzahlwähler 33 U/min.

• Zu verwendende Instrumente

1. Oszilloskop
2. Signalfrequenzmesser

	Abgleichung	Anschlußpunkte	Abgleichpunkte	Abgleichmethode
A	Abgleich der Tonhöhekontrolle $\pm 0\%$ (PITCH)	Signalfrequenzmesser + $\rightarrow$ TP27 - $\rightarrow$ GROUND	VR301	- Schalter für Tonhöhekontrolle auf Mittelstellung. - VR301 auf 262,08 kHz $\pm 0,05$ kHz abgleichen.
B	Abgleich der Tonhöhekontrolle LED (GAIN)	Signalfrequenzmesser + $\rightarrow$ TP27 - $\rightarrow$ GROUND	VR425	- Schalter für Tonhöhekontrolle auf 269,94 kHz abgleichen. - VR425 so abgleichen, daß LED (Tonhöheanzeige plus 3%) auf leuchtet.
C	Bremsenjustierung (BRAKE)	—	VR201	 VR201 innerhalb 120 - 270° nach Haltsignalanzeige auf kompletten Halt justieren. (Plattenteller wird ein paar Sekunden nach Halt frei.)
D	Abgleich des optischen Sensorgewinns (GAIN)	Oszilloskop + $\rightarrow$ TP32 - $\rightarrow$ GROUND	VR501	TP32 Wellenform  Den Arm in die Nähe der Mittelspindel legen, manuell mit gleichmäßiger Bewegung schieben und VR501 so abgleichen, daß die (a) und (b) Tonhöhe der Wellenform TP32 gleich sind.
E	Zeitabgleich der Auto-Rückstellung (TIME)	Oszilloskop + $\rightarrow$ TP38 - $\rightarrow$ GROUND	VR502	TP38 Wellenform  Netzschalter einschalten und VR502 so abgleichen, daß die Zeit (T_0) von Einschalten bis zur Umkehrung der Spannung von TP38 bei 33 U/min. 1,5 Sekunden beträgt.

■ ADJUSTMENTS (Tone arm)

● Adjustment for automatic return position


1. Keep the power switch turned OFF to prevent the turntable from rotation.
2. Remove the rubber cap.
3. Move the tone arm toward the center spindle side, and make the adjustment by gradually turning the adjusting screw.

In case where the tone arm tends to return before the playing has finished.

—Move counterclockwise. (See Photo 18 A)

In cases where the tone arm fails to return after the last groove of the record.

—Move clockwise. (See Photo 18 B)



[Phot 18]

Adjustment of arm-lift height (See Photos 19 and 20.)

The arm-lift height (distance between the stylus tip and record surface when cueing lever is at the up position) has been adjusted at the factory before shipment to approximately 5 to 10 mm.

For using different cartridges available on the market or when further adjustments are particularly necessary, make adjustment as follows:

1. Move the tone arm toward the center spindle.
Attach the stylus protector, if available, to guard the stylus tip from damage.
2. Turn the adjustment screw clockwise or counterclockwise, while pushing the arm lift down.

Clockwise rotation

—distance between the record and stylus tip is reduced.


Counterclockwise rotation

—distance between the record and stylus tip is increased.


Note:

As the adjusting screw has a hexagonal head, be sure to make the adjustment while depressing the arm lift, or the screw will not move freely.

Also be sure that the hexagonal head retracts correctly into the arm lift when the latter is released.



[Photo 19]




[Photo 20]

● Muting adjustment

This unit employs a muting switch to eliminate noise created when the stylus is placed on or moved off the record disk. If the sound is not heard immediately or noise is created when the stylus is shifted down onto the disk, adjust it by turning the muting adjust screw. (Photo 21).

Muting time adjustment screw



[Photo 21]

■ REGLAGES (Bras acoustique)

• Réglage de la position de retour automatique

1. Conserver le commutateur d'alimentation coupé pour éviter que la platine ne tourne.
2. Enlever le tapis de caoutchouc.
3. Porter le bras acoustique vers le côté du mandrin central et effectuer le réglage en tournant progressivement la vis de réglage.

Si le bras acoustique tend à revenir avant la fin de la lecture du disque:

— Déplacer à gauche (voir la photographie 18 A)

Si le bras acoustique ne revient pas après le dernier sillon du disque:

— Déplacer à droite (voir la photographie 18 B)

Réglage du poids du lève-bras (Voir photographies 19 et 20)

Le poids du lève-bras (distance entre la pointe de l'aiguille et la surface du disque lorsque le levier de mise en pile est dans la position levée) a été réglé en usine avant l'expédition, à environ 5 à 10mm.

Lors de l'utilisation de cellules différentes disponibles sur le marché ou quand des réglages ultérieurs sont particulièrement nécessaires, effectuer les réglages de la façon suivante:

1. Porter le bras acoustique vers le mandrin central.

Monter le protecteur de l'aiguille, si fourni, pour protéger l'aiguille contre tout endommagement éventuel.

2. Tourner à droite ou à gauche la vis de réglage tout en poussant le lève-bras vers le bas.

Rotation à droite

— La distance entre le disque et la pointe de l'aiguille, est réduite.

Rotation à gauche

— La distance entre le disque et la pointe de l'aiguille, est augmentée.

Note:

Comme la vis de réglage présente une tête hexagonale, s'assurer d'effectuer le réglage tout en enfonceant la lève-bras, sinon la vis ne se déplacera pas normalement. De plus, s'assurer que la tête hexagonale se rétracte correctement dans le lève-bras quand ce dernier est libéré.

• Réglage de la suppression de sensibilité

Cet appareil présente un commutateur de suppression de sensibilité qui élimine les parasites provoqués quand l'aiguille est posée sur le disque ou quand elle en est retirée. Si le son n'est pas immédiatement entendu ou si un parasite est entendu quand l'aiguille est posée sur le disque, régler des phénomènes à l'aide de la vis de réglage de la suppression de sensibilité (Photographie 21).

■ JUSTIERUNG (Tonarm)

• Justierung für automatische Rückstellung

1. Netzschalter auf OFF halten, um Drehen des Plattentellers zu verhüten.
2. Die Gummidecke abnehmen.
3. Den Tonarm gegen die Mittelspindel bewegen, und unter langsamer Drehung der Justierschraube regulieren.

Wenn der Tonarm geneigt ist, sich schon vor Spielablauf zurückzustellen:

— Die Schraube im Gegensinn zum Uhrzeiger drehen. (Vgl. Foto 18 A)

Wenn sich der Tonarm nach der letzten Führungsrille nicht zurückstellt:

— Die Schraube im Uhrzeigersinn drehen. (Vgl. Foto 18 B)

Justierung der Armhubhöhe (Siehe Foto 19 und 20)

Die Armhubhöhe (Abstand zwischen Nadelspitze und Plattenoberfläche, wenn sich Einsatzhebel an der Oberstellung befindet) ist bereits vor Verschiffung im Werk auf ca. 5 – 10 mm eingestellt.

Zum Gebrauch verschiedener handelsüblicher Tonabnehmer, oder wenn weitere Justierungen praktisch notwendig sind, Justierung folgendermaßen durchführen:

1. Den Tonarm gegen die Mittelspindel bewegen.

Wenn erhältlich den Nadelschoner anbringen, um die Nadelspitze vor Beschädigung zu schützen.

2. Unter Niederdrücken des Armhubhebels die Justierschraube rechts oder links drehen.

Rechtsdrehung

— Abstand zwischen Schallplatte und Nadelspitze nimmt ab.

Links drehung

— Abstand zwischen Schallplatte und Nadelspitze nimmt zu.

Anmerkung:


Da die Justierschraube einen Sechskantkopf aufweist, bei Justierung unbedingt den Armhubhebel niederdrücken, sonst bewegt sich die Schraube nicht frei.

Feststellen, daß der Sechskantkopf richtig in den Armhubhebel einzieht, wenn der letztere gelöst wird.


• Stummabstimmung

In dem Gerät ist ein Schalter für Stummabstimmung eingesetzt, um Geräusch zu beseitigen, das beim Auflegen der Nadel auf die Platte oder beim Wegnehmen davon entsteht. Wenn der Schall nicht direkt zu hören ist oder beim Herabsetzen der Nadel auf die Platte Geräusch entsteht, unter Drehen der Stummabstimmungsschraube justieren. (Foto 21)

■ BLOCK DIAGRAM (Control Circuit, Arm Control Circuit and Pitch Control Circuit)



■ BLOCK DIAGRAM (Drive Circuit)



REPLACEMENT PARTS LIST (Electric Parts)

- Notes:** 1. Part numbers are indicated on most mechanical parts.
Please use this part number for parts orders.
2. Δ indicates that only parts specified by the manufacture be used for safety.

Ref. No.	Part No.	Part Name & Description
INTEGRATED CIRCUITS		
IC1	SV1PC14312	Integrated Circuit, Reference Voltage
IC101	AN6675	Integrated Circuit, Drive
IC201	AN6680	Integrated Circuit, Control
IC301	AN6682	Integrated Circuit
IC302, 427, 455 456, 457, 459	SVITC4011BP	Integrated Circuit, CMOS
IC425, 426, 460	SVITC4013BP	Integrated Circuit, CMOS
IC428	AN6552	Integrated Circuit
IC429	SVIMS1901P	Integrated Circuit
IC458	SVITC4023BP	Integrated Circuit
IC501	SVIMSM4011M	Integrated Circuit, CMOS
TRANSISTORS		
Q1	2SD389A-Q	Transistor
Q2, 3, 202	2SD637	Transistor
Q201	2SC1846-R	Transistor
Q203	2SC1328-T	Transistor
Q425, 426, 428, 429, 455, 456, 457, 501, 502, 503, 504, 508, 509, 512, 513	2SD636	Transistor
Q427	2SC1047-T	Transistor
Q430, 505	2SB641	Transistor
Q506, 510	2SD638	Transistor
Q507, 511	2SB643	Transistor
DIODES		
D1, 3	Δ SVDS1RBA40	Rectifier
D2, 301	MA1051	Diode, 5V Zener
D204, 425, 427, 428, 451, 457, 458, 459, 501, 502, 503, 504, 505	MA162A	Diode
D426	MA26TO-A	Diode
D429~434, 442 436~441, 443	SVDGL-9PR2	Light Emitting Diode, Pitch Control, Speed Selector
D435	SVDGL-9NG2	Light Emitting Diode, Pitch Control
D455, 456	2-0A90	Diode
D444, 445, 446, 447, 448, 449, 450	SVDGD4205ALC	Light Emitting Diode
CRYSTAL		
X201	SVQU306115	Crystal, 4.19328MHz Oscillator
TRANSFORMER		
P.T.	Δ SLTF5899	Transformer, Power Source
LAMP		
PL1	SFDN172-01	Lamp, Stylus Illuminator
FUSE		
F1	Δ XBAS2C025T1A	Fuse, T250mA (250V)
F2, 3	Δ XBA2C08TR0	Fuse, T800mA (250V)
VARIABLE RESISTORS		
VR201	EVLS6AA00B54	Braking Adjustment, 50k Ω (B)
VR301	EVMH1GA00B53	Pitch Control $\pm$ 0% Adjustment, 5k Ω (B)
VR425	EVT56AA00B52	Pitch Control LED Adjustment, 500 Ω (B)
VR426	EVHJX8001A24	Pitch Control and Pitch Control Switch
VR501	EVLS6AA00B24	Optical Sensor Gain Adjustment, 20k Ω (B)
VR502	EVLS6AA00B55	Auto-Return Time Adjustment, 500k Ω (B)
SWITCHES		
S401~404	EVQP5R04K	Switch, Stop, 33 r.p.m. and 45 r.p.m. Selector

Ref. No.	Part No.	Part Name & Description
S406	SFDSD2MSL-4	Switch, Stylus Illuminator
S407, 408	SFDSD2MS-4	Switch, Cueing Down/Cueing Up
S501	ESB6237	Switch, Manual
S601	Δ SFDSS5GL2S	Switch, Power
S701	SFDSSW0665B	Switch, Muting
S602	Δ SFDSHXW13312	Switch, Power Selector
PHOTO INTERRUPTER		
PH402	ON1128	Photo Interrupter
RESISTORS		
R1	ERD25FJ562	Carbon, 5.6k Ω , 1/4W, $\pm$ 5%
R2	ERD25FJ682	Carbon, 6.8k Ω , 1/4W, $\pm$ 5%
R3	ERD25FJ272	Carbon, 2.7k Ω , 1/4W, $\pm$ 5%
R4	ERD25FJ561	Carbon, 560 Ω , 1/4W, $\pm$ 5%
R5	ERD25TJ471	Carbon, 470 Ω , 1/4W, $\pm$ 5%
R101	ERD25FJ103	Carbon, 10k Ω , 1/4W, $\pm$ 5%
R102	ERX1ANJ4R7	Metal Film, 4.7 Ω , 1W, $\pm$ 5%
R103	ERD25FJ472	Carbon, 4.7k Ω , 1/4W, $\pm$ 5%
R104	ERD25TJ473	Carbon, 47k Ω , 1/4W, $\pm$ 5%
R105	ERD25FJ103	Carbon, 10k Ω , 1/4W, $\pm$ 5%
R106	ERD25FJ150	Carbon, 15 Ω , 1/4W, $\pm$ 5%
R107	Δ ERX1ANJ1R5	Metal Film, 1.5 Ω , 1W, $\pm$ 5%
R108	ERD25FJ103	Carbon, 10k Ω , 1/4W, $\pm$ 5%
R109, 110	ERX1ANJ4R7	Metal Film, 4.7 Ω , 1W, $\pm$ 5%
R201	Δ ERG1ANJ561	Metal Oxide, 560 Ω , 1W, $\pm$ 5%
R202	ERD25FJ103	Carbon, 10k Ω , 1/4W, $\pm$ 5%
R203	ERD25FJ470	Carbon, 47 Ω , 1/4W, $\pm$ 5%
R204	ERD25FJ272	Carbon, 2.7k Ω , 1/4W, $\pm$ 5%
R205	ERD25TJ124	Carbon, 120k Ω , 1/4W, $\pm$ 5%
R206	ERD25TJ183	Carbon, 18k Ω , 1/4W, $\pm$ 5%
R207	ERD25TJ563	Carbon, 56k Ω , 1/4W, $\pm$ 5%
R208	ERD25TJ224	Carbon, 220k Ω , 1/4W, $\pm$ 5%
R209	ERD25TJ154	Carbon, 150k Ω , 1/4W, $\pm$ 5%
R210	ERD25TJ223	Carbon, 22k Ω , 1/4W, $\pm$ 5%
R211	ERD25FJ103	Carbon, 10k Ω , 1/4W, $\pm$ 5%
R212	ERD25FJ121	Carbon, 120 Ω , 1/4W, $\pm$ 5%
R213	ERD25FJ122	Carbon, 1.2k Ω , 1/4W, $\pm$ 5%
R214	ERD25TJ223	Carbon, 22k Ω , 1/4W, $\pm$ 5%
R215	ERD25FJ103	Carbon, 10k Ω , 1/4W, $\pm$ 5%
R216	ERD25TJ154	Carbon, 150k Ω , 1/4W, $\pm$ 5%
R217	ERD25TJ223	Carbon, 22k Ω , 1/4W, $\pm$ 5%
R218	ERD25FJ102	Carbon, 1k Ω , 1/4W, $\pm$ 5%
R219	ERD25FJ332	Carbon, 3.3k Ω , 1/4W, $\pm$ 5%
R220	ERD25FJ221	Carbon, 220 Ω , 1/4W, $\pm$ 5%
R221	ERD25FJ471	Carbon, 470 Ω , 1/4W, $\pm$ 5%
R222	ERD25FJ391	Carbon, 390 Ω , 1/4W, $\pm$ 5%
R301	ERO25CKF3301	Metal Film, 3.3k Ω , 1/4W, $\pm$ 1%
R302	ERD25FJ471	Carbon, 470 Ω , 1/4W, $\pm$ 5%
R303	ERD25FJ822	Carbon, 8.2k Ω , 1/4W, $\pm$ 5%
R304	ERD25FJ152	Carbon, 1.5k Ω , 1/4W, $\pm$ 5%
R306	ERD25TJ223	Carbon, 22k Ω , 1/4W, $\pm$ 5%
R307	ERD25TJ103	Carbon, 10k Ω , 1/4W, $\pm$ 5%
R308, 309	ERD25TJ223	Carbon, 22k Ω , 1/4W, $\pm$ 5%
R425	ERD25TJ223	Carbon, 22k Ω , 1/4W, $\pm$ 5%
R426, 427	ERD25FJ103	Carbon, 10k Ω , 1/4W, $\pm$ 5%
R428	ERD25FJ103	Carbon, 10k Ω , 1/4W, $\pm$ 5%
R429	ERD25TJ223	Carbon, 22k Ω , 1/4W, $\pm$ 5%
R430, 431	ERD25FJ103	Carbon, 10k Ω , 1/4W, $\pm$ 5%
R432	ERD25FJ103	Carbon, 10k Ω , 1/4W, $\pm$ 5%
R433	ERD25TJ223	Carbon, 22k Ω , 1/4W, $\pm$ 5%
R434	ERD25TJ473	Carbon, 47k Ω , 1/4W, $\pm$ 5%
R435	ERD25FJ102	Carbon, 1k Ω , 1/4W, $\pm$ 5%
R436	ERD25TJ104	Carbon, 100k Ω , 1/4W, $\pm$ 5%
R437	ERD25FJ152	Carbon, 1.5k Ω , 1/4W, $\pm$ 5%
R438	ERD25FJ562	Carbon, 5.6k Ω , 1/4W, $\pm$ 5%
R439	ERO25CKF1802	Metal Film, 18k Ω , 1/4W, $\pm$ 1%
R440	ERO25CKF4303	Metal Film, 430k Ω , 1/4W, $\pm$ 1%
R441	ERD25FJ103	Carbon, 10k Ω , 1/4W, $\pm$ 5%
R442	ERD25FJ471	Carbon, 470 Ω , 1/4W, $\pm$ 5%
R443	ERD25FJ101	Carbon, 100 Ω , 1/4W, $\pm$ 5%
R444	ERD25FJ681	Carbon, 680 Ω , 1/4W, $\pm$ 5%

SL-1700MK2/ SL-1710MK2

SL-1700MK2(XG) → [XG] SL-1700MK2(XGF) → [XGF] SL-1700MK2(XGB) → [XGB]
 SL-1700MK2(E) → [E] SL-1700MK2(XA) → [XA] SL-1700MK2(XGE) → [XGE]
 SL-1700MK2A(XA) → [AXA] SL-1700MK2A(XG) → [AXG] SL-1700MK2A(E) → [AE]
 SL-1710MK2(XG) → [10XG] SL-1710MK2(E) → [10E] SL-1710MK2A(XG) → [10AXG]
 SL-1710MK2A(E) → [10AE]


Ref. No.	Part No.	Part Name & Description
R445	ERD25FJ102	Carbon, 1kΩ, 1/4W, ± 5%
R446	ERD25FJ222	Carbon, 2.2kΩ, 1/4W, ± 5%
R447	ERD25TJ123	Carbon, 12kΩ, 1/4W, ± 5%
R448	ERD25TJ103	Carbon, 10kΩ, 1/4W, ± 5%
R449	ERD25FJ152	Carbon, 1.5kΩ, 1/4W, ± 5%
R450	ERD25FJ821	Carbon, 820Ω, 1/4W, ± 5%
R451	ERD25TJ473	Carbon, 47kΩ, 1/4W, ± 5%
R455	ERD25TJ123	Carbon, 12kΩ, 1/4W, ± 5%
R456	ERD25TJ473	Carbon, 47kΩ, 1/4W, ± 5%
R457	ERD25TJ223	Carbon, 22kΩ, 1/4W, ± 5%
R458	ERD25TJ123	Carbon, 12kΩ, 1/4W, ± 5%
R459	ERD25TJ473	Carbon, 47kΩ, 1/4W, ± 5%
R460	ERD25TJ223	Carbon, 22kΩ, 1/4W, ± 5%
R461, 462	ERD25TJ104	Carbon, 100kΩ, 1/4W, ± 5%
R463	ERD25TJ223	Carbon, 22kΩ, 1/4W, ± 5%
R464	ERD25TJ104	Carbon, 100kΩ, 1/4W, ± 5%
R465	ERD25FJ681	Carbon, 680Ω, 1/4W, ± 5%
R466	ERD25FJ562	Carbon, 5.6kΩ, 1/4W, ± 5%
R467	ERD25TJ473	Carbon, 47kΩ, 1/4W, ± 5%
R468	ERD25TJ223	Carbon, 22kΩ, 1/4W, ± 5%
R469	ERD25FJ681	Carbon, 680Ω, 1/4W, ± 5%
R470	ERD25FJ562	Carbon, 5.6kΩ, 1/4W, ± 5%
R471	ERD25TJ473	Carbon, 47kΩ, 1/4W, ± 5%
R472	ERD25TJ223	Carbon, 22kΩ, 1/4W, ± 5%
R473	ERD25TJ474	Carbon, 470kΩ, 1/4W, ± 5%
R474	ERD25FJ681	Carbon, 680Ω, 1/4W, ± 5%
R475, 476	ERD25TJ473	Carbon, 47kΩ, 1/4W, ± 5%
R477, 478	ERD25TJ473	Carbon, 47kΩ, 1/4W, ± 5%
R479	ERD25FJ562	Carbon, 5.6kΩ, 1/4W, ± 5%
R480	ERD25TJ473	Carbon, 47kΩ, 1/4W, ± 5%
R481	ERD25TJ104	Carbon, 100kΩ, 1/4W, ± 5%
R482	ERD25TJ223	Carbon, 22kΩ, 1/4W, ± 5%
R483	ERD25TJ123	Carbon, 12kΩ, 1/4W, ± 5%
R484	ERD25TJ223	Carbon, 22kΩ, 1/4W, ± 5%
R485	ERD25TJ474	Carbon, 470kΩ, 1/4W, ± 5%
R486	ERD25TJ223	Carbon, 22kΩ, 1/4W, ± 5%
R487	ERD25TJ474	Carbon, 470kΩ, 1/4W, ± 5%
R488, 489	ERD25TJ473	Carbon, 47kΩ, 1/4W, ± 5%
R501	ERD25FJ681	Carbon, 680Ω, 1/4W, ± 5%
R502	ERD25FJ102	Carbon, 1kΩ, 1/4W, ± 5%
R503	ERD25TJ183	Carbon, 18kΩ, 1/4W, ± 5%
R504	ERD25TJ473	Carbon, 47kΩ, 1/4W, ± 5%
R505, 506	ERD25TJ274	Carbon, 270kΩ, 1/4W, ± 5%
R507	ERD25TJ274	Carbon, 270kΩ, 1/4W, ± 5%
R508	ERD25TJ393	Carbon, 39kΩ, 1/4W, ± 5%
R509	ERD25FJ221	Carbon, 220Ω, 1/4W, ± 5%
R510	ERD25TJ824	Carbon, 820kΩ, 1/4W, ± 5%
R511	ERD25TJ333	Carbon, 33kΩ, 1/4W, ± 5%
R512	ERD25TJ183	Carbon, 18kΩ, 1/4W, ± 5%
R513	ERD25TJ473	Carbon, 47kΩ, 1/4W, ± 5%
R514	ERD25TJ123	Carbon, 12kΩ, 1/4W, ± 5%
R515	ERD25FJ472	Carbon, 4.7kΩ, 1/4W, ± 5%
R516	ERD25TJ473	Carbon, 47kΩ, 1/4W, ± 5%
R517	ERD25TJ393	Carbon, 39kΩ, 1/4W, ± 5%
R518	ERD25FJ102	Carbon, 1kΩ, 1/4W, ± 5%
R519	ERD25FJ332	Carbon, 3.3kΩ, 1/4W, ± 5%
R520	ERD25FJ222	Carbon, 2.2kΩ, 1/4W, ± 5%
R521	ERD25FJ471	Carbon, 470Ω, 1/4W, ± 5%
R522	ERD25TJ473	Carbon, 47kΩ, 1/4W, ± 5%
R523	ERD25FJ102	Carbon, 1kΩ, 1/4W, ± 5%
R524	ERD25FJ332	Carbon, 3.3kΩ, 1/4W, ± 5%
R525	ERD25FJ102	Carbon, 1kΩ, 1/4W, ± 5%
R526	ERD25FJ471	Carbon, 470Ω, 1/4W, ± 5%
R527	ERD25TJ473	Carbon, 47kΩ, 1/4W, ± 5%
R528	ERD25FJ681	Carbon, 680Ω, 1/4W, ± 5%
R529, 530	ERD25TJ123	Carbon, 12kΩ, 1/4W, ± 5%
R531	ERD25TJ104	Carbon, 100kΩ, 1/4W, ± 5%
R601	ERD25TJ477	Carbon, 4.7Ω, 1/4W, ± 5%

CAPACITORS

Ref. No.	Part No.	Part Name & Description
C1	ECEB1HS471	Electrolytic, 470μF, 50V
C2	ECEA1VS330	Electrolytic, 33μF, 35V
C3	ECEA1ES220	Electrolytic, 22μF, 25V
C4	ECEB1HS471	Electrolytic, 470μF, 50V
C5	ECEA1ES101	Electrolytic, 100μF, 25V
C101, 102	ECEA1VS330	Electrolytic, 33μF, 35V
C103	ECEA1VS330	Electrolytic, 33μF, 35V
C104, 105	ECQM1H104KZ	Polyester, 0.1μF, 50V, ±10%
C106, 107	ECQM1H104KZ	Polyester, 0.1μF, 50V, ±10%
C108	ECEA1ES101	Electrolytic, 100μF, 25V
C109, 110	ECQM1H104KZ	Polyester, 0.1μF, 50V, ±10%
C111	ECQM1H562KZ	Polyester, 0.0056μF, 50V, ±10%
C112	ECEA1JS4R7	Electrolytic, 4.7μF, 63V
C201	ECEA1CS330	Electrolytic, 33μF, 16V
C202, 203	ECEA50Z1	Electrolytic, 1μF, 50V
C204	ECQM1H473KZ	Polyester, 0.047μF, 50V, ±10%
C205	ECEA1AS221	Electrolytic, 220μF, 10V
C206	ECEA50Z1	Electrolytic, 1μF, 50V
C207	ECCD1H101K	Ceramic, 100pF, 50V, ±10%
C208	ECCD1H390K	Ceramic, 39pF, 50V, ±10%
C209	ECEA1ES101	Electrolytic, 100μF, 25V
C210	ECQM1H224KZ	Polyester, 0.22μF, 50V, ±10%
C211	ECQM1H473KZ	Polyester, 0.047μF, 50V, ±10%
C212	ECEA50Z3R3	Electrolytic, 3.3μF, 50V
C213	ECCD1H471K	Ceramic, 470pF, 50V, ±10%
C214	ECEA1ES101	Electrolytic, 100μF, 25V
C215	ECEA50Z1	Electrolytic, 1μF, 50V
C216	ECEA1ES470	Electrolytic, 47μF, 25V
C301, 302	ECQK1123FZ	Polyester, 0.012μF, 125V, ±1%
C303	ECEA50Z1	Electrolytic, 1μF, 50V
C304	ECEA1HS100	Electrolytic, 10μF, 50V
C305	ECQM1H122KZ	Polyester, 0.0012μF, 50V, ±10%
C306	ECEA50Z1	Electrolytic, 1μF, 50V
C425, 426	ECCD1H101K	Ceramic, 100pF, 50V, ±10%
C427, 428	ECCD1H101K	Ceramic, 100pF, 50V, ±10%
C429, 430	ECQM1H473KZ	Polyester, 0.047μF, 50V, ±10%
C431	ECEA1HS100	Electrolytic, 10μF, 50V
C432, 433	ECKD1E104ZF	Ceramic, 0.1μF, 25V, ±8%
C434, 435	ECKD1E104ZF	Ceramic, 0.1μF, 25V, ±8%
C455, 456	ECEA50ZR47	Electrolytic, 0.47μF, 50V
C457	ECQM1H102KZ	Polyester, 0.001μF, 50V, ±10%
C458	ECQM1H103KZ	Polyester, 0.01μF, 50V, ±10%
C459	ECEA50ZR47	Electrolytic, 0.47μF, 50V
C460	ECQM1H562KZ	Polyester, 0.0056μF, 50V, ±10%
C461	ECQM1H102KZ	Polyester, 0.001μF, 50V, ±10%
C462	ECEA50ZR47	Electrolytic, 0.47μF, 50V
C463	ECQM1H562KZ	Polyester, 0.0056μF, 50V, ±10%
C464, 465	ECEA50ZR47	Electrolytic, 0.47μF, 50V
C466	ECEA1HS100	Electrolytic, 10μF, 50V
C467, 468	ECQM1H103KZ	Polyester, 0.01μF, 50V, ±10%
C469	ECEA50ZR47	Electrolytic, 0.47μF, 50V
C470	ECKD1E104ZF	Ceramic, 0.1μF, 25V, ±8%
C471	ECEA1ES470	Electrolytic, 47μF, 25V
C472	ECKD1E104ZF	Ceramic, 0.1μF, 25V, ±8%
C473	ECEA1ES470	Electrolytic, 47μF, 25V
C501	ECEA50ZR1	Electrolytic, 0.1μF, 50V
C502	ECQM1H473KZ	Polyester, 0.047μF, 50V, ±10%
C503	ECQM1H184KZ	Polyester, 0.18μF, 50V, ±10%
C504	ECQM1H473KZ	Polyester, 0.047μF, 50V, ±10%
C505	ECEA25Z4R7	Electrolytic, 4.7μF, 25V
C506	ECQM1H104KZ	Polyester, 0.1μF, 50V, ±10%
C507, 508	ECQM1H103KZ	Polyester, 0.01μF, 50V, ±10%
C509	ECKD1E104ZF	Ceramic, 0.1μF, 25V, ±8%
C510	ECEA1ES101	Electrolytic, 100μF, 25V
C601 [XG, XGF, XGB, AXA, 10XG, AXG, 10AXG, XA]	ECQE2A473MZ	Polyester, 0.047μF, 250V, ±20%
C601 [E, 10E, AE, 10AE, XGE, 10XGE]	ECNC4A473M	Paper, 0.047μF, 450V, ±20%



■ CONTROL CIRCUIT BOARD

Earth (Ground) Lines



■ DRIVE CIRCUIT BOARD


Earth (Ground) Lines




■ TERMINAL GUIDE OF TRANSISTOR AND IC


SVIμPC14312 	AN6675 	AN6680
AN6682 	SVITC4011BP 	SVITC4013BP
AN6552 	SVIMSM1901P 	2SD389
2SD637, 2SD638, 2SD636, 2SB641, 2SB643 	2SC1846 	2SC1328, 2SC1047

■ SCHEMATIC DIAGRAM 1 (Control Circuit Board)





■ SCHEMATIC DIAGRAM 2 (Drive Circuit Board)



IC302 (SVITC4011BP)


	Start	Stop		Start	Stop
①	Same as at right		⑤	Same as at right	
②	5V	5V	⑥	5V	5V
③	Same as at right		⑦	0V	0V
④	5V	5V	⑧	Same as at right	

Q202 (2SD637)


	Start	Stop
E	0V	0V
C	Same as at right	
B	Same as at right	

■ TONE ARM DRIVE CIRCUIT BOARD

Earth (Ground) Lines



■ SCHEMATIC DIAGRAM 3 (Tone Arm Drive Circuit Board)



■ REFERENCE VOLTAGE AND WAVEFORM AT EACH IC

IC101 (AN6675)

	Start	Stop		Start	Stop		Start	Stop
①	10V	1.7V	⑫		15V	⑮	Same as at right	
②	10V	1.7V						
③	0V	0V						
④	5V	1.7V	⑬			⑰	20V	20V
⑤	5V	5V				⑲	20V	20V
⑥	5V	6.6V				⑲	20V	20V
⑦	0V	0V	⑭	15V	15V	⑲	20V	20V
⑧	5V	5V				⑲	1.4V	0V
⑨	0V	0V				⑲	20V	20V
⑩		15V	⑯	0V	0V	⑲	10V	1.7V
⑪			⑯	15V	15V			


IC201 (AN6680)

	Start	Stop		Start	Stop		Start	Stop
①	2.5V	2.5V	⑧	0V	0V	⑮	5V	2.5V
②	Same as at right		⑨	10V	10V		5V	5V
③	Same as at right		⑩	9V	9V		0V	0V
④	Same as at right		⑪	Same as at right		⑮	7V	0.14V
⑤	Same as at right		⑫	0V	0V	⑮	0.4V	5.8V
⑥	3.4V	3.4V	⑬		0.2V	⑮	1.5V	0.2V
⑦	0V	0V	⑭			⑮	3V	3V
						⑮	2.8V	2.8V

IC301 (AN6682)

	Start	Stop		Start	Stop		Start	Stop
①	Same as at right		④	Same as at right		⑧	Same as at right	
②	Same as at right		⑤	0V	0V			
③	Same as at right		⑥	3.9V	3.9V			
			⑦	Same as at right				

■ EXPLODED VIEW (Main Base)




■ REPLACEMENT PARTS LIST (Main Base and Bottom Base Parts)

- Notes: 1. Part numbers are indicated on most mechanical parts.
Please use this part number for parts orders.
2. ⚠ indicates that only parts specified by the manufacture be used for safety.




SL-1700MK2(XG) → [XG] SL-1700MK2(XGF) → [XGF] SL-1700MK2(XGB) → [XGB]
SL-1700MK2(E) → [E] SL-1700MK2(XA) → [XA] SL-1700MK2(XGE) → [XGE]
SL-1700MK2A(XA) → [AXA] SL-1700MK2A(XG) → [AXG] SL-1700MK2A(E) → [AE]
SL-1710MK2(XG) → [10XG] SL-1710MK2(E) → [10E] SL-1710MK2A(XG) → [10AXG]
SL-1710MK2A(E) → [10AE]

Ref. No.	Part No.	Part Name & Description	Ref. No.	Part No.	Part Name & Description
CABINET and CHASSIS PARTS					
1	SFAD172-01E	Dust Cover	58	SFKT132-07	Knob, Auto Return Switch
2	SFTG172-01	Turntable Mat	59	SFUP172-10	Bracket, Auto Return Switch
3	SFTE172-01Z	Turntable	60	SFDJ172-04E	Connector, 3 Pin
4	SFUM172-05	Cover, Turntable	61	SFDH028-01	Phono Cord
5	SFKT172-02	Button, Start/Stop Switch	62	SFEL028-01E	Ground Wire
6	SFUM172-02	Bracket (A), Operation Panel	63	SFXGQ20-03	Screw, Stater Frame M'tg
7	SFUM172-01	Panel, Operation	64	SFMGQ20-01	Cover, Stater Frame Ass'y
8	SFKT172-03	Button, Speed Selector, Cueing Switch	65	SFMG520-31A	Stater Frame
9	SFUM172-11	Pin, Switch	66	SFMZ172-01E	FG Detector Coil Ass'y
10	SFUM172-03	Bracket (B), Operation Panel	67	SFMZQ20-01A	Shaft, Stater Frame Ass'y
11	SFKK172-01	Cover, Lamp	68	SFUP172-05	Bracket, Stater Frame M'tg Plate
13	SFXB172-02	Boss, Drive	69	SFUP172-08	Bracket, Drive P.C.B. Ass'y
14	SFQA172-01	Spring, Drive Boss	70	XVG4C30	Screw, Insulator (A) M'tg
15	SFUP172-01E	Plate Assembly, Stylus Illuminating Lamp	71	SFUM172-06	Insulator (A)
16	SFUP172-03	Plate, Lock Operation	72	SFXW172-01	Washer, Insulator (A)
17	SFQA001-02	Spring, Lock Operation Plate Pin	73	SFXW172-02	Washer, Insulator
18	SFXJ172-05	Pin, Lock Operation Plate M'tg	74	SFGA170-01	Rubber, Insulator
19	SFXJ172-01	Pin, Lock Canceler	75	SFQC170-01	Spring, Insulator
20	SFQA520-01	Spring, Lock Caneler Pin	76	SFXG170-02E	Nut, Insulator (A) M'tg
22	SFXO172-01	Pin, Guide	77	SFUP132-01	Cover, Power Transformer
23 [E, XG, XGB, XGF, AE XGE, XA, AXA, AXG]	SFAC172-01	Cabinet (Silver)	78	SFUM172-12	Spacer, Clamper
23 [10E, 10XG, 10AE, 10AXG]	SFAC173-01	Cabinet (Black)	79	SFUM172-07	Insulator Cup
24	SFUM130-01	Cover, Neon	80	SFGA172-01	Insulator Rubber
25	SFDJ172-02E	Connector, 7 Pin	81	SFUM172-13	Spacer, Tone Arm
26	SFUM170-10	Spacer (A), Speed Selector LED	82	SFAU172-01	Bottom Board
27	SFUM172-09	Spacer (B), Speed Selector LED	83 [E, XG, XGF, XGB, AXA, XGE, XA, AE, AXG]	SFGK132-01	Cap, Rubber
28	SFUP172-06	Bracket, Pitch Control Knob Plate	83 [10E, 10XG, 10AXG, 10AE]	SFGK133S01	Cap, Rubber
29	SFKT172-04	Knob, Pitch Control	84	SFUZ172-01	Rubber Cushion, Insulator
30	SFAZ172-01	Supporter, Insulator	SCREWS, WASHERS and CIRCLIPS		
31	SFUM170-06	Spacer, AC Cord	①	XTN3+8BFZ	Screw
32	SFUM170-05	Clamper, AC Cord	②	XUC2FT	Circlip
33	SFUM172-04	Ornament, Stylus Illuminating Lamp	③	XTN3+8B	Screw
34	SFGC132-01	Spacer (Rubber), Power Transformer Bracket	④	XSN2+8	Screw
35	SFUP132-03	Bracket, Power Transformer	⑤	XSN17+3FY	Screw
36	SFXG132-02	Screw, Power Transformer Bracket M'tg	⑥	XUC25FT	Circlip
37	SFDJ172-01E	Connector, 6 Pin	⑦	XWA3B	Washer
38	SFUP172-09	Bracket, Volume Shaft	⑧	XSN3+14S	Screw
39	SFDJ172-03E	Connector, 9 Pin	⑨	XTV3+8GF	Screw
40	SFAT172-01A	Hinge Ass'y	⑩	XWG3	Washer
41	SFUM170-07	Case, Hinge Ass'y	⑪	XTB3+8BFN	Screw
42 [E, AE, 10AE]	SFNN172S01	Name Plate	⑫	XTN4+20J	Screw
42 [XG, XGF, XGB, AXA, XA, AXG]	SFNN172X01	Name Plate	⑬	XTN4+10B	Screw
42 [10E]	SFNN173S01	Name Plate	⑭	XWA4B	Washer
42 [10XG, 10AXG]	SFNN173X01	Name Plate	⑮	XSN3+8S	Screw
42 [XGE]	SFNN172G01	Name Plate	⑯	XWA3B	Washer
43 ⚠	RJA23ZC	AC Cord	⑰	XWA3B	Washer
43 [XGE]	RJA45ZC	AC Cord	⑱	XWA3B	Washer
44	SFUM170-06	Spacer, Phono Cord	⑲	XSN3+10S	Screw
45	SFUM170-11	Clamper Phono Cord	⑳	XWE3F8	Washer
46	SFKT172-01	Button, Power Switch	㉑	XTN3+12BFZ	Screw
47	SFUZ172-03	Spacer, Power Switch Button	㉒	XTB3+8BFZ	Screw
48	SFXJ172-03	Shaft, Power Switch Button	㉓	XWG3	Washer
49	SFQA172-02	Spring, Power Switch	㉔	XTN3+8H	Screw
50	SFUP172-04	Supporter, Power Switch Plate	㉕	XTN3+8B	Screw
51	SFUP172-02E	Bracket, Power Switch M'tg Plate Assembly	㉖	XWA3B	Washer
52	SFUM001-11	Cam, Power Switch	㉗	XSN3+10S	Screw
53	SFUM132-07	Cam, Power Switch	㉘	XTN4+45B	Screw
54	SFUP001-12	Bracket, Power Switch	㉙	XTN4+14GFZ	Screw
56	SFUM132-05	Holder, Power Switch	㉚	XTB3+25BFN	Screw
57	SFUM132-06	Holder, Power Switch	㉛	XWG3	Washer
			㉜	XTN3+8GFZ	Screw
			㉝	XTN4+25B	Screw

■ EXPLODED VIEW (Bottom Base)



EXPLODED VIEW (Tone Arm and Arm Base)



Ref. No.	Part No.	Part Name & Description
SCREWS, WASHERS and CIRCLIPS		
1	XTN3+8B	Screw
2	XTN26+6B	Screw
3	XWG26	Washer
4	XSN3+8S	Screw
5	XWA3B	Washer
6	XUC5FT	Circlip
7	XWG3	Washer
8	XTV3+6BFN	Screw
9	XWE4A10EW	Washer
10	XUC25FT	Circlip
11	XTV3+6BFN	Screw
12	XWG5E12BW	Washer
13	XTN3+25B	Screw
14	XSN23+12	Screw
15	XWE26BW	Washer
16	XWA26B	Washer
17	SFXW910-08	Washer
18	XUC3FT	Circlip
19	XWE3A6BC	Washer
20	XUC2FT	Circlip
21	XWE26BW	Washer
22	XSN26+6	Screw
23	XTN3+6B	Screw
24	XTV3+8BFN	Screw
25	XWG3	Washer
26	XTN3+8B	Screw
27	XTN3+12B	Screw
28	XUC3FT	Circlip
29	XWE4A10BW	Washer
30	XWE4A10EW	Washer
31	XWA3B	Washer
32	XNG3ES	Nut
33	SFXW172-55	Washer
34	XWE3A6BC	Washer
35	XUC2FT	Circlip
36	XWG3FZ	Washer
37	XWA3BFZ	Washer
38	XSN3+23BVS	Screw
39	SFCZV8801	Screw, Except Product for [E, XG, XGF, XGB, 10E, 10XG, XGE, XA]
40	SFPEN3302	Nut, Except Product for [E, XG, XGF, XGB, 10E, 10XG, XGE, XA]
41	SFPEW9601	Washer, Except Product for [E, XG, XGF, XGB, 10E, 10XG, XGE, XA]
42	[AXA, AE, AXG, 10AE, 10AXG] only	
43	[AXA, AE, AXG, 10AE, 10AXG] only	
44	[AXA, AE, AXG, 10AE, 10AXG] only	

■ REPLACEMENT PARTS LIST (Tone Arm and Arm Base Parts)

Note: Part number are indicated on most mechanical parts.
Please use this part number for parts orders.

SL-1700MK2(XG) → [XG] SL-1700MK2(XGF) → [XGF] SL-1700MK2(XGB) → [XGB]
SL-1700MK2(E) → [E] SL-1700MK2(XA) → [XA] SL-1700MK2(XGE) → [XGE]
SL-1700MK2A(XA) → [AXA] SL-1700MK2A(XG) → [AXG] SL-1700MK2A(E) → [AE]
SL-1710MK2(XG) → [10XG] SL-1710MK2(E) → [10E] SL-1710MK2A(XG) → [10AXG]
SL-1710MK2A(E) → [10AE]

Ref. No.	Part No.	Part Name & Description	Ref. No.	Part No.	Part Name & Description
TONE ARM and ARM BASE PARTS					
100	SFPWG17201K	Balance Weight Ass'y	137	SFUP172-52E	Bracket
101 [E, XG, XGF, XGB, AXA, AE, XA, AXG, XGE]	SFPAM17201K	Tone Arm Ass'y (Silver)	138	SFUK172-51E	Bracket Arm
101 [10E, 10XG, 10AXG, 10AE]	SFPAM17202K	Tone Arm Ass'y (Black)	139	SFQH172-51	Spring
102 [E, XG, XGB, XGF, 10E, 10XG, XGE, XA, XGE]	SFPCC31001K	Head Shell	140	SFUP172-51A	Bracket
102 [AXA, AE, AXG, 10AE, 10AXG]	SFPCC31002K	Head Shell	141	SFUG172-52E	Base, Operation Gear Ass'y
103	SFPRT17201K	Arm Rest	142	SFUM172-61	Bracket, PU Output Cord
104 [10E, 10XG, 10AXG, 10AE]	SFPZB17206	Rubber, Lift Cap (Black)	143	SFUP172-56	Shield Case
104 [E, XG, XGF, XGB, AXA, AE, AXG, XGE]	SFPZB17205	Rubber, Lift Cap (Silver)	144	SFUM172-60A	Tone Arm Fixing Plate Ass'y
105 [10E, 10XG, 10AXG, 10AE]	SFPKD17205	Arm Base (Black)	145	SFDJ172-05E	Socket, 9 Pin
105 [E, XG, XGF, XGB, AXA, AE, AXG, XGE]	SFPKD17203	Arm Base (Silver)	146 [AXA, AE, AXG, 10AE, 10AXG] only	EPC207CK	Cartridge, Except Product for [E, XG, XGF, XGB, 10E, 10XG, XGE, XA]
106	SFPKB17201S	Ring, Operation	ACCESSORIES		
107	SFPKD17201	Bracket, Arm Base	A1	SFWE212-01	Adaptor, 45 r.p.m.
108	SFPAB17206	Knob, Anti-skate Force Control	A2 [E, 10E, XG, XGF, 10XG, XGB, XGE, XA]	SFPEN3302	Nut, Cartridge, Except Product for [AXA, 10AXG, AE, 10AE, AXG]
109	SFPEW17201	Washer, Anti-skate Force Control Knob	A3 [E, 10E, XG, XGF, 10XG, XGB, XGE, XA]	SFPEW9601	Washer, Head Shell, Except Product for [AXA, 10AXG, AE, 10AE, AXG]
110	SFXG829-1	Screw, Tone Arm Lift Adjustment	A4 [E, 10E, XG, XGF, 10XG, XGB, XGE, XA]	SFCVZ8801	Screw, Cartridge, Except Product for [AXA, 10AXG, AE, 10AE, AXG]
111	SFPRT17202K	Lift Ass'y	A5 [E, 10E, XG, XGF, 10XG, XGB, XGE, XA]	SFPEV9801	Screw, Cartridge, Except Product for [AXA, 10AXG, AE, 10AE, AXG]
112	SFPZB17202	Knob, Arm Base Lock	A6 [E, 10E, XG, XGF, 10XG, XGB, XGE, XA]	SFKO135-01	Overhang Gauge, Except Product for [AXA, 10AXG, AE, 10AE, AXG]
113	SFOA829-03	Spring, Lift Ass'y	A7	SFPZB3501	Shell Weight
114	SFPAB17201K	Rift Ass'y	A8 [AXA, XA] only	SFKD119118	2 PIN Plug
115	SFPZB17203K	Plate, Position Fix	PACKINGS		
117	SFUM172-58	Base, Muting Switch	P1 [E, XG, XGB, AXA, XGE, XA]	SFHP172M01	Carton
118	SFXJ172-60	Shaft, Operation	P1 [10E, 10XG]	SFHP173S01	Carton
119	SFUP172-60	Bracket, Switch Adjustment Plate	P1 [XGF]	SFHP172C01	Carton
120	SFUK172-52E	Movable Base Assembly	P1 [10AXG, 10AE]	SFHP173Q01	Carton
121	SFUP172-59	Bracket, Switch Adjustment Plate	P1 [AE, AXG]	SFHP172A01	Carton
122	SFUM172-55	Cam, Lift	P2	SFHH172-01	Pad, Front
123	SFXW130-01	Clip, Muting Switch Base	P3	SFHH172-02	Pad, Rear
124	SFUM172-57	Lever, Brake	P4	SFHD172-01	Pad, Top
125	SFGT172-51	Tube, Rubber	P5	SFHD172-02	Pad, Turntable
126	SFUM172-56	Lever, Muting	P6	SFYH60X60	Polyethylene Cover, Turntable Unit
127	SFQA172-52	Spring, Base Supporter Assembly	P7	SFYH60X60	Polyethylene Cover, Dust Cover
128	SFPZB17251	Base, Supporter Assembly	P8	SFYH40X45	Polyethylene Cover, Turntable
129	SFUM172-59	Rest, Sensor Assembly	P9 [E, AE, 10E, 10AE]	SFNU172S01	Instruction Book, Printed Matter
130	SFUP172-55	Bracket, Motor Assembly	P9 [XG, XGF, XGB, AXA, 10XG, 10AXG, AXG, XA]	SFNU172X01	Instruction Book, Printed Matter
131	SFMH172-51E	Motor Assembly	P9 [XGE]	SFNU172G01	Instruction Book, Printed Matter
132	SFGZ172-52	Cover, Motor			
133	SFGB172-51	Belt			
134	SFUP172-58	Bracket, Worm Assembly			
135	SFUG172-53E	Worm Assembly			
136	SFXJ172-52	Shaft			