

Service Manual

Quartz Direct Drive Automatic Turntable System

SL-QL15

[M], [MC]



* The cartridge shown here is an option.

TP is the standard mark for plug-in-connector type. Products carrying this mark are interchangeable and adaptable among each other.

Areas

* [M] is available in U.S.A.
* [MC] is available in Canada.

Specifications

Specifications are subject to change without notice for further improvement.
Weight and dimensions shown are approximate.

■ General

Power supply: 120V AC, 60 Hz

Power consumption: 12W

Dimensions: 43 x 8.8 x 35 cm
(16-59/64" x 3-1/2" x 13-25/32")

43 x 38.5 x 35 cm
(16-59/64" x 15-23/64" x 13-25/32")
(Maximum height when dust
cover is open.)

Weight: 5.1 kg (11.2 lb.)

■ Turntable section

Type: Direct drive

Fully automatic turntable

Auto start/Auto lead-in

Auto return

Auto stop

Programmable band selection

Repeat play

Auto speed select

Manual speed selection possible

Auto size select

Record presence detection

Drive method: Direct drive

Motor: Brushless DC motor

Drive control method: Quartz-phase-locked control

Turntable platter: Aluminium die-cast

Diameter 30 cm (12")

Turntable speeds: 33-1/3 rpm and 45 rpm

Auto speed select

(Manual selection possible)

Wow and flutter: 0.012% WRMS*

0.025% WRMS (JIS C5521)

±0.035% peak

(IEC 98A Weighted)

* Measured by obtaining signal from built-in frequency
generator of motor assembly.

Rumble: -56 dB (IEC 98A Unweighted)
-78 dB (IEC 98A Weighted)

■ Tonearm section

Type: Dynamic balanced type

Linear tracking tonearm

4-pivot gimbal suspension

Effective length: 10.5 cm (4-1/8")

Tracking error angle: Within ±0.1°

Effective mass: 9 g (including cartridge)

Resonance frequency: 12 Hz

Tonearm drive motor: DC motor

Technics

Matsushita Engineering and
Service Company
50 Meadowland Parkway,
Secaucus, New Jersey 07094

Panasonic Hawaii Inc.
91-238 Kauhi St., Ewa Beach
P.O. Box 774
Honolulu, Hawaii 96808-0774

Matsushita Electric
of Canada Limited
5770 Ambler Drive, Mississauga,
Ontario, L4W 2T3

Panasonic Sales Company,
Division of Matsushita Electric
of Puerto Rico, Inc.
Ave. 65 De Infanteria, KM 9.7
Victoria Industrial Park
Carolina, Puerto Rico 00630

■ CONTENTS

	Page
SAFETY PRECAUTION	2
LOCATION OF CONTROLS	3,4
DISASSEMBLY INSTRUCTIONS	5~9
HOW TO REPLACE CHIPS	9
HOW TO SET THE TONEARM DRIVE ROPE	10
MEASUREMENTS AND ADJUSTMENTS	10~12
TROUBLE SHOOTING	13~15
REPLACEMENT PARTS LIST (Electric Parts)	16
RESISTOR AND CAPACITORS	17
BLOCK DIAGRAM	18,19
CIRCUIT BOARD AND WIRING	
CONNECTION DIAGRAM	20~22
SCHEMATIC DIAGRAM	23~26
EXPLODED VIEW	27,28
REPLACEMENT PARTS LIST (Cabinet and Chassis Parts)	29
PACKINGS	30


■ SAFETY PRECAUTION

1. Before servicing, unplug the power cord to prevent an electric shock.
2. When replacing parts, use only manufacturer's recommended components for safety.
3. Check the condition of the power cord. Replace if wear or damage is evident.
4. After servicing, be sure to restore the lead dress, insulation barriers, insulation papers, shields, etc.
5. Before returning the serviced equipment to the customer, be sure to make the following insulation resistance test to prevent the customer from being exposed to a shock hazard.


• INSULATION RESISTANCE TEST

1. Unplug the power cord and short the two prongs of the plug with a jumper wire.
2. Turn on the power switch.
3. Measure the resistance value with ohmmeter between the jumpered AC plug and each exposed metal cabinet part, such as screwheads antenna, control shafts, handle brackets, etc. Equipment with antenna terminals should read between $3M\Omega$ and $5.2M\Omega$ to all exposed parts. (Fig. A) Equipment without antenna terminals should read approximately infinity to all exposed parts. (Fig. B)

Note: Some exposed parts may be isolated from the chassis by design. These will read infinity.



(Fig. A)





(Fig. B)



Resistance = $3M\Omega$ — $5.2M\Omega$

Resistance = Approx. ∞

4. If the measurement is outside the specified limits, there is a possibility of a shock hazard. The equipment should be repaired and rechecked before it is returned to the customer.

■ LOCATION OF CONTROLS





■ DISASSEMBLY INSTRUCTIONS

● How to remove the cartridge

1. Open the upper cabinet.
2. Completely loosen the setscrew and pull out the cartridge. (Fig. 1)
3. When attaching the cartridge again, match the tonearm connector with the cartridge pin, then completely insert it and tighten the setscrew.




Fig. 1

● How to remove the turntable platter

1. Open the upper cabinet.
2. Remove the turntable mat and lift the turntable platter. (Fig. 2)

Note: (1) When removing the turntable platter, it is not necessary to remove the 45 r.p.m. adaptor.

(2) The turntable platter is tight fitted on to the center spindle. When removing the turntable platter, take care not to give damage to the upper cabinet, arm motor cover and tonearm cover.




Fig. 2




Fig. 3

A: Side of spring
 B: Bosses (3 portions) of turntable platter
 C: Bottom of turntable platter
 D: Notches (2 portions) of turntable platter




Fig. 5

● How to remove the bottom board

1. Remove the turntable platter. (Refer to "How to remove the turntable platter.")
2. Close the upper cabinet and turn over the unit on a soft cloth taking care not to damage the upper cabinet.
3. Remove the 6 setscrews (Fig. 5 ① ~ ⑥), 4 insulators and 4 springs (Fig. 5)

● How to remove the operation circuit P.C.B.

1. Remove the bottom board. (Refer to "How to remove the bottom board.")
2. Remove the 7 setscrews (Fig. 6: 7 ~ 13) of the operation circuit P.C.B. and lead wired from the lead clamer.

Note: (1) This printed circuit board is grounded to the stator frame by screw 13. When checking for conduction removing the screw 13, connect the ground terminal of the printed circuit board to the stator frame.

- (2) When mounting the P.C.B., insert the speed selector switch and optical sensor sensitivity selector switch knobs into the holes of the rod.

● How to remove the switches (S301 ~ S312) (Program keys, repeat and cueing control switches)

1. Remove the operation circuit P.C.B. (Refer to "How to remove the operation circuit P.C.B.")
2. To remove the switch holder, turn over the operation circuit P.C.B. and release the L.E.D. from the 2 switch holder's claw. (Fig. 7)
3. To remove S301~S305, release the 3 switch holder's claws (Fig. 8: 14 ~ 16) and remove the switch holder in the direction of the arrow.
* Remove the 5 switches (S306~S310) and 2 switches (S311 and S312) in the same way.
4. Unsolder the 4 switch terminals and remove the switch. (Fig. 8)

● How to remove the drive circuit P.C.B. and stator frame

1. Remove the operation circuit P.C.B. (Refer to "How to remove the operation circuit P.C.B.")
2. Remove the 4 setscrews (Fig. 9: 17 ~ 20) of the stator frame.
3. Pull out connector CN101, then remove the drive circuit P.C.B. with stator frame.
4. Cut off the stopper by nippers and remove the 4 setscrews (Fig. 10: 21 ~ 24) to separate the drive circuit P.C.B. and stator frame.




Fig. 6




Fig. 7




Fig. 8




Fig. 9




Fig. 10

● How to remove the arm moto cover

1. Open the upper cabinet.
2. Remove the 5 setscrews (Fig. 11: 25 ~ 29), and the arm motor cover can be removed in the direction of the arrow (A).

● How to remove the tonearm cover

1. Open the upper cabinet.
2. Remove the 3 setscrews (Fig. 11: 30 ~ 32), and the tonearm cover can be removed in the direction of the arrow (B).




Fig. 11

● How to remove the dust cover

1. Open the upper cabinet.
2. Remove the arm motor cover. (Refer to "How to remove the arm motor cover.")
3. Remove the sub cover setscrew (Fig. 11: 33) and the sub cover.
4. Turn the worm gear pulley by finger to shift the tonearm inward.
5. Remove the 3 setscrews (Fig. 12: 34 ~ 36) of the dust cover.
6. Remove the 2 setscrews (Fig. 13: 37, 38) of the dust cover. Then the dust cover can be removed.




Fig. 12

● How to remove the blank detecting sensor

1. Open the upper cabinet and remove the arm motor cover.
2. Unsolder the lead wires of the blank detecting sensor.
3. Remove the screw of the guide plate. (Fig. 12: 39)
4. Remove the rope fixture of the sensor. (Fig. 12)
5. Remove the guide rod fitting clip 40 and remove the guide rod. (Fig. 12)
6. Pull out the sensor in the direction of the arrow (A). (Fig. 12)




Fig. 13

- How to separate the upper cabinet and lower cabinet

1. Remove the bottom board. (Refer to "How to remove the bottom board.")
2. Unsolder the ground lead wire from the phono output jack, and remove the phono output jack from the lower cabinet.
3. Pull out the 2 connectors (CN301, CN401) from the operation circuit P.C.B. (Fig. 14)
4. Remove the P.C.B. holder setscrew (Fig. 41) and P.C.B. holder.
5. Remove the 4 hinge setscrews (Fig. 15: 42 ~ 45).
6. Release the claws and slowly lift the lower cabinet to separate it from the upper cabinet.




Fig. 14




Fig. 15

- How to remove the tonearm

1. Remove the dust cover and tonearm cover. (Refer to "How to remove the dust cover" and "How to remove the tonearm cover").
2. Unsolder the 5 lead wires from the cartridge (Fig. 16).
3. Remove the tonearm setscrew (Fig. 17: 45).

- How to remove the cueing control ass'y

1. Remove the tonearm cover. (Refer to "How to remove the tonearm cover").
2. Unsolder the 2 lead wires from the cueing plunger (Fig. 16).
3. Remove the 2 cueing control ass'y setscrews (Fig. 16: 46, 47), and the cueing control ass'y can be removed in the direction of the arrow A.

- How to remove the tonearm position indicator board

1. Remove the dust cover and tonearm cover. (Refer to "How to remove the dust cover" and "How to remove the tonearm cover").
2. Unsolder the 2 lead wires from the indicator (Fig. 16).
3. Remove the tonearm position indicator board setscrew (Fig. 16: 48).




Fig. 16




Fig. 17

- How to remove the Hall element

1. Remove the turntable platter.
2. Remove the terminal solder by use of solder sucker.
3. Hold the Hall element with a tweezers and remove it while touching the soldering iron to the terminal.

(Fig. 18)

Note: Fit the Hall element with the part No. print up. The reverse in terminal position is allowable provided that the printed side is up.




Fig. 18

- How to remove the cabinet (Reset) switch

1. Remove the bottom board (Refer to "How to remove the bottom board.")
2. Completely open the upper cabinet.
3. Remove the cabinet switch setscrew (Fig. 19: ⑩).

Note: When fitting the cabinet switch, be sure to open the upper cabinet.





Fig. 19

■ HOW TO REPLACE CHIPS

(Resistor, capacitor and jumper)

- Removing procedure

1. Completely remove the solder from both ends of the chip by use of solder sucker.
2. Touch the soldering iron to the end of the chip as shown in Fig. 20, then turn the tweezers in the direction of the arrow.



Do not re-use chip resistor or capacitor without color cord.

- Replacing procedure

1. Place solder on the foil where the chip is fitted. Then solder the chip by holding the soldering iron as shown in Fig. 21.

Note:

1. If the chip jumper is removed, connect a coated lead wire to the part. (See Fig. 22). Chip jumper is marked with "J" on the printed circuit board.




Fig. 20




Fig. 21

- Note for replacing chips

1. Do not heat the chip more than 3 seconds.
2. Do not rub the electrode against the chip.
3. Use the tweezers with care not to damage the surface of the chip.
4. It is desirable to use a pencil type soldering iron. And use soldering iron less than 60W.




Fig. 22

■ HOW TO SET THE TONEARM DRIVE ROPE

Unit the rope according the following procedure.

1. Remove the dust cover. (Refer to "How to remove the dust cover".)
2. Remove the lead wire holder. (Fig. 23)
3. Remove the C-ring of the arm drive wheel and remove the drive wheel. (Fig. 23 : 50)
4. Turn over the arm drive wheel, and set the rope in the order of 1 ~ 2. (Fig. 24)
5. Holding the rope with the hand, set the drive wheel and rope in the order of 3 ~ 8 of Fig. 25.
6. After setting the rope, match in tonearm and sensor with the position of rope fixture, and secure the parts.
7. Turn the worm gear by finger to see that the tonearm and sensor move, then set the C-ring.




Fig. 23




Fig. 24




Fig. 25

■ MEASUREMENTS AND ADJUSTMENT

• Equipment used and condition of the set

1. Oscilloscope (two channels)
2. DC voltmeter.
3. Record (SFTR007) for adjustment.
4. Connector (SZZP1010F) for adjustment.
5. Remove the bottom board and remove the cover. (Fig. 29)
6. Set the optical sensor sensitivity selector to "M".

Step	Item	Preparations for adjustment	Adjusting portion	Adjusting method
1	Start position	<ol style="list-style-type: none"> 1. Open the upper cabinet and put on the test record. 2. Turn the power switch on. 3. Push the "Start" switch. 	Start position adjusting screw. (Fig. 26)	<ol style="list-style-type: none"> 1. Turn the start position adjusting screw. If it descends between tunes, turn the screw clockwise. If it descends outside the disc, turn the screw counterclockwise.
2	Clock frequency	<ol style="list-style-type: none"> 1. Connect Q1 emitter to IC301 14-pin. (Fig. 27) 2. Connect the oscilloscope to IC301 13-pin. 	VR301 (Fig. 27)	<ol style="list-style-type: none"> 1. Turn the power switch on. 2. Adjust VR301 so that the cycle of output waveform is $40\mu s \pm 2\mu s$. (Fig. 28)
3	Sensor gain	<ol style="list-style-type: none"> 1. Remove the cover and insert the connector for adjustment into terminal CN901. (Fig. 29) 2. Connect the oscilloscope to 6-pin (+) and 1-pin (-). 3. Put on the record for adjustment with side A up. 	VR901 (Fig. 26)	<ol style="list-style-type: none"> 1. Turn the power switch on and move the tonearm to the blank area of the record. 2. Adjust VR901 so that the output voltage is $4V \pm 0.4V$.

Step	Item	Preparations for adjustment	Adjusting portion	Adjusting method
4	Sensor resolution	<ol style="list-style-type: none"> 1. Remove the cover and insert the connector for adjustment into terminal CN901. (Fig. 29) 2. Connect the oscilloscope to 7-pin (+) and 1-pin (-). 3. Put on the record for adjustment with side A up. 	VR902 (Fig. 26)	<ol style="list-style-type: none"> 1. Turn the power switch on. 2. Push the program key to let it search the tonearm. (Output is delivered between the tunes.) 3. Adjust VR902 so that the peak output between tunes is $3V \pm 0.3V$. (Fig. 30)
5	Cueing timer	<ol style="list-style-type: none"> 1. Remove the cover and insert the connector for adjustment into terminal CN901. (Fig. 29) 2. Connect the unit to the amplifier. (Phono output) 3. Connect 3-pin (+) and 1-pin (-) to the channel (1) of two channel oscilloscope. 4. Connect the speaker terminal of amplifier to the channel (2) of two channel oscilloscope. 5. Connect the 2-pin and 1-pin. (Muting operation stops.) 6. Put on the record for adjustment with side B up. 	VR903 (Fig. 26)	<ol style="list-style-type: none"> 1. Turn the power switch on. 2. Move the tonearm to a recorded (groove) part of the record, and push the cueing switch for cueing down. 3. Check the time until completion of cueing (rise of cueing signal) after the stylus touches the record surface. 4. Adjust VR903 so that the time until completion of cueing is $0.3 \sim 0.5$ sec. (Fig. 31) <p>Note: Set the sweep time of oscilloscope to 0.2 sec/cm or 0.5 sec/cm. For example, in the case of 0.2 sec/cm range, adjust it so that the cueing completion signal is delivered 2 scale (0.4 sec) later than delivery of phono output signal.</p>
6	Descending between tunes	<ol style="list-style-type: none"> 1. Open the upper cabinet and hold the cabinet switch with tape. 2. Put on the record for adjustment with side B up. 3. Close the upper cabinet. 4. Connect the unit to the amplifier. (Connect the speakers to the speaker terminals.) 	Sensor shifting screw (Fig. 32)	<ol style="list-style-type: none"> 1. Turn the power switch on. 2. Push the program key 2, followed by start switch. 3. After completion of cueing down, push the program key 2 for the purpose of skipping. 4. Make sure that descending position is at count "20 ~ 21". 5. If the descending position is wrong, open the upper cabinet and turn the sensor shifting screw. 6. Close the upper cabinet and push the program key 2. 7. Adjust so that the descending position is at count "20 ~ 21". Repeat steps 4 ~ 7.
7	Tonearm offset angle	<ol style="list-style-type: none"> 1. Open the upper cabinet and hold the cabinet switch with tape. 2. Close the upper cabinet. 	Adjusting screw (Fig. 33)	<ol style="list-style-type: none"> 1. Turn the power switch on and push the start switch to shift the tonearm inward. 2. Open the upper cabinet. 3. Turn the adjusting screw so that the arm center matches the V-groove of the lift bar.
8	Servo gain and offset voltage	<ol style="list-style-type: none"> 1. Open the upper cabinet and hold the cabinet switch with the tape. 2. Close the upper cabinet. 3. Connect the DC voltmeter to CN301 terminal 3 and ground terminal. 4. Remove the Label of the tonearm cover. 	VR501 (Servo gain) P.C.B. (Offset voltage) (Fig. 32)	<ol style="list-style-type: none"> 1. Turn the power switch on and push the start switch to shift the tonearm inward. 2. Open the upper cabinet. 3. Completely shift the tonearm to the right. Then, adjust VR501 so that the voltage is 3.6V. (Servo gain) 4. Set the tonearm to the center and make sure that the output voltage is 1.8V. 5. If the voltage is not 1.8V, loosen the printed circuit board screw and move the board to the right or left with a screwdriver so that the output voltage becomes 1.8V. <p>After the adjustment, tighten the printed circuit board screw. (Offset adjustment)</p>

● Adjustment points




Fig. 26




Fig. 28




Fig. 27




Fig. 30




Fig. 29

Pin No.	Color	Description
1	Black	Ground
2	Red	Muting signal
3	Orange	Cueing signal
6	Blue	Sensor amp. output signal
7	Violet	Filter amp. output signal




Fig. 31




Fig. 33




Fig. 32

St

■ TROUBLE SHOOTING

1. How to use the repair table (Fig. 34)

- ① Remove the bottom board.
- ② Remove the operation circuit P.C.B. and connect the P.C.B. ground terminal to the chassis (Stator frame).
- ③ Put the unit on the repair table.
- ④ Fit the turntable platter and put on the turntable mat.
- ⑤ Put on the record and check the circuits from under the unit.




Fig. 34

Hold the switch with the tape.

2. How to raise the set (Fig. 35)

Note: Turntable platter is not fixed on the center spindle. Take care so that the turntable platter will not come loose. Also, take care allow the set to fall down.

- ① Remove the bottom board.
- ② Completely open the upper cabinet.
- ③ Hold the cabinet (Reset) switch with tape.
- ④ Fit the turntable platter.
- ⑤ Raise the unit and check the circuits.




Fig. 35

3. How to turn over the set (Fig. 36)

Note: This purpose is to check the voltage of each circuit during stop of the turntable.

- ① Remove the turntable platter and turn over the unit.
- ② Remove the bottom board.
- ③ Turn the power switch "on" and check the voltage.







Fig. 36







REPLACEMENT PARTS LIST...Electric Parts

Notes:


- Part numbers are indicated on most mechanical parts.
Please use this part number for parts orders.
- Important safety notice:**
Components identified by  mark have special characteristics important for safety.
When replacing any of these components, use only manufacturer's specified parts.
- Bracketed indications in Ref. No. columns specify the area.
Parts without these indications can be used for all areas.
- The "" mark is service standard parts and may differ from production parts.

Areas

- * [M] is available in U.S.A.
- * [MC] is available in Canada.

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description	Ref. No.	Part No.	Description			
INTEGRATED CIRCUITS											
IC1	AN7812	Regulator	D301~311,	SVDGL-9PR2F1	Light Emitting Diode	Z301,302,	EXBT44471K	470Ω X4			
IC101	AN6637	Turntable Drive	320	MA162A	Key Matrix	307					
IC201	AN6683	Turntable Control	D312~317,	MA162A	7.5V Zener	Z303	EXBP84333K	33KΩ X4			
IC301	MN1425FPF	System Control	801,802,	RVDRD7R5FB	Relay Protection	Z304	EXBP84103K	10KΩ X4			
IC401	AN6552	Arm Motor Control	804,805	MA162A	Light Emitting Diode	Z305	EXBP84332K	3.3KΩ X4			
IC801	AN6562	DC Amplifier & Band Pass Filter	D319,806	SVDPR3432S	4.7V Zener	Z306	EXBP86122J	1.2KΩ X6			
IC802	AN6912	Comparator	D501,502	MA1047A							
TRANSISTORS											
Q1	2SC1383Q	Regulator	X201	SVQSH41TR	4.193MHz	CRYSTAL					
Q302,303	2SD636	Muting Relay	VARIABLE RESISTORS								
306,802		Drive,Cueing Drive,V/I Converter	VR301	EVN61AA00B54	Clock Frequency Adj.,50KΩ(B)	S1	△ SFDSC05N08	Power			
Q304	2SD892	& Bias	VR501	EVNK6AA00B53	Servo Gain Adj.,5KΩ(B)	S301~314	EVQQJ104K	Program,Repeat, Cueing & Start/Clear			
Q305,308	2SB641	Cueing Drive	VR901,902	EVN61AA00B15	Sensor Gain & Resolution	S315,801	SFDHSW0699	Speed Selector & Sensor			
309,801		Switching, Waveform	VR903	EVN61AA00B24	Adj.,100KΩ(B)	S601	SFDSD2MSL-C	Gain Selector			
Q401,402	2SD973S	Shaping & Bias			Cueing Timer Adj.,20KΩ(B)	S701	SFDSC05N01	Rest Cabinet			
Q403,404	2SD638	Arm Motor Control	PHOTO INTERRUPTERS								
		Arm Motor Control	PC501	ON1186	Arm Position Detection	POWER TRANSFORMERS					
D1	△	SVDS1RBA20F	PC601	ON1161	Offset Angle Detection	T1 (M)	△ SLT48DTL3A	Power Source			
D2	◎	MA1056	PC701	ON2159	Blank Groove Detection	T1 (MC)	△ SLT48DT11C	Power Source			
DIODES											
D1	△	SVDS1RBA20F				FUSE					
D2	◎	MA1056				F1 (MC) only	△ XBA2F08NU100	800mA,250V			

• Terminal guide of transistors, and IC's



■ RESISTOR AND CAPACITORS

Notes:

- Part numbers are indicated on most mechanical parts.
Please use this part number for parts orders.
- Important safety notice:**
Components identified by Δ mark have special characteristics important for safety. When replacing any of these components use only manufacturer's specified parts.
- This " \odot " mark is service standard parts and may differ from production parts.

- Unless otherwise specified.
All resistors are in OHMS (Ω) $K = 1000\Omega$, $M = 1000k\Omega$
- All capacitors are in MICROFARADS (μF) $P = 10^{-6} \mu F$

Numbering System of Resistor

Example

ERD	25	F	J	101	ECKD	1H	102	Z	F
Type	Wattage	Shape	Tolerance	Value	Type	Voltage	Value	Tolerance	Peculiarity

ERG	1	AN	J	2R2	ECEA	50	M	R47	R
Type	Wattage	Shape	Tolerance	Value	Type	Voltage	Peculiarity	Value	Special use

Resistor Type	Wattage	Tolerance
ERD : Carbon	25 : 1/4W	J : $\pm 5\%$
ERX : Metal Film	1 : 1W	G : $\pm 2\%$

ERD2FCG□□□ → Fuse type carbon (1/4W)

ERD10TLJ □□□ → Chip type carbon (1/8W)

ECUV1H □□□ → Chip type ceramic

Numbering System of Capacitor

Example

ERD	25	F	J	101	ECKD	1H	102	Z	F
Type	Wattage	Shape	Tolerance	Value	Type	Voltage	Value	Tolerance	Peculiarity

ERG	1	AN	J	2R2	ECEA	50	M	R47	R
Type	Wattage	Shape	Tolerance	Value	Type	Voltage	Peculiarity	Value	Special use

Capacitor Type	Voltage		Tolerance
	ECEA Type	Others	
ECEA : Electrolytic	1A : 10V	1H : 50V DC	J : $\pm 5\%$
ECEB : Electrolytic	1C : 16V	2H : 500V DC	K : $\pm 10\%$
ECKD : Ceramic	1E : 25V	1 : 100V	Z : +80%, -20%
ECQM : Polyester	1V : 35V		P : +100%, -0%
	1H : 50V		M : $\pm 20\%$
	50 : 50V		

Part Numbering System

Ref. No.	Part No	Value
RESISTORS		
R1	ERD25FJ101	100
R2	ERD25FJ221	220
R3	ERG2SJ330	33
R4	ERD25FJ221	220
R103	ERD10TLJ104U	100K
R104	ERXIANJ2R7	2.7
R105	ERD10TLJ270U	27
R201	ERD10TLJ393U	39K
R202	ERD10TLJ394U	390K
R203	ERD10TLJ680U	68
R204	ERD10TLJ151U	150
R205	ERD10TLJ223U	22K
R207	ERD10TLJ102U	1K
R208	ERD10TLJ680U	68
R320	ERD25TJ333	33K
R321	ERD25FJ471	470
R322	ERD25FJ102	1K
R329	ERD25FJ392	3.9K
R330	ERD25FJ103	10K
R331	ERD25FJ472	4.7K
R334,335	ERD25FJ331	330
R336	ERD25FJ103	10K
R337	ERD25TJ223	22K
R338	ERD25FJ272	2.7K
R341	ERD25TJ563	56K
R343	ERD25FJ103	10K
R345	ERD25FJ472	4.7K
R346	ERD25TJ333	33K
R347	ERD25TJ563	56K

Ref. No.	Part No	Value
RESISTORS		
R348	ERD25TJ333	33K
R351	ERD25FJ471	470
R352,353	ERD25FJ222	2.2K
R357	ERD25TJ223	22K
R358	ERD25TJ333	33K
R359	ERD25FJ471	470
R360	ERD25TJ683	68K
R361	ERD25FJ470	47
R401	ERD25TJ683	68K
R402	ERD25FJ222	2.2K
R403	ERD25FJ102	1K
R404	ERD25TJ224	220K
R405	ERD25TJ683	68K
R406	ERD25FJ222	2.2K
R407	ERD25TJ102	1K
R408	ERD25TJ224	220K
R409	ERD25TJ273	27K
R410	ERD25FJ103	10K
R501	ERD25FJ561	560
R502	ERD25FJ391	390
R601	ERD25FJ681	680
R801	ERD25TJ124	120K
R802	ERD25FJ472	4.7K
R803	ERD25TJ124	120K
R804	ERD25FJ332	3.3K
R805	ERD25FJ222	2.2K
R806	ERD25FJ472	4.7K
R807	ERD25FJ332	3.3K
R808	ERD25FJ682	6.8K

Ref. No.	Part No	Value
RESISTORS		
R809	ERD25FJ102	1K
R810	ERD25FJ103	10K
R811	ERD25TJ684	680K
R812	ERD25TJ223	22K
R813	ERD25TJ104	100K
R814	ERD25TJ684	680K
R815	ERD25TJ224	220K
R816	ERD25FJ221	220
R817	ERD25TJ104	100K
R818	ERD25FJ102	1K
R819	ERD25FJ822	8.2K
R820	ERD25FJ222	2.2K
R821	ERD25FJ272	2.7K
R822	ERD25TJ220	22
R823	ERD25FJ103	10K
R825	ERD25FJ101	100
R826	ERD25TJ223	22K
R828	ERD25TJ223	22K
R829	ERD25FJ682	6.8K
R840	ERD25FJ102	1K
R841	ERD25FJ272	2.7K
RF1	ERD2FCG180	18


CAPACITORS		
C1,2	ECQM1223KZ	0.022
C3	ECQM1223KZ	0.022
C4	ECEB1EU222	2200
C5	ECEA1CU330	33

Ref. No.	Part No	Value
CAPACITORS		
C101	ECEA1CU330	33
C102	ECEA50ZR22	0.22
C103	ECQV05274JZ	0.27
C105,106	Δ	47
C107	ECKD1H223Z	0.022
C201	ECEA0JU470	47
C202	ECEA50ZR22	0.22
C203	ECQM1H683KV	0.068
C204	ECUV1H121JC	120
C205	ECUV1H330KV	33
C206	ECUV1H101JC	100
C207	ECEA0JU470	47
C208	ECEA1AU470	47
C301	ECCD1H470K	47P
C302	ECQM1H104KV	0.1
C303	ECKD1H104ZV	0.1
C304	ECEA0JSS330	33
C306	ECEA1EU4R7	4.7
C307	ECKD1H102KB	0.001
C308	ECKD1H104ZV	0.1
C401,402	ECQM1H223KV	0.022
C403	ECQV05224JZ	0.22
C501	ECEA1ES101	100
C601	ECFB1B104ZRM	0.1
C801	ECQM1H103KV	0.01
C802,803	ECQM1H104KV	0.1
C804	ECEA1CU220	22
C805	ECEA1CU470	47
C806	ECQM1H473KV	0.047

■ BLOCK DIAGRAM


• Description of each terminal of MN1425FPP


Pin No.	Symbol	Description
1.	VSS	Ground terminal
2.	CO11	Turntable speed select output terminal (45 rpm at "H", 33 rpm at "L")
3.	CO10	
4.	CO9	
5.	CO8	
6.	CO7	
7.	CO6	Program LED display output terminal (LED ON at "L")
8.	CO5	
9.	CO4	
10.	CO3	
11.	CO2	
12.	CO1	
13.	CO0	Repeat LED display output terminal (LED ON at "L")
14.	AI3	
15.	AI2	
16.	AI1	Key scan input terminal (Each key is read in through key scan with E-port.)
17.	AI0	
18.	BI3	Rest position detection input terminal ("L" when tonearm is on rest.)
19.	BI2	Blank groove detection and record detection terminal [Blank groove detection pulse is active "L". When it is "H" at start, 30cm record is detected. When it is "L", it is judged that there is no 30cm record (17cm or 25cm record is present).]
20.	BI1	Cueing time read input terminal.
21.	BI0	Turntable speed select and cabinet opening/closing detection terminal (Each operation is done through key scan with E-port.)
22.	EO0	
23.	EO1	
24.	EO2	
25.	EO3	Key scan output terminal (Each key is read in through key scan with A-port.)
26.	TST	Test terminal (connected to Ground not used)
27.	RST	Reset terminal (The microcomputer is reset at "L" and is not reset at "H".)
28.	SLCT	Select terminal (The level is set to "H" by the select terminal of the inside counter.)
29.	SNSO	Offset angle detection signal input terminal
30.	SNST	Arm position detection signal input terminal
31.	DO0	Turntable start/stop select terminal (Start at "L", stop at "H")
32.	DO1	
33.	DO2	
34.	DO3	Arm motor drive control terminal
35.	DO4	
36.	DO5	Muting control terminal
37.	DO6	Cueing control terminal ("H" during cueing and cueing down.)
38.	DO7	Cueing control terminal ("H" only during cueing down.)
39.	VDD	Power supply terminal
40.	OSC	Oscillation terminal





CIRCUIT BOARD AND WIRING CONNECTION DIAGRAM

Ground (Earth) lines











■ EXPLODED VIEW


A




B




C




D



E




F



G

● Tonearm Parts



REPLACEMENT PARTS LIST (Mechanical Parts)

Notes: 1. Part numbers are indicated on most mechanical parts.

Please use this part number for parts orders.

2. **Important safety notice:**

Components identified by  mark have special characteristics important for safety.

When replacing any of these components, use only manufacturer's specified parts.

3. Bracketed indications in Ref. No. columns specify the area.

Parts without these indications can be used for all areas.

4. The "" mark is service standard parts and may differ from production parts.

5. The parenthesized numbers in the columns of description stand for the quantity per set.


Areas

* [M] is available in U.S.A.


* [MC] is available in Canada.

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
CABINET AND CHASSIS PARTS								
1	SFWEC06N01	45r.p.m Adaptor (1)	37	SFXJC05N01	Guide Rail,Arm Drive (1)	N2	S XTV3+6BFN	Screw 6
2	SFQAC06N01	Spring,45r.p.m.Adaptor (1)	38	SFGCC05N05	Cushion Rubber, (2)	N3	S XTV3+8BFN	Screw (2)
3	SFTGQ15N01	Turntable Mat (1)	39	SFUPC05N03	Bracket,Guide Rail (1)	N4	S XTV3+20BFN	Screw (2)
4	SFTEQ15N01A	Turntable Platter (1)	40	SFUMC06N05E	Sensor Ass'y (1)	N5	S XTV3+20BFN	Screw 1
5(M)	SFNNQ15M01	Name Plate (1)	41	SFXJC06N01	Guide Rail,Sensor Ass'y (1)	N6	S XTW3+10Q	Screw 1
5(MC)	SFNNQ15C01	Name Plate (1)	42	SFUMC05N17	Arm Drive Wheel (1)	N7	S XTW3+14QFYR	Screw (6)
6	SFACQ15N01	Cabinet (1)	43	SFUMC06N08	Holder,Lead Wires (1)	N8	S XTN3+20BFZ	Screw 2
7	SFKKQ15N03	Surface Plate (1)	44	SFUZC05N01	Rod,Rest Switch (1)	N9	S XTN3+20BFZ	Screw 2
8	SFKTD05N02	Knob,Speed Select (2)	45	SFUMC06N03A	Rest Switch Ass'y (1)	N10	SFXGC05N03	Screw (2)
9	SFUMC05N15	Holder,Cabinet Switch (1)	46	SFUMC05N16A	Worm Ass'y (1)	N11	SFXGC05N02	Screw 3
10	SFQPC05N01	Spring,Cabinet Switch (1)	47	SFGBC10-01	Belt,Arm Drive (1)	N12	SFXGD05N01E	Screw (2)
11	SFNZQ15N01	Label,Speed Select (1)	48	SFMHC05N01E	Motor Ass'y (with Pulley), (1)	N13	SFXWC06N02	Washer (1)
12	SFNUMD05N03	Rod,Speed Select Knob (2)	49	SFUKQ15M01Z	Tonearm Base Ass'y (1)	N14	SFXWC05N07	Washer (3)
13	SFKTQ15N01	Button(A),Operation (1)	50	SFUMD05N02	Sub Cover,Tonearm Base (1)	N15	SFXW551D2	Washer (1)
14	SFKTQ15N02	Button(B),Operation (1)	51	SFUPC15N11	Stopper,Shutter (1)	N16	S XUC4FT	Retaining Ring (1)
15	SFUPQ15N01	Holder,Operation Button (1)	52	SFUMC06N10	Shutter (1)	N17	S XUC2FT	Retaining Ring (1)
16	SFKBQ15N01	Badge,Cabinet (1)	53	SFUMQ15N01	Cover,Arm Drive Motor (1)	N18	XNC3HS	Nut (5)
17	SFKTQ15N03	Button,On/Off Switch (1)	54	SFUZC06N01E	Arm Drive Lope Ass'y (1)	N19	XTN3+5J	Screw (3)
18	SFXJBL3N02E	Shaft Ass'y,On/Off Switch (1)	55	SFUMC05N23	Cap,Pulley (5)	N20	SFPEV00502	Screw (1)
19	SFQABL3N02	Spring,On/Off Switch (1)	56	SFUMC05N22	Pulley (5)			
20	SFUMBL3N05	Holder,On/Off Switch (1)	58	SFDHC06N01E	Jack,Phono Output (1)			
21	SFUMQ15N02	Holder,Light Emitting (2)	59	SFDJHSC0491	AC Socket (1)			
22	SFUMQ15N03	Diodes (1)	60	SFUMC05N20	Holder,Lead Wires (1)			
23	SFMGQ34N01	Holder,Light Emitting (1)	61	SFUZC05N03	Lutch (1)			
25	SFMZC06N01R	Diodes (1)	62	SFGCC05N04	Cushion Rubber (3)			
26	SFMZC05N01E	Cover,Stator Coil (1)	63	SFGCC05N02	Cushion Rubber,Power (2)			
27	SFQCC05N01	Stator Frame Ass'y (1)			Transformer (1)			
28	SFGAC05N02	Thruster Ass'y (1)						
29	SFAUL12M01	Spring,Audio Insulator (4)						
30	SFKKQ12M01	Audio Insulator (4)						
31	SFKKQ15N02	Bottom Case (1)						
32	SFATQ15N01A	Graduated Plate (1)						
33	SFATQ15N02A	Hinge(Right) (1)						
34	SFADQ15N01E	Hinge(Left) (1)						
34-1	SFADC06N02	Cushion Rubber, (2)						
35	SFGCD05N01	Dust Cover (1)						
36	SFGCC05N06	Dust Cover (2)						
SCREWS,WASHERS,RINGS AND NUTS								
	N1	S XTV3+10BFN	Screw (15)					
CABINET AND CHASSIS PARTS								
	37	SFXJC05N01	Guide Rail,Arm Drive (1)					
	38	SFGCC05N05	Cushion Rubber, (2)					
	39	SFUPC05N03	Bracket,Guide Rail (1)					
	40	SFUMC06N05E	Sensor Ass'y (1)					
	41	SFXJC06N01	Guide Rail,Sensor Ass'y (1)					
	42	SFUMC05N17	Arm Drive Wheel (1)					
	43	SFUMC06N08	Holder,Lead Wires (1)					
	44	SFUZC05N01	Rod,Rest Switch (1)					
	45	SFUMC06N03A	Rest Switch Ass'y (1)					
	46	SFUMC05N16A	Worm Ass'y (1)					
	47	SFGBC10-01	Belt,Arm Drive (1)					
	48	SFMHC05N01E	Motor Ass'y (with Pulley), (1)					
	49	SFUKQ15M01Z	Tonearm Base Ass'y (1)					
	50	SFUMD05N02	Sub Cover,Tonearm Base (1)					
	51	SFUPC15N11	Stopper,Shutter (1)					
	52	SFUMC06N10	Shutter (1)					
	53	SFUMQ15N01	Cover,Arm Drive Motor (1)					
	54	SFUZC06N01E	Arm Drive Lope Ass'y (1)					
	55	SFUMC05N23	Cap,Pulley (5)					
	56	SFUMC05N22	Pulley (5)					
	58	SFDHC06N01E	Jack,Phono Output (1)					
	59	SFDJHSC0491	AC Socket (1)					
	60	SFUMC05N20	Holder,Lead Wires (1)					
	61	SFUZC05N03	Lutch (1)					
	62	SFGCC05N04	Cushion Rubber (3)					
	63	SFGCC05N02	Cushion Rubber,Power (2)					
			Transformer (1)					
ACCESORIES								
A1(M)	SFNUQ15M01	Instruction Book (1)						
A1(MC)	SFNUQ15C01E	Instruction Book (1)						
A2	SFDHC05N01	Phono Output Cord (1)						
A3	SFDLC05N01	Ground Wire (1)						
A4	SFDAC05M01	AC Cord (1)						
A5	SFNZC06M01	Caution sheet,Unusual Record (1)						
PACKING PARTS								
P1(M)	SFHPQ15M01	Carton Box (1)						
P1(MC)	SFHPQ15C01	Carton Box (1)						
P2	SFHHL13R01	Pad,Front (1)						
P3	SFHHL13R02	Pad,Rear (1)						
P4	SFHKC05N01	Clamper,Turntable Platter (1)						
P5	SFHKC05N02	Spacer,Tonearm (1)						
P6	SFHSL13R01	Spacer,Dust Cover (1)						
P7	SFHDC05M01	Pad,Turntable Mat (1)						
P8	SFYF33B35	Polyethylene Bag, Turntable Mat (1)						
P9	SFYH60X60	Polyethylene Bag, Cabinet (1)						
P10	SFYH17X16	Polyethylene Bag, Accessories (1)						

■ PACKING



1. Place the unit (with cushions attached) as illustrated.
2. Fold the flaps according to the line marks.
3. Seal the top with adhesive tape.
 - * Use gum tape or adhesive cloth tape of 50mm wide at least.
4. For the edges, first fold the flap "a" and then flap "b", and staple. Remember to staple only flap "b". (Use 15 or 16mm staple)



* Stapling positions are shown below.

