

AM-NX1


SERVICE MANUAL

Ver 1.1 2003. 08

*AEP Model
UK Model
E Model*




6-6. SCHEMATIC DIAGRAM – MAIN Board (1/4) – • See page 39 for Waveforms. • See page 46 for IC Block Diagrams.




The components identified by mark  or dotted line with mark  are critical for safety.
Replace only with part number specified.



6-8. SCHEMATIC DIAGRAM – MAIN Board (3/4) – • See page 39 for Waveform. • See page 46 for IC Block Diagrams.



6-9. SCHEMATIC DIAGRAM – MAIN Board (4/4) – • See page 46 for IC Block Diagrams.



When IC851 is damaged, replace the MAIN board.