

aiwa



HS-GS392 HS-GM700MK3

STEREO CASSETTE PLAYER

• TYPE: 700Y1
392Y1

SIMPLE MANUAL

• Replace this Service Manual with "Revision Publishing" when it is issued.

S/M Code No. 09-991-405-7T1

MANUAL
SERVICE

ELECTRICAL MAIN PARTS LIST - 1/1

NOTE: The characters in the suffix column indicate the part usage.

Y1B		XX		A
392Y1		XX		B
700Y1		XX		C
		KANRI		
REF.NO	PARTS NO.	NO.	DESCRIPTION	SUFFIX
C	101	87-010-178-080	CHIP CAP 1000P	ABC
C	102	87-010-178-080	CHIP CAP 1000P	ABC
C	103	87-010-213-080	C-CAP, S 0.015-50 B	ABC
C	104	87-010-213-080	C-CAP, S 0.015-50 B	ABC
C	105	87-010-501-040	E/CAP GAS 47-4	ABC
C	106	87-010-501-040	E/CAP GAS 47-4	ABC
C	111	87-010-182-080	C-CAP, S 2200P-50 B	ABC
C	112	87-010-182-080	C-CAP, S 2200P-50 B	ABC
C	119	87-016-350-040	CAP, E 470-4 MA GAS	ABC
C	127	87-010-197-080	CAP, CHIP 0.01 DM	ABC
C	125	87-010-499-040	CAP, E 22-6.3 GAS	ABC
C	123	87-010-499-040	CAP, E 22-6.3 GAS	ABC
C	126	87-010-503-040	CAP, E 220-4 GAS	ABC
C	124	87-010-596-080	CAP, S 0.047-16	ABC
C	120	87-016-350-040	CAP, E 470-4 MA GAS	ABC
C	230	87-010-197-080	CAP, CHIP 0.01 DM	ABC
C	312	87-012-360-080	CAP, CER 1-10	ABC
C	311	87-012-360-080	CAP, CER 1-10	ABC
C	703	87-010-196-080	CHIP CAPACITOR, 0.1-25	ABC
C	702	87-012-157-080	C-CAP, S 330P-50 CH	ABC
C	701	87-012-157-080	C-CAP, S 330P-50 CH	ABC
IC	101	87-A20-460-040	IC, MM1336CF	ABC
J	102	83-HRL-602-010	JACK, 3.5ST	ABC
J	101	87-A60-849-010	JACK, DC DIA 2.75 BLK	ABC
S	103	87-A90-050-010	SW, SL 2-2-2 NS (BLK)	ABC
S	101	87-A91-077-010	SW, LEAF	ABC
S	102	82-HRB-607-010	SW, SL 2-2-2 SSZZ-S-502(S)	ABC
VR	101	87-A90-818-010	VR, RTRY 20KCX2	ABC
C	308	87-010-186-080	CAP, CHIP 4700P	ABC
C	307	87-010-186-080	CAP, CHIP 4700P	ABC
C	305	87-010-186-080	CAP, CHIP 4700P	ABC
C	306	87-010-186-080	CAP, CHIP 4700P	ABC
C	309	87-010-193-080	CHIP CAPACITOR, 0.033	ABC
C	301	87-010-196-080	CHIP CAPACITOR, 0.1-25	ABC
C	302	87-010-196-080	CHIP CAPACITOR, 0.1-25	ABC
C	303	87-016-461-080	C-CAP, S 0.47-16F	ABC
C	304	87-016-461-080	C-CAP, S 0.47-16F	ABC
C	310	87-010-193-080	CHIP CAPACITOR, 0.033	ABC
C	313	87-012-360-080	CAP, CER 1-10	ABC
C	314	87-012-360-080	CAP, CER 1-10	ABC
C	322	87-010-196-080	CHIP CAPACITOR, 0.1-25	ABC
C	321	87-016-436-080	C-CAP, TN 47-4(B2)	ABC
IC	102	87-017-805-080	IC, AN7375NS(OP AMP)	ABC
S	301	87-A90-917-010	C-SW, SL 1-1-2 SS-350-B12W-C-L	ABC
SFR	102	87-A90-958-080	C-SFR, 1K B RH03AXAN4X	ABC
SFR	103	87-A90-958-080	C-SFR, 1K B RH03AXAN4X	ABC
C	409	87-010-195-080	C-CAP, S 0.068-25 F	ABC
C	404	87-010-197-080	CAP, CHIP 0.01 DM	ABC
C	403	87-010-197-080	CAP, CHIP 0.01 DM	ABC
C	406	87-012-141-080	CHIP-CAPACITOR, 0.22-16F	ABC
C	405	87-012-141-080	CHIP-CAPACITOR, 0.22-16F	ABC
C	407	87-012-360-080	CAP, CER 1-10	ABC
C	408	87-012-360-080	CAP, CER 1-10	ABC
C	412	87-010-188-080	CAP, CHIP 6800P	ABC
C	411	87-010-188-080	CAP, CHIP 6800P	ABC
C	410	87-010-195-080	C-CAP, S 0.068-25 F	ABC
C	417	87-010-198-080	CAP, CHIP 0.022	ABC
C	413	87-010-198-080	CAP, CHIP 0.022	ABC
C	418	87-010-198-080	CAP, CHIP 0.022	ABC
C	414	87-010-198-080	CAP, CHIP 0.022	ABC
C	415	87-010-501-040	E/CAP GAS 47-4	ABC
C	420	87-012-360-080	CAP, CER 1-10	ABC
C	421	87-012-360-080	CAP, CER 1-10	ABC
D	401	87-020-027-080	CHIP-DIODE 1SS184	ABC
Q	402	87-026-264-080	C-TR, RN1411	ABC
Q	401	87-026-264-080	C-TR, RN1411	ABC
Q	403	87-026-264-080	C-TR, RN1411	ABC
Q	404	87-026-264-080	C-TR, RN1411	ABC
Q	406	89-327-125-080	CHIP TR, 2SC2712GR	ABC
Q	405	89-327-125-080	CHIP TR, 2SC2712GR	ABC
Q	407	89-327-125-080	CHIP TR, 2SC2712GR	ABC
Q	408	89-327-125-080	CHIP TR, 2SC2712GR	ABC
S	401	87-A91-285-010	C-SW, SL 1-1-4 SS-350-B14B-C-L	ABC
C	122	87-010-184-080	CHIP CAPACITOR 3300P(K)	ABC
C	128	87-010-196-080	CHIP CAPACITOR, 0.1-25	ABC
C	121	87-012-360-080	CAP, CER 1-10	ABC
R	115	87-A00-404-080	RES, 0.51-1/8W G 4300	ABC
SFR	101	87-024-050-010	SEMI-FIXED RESISTOR, 1K	ABC
TH	101	87-026-256-090	THERMISTOR, HT-100	ABC

MECHANICAL PARTS LIST - 1/1

NOTE: The characters in the suffix column indicate the part usage.


Y1B		XX		A	
392Y1		XX		B	
700Y1		XX		C	
REF.NO	PARTS NO.	KANRI NO.	DESCRIPTION	SUFFIX	
	8Z-HG6-007-010		LID,CASS P GRY	..C	
	8Z-HG6-008-010		LID,CASS P GRY EG	AB	
	8Z-HRB-002-010		WINDOW,CASS	ABC	
	8Z-HRB-217-010		SPR-T,CASS	ABC	
	8Z-HG6-002-010		PANEL,MSP 392 SIL	ABC	
	8Z-HG6-010-010		CABI,REAR 392 SIL EG	AB	
	8Z-HG6-011-010		CABI,REAR GM700 SIL	..C	
	8Z-HRB-003-010		FRAME,CENTER GRY	ABC	
	8Z-HRB-005-010		LID,BAT SIL	ABC	
	8Z-HG9-003-010		KNOB,SL DOLBY SIL	ABC	
	8Z-HG9-004-010		KNOB,RTRY MSP	ABC	
	8Z-HG6-003-010		PLATE,IND 392	ABC	
	8Z-HG6-005-010		LBL,SPEC 392 Y(CE)	AB	
	8Z-HG6-012-010		LBL,SPEC GM700MK3	..C	
	87-264-527-310		V 1.7-3 SCREW	ABC	
	87-B10-048-010		VT2+1.4-3 (3) CR HL	ABC	
*	87-B10-196-010		VT2+1.4-4 BLK (3) HL	ABC	
	8Z-HG9-201-010		HLDR,HP JACK	ABC	
	8Z-HG9-202-010		RACK,MSP	ABC	
	8Z-HG9-203-010		SPR,CLIC MSP	ABC	
	8Z-HG9-204-010		GEAR,MSP	ABC	
	8Z-HRB-208-010		BAT-CONTACT,P	ABC	
	8Z-HRB-209-010		BAT-CONTACT,M	ABC	
	87-067-732-010		TAPPING SCREW, VT1.4-3	ABC	
	8Z-HRB-014-010		KNOB,SL OPEN	ABC	
	8Z-HRB-202-010		HLDR,DC JACK	ABC	
	8Z-HRB-204-010		LEVER,EJECT	ABC	
	8Z-HRB-205-010		SPR-T,EJECT	ABC	
	8Z-HRB-207-010		SPR-P,CASS	ABC	
	8Z-HRB-213-010		SPR-P,EJECT	ABC	
	8Z-HRB-214-010		SHAFT,EJECT	ABC	
	8Z-HRB-215-010		SHAFT,ASSY	ABC	
	8Z-HRB-216-010		CAP,EJECT	ABC	
*	87-B10-196-010		VT2+1.4-4 BLK (3) HL	ABC	
*	8Z-HRB-206-010		PLATE,EJECT	ABC	

ACCESSORIES / PACKAGE LIST - 1/1

NOTE: The characters in the suffix column indicate the part usage.

Y1B		XX		A	
392Y1		XX		B	
700Y1		XX		C	
REF.NO	PARTS NO.	KANRI NO.	DESCRIPTION	SUFFIX	
	8Z-HG6-907-010		IB,Y(EGFSI) S	ABC	
	8Z-HG6-908-010		IB,Y(EDPHNCZ) S	AB	
	87-B30-176-010		HEADPHONE, HP-M007(S)	ABC	
	8Z-HRB-050-010		CLIP,BELT ASSY	ABC	

SCHEMATIC DIAGRAM - 1 (MAIN)



サービス技術ニュース	
番号	連絡内容
G- -	
G- -	
G- -	

アイワ株式会社
AIWA CO.,LTD.

9630469

Tokyo Japan