

aiwa



HS-GS192 HS-EM40MK2

STEREO CASSETTE PLAYER

- TYPE: Y1,YJ<192>
Y1<40>

SIMPLE MANUAL

- Replace this Service Manual with "Revision Publishing" when it is issued.

ELECTRICAL MAIN PARTS LIST - 1/1

NOTE: The characters in the suffix column indicate the part usage.

[S]	192Y1B	XX	A	
[L]	192Y1	XX	B	
[S]	192Y1	XX	C	
[S]	192YJ1	XX	D	
[S]	40Y1	XX	E	
[L]	40Y1	XX	F	
[G]	40Y1	XX	G	
		KANRI		
REF.NO	PARTS NO.	NO.	DESCRIPTION	SUFFIX
	8Z-HG8-605-010		F-CABLE, 4P	ABCDEF
C	4	87-010-178-080	CHIP CAP 1000P	ABCDEF
C	3	87-010-178-080	CHIP CAP 1000P	ABCDEF
C	2	87-010-180-080	C-CER 1500P	ABCDEF
C	1	87-010-180-080	C-CER 1500P	ABCDEF
C	7	87-010-189-080	C-CAP, S 8200P-50 B	ABCDEF
C	8	87-010-189-080	C-CAP, S 8200P-50 B	ABCDEF
C	9	87-016-462-080	C-CAP, S 1-16 F	ABCDEF
C	5	87-A10-488-010	CAP, E 47-4 7L SR	ABCDEF
C	6	87-A10-488-010	CAP, E 47-4 7L SR	ABCDEF
C	11	87-010-193-080	CHIP CAPACITOR, 0.033	ABCDEF
C	12	87-010-193-080	CHIP CAPACITOR, 0.033	ABCDEF
C	10	87-010-452-080	CAPACITOR, 1-16	ABCDEF
C	15	87-015-681-010	ELECTROLYTIC CAPACITOR, SRA16V	ABCDEF
C	14	87-016-462-080	C-CAP, S 1-16 F	ABCDEF
C	16	87-A10-264-080	C-CAP, S 0.1-16ZF	ABCDEF
C	17	87-A10-489-010	CAP, E 220-4 7L SR	ABCDEF
C	13	87-A10-489-010	CAP, E 220-4 7L SR	ABCDEF
C	18	87-A10-489-010	CAP, E 220-4 7L SR	ABCDEF
C	23	87-010-180-080	C-CER 1500P	ABCDEF
C	24	87-010-180-080	C-CER 1500P	ABCDEF
C	26	87-016-462-080	C-CAP, S 1-16 F	ABCDEF
C	21	87-016-462-080	C-CAP, S 1-16 F	ABCDEF
C	22	87-016-462-080	C-CAP, S 1-16 F	ABCDEF
C	20	87-A10-489-010	CAP, E 220-4 7L SR	ABCDEF
D	1	87-020-339-080	CHIP DIODE, 1SS226	ABCDEF
IC	1	87-A21-144-040	C-IC, TA2069AF	ABCDEF
J	1	85-HRL-623-010	JACK, 3.5 ST BLK	ABCDEF
Q	4	87-026-262-080	C-TR, RN1407	ABCDEF
Q	3	87-026-264-080	C-TR, RN1411	ABCDEF
Q	2	87-026-264-080	C-TR, RN1411	ABCDEF
Q	5	87-026-268-080	C-TR, RN2411	ABCDEF
SW	1	87-A90-133-010	SW LEAF LSA1120JAU	ABCDEF
SW	2	87-A91-163-010	C-SW, SL 1-1-2 4MM	ABCDEF
VR	1	87-A90-981-010	VR, RTRY 20KBX1	ABCDEF
C	404	87-010-184-080	CHIP CAPACITOR 3300P(K)	ABCDEF
C	403	87-010-184-080	CHIP CAPACITOR 3300P(K)	ABCDEF
C	409	87-010-956-080	CHIP-CAP, S 0.068-25B	ABCDEF
C	405	87-012-141-080	CHIP-CAPACITOR, 0.22-16F	ABCDEF
C	406	87-012-141-080	CHIP-CAPACITOR, 0.22-16F	ABCDEF
C	407	87-016-462-080	C-CAP, S 1-16 F	ABCDEF
C	408	87-016-462-080	C-CAP, S 1-16 F	ABCDEF
C	412	87-010-188-080	CAP, CHIP 6800P	ABCDEF
C	411	87-010-188-080	CAP, CHIP 6800P	ABCDEF
C	415	87-010-189-080	C-CAP, S 8200P-50 B	ABCDEF
C	416	87-010-189-080	C-CAP, S 8200P-50 B	ABCDEF
C	410	87-010-956-080	CHIP-CAP, S 0.068-25B	ABCDEF
C	413	87-012-365-080	C-CAP, S 0.027-25VBK	ABCDEF
C	414	87-012-365-080	C-CAP, S 0.027-25VBK	ABCDEF
C	417	87-A10-488-010	CAP, E 47-4 7L SR	ABCDEF
Q	403	87-026-264-080	C-TR, RN1411	ABCDEF
Q	402	87-026-264-080	C-TR, RN1411	ABCDEF
Q	401	87-026-264-080	C-TR, RN1411	ABCDEF
Q	404	87-026-264-080	C-TR, RN1411	ABCDEF
Q	408	89-327-125-080	CHIP TR, 2SC2712GR	ABCDEF
Q	406	89-327-125-080	CHIP TR, 2SC2712GR	ABCDEF
Q	407	89-327-125-080	CHIP TR, 2SC2712GR	ABCDEF
Q	405	89-327-125-080	CHIP TR, 2SC2712GR	ABCDEF
C	51	87-016-462-080	C-CAP, S 1-16 F	ABCDEF
C	53	87-016-462-080	C-CAP, S 1-16 F	ABCDEF
R	51	87-022-335-080	C-RES, S180-1/10W F	ABCDEF
SFR	51	87-A91-279-080	C-SFR, 2.2K B RH03AXAN4W	ABCDEF
D	401	87-020-027-080	CHIP-DIODE 1SS184	ABCDEF
SW	401	87-036-146-080	C-SLIDE SWITCH 1-1-4	ABCDEF

MECHANICAL PARTS LIST - 1/1

NOTE: The characters in the suffix column indicate the part usage.

[S]	192Y1B	XX	A
[L]	192Y1	XX	B
[S]	192Y1	XX	C
[S]	192YJ1	XX	D
[S]	40Y1	XX	E
[L]	40Y1	XX	F
[G]	40Y1	XX	G


REF.NO	PARTS NO.	KANRI NO.	DESCRIPTION	SUFFIX
	8Z-HG8-001-010		LID, CASS	A.CD
	8Z-HG8-002-010		WINDOW, MSP	A.CDE
	8Z-HG8-009-010		LID, CASS BLUE	.B
	8Z-HG8-012-010		LID, CASS MGREEN	
	8Z-HG8-014-010		WINDOW, MSP BLUE	.B...F
	8Z-HG8-015-010		WINDOW, MSP GREEN	...G
	8Z-HG8-019-010		LID, CASS MBLUE	
	8Z-HG8-020-010		LID, CASS EM40 SIL	...E
	8Z-HG8-021-010		LID, CASS EM40 MBLUE	...F
	8Z-HG8-022-010		LID, CASS EM40 MGREEN	...G
	8Z-HG8-003-010		KNOB, RTRY MSP	ABCDEFGG
	87-067-385-010		SCREW, VT +1.4-2.5HL	ABCDEFGG
	8Z-HG8-201-010		GEAR, MSP	ABCDEFGG
	88-HG8-020-010		LID, BATT J-129G	...G
	88-HG8-025-010		LID, BATT J-224B	.B...F
	88-HKA-027-010		FRAME, CENTER VIO	.B...F
	88-HKA-029-010		FRAME, CENTRE GRE	...G
	88-HKA-033-010		FRAME, CENTRE J034	A.CDE
	8Z-HG8-010-010		CABI, REAR J224B	.B...F
	8Z-HG8-013-010		CABI, REAR J129G	...G
	8Z-HG8-016-010		CABI, REAR J049N	A.CDE
	8Z-HG8-018-010		LID, BATT J049N	A.CDE
	88-HG8-036-010		KNOB, SL EGS J-129G	...G
	88-HG8-037-010		KNOB, SL EGS J-224B	.B...F
	88-HG8-038-010		KNOB, SL EGS J-089N	A.CD
	8Z-HG8-024-010		KNOB, SL TAPE J049N	...E
	87-067-691-010		SCREW VT+1.7-6	ABCDEFGG
	87-264-525-310		SCREW, V+1.7-2.5	ABCDEFGG
	81-HK9-208-210		SPR-P, CASS A	ABCDEFGG
	86-HKA-201-010		HLDR, JACK	ABCDEFGG
	86-HKA-202-010		BAT-CONTACT, (+)	ABCDEFGG
	86-HKA-203-010		BAT-CONTACT, (-)	ABCDEFGG
	86-HRM-205-010		SPR-T, CLICK	ABCDEFGG
	88-HG8-202-010		PLATE, HEAD J-266G	...G
	88-HG8-203-010		PLATE, HEAD J-268B	.B...F
	88-HG8-204-010		PLATE, HEAD J-034N	A.CDE
	8Z-HG8-605-010		F-CABLE, 4P	ABCDEFGG

ACCESSORIES / PACKAGE LIST - 1/1

NOTE: The characters in the suffix column indicate the part usage.

[S]	192Y1B	XX		A
[L]	192Y1	XX		B
[S]	192Y1	XX		C
[S]	192YJ1	XX		D
[S]	40Y1	XX		E
[L]	40Y1	XX		F
[G]	40Y1	XX		G
		KANRI		
REF.NO	PARTS NO.	NO.	DESCRIPTION	SUFFIX
	8Z-HG8-904-010	IB,YJ(ESC)	-C	...D
	8Z-HG8-905-010	IB,Y(EGFSI)	-C	ABC
	8Z-HG8-906-010	IB,Y(EDPOHCZ)	-C	ABC
	8Z-HG8-909-010	IB,Y(EGFSI)	-EM40MK2	...EFG
	8Z-HG8-910-010	IB,Y(EDPOHCZ)	-EM40MK2	...EFG
	84-447-019-310	CLIP,BELT		ABCDEFG
	87-B30-155-010	HEADPHONE,HP-M006BL(T)		.B...F
	87-B30-156-010	HEADPHONE,HP-M006G(T)		...G
	87-B30-168-110	HEADPHONE,HP-M006(K)		A.CDE

SCHEMATIC DIAGRAM -1(MAIN)



SCHEMATIC DIAGRAM

サービス技術ニュース	
番号	連絡内容
Gー ー	
Gー ー	
Gー ー	

アイワ株式会社
AIWA CO.,LTD.

9630469

Tokyo Japan