



COMPUTERIZED HIGH SPEED STEREO RECEIVER



* Refer to Parts List on page 10.

BLOCK/LEVEL DIAGRAM



ADJUSTMENT/REGLAGES/ABGLEICH

TEST INSTRUMENT

Oscilloscope
 AM signal generator
 FM signal generator
 Audio generator
 AC voltmeter
 FM multiplex generator
 Frequency counter
 DC voltmeter
 Distortion meter
 Dummy antenna


APPAREILLAGE

Oscilloscope
 Générateur MA
 Générateur MF
 Générateur audio fréquences
 Voltmètre CA
 Générateur multiplex stéréo
 Fréquence-mètre
 Voltmètre CC
 Distorsiomètre
 Antenne fictive

PRÜFINSTRUMENTE

Oszilloskop SCOPE
 MW-Signalgenerator AM-SG
 UKW-Signalgenerator FM-SG
 NF-Signalgenerator AG
 Wechselspannungsmesser
 UKW-Multiplexgenerator FM-MPX
 Frequenzzähler
 Gleichspannungsmesser
 Klirrfaktormesser
 Antennennachbildung

SYSTEM CONNECTIONS/RACCORDEMENTS DU SYSTEME/SYSTEM-ANSCHLÜSSE



ADJUSTMENT

NO.	ITEM	INPUT SETTINGS	OUTPUT SETTINGS	TUNER SETTINGS	ALIGNMENT POINTS	ALIGN FOR	FIG.
FM SECTION		SELECTOR : FM	FM MODE : AUTO/ MUTING				
1	DISCRIMINATOR (1)	(A) 100.1MHz 1kHz $\pm$ 75kHz dev 60dB (ANT input)	Connect a DC voltmeter across R13	MONO 100.1MHz	L1	0V	(a)
2	DISCRIMINATOR (2)	(A) 100.1MHz 1kHz $\pm$ 75kHz dev 60dB (ANT input)	(B)	MONO 100.1MHz	L2	Minimum distortion	
Repeat alignments 1 and 2 several times.							
3	VCO	(A) 100.1MHz 0 dev 60dB (ANT input)	Connect a frequency counter to 9 pin of IC2.	100.1MHz	VR2	19.00kHz	(b)
4	SEPARATION	(C) 100.1MHz 1kHz $\pm$ 68.25kHz dev Selector : L or R Pilot : $\pm$ 6.75kHz dev 60dB (ANT input)	(B)	100.1MHz	VR1	Minimum crosstalk. A compromise adjustment may be required if left-to-right and right-to-left separations are unequal.	
5	DISTORTION (STEREO)	(C) 100.1MHz 1kHz $\pm$ 68.25kHz dev Selector : L or R Pilot : $\pm$ 6.75kHz dev 60dB (ANT input)	(B)	100.1MHz	T1 (Front end)	Minimum distortion. (Repeat alignments 1 and 2)	
AM SECTION		SELECTOR : AM	Keep the loop antenna installed.				
(1)	BAND EDGE (1)	—	Connect a DC voltmeter to terminal 7.	1620kHz (1611kHz)	L4	9.0V	(c)
(2)	RF ALIGNMENT (1)	(D) 630kHz 400Hz, 30% mod	(B)	630kHz	L3, 5	Maximum amplitude and symmetry of the oscilloscope display.	
(3)	RF ALIGNMENT (2)	(D) 1440kHz 400Hz, 30% mod	(B)	1440kHz	TC1	Maximum amplitude and symmetry of the oscilloscope display.	
Repeat alignments (3) and (4) several times.							

REGLAGES


N°	ITEM	REGLAGE DE L'ENTREE	REGLAGE DE LA SORTIE	REGLAGE DU TUNER	POINTS DE L'ALIGNEMENT	ALIGNER POUR	FIG.
SECTION MF		SELECTEUR : FM	FM MODE : AUTO/MUTING				
1	DISCRIMINA-TEUR (1)	(A) 100,1MHz 1kHz $\pm$ 75kHz dév 60dB (Entrée ANT)	Connecter un voltmètre CC sur R13.	MONO 100,1MHz	L1	0V	(a)
2	DISCRIMINA-TEUR (2)	(A) 100,1MHz 1kHz $\pm$ 75kHz dév 60dB (Entrée ANT)	(B)	MONO 100,1MHz	L2	Distorsion minimale.	
Répéter les points 1 et 2 plusieurs fois.							
3	OSCILLATEUR CONTROLE PAR LA TENSION	(A) 100,1MHz 0 dév 60dB (Entrée ANT)	Connecter un compteur de fréquence à la fiche 9 de IC2.	100,1MHz	VR2	19,00kHz	(b)
4	SEPARATION	(C) 100,1MHz 1kHz $\pm$ 68,25kHz dév Sélection : L ou R Signal pilote : $\pm$ 6,75kHz dév 60dB (Entrée ANT)	(B)	100,1MHz	VR1	Diaphonie minimale. Un compromis de réglage peut être nécessaire si les séparations de gauche à droite et de droite à gauche sont inégales.	
5	DISTORSION (STEREO)	(C) 100,1MHz 1kHz $\pm$ 68,25kHz dév Sélection : L ou R Signal pilote : $\pm$ 6,75kHz dév 60dB (Entrée ANT)	(B)	100,1MHz	T1 (Tête H.F.)	Distorsion minimale. (Répéter les points 1 et 2 plusieurs fois)	
SECTION MA		SELECTEUR : AM	Laisser l'antenne bouche MA installée.				
(1)	BORD DE BANDE (1)	—	Connecter un voltmètre CC au terminal 7.	1620kHz (1611kHz)	L4	9,0V	(c)
(2)	ALIGNEMENT H.T. (1)	(D) 630kHz 400Hz, 30% mod	(B)	630kHz	L3, 5	Amplitude et symétrie maximale de l'affichage de l'oscilloscope.	
(3)	ALIGNEMENT H.T. (2)	(D) 1440kHz 400Hz, 30% mod	(B)	1440kHz	TC1	Amplitude et symétrie maximale de l'affichage de l'oscilloscope.	
Répéter les points (3) et (4) plusieurs fois.							

ABGLEICH

NR.	GEGENSTAND	EINGANGS-EINSTELLUNG	AUSGANG-EINSTELLUNG	TUNER EINSTELLUNG	ABGLEICHE PUNKTE	ABGLEICHEN FÜR	ABB.
UKW-EMPFANGSABTEILUNG		WÄHLER : FM		FM MODE : AUTO/ MUTING			
1	DISKRIMINATOR (1)	(A) 100,1MHz 1kHz $\pm$ 75kHz Hub 60dB (ANT-Eingang)	Einen Gleichspannungs über R13 anschließen.	MONO 100,1MHz	L1	0V	(a)
2	DISKRIMINATOR (2)	(A) 100,1MHz 1kHz $\pm$ 75kHz Hub 60dB (ANT-Eingang)	(B)	MONO 100,1MHz	L2	Minimaler Klirrfaktor	
Abstimmungen 1 und 2 mehrere Male wiederholen.							
3	SPANNUNGS-GEREGELTER OSZILLATOR	(A) 100,1MHz 0 Hub 60dB (ANT-Eingang)	Einen Frequenzmesser zum Stift 9 von IC2 anschließen.	100,1MHz	VR2	19,00kHz	(b)
4	STEREO KANAL TRENNUNG	(C) 100,1MHz 1kHz $\pm$ 68,25kHz Hub Wähler : L oder R Piloton : $\pm$ 6,75kHz Hub 60dB (ANT-Eingang)	(B)	100,1MHz	VR1	Minimales Übersprechen. Eine Ausgleichregelung kann notwendig sein, falls links-zu-rechts und rechts-zu-links Trennungen ungleich sind.	
5	KLIRRFAKTOR (STEREO)	(C) 100,1MHz 1kHz $\pm$ 68,25kHz Hub Wähler : L oder R Piloton : $\pm$ 6,75kHz Hub 60dB (ANT-Eingang)	(B)	100,1MHz	T1 (Frontende)	Minimaler Klirrfaktor. (Abstimmungen 1 und 2 mehrere Male wiederholen)	
MW-EMPFANGSABTEILUNG		Die MW-Rahmenantenne angebracht lassen.					
(1)	BANDKANTE (1)	—	Einen Gleichstromspannungsmesser zu Klemme 7 anschließen.	1620kHz (1611kHz)	L4	9,0V	(c)
(2)	HF-ABGLEICH (1)	(D) 630kHz 400Hz, 30% mod	(B)	630kHz	L3, 5	Maximale amplitude und Symmetrie des Oszilloskopbildes.	
(3)	HF-ABGLEICH (2)	(D) 1440kHz 400Hz, 30% mod	(B)	1440kHz	TC1	Maximale amplitude und Symmetrie des Oszilloskopbildes.	
Abstimmungen (3) und (4) mehrere Male wiederholen.							

PC BOARD


RECEIVER (X14-1370-10) Component side view



Refer to the schematic diagram for the values of resistors and capacitors.
The PC board drawing is viewed from the side easy to check.


PC BOARD

SYNTHESIZER (X14-1380-10) Component side view




Refer to the schematic diagram for the values of resistors and capacitors.
The PC board drawing is viewed from the side easy to check.


2SC1675
2SC1841
JA101(P)
JC501(P)




2SD330




AN6552
μPB553AC




HA11225




μPC1235C





STK-460A



LA1245




μPD1703C-018



E	F	G	H
---	---	---	---



KR-810



SPECIFICATIONS

Audio section

Power Output

23 watts* per channel minimum RMS, both channel driven at 8 ohms from 20 Hz to 20,000 Hz with no more than 0.07% total harmonic distortion.

Total Harmonic Distortion

(20 Hz to 20,000 Hz from TAPE)
rated power into 8 ohms 0.07%
1 watt power into 8 ohms 0.03%

Intermodulation Distortion

(60 Hz:7 kHz=4:1 SMPTE)
rated power into 8 ohms 0.07%

Slew Rate ± 40 V/ μ sec

Rise Time 3 μ sec

Damping Factor (at 8 ohms
1 kHz) 50

Input Sensitivity/Impedance

PHONO 2.5 mV/50 k ohms

TAPE 150 mV/50 k ohms

Signal to Noise Ratio (A weighted)

PHONO 72 dB for 2.5 mV input

78 dB for 5.0 mV input

TAPE 100 dB for 150 mV input

Maximum PHONO Input Level

at 1,000 Hz 150 mV (rms),

THD 0.07%

Frequency Response

PHONO RIAA Standard

Curve 20 Hz to 20,000 Hz

± 0.3 dB

TAPE 5 Hz to 100 kHz

± 3 dB

Tone Control

Bass ± 8 dB at 100 Hz

Treble ± 8 dB at 10 kHz

Loudness Control

(VOL. -30dB) +10 dB at 100 Hz

Output Level/Impedance

TAPE REC Out (Pin) 150 mV/1 k ohms

FM tuner section

Usable Sensitivity 10.8 dBf (1.9 μ V)

50 dB Quietest Sensitivity

Mono 17.3 dBf (4.0 μ V)

Stereo 37.5 dBf (40.0 μ V)

Signal to Noise Ratio at 65 dBf

Mono 75 dB

Stereo 71 dB

Total Harmonic Distortion at

1,000 Hz

Mono 0.1%

Stereo 0.15%

Frequency Response 30 Hz to 15,000 Hz,

+0.5 dB, -2.0 dB

Capture Ratio 1 dB

Image Rejection Ratio 45 dB

Spurious Response Ratio 85 dB

IF Response Ratio 95 dB

Alternate Channel Selectivity 50 dB at 400 kHz

AM Suppression Ratio 50 dB

Stereo Separation Ratio

at 1,000 Hz 45 dB

at 50 Hz to 10,000 Hz 3.3 dB

Subcarrier Product Ratio 53 dB

Antenna Impedance 300 ohms balanced &

75 ohms unbalanced

FM Frequency Range 88 MHz to 108 MHz

AM tuner section

Usable Sensitivity 10 μ V

Signal to Noise Ratio 50 dB

Image Rejection 40 dB

Selectivity 30 dB

GENERAL

Power Consumption 1.6 A

18 watts at no signal

Switched x 1

Unswitched x 1

Dimensions W440 mm (17-5/16")

H 108 mm (4-1/4")

D 245 mm (9-41/64")

Net Weight 4.5 kg (10.6 lb)


Gross Weight 5.4 kg (11.9 lb)

* Measured pursuant to Federal Trade Commission's Trade Regulation rule on Power Output Claims for Amplifier in U.S.A.


Kenwood follows a policy of continuous advancements in development. For this reason specifications may be changed without notice.

Kenwood poursuit une politique de progrès constants en ce qui concerne le développement. Pour cette raison, les spécifications sont sujettes à modifications sans préavis.

Kenwood strebt ständige Verbesserungen in der Entwicklung an. Daher bleiben Änderungen der technischen Daten jederzeit vorbehalten.



EXPLODED VIEW



PARTS LIST

★ New Parts

Parts without **Parts No.** are not supplied.Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.Teile ohne **Parts No.** werden nicht geliefert.

Ref. No. 参照番号	Parts No. 部品番号	Description 部品名 / 規格	Re- marks 備考
KR-810/815 (UNIT)			
1 3B	NO STOCK	METALLIC FRAME	
2 2A	NO STOCK	METALLIC FRAME	
3 2B	NO STOCK	SUB PANEL ASSY	
4 1B	NO STOCK	REAR PANEL	
5 3B	NO STOCK	BOTTOM PLATE	
11 1A	A01-0451-02	METALLIC CABINET	*
12 3A	A20-3269-02	FRONT PANEL ASSY	*K
12 3A	A20-3269-02	FRONT PANEL ASSY	PU
12 3A	A20-3269-02	FRONT PANEL ASSY	MH
12 3A	A20-3269-02	FRONT PANEL ASSY	UE
12 3A	A20-3269-02	FRONT PANEL ASSY	XE
12 3A	A20-3270-02	FRONT PANEL ASSY	*T
-	B46-0055-30	WARRANTY CARD	P
-	B46-0060-00	WARRANTY CARD	T
-	B46-0061-30	WARRANTY CARD	K
-	B46-0062-30	WARRANTY CARD	UH
-	B46-0062-30	WARRANTY CARD	UE
-	B46-0063-13	WARRANTY CARD MILITARY	UH
-	B46-0063-13	WARRANTY CARD MILITARY	UE
-	B46-0064-20	WARRANTY CARD	X
-	B46-0078-03	WARRANTY CARD	E
-	B50-4430-00	INSTRUCTION MANUAL	*K
-	B50-4431-00	INSTRUCTION MANUAL	*P
-	B50-4431-00	INSTRUCTION MANUAL	UM
-	B50-4431-00	INSTRUCTION MANUAL	HX
-	B50-4431-00	INSTRUCTION MANUAL	UE
-	B50-4432-00	INSTRUCTION MANUAL	*P
-	B50-4432-00	INSTRUCTION MANUAL	MX
-	B50-4433-00	INSTRUCTION MANUAL	*M
-	B50-4434-00	INSTRUCTION MANUAL	*T
-	B50-4435-00	INSTRUCTION MANUAL	*E
13 3A	B10-0349-04	FRONT GLASS	*
14 2B	C91-0023-05	CERAMIC 0.01UF AC250V	UM
14 2B	C91-0023-05	CERAMIC 0.01UF AC250V	HX
14 2B	C91-0023-05	CERAMIC 0.01UF AC250V	UE
14 2B	C91-0079-05	CERAMIC 0.01UF AC125V	KP
14 2B	C91-0079-05	CERAMIC 0.01UF AC125V	TE
-	E04-0006-05	COAXIAL CONNECTOR	TE
-	E06-0514-05	CYLINDRICAL RECEPTACLE	TE
-	E20-0228-05	TERMINAL BOARD	TE
15 1B	E03-0036-05	AC OUTLET	KP
15 1B	E03-0036-05	AC OUTLET	UM
15 1B	E03-0036-05	AC OUTLET	HX
15 1B	F03-0036-05	AC OUTLET	UE
16 1B	E30-0181-05	POWER CORD	KP
16 1B	E30-0459-05	POWER CORD	E
16 1B	E30-0545-05	POWER CORD	UM
16 1B	E30-0545-05	POWER CORD	UE
16 1B	E30-0545-05	POWER CORD	H
16 1B	E30-0587-15	POWER CORD	T
16 1B	E30-0649-05	POWER CORD	X
17 1A	F07-0428-03	COVER (BATTERY)	*
-	H01-3452-04	CARTON BOX	*K
-	H01-3452-04	CARTON BOX	PU
-	H01-3452-04	CARTON BOX	MH
-	H01-3452-04	CARTON BOX	UE
-	H01-3452-04	CARTON BOX	XE

Ref. No. 参照番号	Parts No. 部品番号	Description 部品名 / 規格	Re- marks 備考
-	H01-3453-04	CARTON BOX	*T
-	H10-1619-02	POLYSTYRENE FIXTURE	*
-	H20-0462-04	COVER	
-	H25-0078-04	BAG (235X315)	
18 3B	J02-0343-05	FOOT	
19 1B	J19-0626-02	ANTENNA HOLDER	
20 1B	J19-0654-03	BATTERY HOLDER	*
21 1B	J42-0083-05	BUSHING	KP
21 1B	J42-0083-05	BUSHING	UM
21 1B	J42-0083-05	BUSHING	HT
21 1B	J42-0083-05	BUSHING	UE
21 1B	J42-0083-05	BUSHING	X
21 1B	J42-0085-05	BUSHING	
25 2A	K27-0656-14	KNOB POWER	
26 3A	K27-0715-04	KNOB TAPE	
27 2A	K27-0716-04	KNOB TUNER	
28 2A	K27-0717-04	KNOB PRESET	
29 3A	K27-0718-04	KNOB UP,DOWN	
30 2A	K27-0719-04	KNOB MEMORY	
31 3A	K29-0463-04	KNOB TONE	
32 3A	K29-0464-04	KNOB VOL.	
33 1A	L01-2781-05	POWER TRANS	*K
33 1A	L01-2786-05	POWER TRANS	*T
33 1A	L01-2786-05	POWER TRANS	E
33 1A	L01-2787-05	POWER TRANS	*U
33 1A	L01-2787-05	POWER TRANS	MH
33 1A	L01-2787-05	POWER TRANS	UE
33 1A	L01-2787-05	POWER TRANS	X
33 1A	L01-2788-05	POWER TRANS	*P
35 1B	N08-0128-35	GND TERMINAL	
-	S31-2050-05	SLIDE SWITCH	UM
-	S31-2050-05	SLIDE SWITCH	HX
-	S31-2050-05	SLIDE SWITCH	UE
-	S31-2050-05	SLIDE SWITCH	E
36 2B	S40-1022-05	PUSH SWITCH	UM
36 2B	S40-1022-05	PUSH SWITCH	HX
36 2B	S40-1022-05	PUSH SWITCH	UE
36 2B	S40-1024-05	PUSH SWITCH	KP
36 2B	S40-1025-05	PUSH SWITCH	TE
-	T90-0122-05	ANTENNA ADP.	
-	T90-0202-05	FM INDOOR ANTENNA	
40 1B	T90-0104-15	LOOP ANTENNA	TE
41 2B	X14-1370-10	RECEIVER PCB ASSY	*K
41 2B	X14-1370-10	RECEIVER PCB ASSY	P
41 2B	X14-1370-51	RECEIVER PCB ASSY	*T
41 2B	X14-1370-81	RECEIVER PCB ASSY	*U
41 2B	X14-1370-81	RECEIVER PCB ASSY	MH
41 2B	X14-1370-81	RECEIVER PCB ASSY	UE
41 2B	X14-1370-81	RECEIVER PCB ASSY	X
41 2B	X14-1372-71	RECEIVER PCB ASSY	*E
42 2A	X14-1380-10	SYNTHESIZER PCB ASSY	*K
42 2A	X14-1380-10	SYNTHESIZER PCB ASSY	P
42 2A	X14-1380-51	SYNTHESIZER PCB ASSY	*T
42 2A	X14-1380-51	SYNTHESIZER PCB ASSY	E
42 2A	X14-1380-81	SYNTHESIZER PCB ASSY	*U
42 2A	X14-1380-81	SYNTHESIZER PCB ASSY	MH
42 2A	X14-1380-81	SYNTHESIZER PCB ASSY	UE
42 2A	X14-1380-81	SYNTHESIZER PCB ASSY	X

E : Scandinavia & Europe H : Audio Club K : USA P : Canada

S : South Africa T : England U : PX (Far East, Hawaii)

UE : AAFES (Europe) X : Australia M : Other Areas

PARTS LIST

★ New Parts

Parts without **Parts No.** are not supplied.

Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.

Teile ohne **Parts No.** werden nicht geliefert.

Ref. No. 参照番号	Parts No. 部品番号	Description 部品名 / 規格	Re- marks 備考
RECEIVER (X14-1370-10)			
C1	C55-1722-38	CERAMIC 0.022UF Z	TE
C2	C24-1222-77	ELECTRO 220UF 16WV	
C3 ,4	C91-0083-05	CERAMIC 0.01UF N	
C5	C24-1222-67	ELECTRO 22UF 16WV	
C6 -8	C91-0085-05	CERAMIC 0.022UF N	TE
C9	C24-1710-57	ELECTRO 1UF 50WV	
C10	C52-1733-16	CERAMIC 330PF K	
C11	C91-0085-05	CERAMIC 0.022UF N	
C12	C24-1747-47	ELECTRO 0.47UF 50WV	TE
C13 ,14	C91-0083-05	CERAMIC 0.01UF N	
C15	C24-1747-47	ELECTRO 0.47UF 50WV	
C16	C91-0083-05	CERAMIC 0.01UF N	
C17	C24-1247-67	ELECTRO 47UF 16WV	TE
C18 ,19	C24-1210-67	ELECTRO 10UF 16WV	
C20	C26-1247-57	NP-ELEC 4.7UF 16WV	
C40	C24-1210-77	ELECTRO 100UF 16WV	TE
C41 ,42	C24-1210-67	ELECTRO 10UF 16WV	
C43 ,44	C46-1747-26	MYLAR 0.0047UF K	
C45 ,46	C46-1715-26	MYLAR 0.0015UF K	
C45 ,46	C46-1722-26	MYLAR 0.0022UF K	TE
C47	C24-1722-57	ELECTRO 2.2UF 50WV	
C48	C24-1722-57	ELECTRO 2.2UF 50WV	
C49	C46-1747-36	MYLAR 0.047UF K	
C50	C47-1747-15	POLYSTY 470PF J	TE
C51	C24-1710-57	ELECTRO 1UF 50WV	
C52	C24-1710-57	ELECTRO 1UF 50WV	
C53	C24-1710-57	ELECTRO 1UF 50WV	
C54	C71-1768-05	CERAMIC 68PF J	TE
C55 ,56	C24-1747-57	ELECTRO 4.7UF 50WV	
C57	C26-1422-57	NP-ELEC 2.2UF 25WV	
C58	C24-1222-67	ELECTRO 22UF 16WV	
C80	C24-1210-77	ELECTRO 100UF 16WV	TE
C81	C55-1722-38	CERAMIC 0.022UF Z	
C82	C91-0083-05	CERAMIC 0.01UF N	
C83	C53-1710-27	CERAMIC 0.001UF M	
C84	C91-0085-05	CERAMIC 0.022UF N	TE
C85	C24-1247-67	ELECTRO 47UF 16WV	
C86	C55-1722-38	CERAMIC 0.022UF Z	
C87	C70-1722-05	CERAMIC 22PF J	
C88	C47-1743-15	POLYSTY 430PF J	TE
C89	C55-1747-38	CERAMIC 0.047UF Z	
C90	C24-1747-57	ELECTRO 4.7UF 50WV	
C91	C24-1710-57	ELECTRO 1UF 50WV	
C92	C91-0083-05	CERAMIC 0.01UF N	TE
C93	C24-1710-57	ELECTRO 1UF 50WV	
C94	C55-1722-38	CERAMIC 0.022UF Z	
C95	C46-1710-26	MYLAR 0.001UF K	
C96	C46-1722-36	MYLAR 0.022UF K	TE
C97	C91-0083-05	CERAMIC 0.01UF N	
C98	C53-1710-27	CERAMIC 0.001UF M	
C99	C46-1739-36	MYLAR 0.039UF K	
C101,102	C71-1733-05	CERAMIC 33PF J	TE
C103,104	C25-6533-57	LL-ELEC 3.3UF 35WV	
C105,106	C71-1718-15	CERAMIC 180PF J	
C107,108	C52-1722-26	CERAMIC 0.0022UF K	
C109,110	C24-1047-67	ELECTRO 47UF 10WV	TE
C111,112	C46-1733-25	MYLAR 0.0033UF J	
C113,114	C46-1712-35	MYLAR 0.012UF J	
C115,116	C25-1722-57	LL-ELEC 2.2UF 50WV	
C117,118	C24-1210-77	ELECTRO 100UF 16WV	TE

Ref. No. 参照番号	Parts No. 部品番号	Description 部品名 / 規格	Re- marks 備考
C119-125	C52-1756-16	CERAMIC 560PF K	E KU T E
C123-125	C52-1756-16	CERAMIC 560PF K	
C123-125	C52-1756-16	CERAMIC 560PF K	
C126	C55-1722-38	CERAMIC 0.022UF Z	
C127,128	C46-1718-36	MYLAR 0.018UF K	E KU T
C129,130	C25-1722-57	LL-ELEC 2.2UF 50WV	
C131,132	C52-1747-16	CERAMIC 470PF K	
C133,134	C71-1710-15	CERAMIC 100PF J	
C135,136	C71-1702-01	CERAMIC 2PF C	E E KU T
C135,136	C71-1702-01	CERAMIC 2PF C	
C135,136	C71-1705-01	CERAMIC 5PF C	
C137,138	C71-1701-01	CERAMIC 1PF C	
C137,138	C71-1703-01	CERAMIC 3PF C	E KU T
C137,138	C71-1703-01	CERAMIC 3PF C	
C139,140	C24-1447-67	ELECTRO 47UF 25WV	
C141,142	C24-1210-67	ELECTRO 10UF 16WV	E KU T
C143,144	C24-1010-77	ELECTRO 100UF 10WV	
C145,146	C26-1210-67	NP-ELEC 10UF 16WV	
C147,148	C46-1747-26	MYLAR 0.0047UF K	
C149,150	C46-1715-36	MYLAR 0.015UF K	E KU T
C151,152	C46-1768-36	MYLAR 0.068UF K	
C153,154	C52-1733-16	CERAMIC 330PF K	
C155,156	C46-1715-26	MYLAR 0.0015UF K	
C157,158	C46-1722-36	MYLAR 0.022UF K	E KU T
C159	C24-6510-67	ELECTRO 10UF 35WV	
C160	C24-6522-77	ELECTRO 220UF 35WV	
C161	C24-1710-57	ELECTRO 1UF 50WV	
C162	C24-6547-67	ELECTRO 47UF 35WV	E KU T
C163	C24-1747-57	ELECTRO 4.7UF 50WV	
C164	C24-6533-67	ELECTRO 33UF 35WV	
C165	C24-6510-67	ELECTRO 10UF 35WV	
C166	C24-1710-67	ELECTRO 10UF 50WV	E KU T
C167,168	C90-0412-05	ELECTRO 6800UF 35WV	
C169,170	C54-2710-39	CERAMIC 0.01UF P	
C171,172	C46-1747-36	MYLAR 0.047UF K	
C173	C24-1247-67	ELECTRO 47UF 16WV	E KU T
C174	C24-1010-77	ELECTRO 100UF 10WV	
C175,176	C52-1722-26	CERAMIC 0.0022UF K	
C177	C24-1810-67	ELECTRO 10UF 63WV	
C178	C55-1747-38	CERAMIC 0.047UF Z	E KU T
TC1	C05-0088-05	TRIMMER CAPACITOR	
-	E23-0104-05	TERMINAL	
100 2A	F11-0105-05	PHONE JACK	* TE
101 2B	E13-0432-05	PHONO JACK	
102 2B	E13-0618-05	PHONO JACK	
103 2B	E20-0438-05	TERMINAL BOARD ANT	
104 2B	E20-0450-05	TERMINAL BOARD SPEAKER	* TE
F1	F05-2023-05	FUSE 250V 2A	
F1	F05-2029-05	FUSE 250V F2A	
F1	F06-2027-05	FUSE 250V 2A	
F2	F05-1023-05	FUSE 250V 1A	* TE
F2	F06-1021-05	FUSE 250V F1A	
-	J13-0055-05	FUSE HOLDER	
-	L79-0147-05	FILTER KIT	
CF1	L72-0133-05	CERAMIC FILTER	TE TE KU TE
CF1 ,2	L72-0138-05	CERAMIC FILTER	
CF2	L72-0128-05	CERAMIC FILTER	
CF3	L72-0099-05	CERAMIC FILTER	
CF4	L72-0096-05	CERAMIC FILTER	TE TE KU TE
L1	L30-0327-15	IFT	

For RECEIVER

K : X14-1370-10

U : X14-1370-81

T : X14-1370-51

E : X14-1372-71

PARTS LIST

★ New Parts

Parts without **Parts No.** are not supplied.Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.Teile ohne **Parts No.** werden nicht geliefert.

Ref. No. 参照番号	Parts No. 部品番号	Description 部品名 / 規格	Re- marks 備考
L2	L30-0328-05	IFT	TE
L3	L31-0455-05	RF COIL	
L4	L32-0258-05	OSCILLATING COIL	
L5	L30-0362-05	IFT	
L6	L79-0109-05	FILTER L.P.F	
L7	L79-0140-05	FILTER	
R2	R42-1268-05	FL-PROOF RD68 J 2E	TE
R8	R42-1210-15	FL-PROOF RD100 J 2E	
R16	R42-1210-15	FL-PROOF RD100 J 2E	
R40	R42-1210-15	FL-PROOF RD100 J 2E	
R85	R42-1210-15	FL-PROOF RD100 J 2E	
R86	R42-1215-15	FL-PROOF RD150 J 2E	TE
R119,120	R42-1210-15	FL-PROOF RD100 J 2E	
R135,136	R40-8333-26	RC 3,3K K 2H	
R143,144	R92-0166-05	METAL-PLATE0,22 K 3D	
R155	R43-1247-95	FL-PROOF RD4,7 J 2E	
R158	R42-1247-95	FL-PROOF RD4,7 J 2E	UT E K
R161,162	R47-5456-15	FL-PROOF RS560 J 3A	
R163	R42-1222-25	FL-PROOF RD2,2K J 2E	
R165	R47-5422-25	FL-PROOF RS2,2K J 3A	
R166	R40-8312-26	RC 1,2K K 2H	
R167	R43-1247-95	FL-PROOF RD4,7 J 2E	
R167	R43-1247-95	FL-PROOF RD4,7 J 2E	K TE KU
R167	R92-0514-05	FUSE-RESIST4,7 2E	
R168	R47-5533-15	FL-PROOF RS330 J 3D	
R175,176	R47-5447-95	FL-PROOF RS4,7 J 3A	
R177	R92-0173-05	RC 2,2M M 2H	
VR1	R12-4302-05	TRIMMING POT, 50K	
VR1	R12-5302-05	TRIMMING POT, 100K	U K *
VR2	R12-2302-05	TRIMMING POT, 5K	
VR3	R06-5068-05	POTENTIOMETER VOL.	
VR4,5	R06-4057-05	POTENTIOMETER TONE.	
VR6	R01-5038-05	POTENTIOMETER BAL.	
S1	S42-2064-15	PUSH SWITCH	K TE KU
S2,3	S31-2072-05	SLIDE SWITCH	
S3	S31-2072-05	SLIDE SWITCH	
S4	S29-4012-05	ROTARY WAFER SWITCH	
S5	S40-2153-15	PUSH SWITCH	
S6	S42-2076-05	PUSH SWITCH	
D1	V11-1200-80	1SS53	KU TE KU TE
D1-4	V11-1200-80	1SS53	
D3-8	V11-1200-80	1SS53	
D6-8	V11-1200-80	1SS53	
D9	V11-7702-50	KV1236(Z1)	
D10	V11-1200-80	1SS53	
D11-14	V11-1301-40	S2V20*1	K UT K
D15,16	V11-0295-05	W06B	
D17	V11-4108-50	WZ-250	
D18	V11-1200-80	1SS53	
D19	V11-0254-05	YZ-140	
D20	V11-4103-60	XZ-051	
D21	V11-0295-05	W06B	*
D22,23	V11-1200-80	1SS53	
D24	V11-4101-20	XZ-060	
IC1	V30-0321-10	HA11225	
IC2	V30-0688-10	UPC1235C	
IC3	V30-0519-10	LA1245	*
IC4	V30-0836-10	STK-460A	
IC5	V30-0405-10	AN6552	
Q1	V03-1675-00	Z5C1675	

For RECEIVER

K : X14-1370-10

U : X14-1370-81

T : X14-1370-51

E : X14-1372-71

Ref. No. 参照番号	Parts No. 部 品 番 号	Description 部 品 名 / 規 格	Re- marks 備考	
Q2 -5 Q4 ,5 Q6 Q7 Q8	V08-0289-10 V08-0289-10 V08-0287-10 V08-0289-10 V08-0287-10	JC501(P) JC501(P) JA101(P) JC501(P) JA101(P)	TE KU	
Q9 -12 Q13 ,14 Q15 Q16 ,17	V08-0289-10 V08-0287-10 V04-0330-00 V08-0289-10	JC501(P) JA101(P) ZSD330 JC501(P)		
- - - -	W02-0507-05 W02-0507-05 W02-0508-05 W02-0508-05	FM FRONT END FM FRONT END FM FRONT END FM FRONT END		*K U *T E
SYNTHESIZER (X14-1380-10)				
D30 D31 D32 -34	B30-0379-05 B30-0378-05 B30-0231-05	LAMP LAMP LAMP	* * 	


For SYNTHESIZER

K : X14-1380-10

U : X14-1380-81

T : X14-1380-51

WORLD MAP & AREA CODE



Note:

Component and circuitry are subject to modification to insure best operation under differing local conditions. This manual is based on, the U.S. (K) standard, and provides information on regional circuit modification through use of alternate schematic diagrams, and information on regional component variations through use of parts list.

A product of

TRIO-KENWOOD CORPORATION

Shionogi Shibuya Building, 17-5, 2-chome Shibuya, Shibuya-ku, Tokyo 150 Japan

KENWOOD U.S.A. CORPORATION

1315 E. Watsoncenter Rd, Carson, California 90745, U.S.A.
75 Seaview Drive, Secaucus, New Jersey 07094, U.S.A.

TRIO-KENWOOD CANADA INC.

1070 Jayson Court, Mississauga, Ontario, Canada L4W 2V5

TRIO-KENWOOD ELECTRONICS, N.V.

Leuvensesteenweg 504, B-1930 Zaventem, Belgium

TRIO-KENWOOD ELECTRONICS, GmbH

Rudolf-Braas-Str. 20, 6056 Heusenstamm, West Germany

TRIO-KENWOOD FRANCE S.A.

5, Boulevard Ney, 75018 Paris, France

TRIO-KENWOOD AG

Unterboesch 6331 Huenenberg/ZUG Switzerland

TRIO-KENWOOD (AUSTRALIA) PTY. LTD.

4E Woodcock Place, Lane Cove, N.S.W. 2066, Australia

KENWOOD & LEE ELECTRONICS, LTD.

Wang Kee Building, 5th Floor, 34-37, Connaught Road, Central, Hong Kong