

Service Manual

74 PM34/00B/01B/02B/05B

Integrated stereo amplifier

This service manual explains them by extracting the different specifications from those of the model PM-34, based on the model PM-32/ (PM-30). For both electrical and mechanical information on the after-sales service which is not stated, all information is described in the model PM-32/ (PM-30) service manual (Code number 4822 725 50971/4822 725 50912). The dispatch of the parts for after-sales service has to be referred to this service manual, with the first priority.

For this reason, please use this service manual with referring to the model PM-32/ (PM-30) service manual, without fail.

marantz®

model PM-34

4822 725 51071

First Issue : 1994/9

PCS 79 456

DIFFERENT PARTS BETWEEN PM-32/(PM-30) AND PM-34

PAGE	REF. DESIG.	PM-32/(PM-30)	PM-34	DESCRIPTION
		PART NO.	PART NO.	
14	001B	4822 425 40184	4822 425 60159	FRONT PANEL ASSEMBLY KNOB,VOLUME KNOB,SELECTOR USER MANUAL
	010B	4822 413 41544	4822 413 41679	
	011B	4822 413 41545	4822 413 41681	
	001T	4822 736 21419	4822 736 22195	
	▲ J091	4822 272 10227	4822 272 10382	
16	LN51	4822 280 20196	4822 280 20469	VOLTAGE SELECTOR /01B RELAY,SVR – 24A

