



23. 24. 27. 52. 25. 3. 10. 30 34a. 34. 33. 16. 31. 32. 44. 40. 39. 37. 38. 50. 41. . 42. 43. 49 79.
 0.38. 39. 86. 42. 41. 43. 87. 46. 85. 9. 45. 83. 84. 44. 26. 49. 52. 53. 50. 75. 34. 48. 54. 51. 55. 67. 76. 56. 57. 58. 59. 60. 61. 64. 62. 63. 77. 66. 78. 68. 69. 65. 70.



EL78B
PHILIPS: N4 306

C 2. 1 4. 5. 79. 8. 51. 11. 12. 13. 15. 14. 16. 72. 71. 18. 20. 80. 82. 88. 19. 21. 22. 28. 25. 23. 24. 27. 29. 30. 32. 33. 35. 20. 48. 26. 23. 24. 27.

R 90. 5. 1. 6. 4. 2. 8. 7. 81. 3. 10. 11. 15. 14. 12. 13. 17. 16. 72. 71. 18. 20. 80. 82. 88. 19. 21. 22. 28. 25. 23. 24. 27. 29. 30. 32. 33. 35. 36. 37. 73. 74. 40. 38. 39. 86.



1W ± 5%

I = ③ → recording VI manual

1/2W ± 1%

II = ③ ← play back VII aut. ○

1/8W ± 5%

III = 1-4 VIII aut. ○

1/4W ± 5%

IV = 2-3

V = par.

500V ± 20%

① = SK1

400V ± 10%

② = SK2

③ = SK3

④ = SK4

⑤ = SK5

