

Service Manual

ORDER NO.
RRV2891

DJ MIXER

DJM-300-S

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Type	Model	Power Requirement	The voltage can be converted by the following method.
	DJM-300-S		
SAXCN	○	AC110V/ 120V/ 220-230V/ 240V	With the voltage selector

- This service manual should be used together with the following manual(s):

Model No.	Order No.	Remarks
DJM-300/SYL	RRV1711	

1. CONTRAST OF MISCELLANEOUS PARTS

NOTES: • Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.

- The \triangle mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.

- Screws adjacent to ∇ mark on product are used for disassembly.

- Reference Nos. indicate the pages and Nos. in the service manual for the base model.

- When ordering resistors, first convert resistance values into code form as shown in the following examples.

Ex.1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47k ohm (tolerance is shown by J=5%, and K=10%).

560 \rightarrow $56 \times 10^1 \rightarrow 561$ RD1/4PU[5][6][J]J

47k \rightarrow $47 \times 10^3 \rightarrow 473$ RD1/4PU[4][7][3]J

0.5 \rightarrow R50 RN2H[R][5][0]K

1 \rightarrow 1R0 RS1P[1][R][0]K

Ex.2 When there are 3 effective digits (such as in high precision metal film resistors).

5.62k \rightarrow $562 \times 10^1 \rightarrow 5621$ RN1/4PC[5][6][2][1]F

■ CONTRAST TABLE

DJM-300-S/ SAXCN and DJM-300/ SYL are constructed the same except for the following :


Ref. No.	Mark	Symbol and Description	Part No.		Remarks
			DJM-300/ SYL	DJM-300-S/ SAXCN	
P3 - 5 P3 - 7	NSP	PACKING Packing Case	DHG1736	DHG2417	
		Operating Instructions (English/ French/ German/ Italian/ Dutch/ Swedish/ Spanish/ Chinese)	DRB1207	Not used	
P3 - 7 P3 - 11		Operating Instructions (Chinese/ English) Caution Card 220V	Not used ARR7003	DRB1363 Not used	
P5 - 9 P5 - 13	NSP	EXTERIOR AC Power Cord	PDG1003	PDG1073	
		Rear Panel	DNC1639	DNC1691	
		Label	Not used	VRW1739	No.1
	NSP	CCC S&E Label	Not used	VRW1945	No.2
P7 - 13 P7 - 24 P7 - 25	NSP	FRONT PANEL SECTION CF Cover	DEC2039	DEC2537	
		Slider Panel	DAH1825	DAH1892	
		Control Panel	DNB1068	DNB1108	
		Washer	Not used	DEC2463	No.3

C Notes: The numbers in the remarks column correspond to the numbers on the " EXPLODED VIEWS ".

■ EXPLODED VIEWS

• EXTERIOR


No.1



[Rear]

• FRONT PANEL SECTION

No.3



Slider Panel