

Service Manual

ORDER NO.
RRV2618

DJ MIXER

DJM-600-K DJM-600-S

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Type	Model		Power Requirement	Remarks
	DJM-600-K	DMJ-600-S		
KUCXCN	○	-	AC120V	
WYXCN	-	○	AC220- 240V	

● **This service manual should be used together with the following manual(s):**

Model No.	Order No.	Remarks
DJM-600/ KUC, WY	RRV2234	

1. CONTRAST OF MISCELLANEOUS PARTS

NOTES: ● Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.

● The Δ mark found on some component parts indicates the importance of the safety factor of the part.

Therefore, when replacing, be sure to use parts of identical designation.

● Screws adjacent to ∇ mark on product are used for disassembly.

● Reference Nos. indicate the pages and Nos. in the service manual for the base model.

● When ordering resistors, first convert resistance values into code form as shown in the following examples.

Ex.1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47k ohm (tolerance is shown by J=5%, and K=10%).

560 $\rightarrow$ $56 \times 10^1 \rightarrow$ 561 RD1/4PU $\boxed{5}\boxed{6}\boxed{1}J$

47k $\rightarrow$ $47 \times 10^3 \rightarrow$ 473 RD1/4PU $\boxed{4}\boxed{7}\boxed{3}J$

0.5 $\rightarrow$ R50 RN2H $\boxed{R}\boxed{5}\boxed{0}K$

1 $\rightarrow$ 1R0 RS1P $\boxed{1}\boxed{R}\boxed{0}K$

Ex.2 When there are 3 effective digits (such as in high precision metal film resistors).

5.62k $\rightarrow$ $562 \times 10^1 \rightarrow$ 5621 RN1/4PC $\boxed{5}\boxed{6}\boxed{2}\boxed{1}F$

■ CONTRAST TABLE

DJM-600-K/KUCXCN and DJM-600/KUC are constructed the same except for the following :

Ref. No.	Mark	Symbol and Description	Part No.		Remarks
			DJM-600/ KUC	DJM-600-K/ KUCXCN	
P3 - 1	NSP	PACKING SECTION			No.1
P3 - 2		Pad A	DHA1456	DHA1541	
P3 - 3		Pad B	DHA1457	DHA1542	
P3 - 4		Pad C	DHA1458	DHA1543	
P3 - 5		Pad D	DHA1469	DHA1544	
P3 - 7		Packing Case	DHG1964	DHG2263	
P3 - 7		Operating Instructions (English, French)	DRB1251	DRB1319	
P5 - 25		EXTERIOR SECTION			
P7 - 47		Chassis	DNA1258	DNA1286	
P7 - 48		Washer	Not used	DEC2484	
P7 - 50		CONTROL PANEL SECTION			
P7 - 47		Slider Panel	DAH1945	DAH2105	
P7 - 48		Sub Panel	DAH1946	DAH2103	
P7 - 50		Control Panel	DNB1075	DNB1112	

Note: The numbers in the remarks column correspond to the numbers on the "EXPLODED VIEWS".

■ CONTRAST TABLE

DJM-600-S/WYXCN and DJM-600/WY are constructed the same except for the following :

Ref. No.	Mark	Symbol and Description	Part No.		Remarks
			DJM-600/ WY	DJM-600-S/ WYXCN	
P3 - 1	NSP	PACKING SECTION			No.1
P3 - 2		Pad A	DHA1456	DHA1541	
P3 - 3		Pad B	DHA1457	DHA1542	
P3 - 4		Pad C	DHA1458	DHA1543	
P3 - 5		Pad D	DHA1469	DHA1544	
P3 - 7		Packing Case	DHG1959	DHG2262	
P3 - 7		Operating Instructions (English, French, German, Italian, Dutch, Spanish)	DRB1252	DRB1317	
P5 - 25		EXTERIOR SECTION			
P7 - 47		Chassis	DNA1256	DNA1285	
P7 - 48		Washer	Not used	DEC2484	
P7 - 50		CONTROL PANEL SECTION			
P7 - 47		Slider Panel	DAH1955	DAH2104	
P7 - 48		Sub Panel	DAH1956	DAH2100	
P7 - 50		Control Panel	DNB1076	DNB1111	

Note: The numbers in the remarks column correspond to the numbers on the "EXPLODED VIEWS".

■ EXPLODED VIEWS

• EXTERIOR

