

# ***Service Manual***

ORDER NO.  
**RRV3474**

**DJ MIXER**

# **DJM-800**

**THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).**

Model	Type	Power Requirement	Remarks
DJM-800	WAXJ5	AC 220 to 240 V	

● **This service manual should be used together with the following manual(s):**

Model No.	Order No.	Remarks
DJM-800/KUCXJ	RRV3340	

● **For SPECIFICATIONS and PANEL FACILITIES, refer to the operating instructions.**

# 1. CONTRAST OF MISCELLANEOUS PARTS

**NOTES:** ● Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.

● The  $\Delta$  mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.

● Screws adjacent to  $\nabla$  mark on product are used for disassembly.

● Reference Nos. indicate the pages and Nos. in the service manual for the base model.

● For the applying amount of lubricants or glue, follow the instructions in this manual.

(In the case of no amount instructions, apply as you think it appropriate.)

● When ordering resistors, first convert resistance values into code form as shown in the following examples.

Ex.1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47k ohm (tolerance is shown by J=5%, and K=10%).

560  $\Omega$   $\rightarrow$   $56 \times 10^1$   $\rightarrow$  561 ..... RD1/4PU  $\begin{bmatrix} 5 \\ 6 \end{bmatrix} \begin{bmatrix} 1 \\ J \end{bmatrix}$

47k  $\Omega$   $\rightarrow$   $47 \times 10^3$   $\rightarrow$  473 ..... RD1/4PU  $\begin{bmatrix} 4 \\ 7 \end{bmatrix} \begin{bmatrix} 3 \\ J \end{bmatrix}$

0.5  $\Omega$   $\rightarrow$  R50 ..... RN2H  $\begin{bmatrix} R \\ 5 \end{bmatrix} \begin{bmatrix} 0 \\ K \end{bmatrix}$

1  $\Omega$   $\rightarrow$  1R0 ..... RS1P  $\begin{bmatrix} 1 \\ R \end{bmatrix} \begin{bmatrix} 0 \\ K \end{bmatrix}$

Ex.2 When there are 3 effective digits (such as in high precision metal film resistors).

5.62k  $\Omega$   $\rightarrow$   $562 \times 10^1$   $\rightarrow$  5621 ..... RN1/4PC  $\begin{bmatrix} 5 \\ 6 \end{bmatrix} \begin{bmatrix} 2 \\ 1 \end{bmatrix} F$

## ■ CONTRAST TABLE

DJM-800/WAXJ5 and DJM-800/KUCXJ are constructed the same except for the following :

Ref. No.	Mark	Symbol and Description	Part No.		Remarks
			DJM-800 /KUCXJ	DJM-800 /WAXJ5	
P7-5	△ NSP	<b>PACKING SECTION</b>			
P7-5		Instruction Manual (English)	DRB1393	Not used	
P7-6		Instruction Manual (English, Chinese)	Not used	DRB1395	
P7-8		Packing Case	DHG2559	DHG2603	
P7-11		Power Cord	DDG1028	ADG7105	
		Warranty Card	ARY7043	Not used	
		<b>EXTERIOR SECTION</b>			
P9-28	△ NSP	AC Inlet Assy	DKP3761	DKP3762	
P9-34		Rear Panel	DNC1800	DNC1793	
P9-55		Label	DRW2294	DRW2297	
P9-70		Caution Label	DRW1975	Not used	
	NSP	CCC S&E Label	Not used	DRW2310	
P9-71	NSP	Earth Label	DRW2276	Not used	
	NSP	Serial Label	DRW2311	VRW1629	