

Service Manual

ORDER NO.
RRV1967

FILE-TYPE CD PLAYER
PD-F807

● Refer to the service manual **RRV1898** for **PD-F907/KU**.

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Type	Model	Power Requirement	Remarks
	PD-F807		
KUXQ	○	AC120V	_____

■ CONTRAST OF MISCELLANEOUS PARTS

NOTES : • Parts marked by “ NSP ” are generally unavailable because they are not in our Master Spare Parts List.

- The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.

- Reference Nos. indicate the pages and Nos. in the service manual for the base model.

- When ordering resistors, first convert resistance values into code form as shown in the following examples.

Ex. 1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47k ohm (tolerance is shown by $J = 5\%$, and $K = 10\%$).

$560 \Omega \rightarrow 56 \times 10^1 \rightarrow 561$ RD1/4PU 5 6 1 J

$47k \Omega \rightarrow 47 \times 10^3 \rightarrow 473$ RD1/4PU 4 7 3 J

$0.5 \Omega \rightarrow R50$ RN2H R 5 0 K

$1 \Omega \rightarrow 1R0$ RS1P 1 R 0 K

Ex. 2 When there are 3 effective digits (such as in high precision metal film resistors).

$5.62k \Omega \rightarrow 562 \times 10^3 \rightarrow 5621$ RN1/4PC 5 6 2 1 F

■ CONTRAST TABLE

PD-F807/KUXQ and PD-F907/KU are constructed the same except for the following:

Ref. No.	Mark	Symbol and Description	Part No.		Remarks
			PD-F907/KU	PD-F807/KUXQ	
P6-4	NSP	ASSEMBLIES			
		MOTHER BOARD ASSY	PWM2119	PWM2124	
	NSP	└ SWITCH BOARD ASSY	PWZ3432	PWZ3434	
		PACKING			
P3-3		Remote Control Unit (CU-PD080)	PWW1132	Not used	
P3-4		Battery Cover	AZA7204	Not used	
P3-6		Operating Instructions(English)	PRB1263	PRB1275	
P3-8		Polyethylene Bag	Z21- 038	Not used	
P3-11		Packing Case	PHG2285	PHG2332	
P3-12	NSP	Mirror Mat	Z23- 020	Not used	
P3-12		Packing Sheet	Not used	PHF1001	
P3-13		Battery (R6P,AA)	VEM- 013	Not used	
P6-18	NSP	EXTERIOR			
P6-21		Rear Base	PNA2389	PNA2445	
P6-26		Back Fence	PNW2671	PNW2848	
P6-35		Hood Base	PNW2633	PNW2847	
P6-36		Disc Rack	PNW2632	PNW2845	
P6-50		Mecha Base	PNW2639	PNW2851	
P6-52		Operation Panel	PNW2773	PNW2862	
		Hood	PNW2732	PNW2850	

■ CONTRAST OF PCB ASSEMBLIES

○ SWITCH BOARD ASSY

PWZ3434 and PWZ3432 are constructed the same except for the following:

Mark	Symbol and Description	Part No.		Remarks
		PWZ3432	PWZ3434	
	C752 Remote receiver unit	CKCYF103Z50 GP1U27X	Not used Not used	