

Service Manual

ORDER NO.
RRV4229

AUDIO/VIDEO MULTI-CHANNEL RECEIVER

SC-LX85

SC-LX75

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Model	Type	Power Requirement	Remarks
SC-LX85	SYXJ5	AC 220 V to 230 V	
SC-LX75	SYXJ5	AC 220 V to 230 V	

This service manual should be used together with the following manual(s).

Model No.	Order No.	Remarks
SC-57/UXJCB	RRV4195	

For SPECIFICATIONS and PANEL FACILITIES, refer to the operating instructions.

1. CONTRAST OF MISCELLANEOUS PARTS

NOTES: ● Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.

● The  mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.

● Screws adjacent to ▼ mark on product are used for disassembly.

● For the applying amount of lubricants or glue, follow the instructions in this manual. (In the case of no amount instructions, apply as you think it appropriate.)

● Nos. indicate the pages and Nos. in the service manual for the base model.

● When ordering resistors, first convert resistance values into code form as shown in the following examples.

Ex.1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47k ohm (tolerance is shown by J=5%, and K=10%).

560Ω → 56 x 10¹ → 561 RD1/4PU    J
47kΩ → 47 x 10³ → 473 RD1/4PU    J
0.5Ω → R50 RN2H   K
1Ω → 1R0 RS1P    K

Ex.2 When there are 3 effective digits (such as in high precision metal film resistors).

5.62kΩ → 562 x 10¹ → 5621 RN1/4PC     F

CONTRAST TABLE

SC-57/UXJCB, SC-LX85/SYXJ5 and SC-LX75/SYXJ5 are constructed the same except for the following:

Mark	No.	Symbol and Description	SC-57/UXJCB	SC-LX85/SYXJ5	SC-LX75/SYXJ5	Remarks
PCB ASSEMBLIES						
NSP	P85-1	1..IR POWER AMP ASSY	AWH7030	AWH7037	AWH7040	
	P85-2	1..IR BUFFER ASSY	AWM8249	AWM8282	AWM8282	
		2..IR BUFFER ASSY	AWX9793	AWX9952	AWX9952	
	P85-4	1..PRIM DISPLAY ASSY	AWM8250	AWM8262	AWM8262	
NSP	P87-1	2..PRIMARY ASSY	AWX9799	AWX9848	AWX9848	
	P87-1	2..DISPLAY ASSY	AWX9796	AWX9967	AWX9967	
	P87-4	2..MIC HP ASSY	AWX9800	AWX9968	AWX9968	
	P87-4	2..MIC HP ASSY	AWX9800	AWX9968	AWX9968	
NSP	P83-2	1..AUDIO COMPOSITE ASSY	AWR7106	AWR7107	AWR7113	
		2..AUDIO ASSY	AWX9790	AWX9831	AWX9834	
	P83-3	2..COMPOSITE ASSY	AWX9791	AWX9791	AWX9836	
	P83-3	2..COMPOSITE ASSY	AWX9791	AWX9791	AWX9836	
NSP	P81-3	1..INTERFACE REG ASSY	AWR7111	AWR7124	AWR7124	
		2..IR REG ASSY	AWX9806	AWX9954	AWX9954	
	P81-4	2..B DIODE ASSY	AWX9808	AWX9958	AWX9958	
	P85-7	2..A REG BRIDGE ASSY	AWX9810	AWX9970	AWX9970	
NSP	P81-6	1..REG BRIDGE ASSY	AWR7112	AWR7115	AWR7125	
		2..DISPLAY BRIDGE ASSY	AWX9815	AWX9956	AWX9956	
	P81-7	2..F-IN BRIDGE ASSY	AWX9816	AWX9965	AWX9965	
	P83-9	2..MCH BRIDGE ASSY	AWX9818	AWX9818	Not used	
NSP	P83-11	2..MULTI CH IN ASSY	AWX9857	AWX9856	Not used	
	P85-8	2..REG ASSY	AWX9813	AWX9955	AWX9955	
	P85-10	2..FB-CONNECT ASSY	AWX9819	AWX9966	AWX9966	
	P85-10	2..FB-CONNECT ASSY	AWX9819	AWX9966	AWX9966	
NSP	P87-6	1..FRONT HDMI USB ASSY	AWX9749	AWX9969	AWX9969	
	P83-13	1..DAC HIGH ASSY	AWX9822	AWX9858	AWX9861	
	P83-14	1..DIGITAL MAIN ASSY	AWX9827	AWX9727	AWX9950	
	P83-15	1..COMPONENT ASSY	AWX9866	AWX9951	AWX9867	
PACKING SECTION						
	P79-2	AC Power Cord	ADG7111	ADG7062	ADG7062	
	P79-6	Packing Case	AHD8722	AHD8723	AHD8730	
	P79-9	Operating Instructions (En)	ARB7459	Not used	Not used	
	P79-12	Operating Instructions (CD-ROM)	ARU7006	ARU7004	ARU7028	
NSP	P79-13	Warranty Card	ARY7007	ARY7128	ARY7128	
	P79-14	Remote Control Unit SEL/MID	AXD7612	Not used	AXD7613	
	P79-14	RF Remote Control Unit	Not used	AXD7580	Not used	
	P79-14	RF Remote Control Unit	Not used	AXD7580	Not used	

Mark	No.	Symbol and Description	SC-57/UXJCB	SC-LX85/SYXJ5	SC-LX75/SYXJ5	Remarks
NSP	P79-15	Battery Door	AZN8047	Not used	AZN8047	
	P79-15	Battery Cover	Not used	AZN8049	Not used	
	P79-17	Dry Cell Battery (R3)	VEM1051	Not used	VEM1051	
NSP	P79-17	Dry Cell Battery (LR6)	Not used	VEM1053	Not used	
		Operating Instructions	Not used	ARH7107	ARH7107	
		Operating Instructions	Not used	ARH7108	ARH7108	
NSP		Operating Instructions	Not used	ARH7109	ARH7109	
		Label (WEEE)	Not used	ARW7322	Not used	
NSP		Name Label AD(EL)	Not used	AAL7447	Not used	
NSP		Name Label RC(EL)	Not used	AAL7446	Not used	
		IR Bluster Cable	Not used	ADF7007	Not used	
		RF Receiver Box	Not used	AXX7272	Not used	
		RF Remote Caution	Not used	ARM7131	Not used	
NSP		Manual Assy	Not used	AXX7286	AXX7286	
		Wifi Cable (service)	Not used	ADE7138	ADE7138	
		Wifi Converter E	Not used			
		EXTERIOR SECTION				
	P81-9	Power Transformer (T1501)	ATS7447	ATS7448	ATS7439	
⚠	P81-10	Fuse (FU13, FU14 : 1 A)	REK1142	Not used	Not used	
⚠	P81-10	Fuse (FU13, FU14 : T800mA)	Not used	AEK7072	AEK7072	
⚠	P81-11	Fuse (FU11, FU12, FU15 : 1.25 A)	REK1143	Not used	Not used	
⚠	P81-11	Fuse (FU11, FU12, FU15 : T1 A)	Not used	AEK7073	AEK7073	
⚠	P81-12	Fuse (FU10 : 4 A)	REK1149	Not used	Not used	
⚠	P81-12	Fuse (FU10 : T3.15 A)	Not used	AEK1059	AEK1059	
	P81-24	Insulator	AMR7198	DXA1904	DXA1904	
		REAR SECTION				
	P83-16	AM/FM Tuner Unit	AXX7282	AXX7283	AXX7283	
	P83-23	Rear Panel	ANC8599	ANC8600	ANC8607	
	P83-25	D. Main Shield 85 (MTL)	ANK7162	ANK7162	Not used	
NSP	P83-26	PC Support	VEC1749	VEC1749	Not used	
	P83-36	Nylon Rivet	AEC7406	AEC7406	Not used	
		CHASSIS SECTION				
⚠	P85-13	Fuse (FU4 : 2 A)	REK1139	Not used	Not used	
⚠	P85-13	Fuse (FU4 : T4 A)	Not used	REK1104	REK1104	
⚠	P85-14	Fuse (FU21, FU22, FU31, FU32 : 1.25A)	REK1143	Not used	Not used	
⚠	P85-14	Fuse (FU21, FU22 : T800 mA)	Not used	AEK7072	AEK7072	
⚠	P85-14	Fuse (FU31, FU32 : T1 A)	Not used	AEK7073	AEK7073	
⚠	P85-15	Fuse (FU1 : 10 A)	REK1154	Not used	Not used	
⚠	P85-15	Fuse (FU1 : T5 A)	Not used	AEK1061	AEK1061	
		FRONT SECTION				
	P87-13	Filter	AAK8443	AAK8459	AAK8459	
	P87-14	Display Panel	AAK8567	AAK8568	AAK8568	
NSP	P87-23	Panel Base	AMB8041	AMB8042	AMB8042	
	P87-26	Door Panel	ANB7562	ANB7563	ANB7563	
	P87-27	Front Panel (AL)	ANB7565	ANB7566	ANB7570	
	P87-29	PIONEER Badge (AL)	VAM1159	VAM1158	VAM1158	

Notes : For PCB ASSEMBLIES, Refer to “CONTRAST OF PCB ASSEMBLIES”.

When a Wifi converter is defective, please replace with a product stock of AS-WL300.

When a Wifi cable is defective or broken, please replace to ADE7138 which has clamp filter attached for this model.

CONTRAST OF PCB ASSEMBLIES

A F AUDIO ASSY

A AWX9790, AWX9831 and AWX9834 are constructed the same except for the following:

Mark	Symbol and Description	AWX9790	AWX9831	AWX9834	Remarks
B	JA2502, JA3202 2P PIN JACK CN2510 18P SOCKET JA2501, JA2503, JA2504, JA2951 JA3101 PIN JACK(4P) JA3102 RCA JACK	AKB7234 AKP7123 AKB7218 AKB7218 AKB7237	AKB7234 AKP7123 AKB7218 AKB7218 AKB7237	AKB7233 Not used XKB3017 XKB3017 AKB7236	
	JA3201 PIN JACK(6P) R2663, R2664 R3030, R3034 R3032 R3951-R3958	AKB7221 RS1/10SR331J Not used RS1/8SQ562J Not used	AKB7221 RS1/10SR561J RS1/10SR472J RS1/8SQ182J Not used	XKB3037 RS1/10SR561J RS1/10SR472J RS1/8SQ182J RS1/10SR473J	
	C2501-C2504, C2521-C2524 C2541-C2544, C2561, C2562 C2583, C2584, C2603, C2604 C3113, C3114, C3163, C3164 C3213, C3214, C3263, C3264	Not used Not used Not used Not used Not used	CCSRCH101J50 CCSRCH101J50 CCSRCH101J50 CCSRCH101J50 CCSRCH101J50	CCSRCH101J50 CCSRCH101J50 CCSRCH101J50 CCSRCH101J50 CCSRCH101J50	
	C3283, C3284, C3922, C3923 C3945 C2563, C2564 C2661, C2662 C2665, C2666, C3111, C3112	Not used Not used Not used Not used Not used	CCSRCH101J50 CCSRCH101J50 CCSRCH220J50 CCSRCH221J50 CCSRCH331J50	CCSRCH101J50 CCSRCH101J50 CCSRCH220J50 CCSRCH221J50 CCSRCH331J50	
C	C3161, C3162, C3211, C3212 C3261, C3262, C3281, C3282 C3924, C3925, C3944 C2951, C2952, C2971, C2972 C2667, C2668	Not used Not used Not used Not used Not used	CCSRCH331J50 CCSRCH331J50 CCSRCH331J50 CCSRCH471J50 CCSRCH561J50	CCSRCH331J50 CCSRCH331J50 CCSRCH331J50 CCSRCH471J50 CCSRCH561J50	
	C3011, C3012	CCSRCH331J50	Not used	Not used	

The mounting positions of the additional parts are described in the circuit diagram and PCB diagram of the parent manual.

D B F DAC HIGH ASSY

AWX9822, AWX9858 and AWX9861 are constructed the same except for the following:

Mark	Symbol and Description	AWX9822	AWX9858	AWX9861	Remarks
E	D2130 JA2008 RCA JACK JA2101 8P MINI DIN SOCKET R2002, R2004 R2133, R2134	1SS302 AKB7235 BKP1127 RS1/10SR220J Not used	Not used AKB7235 Not used RS1/10SR270J RS1/10SR0R0J	Not used AKB7173 Not used RS1/10SR270J RS1/10SR0R0J	
	R2135 R2140, R2141 R2142, R2143 R2144, R2145, R2231-R2233 R2491	RS1/10SR0R0J RS1/10SR474J RS1/10SR331J Not used RS1/8SQ105J	Not used Not used Not used RS1/10SR0R0J RS1/8SQ222J	Not used Not used Not used RS1/10SR0R0J RS1/8SQ222J	
	R2492 C2124, C2126 C2127, C2128	RS1/8SQ474J CKSRYB103K50 CEAT220M50	RS1/8SQ105J Not used Not used	RS1/8SQ105J Not used Not used	

The mounting positions of the additional parts are described in the circuit diagram and PCB diagram of the parent manual.

C F FRONT HDMI USB ASSY

AWX9749 and AWX9969 are constructed the same except for the following:

Mark	Symbol and Description	AWX9749	AWX9969	Remarks
	C8043, C8108	CKSSYB102K50	CCSSCH102J50	

F MULTI CH IN ASSY

AWX9857 and AWX9856 are constructed the same except for the following:

Mark	Symbol and Description	AWX9857	AWX9856	Remarks
	C7761-C7764, C7767-C7770	Not used	CCSRCH101J50	
	C7773-C7776, C7779-C7782	Not used	CCSRCH101J50	

The mounting positions of the additional parts are described in the circuit diagram and PCB diagram of the parent manual.

F DIGITAL MAIN ASSY

AWX9827, AWX9727 and AWX9950 are constructed the same except for the following:

Mark	Symbol and Description	AWX9827	AWX9727	AWX9950	Remarks
	R610, R618	Not used	RS1/8SQ105J	RS1/8SQ105J	
	R9513	RS1/16SS100J	RS1/16SS0R0J	RS1/16SS100J	
	R9518	RS1/16SS82R0D	RS1/16SS82R0D	RS1/16SS1501D	
	R9519	RS1/16SS331J	RS1/16SS331J	RS1/16SS152J	
	R9520	RS1/16SS7501D	RS1/16SS7501D	RS1/16SS3302D	
	R9521	RS1/16SS622J	RS1/16SS622J	RS1/16SS163J	
	R9522	RS1/16SS3301D	RS1/16SS3301D	RS1/16SS1502D	
	R9531	RS1/16SS3302D	RS1/16SS9101D	RS1/16SS3302D	
	R9532	RS1/16SS123J	RS1/16SS562J	RS1/16SS123J	
	R9533	RS1/16SS2402D	RS1/16SS6801D	RS1/16SS2402D	
	R9534	RS1/16SS2401D	RS1/16SS4700D	RS1/16SS2401D	
	R9535	RS1/16SS112J	RS1/16SS301J	RS1/16SS112J	
	R9536, R9540, R9542, R9543	RS1/8SQ0R0J	Not used	RS1/8SQ0R0J	
	R9555, R9564	RS1/8SQ0R0J	Not used	RS1/8SQ0R0J	
	C9577	Not used	ACH7309	Not used	
	C9578	Not used	ACH7314	Not used	
	C140, C995, C1355	VCH1277	VCH1277	CEVW221M4	
	C197	Not used	CCSSCH101J50	CCSSCH101J50	
	C203, C428, C447	CKSSYB104K16	CCSSCH331J50	CCSSCH331J50	
	C619, C650	CCSSCH102J50	CCSSCH101J50	CCSSCH101J50	
	C996, C1672, C1673	ACH7306	ACH7306	Not used	
	C1008	CCSSCH471J50	CCSSCH101J50	CCSSCH101J50	
	C1770, C1847	CEVW101M16	CEVW101M16	Not used	
	C9056, C9072	CCSSCH471J50	CCSSCH101J50	CCSSCH101J50	
	C9314	CKSSYB104K16	CCSSCH180J50	CCSSCH180J50	
	C9322	Not used	CCSSCH220J50	CCSSCH220J50	
	C9547	CKSSYB682K25	CKSSYB682K25	CCSSCH102J50	
	C9553	CKSSYB472K50	CKSSYB472K50	CCSSCH102J50	
	C9565	CKSSYB152K50	CKSSYB472K50	CKSSYB152K50	
	C9570	CCSSCH102J50	CKSSYB682K25	CCSSCH102J50	
	C9588, C9608	CFHXSQ103J16	CFHXSQ103J16	Not used	
	C9593	ACH7306	ACH7306	Not used	
	C9621	CCSSCH101J50	CKSSYB104K16	CCSSCH101J50	
	C9742	CCSSCH221J50	CCSSCH101J50	CCSSCH101J50	
	C9751	CCSSCH471J50	CCSSCH101J50	CCSSCH101J50	
	C9757	CKSSYB104K16	CCSSCH101J50	CCSSCH101J50	
	C1836	CEVW470M16	CEVW470M16	Not used	
	C156	VCH1268	VCH1268	CEVW101M4	
	C1031, C9004, C9702	VCH1234	VCH1234	CEVW101M16	
	C9537	VCH1234	VCH1234	Not used	

The mounting positions of the additional parts are described in the circuit diagram and PCB diagram of the parent manual.

H F COMPONENT ASSY

AWX9866, AWX9951 and AWX9867 are constructed the same except for the following:

A

Mark	Symbol and Description	AWX9866	AWX9951	AWX9867	Remarks
	JA8301 6P PIN JACK AU JA8302, JA8304 3P PIN JACK AU JA8305 3P PIN JACK AU R8316, R8318, R8320 R8317, R8319, R8321	AKB7225 AKB7228 AKB7228 RS1/10SR68R0F RS1/10SR3R9J	AKB7225 AKB7228 AKB7228 RS1/10SR68R0F RS1/10SR3R9J	AKB7224 AKB7227 Not used Not used Not used	
	R8361, R8362 C8394	RS1/10SR0R0J CCSRCH470J50	RS1/10SR100J CCSRCH470J50	RS1/10SR100J Not used	

I F COMPOSITE ASSY

B

AWX9791 and AWX9836 are constructed the same except for the following:

Mark	Symbol and Description	AWX9791	AWX9836	Remarks
	JA3601-JA3603 2P PIN JACK JA3604, JA3605 1P PIN JACK R3616 C3608, C3610	AKB7230 AKB7232 RS1/10SR68R0D CKSRYB104K16	AKB7229 AKB7231 RS1/10SR68R0F CKSRYB104K50	

J F MIC HP ASSY

AWX9800 and AWX9968 are constructed the same except for the following:

C

Mark	Symbol and Description	AWX9800	AWX9968	Remarks
	C3473 C3490	CKSRYB471K50 CKSRYB102K50	CCSRCH471J50 CCSRCH102J50	

K F DISPLAY ASSY

■

AWX9796 and AWX9967 are constructed the same except for the following:

Mark	Symbol and Description	AWX9796	AWX9967	Remarks
	C3006, C3302 C3102, C3201, C3306 C3104	CKSRYB471K50 CKSRYB102K50 CKSRYB102K50	CCSRCH471J50 CCSRCH102J50 CCSRCH330J50	

D

O F IR BUFFER ASSY

AWX9793 and AWX9952 are constructed the same except for the following:

Mark	Symbol and Description	AWX9793	AWX9952	Remarks
	R6857	RS1/8SQ225J	RS1/8SQ224J	

R F IR POWER AMP ASSY

AWH7030, AWH7037 and AWH7040 are constructed the same except for the following:

E

Mark	Symbol and Description	AWH7030	AWH7037	AWH7040	Remarks
	IC4004 IC4905 IC5101 Q4121, Q4221, Q4721 Q4111, Q4211, Q4311, Q4411	TC74VHC08FK TC7SH08FUS1 UPC4570G2-A 2SC2713 LSA1576UB	TC74VHCT08AFKS1 TC7SET08FUS1 Not used Not used LTA114TUB	TC74VHCT08AFKS1 TC7SET08FUS1 Not used Not used LTA114TUB	
	Q4511, Q4611, Q4711, Q4811 Q4911 Q4122, Q4222, Q4722 Q4023, Q4025 Q5101	LSA1576UB LSA1576UB LSA1576UB LSC4081UB LSC4081UB	LTA114TUB LTA114TUB Not used DTC623TU Not used	LTA114TUB LTA114TUB Not used DTC623TU Not used	
	Q4105, Q4106, Q4205, Q4206 Q4305, Q4306, Q4405, Q4406 Q4505, Q4506, Q4605, Q4606 Q4705, Q4706, Q4805, Q4806	LTC124EUB LTC124EUB LTC124EUB LTC124EUB	DTC115EUA DTC115EUA DTC115EUA DTC115EUA	DTC115EUA DTC115EUA DTC115EUA DTC115EUA	

F

Mark	Symbol and Description	AWH7030	AWH7037	AWH7040	Remarks
	Q4905, Q4906	LTC124EUB	DTC115EUA	DTC115EUA	
	D4116, D4216, D4316, D4416	RB161VA-20	RB500V-40	RB500V-40	A
	D4516, D4616, D4716, D4816	RB161VA-20	RB500V-40	RB500V-40	
	D4916	RB161VA-20	RB500V-40	RB500V-40	
	D4005	1SS352	1SS355	1SS355	
	D4103, D4120, D4203, D4220	1SS302	Not used	Not used	
	D4111, D4211, D4311, D4411	1SS302	DAN217U	DAN217U	
	D4511, D4611, D4711, D4811	1SS302	DAN217U	DAN217U	
	D4703, D4720	1SS302	Not used	Not used	
	D4911	1SS302	DAN217U	DAN217U	
	D4027, D4028, D4029, D4030	RKZ4.7KG	Not used	Not used	
	D4031	RKZ4.7KG	Not used	Not used	
	L4000	QTL1013	RS1/10SR101J	RS1/10SR101J	B
	JA4301, JA4501, JA4901	AKE7149	AKE7147	AKE7143	
	JA5101 SP TERMINAL 4-P(V0)	AKE7149	AKE7147	AKE7143	
	JA4101 SP TERMINAL 6-P(V0)	AKE7150	AKE7148	AKE7144	
	R4176, R4180, R4276, R4280	ACN7195	RS1/4S0R0J	RS1/4S0R0J	
	R4776, R4780	ACN7195	RS1/4S0R0J	RS1/4S0R0J	
	R5034, R5036	Not used	RS1/8SQ0R0J	RS1/8SQ0R0J	
	R4113, R4213, R4713, R5107	RS1/10SR0R0J	Not used	Not used	
	R5108, R5112, R5121, R5130	RS1/10SR0R0J	Not used	Not used	
	R5134, R5136, R5138, R5140	RS1/10SR0R0J	Not used	Not used	C
	R5027, R5028, R5031, R5032	RS1/10SR0R0J	RS1/10SR101J	RS1/10SR101J	
	R4005	RS1/10SR0R0J	RS1/10SR103J	RS1/10SR103J	
	R5113, R5114, R5122, R5123	RS1/10SR100J	Not used	Not used	
	R5131, R5132	RS1/10SR100J	Not used	Not used	
	R4275, R4475, R4675, R4775	RS1/10SR100J	RS1/10SR101J	RS1/10SR101J	
	R4875	RS1/10SR100J	RS1/10SR101J	RS1/10SR101J	
	R4144, R4161, R4175, R4244	RS1/10SR101J	Not used	Not used	
	R4261, R4282, R4744, R4761	RS1/10SR101J	Not used	Not used	
	R4793	RS1/10SR101J	Not used	Not used	
	R4185, R4285, R4785, R5141	RS1/10SR103J	Not used	Not used	
	R4071, R4074, R5079	RS1/10SR103J	RS1/10SR104J	RS1/10SR104J	D
	R4041, R4045, R4127, R4160	RS1/10SR103J	RS1/10SR473J	RS1/10SR473J	
	R4227, R4260, R4327, R4360	RS1/10SR103J	RS1/10SR473J	RS1/10SR473J	
	R4427, R4460, R4527, R4560	RS1/10SR103J	RS1/10SR473J	RS1/10SR473J	
	R4627, R4660, R4727, R4760	RS1/10SR103J	RS1/10SR473J	RS1/10SR473J	
	R4827, R4860, R4927, R4960	RS1/10SR103J	RS1/10SR473J	RS1/10SR473J	
	R4186, R4190, R4286, R4290	RS1/10SR104J	Not used	Not used	
	R4786, R4790, R5104	RS1/10SR104J	Not used	Not used	
	R5105	RS1/10SR105J	Not used	Not used	
	R4032, R4033, R4040, R4157	RS1/10SR153J	RS1/10SR473J	RS1/10SR473J	E
	R4257, R4357, R4457, R4557	RS1/10SR153J	RS1/10SR473J	RS1/10SR473J	
	R4657, R4757, R4857, R4957	RS1/10SR153J	RS1/10SR473J	RS1/10SR473J	
	R4000, R4027, R4078, R4079	RS1/10SR182J	RS1/10SR562J	RS1/10SR562J	
	R4090	RS1/10SR182J	RS1/10SR562J	RS1/10SR562J	
	R4184, R4284, R4784	RS1/10SR183J	Not used	Not used	
	R5115, R5124, R5133	RS1/10SR1R0J	Not used	Not used	
	R5106, R5137, R5142	RS1/10SR223J	Not used	Not used	
	R4042, R4189, R4289	RS1/10SR273J	Not used	Not used	
	R4789	RS1/10SR273J	Not used	Not used	
	R4059	RS1/10SR2R2J	RS1/10SR100J	RS1/10SR100J	
	R5001	RS1/10SR3901F	RS1/10SR1002F	RS1/10SR1002F	F
	R4124, R4224, R4324, R4424	RS1/10SR471J	RS1/10SR431J	RS1/10SR431J	
	R4524, R4624, R4724, R4824	RS1/10SR471J	RS1/10SR431J	RS1/10SR431J	
	R4924	RS1/10SR471J	RS1/10SR431J	RS1/10SR431J	

Mark	Symbol and Description	AWH7030	AWH7037	AWH7040	Remarks
A	R4096, R4110, R4210, R4310 R4410, R4510, R4610, R4710 R4810, R4910 R5101, R5102 R5111, R5120, R5129	RS1/10SR472J RS1/10SR472J RS1/10SR472J RS1/10SR473J RS1/10SR4R7J	RS1/10SR103J RS1/10SR103J RS1/10SR103J Not used Not used	RS1/10SR103J RS1/10SR103J RS1/10SR103J Not used Not used	
	R5000 R5103 R5135 R5035, R5037 R5029, R5030	RS1/10SR5600F RS1/10SR682J RS1/10SR821J RS1/8SQ0R0J RS1/8SQ0R0J	RS1/10SR1501F Not used Not used Not used RS1/8SQ103J	RS1/10SR1501F Not used Not used Not used RS1/8SQ103J	
	R5012, R5013, R5020, R5021 R5011 R5019 R5018 R5083-R5087	RS1/8SQ103J RS1/8SQ103J RS1/8SQ104J RS1/8SQ104J RS1/8SQ105J	RS1/8SQ104J RS1/8SQ473J RS1/8SQ224J RS1/8SQ474J Not used	RS1/8SQ104J RS1/8SQ473J RS1/8SQ224J RS1/8SQ474J Not used	
	R5014, R5022 R5016, R5024 C4186, C4286, C4786 C4012 C4045, C4049, C5001-C5005	RS1/8SQ223J RS1/8SQ473J CCSRCH100D50 CCSRCH331J50 CCSRCH331J50	RS1/8SQ683J RS1/8SQ104J Not used CCSRCH221J50 Not used	RS1/8SQ683J RS1/8SQ104J Not used CCSRCH221J50 Not used	
	C4184, C4284, C4784 C4121, C4122, C4221, C4222 C4321, C4322, C4421, C4422 C4521, C4522, C4621, C4622 C4721, C4722, C4821, C4822	CCSRCH471J50 CFHXSQ103J16 CFHXSQ103J16 CFHXSQ103J16 CFHXSQ103J16	Not used CFHXSQ472J16 CFHXSQ472J16 CFHXSQ472J16 CFHXSQ472J16	Not used CFHXSQ472J16 CFHXSQ472J16 CFHXSQ472J16 CFHXSQ472J16	
B	C4921, C4922 C5102, C5103 C4151, C4251, C4351, C4451 C4551, C4651, C4751, C4851 C4951	CFHXSQ103J16 CFHXSQ103J16 CKSRYB103K50 CKSRYB103K50 CKSRYB103K50	CFHXSQ472J16 Not used Not used Not used Not used	CFHXSQ472J16 Not used Not used Not used Not used	
	C4258, C4458, C4658, C4758 C4858 C4006, C4124, C4152, C4153 C4224, C4252, C4253, C4324 C4352, C4353, C4424, C4452	CKSRYB104K50 CKSRYB104K50 CKSRYB104K50 CKSRYB104K50 CKSRYB104K50	CKSRYB103K50 CKSRYB103K50 Not used Not used Not used	CKSRYB103K50 CKSRYB103K50 Not used Not used Not used	
	C4453, C4524, C4552, C4553 C4624, C4652, C4653, C4724 C4752, C4753, C4824, C4852 C4853, C4924, C4952, C4953 C5101	CKSRYB104K50 CKSRYB104K50 CKSRYB104K50 CKSRYB104K50 CKSRYB104K50	Not used Not used Not used Not used Not used	Not used Not used Not used Not used Not used	
	C5106 C4083, C4084	CKSRYB224K25 Not used	Not used ACE7082	Not used ACE7082	

The mounting positions of the additional parts are described in the circuit diagram and PCB diagram of the parent manual.

PRIMARY ASSY

AWX9799 and AWX9848 are constructed the same except for the following:

Mark	Symbol and Description	AWX9799	AWX9848	Remarks
	L1 LINE FILTER CN81 CONNECTOR CN82 CONNECTOR(VH) VA1 VARISTOR C81	ATF7046 B2P3-VH Not used Not used ACE7013	ATF7050 Not used B3P5-VH TND10V-511KB00AAA0 Not used	

The mounting positions of the additional parts are described in the circuit diagram and PCB diagram of the parent manual.

U F REG ASSY

Although AWX9813 and AWX9955 are different in part number, they consist of the same service components.

V F IR REG ASSY

AWX9806 and AWX9954 are constructed the same except for the following:

Mark	Symbol and Description	AWX9806	AWX9954	Remarks
	R7258	RS1/4SA822J	RS1/4SA105J	

W F B DIODE ASSY

AWX9808 and AWX9958 are constructed the same except for the following:

Mark	Symbol and Description	AWX9808	AWX9958	Remarks
	R7400	RS1/4SA823J	RS1/4SA913J	
	R7401	RS1/4SA823J	RS1/4SA683J	

Y F FB-CONNECT ASSY

AWX9819 and AWX9966 are constructed the same except for the following:

Mark	Symbol and Description	AWX9819	AWX9966	Remarks
	C7693, C7696	CCSRCH270J50	Not used	
	C7694, C7697	CCSRCH331J50	Not used	

AE F DISPLAY BRIDGE ASSY

AWX9815 and AWX9956 are constructed the same except for the following:

Mark	Symbol and Description	AWX9815	AWX9956	Remarks
	C7654	Not used	CCSRCH101J50	
	C7901, C7905	Not used	CCSRCH100D50	

The mounting positions of the additional parts are described in the circuit diagram and PCB diagram of the parent manual.

AF F F-IN BRIDGE ASSY

AWX9816 and AWX9965 are constructed the same except for the following:

Mark	Symbol and Description	AWX9816	AWX9965	Remarks
	R7161	RS1/10SR0R0J	RS1/10SR100J	
	R7669	Not used	RS1/10SR105J	
	C7168	Not used	CCSRCH101J50	
	C7171	Not used	CCSRCH330J50	

The mounting positions of the additional parts are described in the circuit diagram and PCB diagram of the parent manual.


AH F A REG BRIDGE ASSY

AWX9810 and AWX9970 are constructed the same except for the following:

Mark	Symbol and Description	AWX9810	AWX9970	Remarks
	R5777, R5780	Not used	RS1/10SR472J	

The mounting positions of the additional parts are described in the circuit diagram and PCB diagram of the parent manual.


Service Manual



SC-57

OR R O.
RRV

AUDIO VIDEO ULTI C ANNEL RECEIVER



THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Model	Type	Power Requirements	Remarks
SC-57	U JCB	AC 120	
SC-55	U JCB	AC 120	
SC-1526-K	CU J	AC 120	



SAFETY INFORMATION



A

The following check should be performed for the continued protection of the customer and service technician. The following check should be performed for the continued protection of the customer and service technician.

Use symbols fast operating use and or slow operating use on PCB indicate that replacement parts must be of identical designation.

ARNIN

The following check should be performed for the continued protection of the customer and service technician. The following check should be performed for the continued protection of the customer and service technician.

Use symbols **S** fast operating use and or **S** slow operating use on PCB indicate that replacement parts must be of identical designation.

B

ORCA A A MO L O L

use symbols fast operating use and or slow operating use on PCB indicate that replacement parts must be of identical designation.

R MAR U

POUR MO L CA A S UL M

Les symboles de utilisable utilisable de type rapide et ou utilisable de type lent sur CC indiquent que les pièces de remplacement doivent avoir la même désignation.

C


(FOR USA & CANADA ONLY)

1. SAFETY PRECAUTIONS

The following check should be performed for the continued protection of the customer and service technician.

LEAKAGE CURRENT CHECK

Measure leakage current to a known earth ground water pipe, conduit, etc. by connecting a leakage current tester such as Simpson Model 229-2 or equivalent between the earth ground and all exposed metal parts of the appliance input/output terminals, screwheads, metal overlays, control shaft, etc. Plug the AC line cord of the appliance directly into a 120 AC 60 Hz outlet and turn the AC power switch on. An current measured must not exceed 0.5 mA.



AC Leakage Test

AND MEASUREMENTS NOT WITHIN THE LIMITS OUTLINED ABOVE ARE INDICATIVE OF A POTENTIAL SAFETY HAZARD AND MUST BE CORRECTED BEFORE RETURNING THE APPLIANCE TO THE CUSTOMER.

2. PRODUCT SAFETY NOTICE

Many electrical and mechanical parts in the appliance have special safety related characteristics. These are often not evident from visual inspection nor the protection afforded by them necessarily can be obtained by using replacement components rated for voltage, wattage, etc. Replacement parts which have these special safety characteristics are identified in this Service Manual.

Electrical components having such features are identified by marking with a ⚠ on the schematics and on the parts list in this Service Manual.

Do not use a substitute replacement component which does not have the same safety characteristics as the P.O.R. recommended replacement one, shown in the parts list in this Service Manual, may create shock, fire, or other hazards.

Product Safety is continuously under review and new instructions are issued from time to time. For the latest information, always consult the current P.O.R. Service Manual. A subscription to, or additional copies of, P.O.R. Service Manual may be obtained at a nominal charge from P.O.R.

CONTENTS

SA ORMA O	2	
1. S R C PR CAU O S	5	
1.1 O SO SOL R	5	A
1.2 O SO R PLAC	5	
1.3 CAU O	5	
1.4 O SO ASS MBL	6	
2. SP C CA O S	7	
2.1 SC-57 SC-55 SP C CA O S	7	
2.2 SC-1526-K SP C CA O S	9	
3. BAS C MS ORS R C	11	
3.1 CH CK PO SA RS R C	11	
3.2 PCB LOCA O S	12	
3.3 J SLS	14	
4. BLOCK A RAM	16	
4.1 O RALL R A RAM	16	B
4.2 BLOCK A RAM OR AU O BLOCK	18	
4.3 BLOCK A RAM OR AL MA O BLOCK	20	
4.4 BLOCK A RAM OR AL MA AU O BLOCK	22	
4.5 BLOCK A RAM OR O BLOCK	24	
4.6 BLOCK A RAM OR COMPOS O BLOCK	25	
4.7 BLOCK A RAM OR COMPO O BLOCK	26	
4.8 BLOCK A RAM OR PO R BLOCK 1	28	
4.9 BLOCK A RAM OR PO R BLOCK 2	30	
5. A OSS	32	
5.1 A OSS LO CHAR	32	
5.2 C RCU SCR P O	42	
6. S R C MO	49	C
6.1 S MO	49	
7. SASS MBL	51	
8. ACH S A A JUS M	72	
8.1 A JUS M R UR H H U SR PAR ORR PLAC	72	
8.2 HO OSA A LOA H S US BACKUP U C O H USB M MOR	73	
8.3 R O R	74	
8.4 HO OUP A RM AR	75	
9. PLO SA PAR SLS	78	
9.1 PACK S C O	78	
9.2 RORS C O	80	
9.3 R ARS C O	82	
9.4 CHASS S S C O	84	
9.5 RO S C O	86	
10. SCH MA C A RAM	88	
10.1 AU O ASS 13 U PA	88	
10.2 AU O ASS 23	94	
10.3 AU O ASS 33	96	
10.4 ACH H ASS 12	98	
10.5 ACH H ASS 22	100	
10.6 RO H M USB ASS	102	
10.7 USB R C and MUL CH SC-57 ASS S	104	
10.8 AL MA ASS 111 U PA	106	
10.9 AL MA ASS 211	112	
10.10 AL MA ASS 311	114	
10.11 AL MA ASS 411	116	
10.12 AL MA ASS 511	118	
10.13 AL MA ASS 611	120	
10.14 AL MA ASS 711	122	
10.15 AL MA ASS 811	124	
10.16 AL MA ASS 911	126	
10.17 AL MA ASS 1011	128	
10.18 AL MA ASS 1111	130	
10.19 R AC ASS	132	
10.20 COMPO ASS	134	
10.21 COMPOS ASS	136	
10.22 M C HP ASS	138	
10.23 SPLA ASS	140	
10.24 OL and PO RS ASS S	142	

	10.25	CO	R ASS		143
	10.26	R BU	R ASS		144
	10.27	BU	R and R R AC ASS S		146
A	10.28	R PO	R AMP ASS 1 6		148
	10.29	R PO	R AMP ASS 2 6		150
	10.30	R PO	R AMP ASS 3 6		152
	10.31	R PO	R AMP ASS 4 6		154
	10.32	R PO	R AMP ASS 5 6		156
	10.33	R PO	R AMP ASS 6 6		158
	10.34	PR MAR	and PR MAR SH L ASS S		160
	10.35	R	ASS		162
	10.36	R R	ASS		164
	10.37	B O	ASS		166
	10.38	CO	C ASS		167
	10.39	B-CO	C ASS		168
B	10.40	PR BR	and A- AC BR ASS S		169
	10.41	-AU O BR	and - AC BR ASS S		170
	10.42	RO BR	ASS		171
	10.43	SPLA BR	ASS		172
	10.44	- BR	ASS		173
	10.45	MCH BR	ASS SC-57		174
	10.46	A R BR	, M C HP UAR , A CO C , B MB B CABL , C UAR 2 and		
		R	UAR ASS S		175
	11.	PCB CO	C O A RAM		176
	11.1	AU O ASS		176	
	11.2	AC H H ASS		180	
	11.3	RO H M USB, USB R C	and MUL CH SC-57 ASS S		184
C	11.4	AL MA	ASS		188
	11.5	R AC	ASS		192
	11.6	COMPO	ASS		196
	11.7	COMPOS	ASS		200
	11.8	M C HP and	SPLA ASS S		202
	11.9	OL, PO	R S and CO R ASS S		206
	11.10	R BU	R ASS		208
	11.11	BU	R and R R AC ASS S		210
	11.12	R PO	R AMP ASS		212
	11.13	PR MAR	ASS		216
	11.14	PR MAR	SH L and R ASS S		220
	11.15	R R	ASS		224
	11.16	B O	ASS		226
	11.17	CO	C ASS		228
	11.18	B-CO	C and PR BR ASS S		230
	11.19	A- AC -AU O - AC RO	BR ASS S		232
	11.20	SPLA BR	and - BR ASS S		236
	11.21	MCH BR	, A R BR and M C HP UAR ASS S		240
	11.22	A CO	C , B MB B CABL , C UAR 2 and R UAR ASS S		244
	12.	PCB PAR	S L S		246

1. SERVICE PRECAUTIONS

1.1 NOTES ON SOLDERING

For environmental protection, lead-free solder is used on the printed circuit boards mounted in this unit.
Be sure to use lead-free solder and a soldering iron that can meet specifications or use with lead-free solders or repairs accompanied by reworking or soldering.

Compared with conventional eutectic solders, lead-free solders have higher melting points, by approximately 40 °C.
Therefore, for lead-free soldering, the tip temperature of a soldering iron must be set to around 373 °C in general, although the temperature depends on the heat capacity of the PC board on which reworking is required and the weight of the tip of the soldering iron.

- Use a soldering iron whose tip temperature cannot be controlled.

Compared with eutectic solders, lead-free solders have higher bond strengths but slower wetting times and higher melting temperatures, hard to melt easily to harden.

The following lead-free solders are available as service parts.

Parts numbers of lead-free solder

- P1006 1.0 in dia.
- P1007 0.6 in dia.
- P1008 0.3 in dia.

1.2 NOTES ON REPLACING

The part listed below is difficult to replace as a discrete component part.
When the part listed in the table is defective, replace whole Assy.

ASSY NAME	PC Assy Part No.	Parts List			
		Part No.	FUNCTION	Part No.	Remarks
ALMA ASSY	A 9827 SC-57	C101	MA CPU	UP 61283 1-407LU2A	B A
		C903	H M R C R	S 9233AC U	C with heat-pad
		C905	H M S CH	S 9387C U	C with heat-pad
		C1204	AL CO O ORMA R R	88 2750	B A
		C1212 MA	R2-S RAM	H5PS5162 R-S5C-K	B A
		C1212 SUB	R2-S RAM	K4 51163 -HC 7	B A
		JA1501	CO C OR or BLU OO H	CKS5712-A	Land is under parts
		C1602	H M RA SM R	S 9136C U	C with heat-pad
		C1603	H M RA SM R	S 9136C U	C with heat-pad
		C9002	1st SP	810K013B KB400-K	B A
	A 9824 SC-55 SC-1526-K	C9702	2nd SP	810K013B KB400-K	B A
		C9204	M A PROC SSOR	M860	B A
		C9203	LA PH	LA 8700C-A	C with heat-pad
		C9205	LASH ROM	A 7346-A	MAC Address closed-door
		C9510	R ULA OR	JM2846 L3-33	C with heat-pad
		C9509	R ULA OR	MM1701 H	C with heat-pad
		4101,4102 4201,4202 4301,4302 4401,4402 4501,4502 4601,4602 4701,4702 4801,4802 4901,4902		R 6775MPB	Land is under parts

1.3 CAUTION

1.3.1 Discharge

Before starting the diagnosis, wait for three minutes until the electricity of the unit is discharged.

1.3.2 Points


Please refer to page 51, Round Points.

NOTES ON ASSEMBLY LINE




The right and left positions of the attachment positioning of R amplifier block are gradual, however, adjust the front and back positions correctly. For the positioning procedure, refer to 7. SASS MBL.

When assembling the R amplifier block, please note the following points of screws to prevent from short-circuit.

Top view of the R amplifier block showing the assembly points for the R Cover 85 and the BU R ASS.



Front view of the R amplifier block showing the assembly points for the Accessory Panel Base.



A screw at any of these points needs to be removed for service, be sure to check that the swarf is not on the screw before re-attaching.

SPECIFICATIONS

SC-57 SC-55 SPECIFICATIONS

A

Continuous Power Output 1 kHz, 8Ω, 0.08

Front	140	140
Center	140	
Surround	140	140
Surround back	140	140
Front height	140	140
Front wide	140	140

Continuous Power Output 1 kHz, 6Ω, 1.0

Front	180	180
Center	180	
Surround	180	180
Surround back	180	180
Front height	180	180
Front wide	180	180

total harmonic distortion 0.04

1 kHz, 130	130	8Ω
------------	-----	----

Guaranteed speaker impedance 6Ω to 16Ω

* Measured pursuant to the Federal Trade Commission's Trade Regulation rule on Power Output Claims for Amplifiers

** Measured by Audio Spectrum Analyzer

Multi channel simultaneous power output

1 kHz, 1Ω, 8Ω

9 ch total 810 SC-57 720 SC-55

Continuous Power Output 1 kHz, 8Ω, 0.08

Front	140	140
-------	-----	-----

Center	140	
--------	-----	--

Surround	140	140
----------	-----	-----

Surround back	140	140
---------------	-----	-----

Front height	140	140
--------------	-----	-----

Front wide	140	140
------------	-----	-----

Continuous Power Output 1 kHz, 6Ω, 1.0

Front	180	180
-------	-----	-----

Center	180	
--------	-----	--

Surround	180	180
----------	-----	-----

Surround back	180	180
---------------	-----	-----

Front height	180	180
--------------	-----	-----

Front wide	180	180
------------	-----	-----

total harmonic distortion 0.04

1 kHz, 130	130	8Ω
------------	-----	----

Guaranteed speaker impedance 6Ω to 16Ω

* Measured pursuant to the Federal Trade Commission's Trade Regulation rule on Power Output Claims for Amplifiers

** Measured by Audio Spectrum Analyzer

A

Input Sensitivity Impedance

PHONO MM	5 m	47 kΩ
----------	-----	-------

L	400 m	47 kΩ
---	-------	-------

Output Level Impedance

R C	380 m	2.2 kΩ
-----	-------	--------

Signal-to-Noise Ratio

H, short circuited, A network

L	103 dB
---	--------

T

Frequency Range M 87.5MHz to 108 MHz

Antenna Input M 75Ω unbalanced

Frequency Range AM 531 kHz to 1602 kHz

Antenna AM Loop antenna balanced

V

Signal level

Composite Video 1 p-p 75Ω

Component Video 1.0 p-p 75Ω,

PB PR 0.7 p-p 75Ω

Corresponding maximum resolution

Component Video 1080p 1125p

Video convert o

D

HDMI terminal 19-pin

HDMI output type 5, 55 mA

USB terminal USB2.0 Full Speed type A

iPod terminal USB, and Video Composite

SRUS antenna cable 8-pin mini cable

AP R POR terminal 5, 100 mA

R L SS LA A AP R terminal

5, 600 mA

I

Control SR terminal 3.5 Mini-ack MO O

Control R terminal 3.5 Mini-ack MO O

R signal High Active High Level 2.0

12 trigger terminal 3.5 Mini-ack MO O

12 trigger output type 12, total 150 mA

RS-232C cable type 9-pin, cross type,

female-female

SO terminal 5, 150 mA

N

LA terminal 10 BAS - 100 BAS -

P

Power requirements AC 120, 60 Hz

Power consumption 370

standby 0.1

H M Setup Control O

0.3 H M Setup Control O

Dimensions

435 mm x 185.6 mm H x 440.3 mm

17 3 16 in. x 7 5 16 in. H x 17 3 8 in.

eight without package

SC-57..... 17.7 kg 39.0 lb

SC-55..... 17.4 kg 38.4 lb

NOTE The following items are included in the package:

MCACC Setup microphone 1

Remote control unit 1

AAA size C R03 dry cell batteries 2

iPod cable..... 1

AM loop antenna..... 1

M wire antenna..... 1

Warrant card 1

Power cord

C-ROM Audio navigator

These operating instructions



NOTE

- Specifications and the design are subject to possible modifications without notice, due to improvements.
- This product includes content from Avenue Content, a licensed content provider. Avenue is a registered trademark of C Corporation.

Manufactured under license from Dolby Laboratories. "Dolby", "Pro Logic", "Surround EX" and the double-D symbol are trademarks of Dolby Laboratories.

Manufactured under license under U.S. Patent Nos: 5,956,674, 5,974,380, 5,978,762, 6,487,535, 6,226,616, 7,212,872, 7,003,467, 7,272,567, 7,668,723, 7,392,195, 7,333,929, 7,548,853, 7,283,634, 7,853,022 & other U.S. and world-wide patents issued and pending. DTS-HD, the Symbol, & DTS-HD and the Symbol together are registered trademarks & DTS-HD Master Audio is a trademark of DTS, Inc. Product includes software. © DTS, Inc. All Rights Reserved.

THX, the THX logo Ultra2 Plus and Select2 Plus are trademarks of THX Ltd. which are registered in some jurisdictions. All rights reserved. All other trademarks are the property of their respective owners.

Apple, AirPlay, the AirPlay logo, iPad, iPhone, iPod, iPod shuffle, iPod nano, iPod classic, iPod touch, iTunes and Mac are trademarks of Apple Inc., registered in the U.S. and other countries.

SIRIUS, XM and all related marks and logos are trademarks of Sirius XM Radio Inc. and its subsidiaries. All rights reserved.

SC-57 SPECIFICATIONS

Audio Specifications

Continuous Power Output (CPO) is the average power output of the amplifier over a 1 kHz bandwidth, measured at 1 kHz, 8 Ω, 0.08 V RMS, 10% THD+N, and 10% modulation. CPO is measured pursuant to the Federal Trade Commission's Trade Regulation rule on Power Output Claims for Amplifiers.

Multi channel simultaneous power output

1 kHz, 100 W, 8 Ω

9 ch total.....720 W

Continuous Power Output 1 kHz, 8 Ω, 0.08 V

Front.....140 W 140 W

Center.....140 W

Surround.....140 W 140 W

Surround back.....140 W 140 W

Front height Front wide.....140 W 140 W

Continuous Power Output 1 kHz, 6 Ω, 1.0 V

Front.....180 W 180 W

Center.....180 W

Surround.....180 W 180 W

Surround back.....180 W 180 W

Front height Front wide.....180 W 180 W

Total harmonic distortion ... 0.04% 1 kHz, 130 W

130 W, 8 Ω

Guaranteed speaker impedance..... 6 Ω to 16 Ω

** Measured pursuant to the Federal Trade*

Commission's Trade Regulation rule on Power Output Claims for Amplifiers

*** Measured by Audio Spectrum Analyzer*

Audio Specifications

Input Sensitivity Impedance

PHONO MM..... 5 mV 47 k Ω

Line..... 400 mV 47 k Ω

Output Level Impedance

Rated..... 380 mV 2.2 k Ω

Signal-to-Noise Ratio (H, short circuited, A network)

Line..... 103 dB

Technical Specifications

Frequency Range (M)..... 87.5 MHz to 108 MHz

Antenna Input (M)..... 75 Ω unbalanced

Frequency Range (AM)..... 531 kHz to 1602 kHz

Antenna (AM)..... Loop antenna balanced

Video Specifications

Signal level

Composite video..... 1 V p-p 75 Ω

Component video..... 1.0 V p-p 75 Ω,

PB PR 0.7 V p-p 75 Ω

Corresponding maximum resolution

Component video..... 1080p 1125p

video convert to

Dimensions and Connections

HDMI terminal..... 19-pin D-sub

HDMI output type..... 5 V, 55 mA

USB terminal..... USB2.0 Full Speed type A

iPod terminal..... USB, and video Composite

S/R US antenna cable..... 8-pin mini cable

APR POR terminal..... 5 V, 100 mA

R/L SS LA A APR R

terminal..... 5 V, 600 mA

Control and Signal Specifications

Control SR terminal..... 3.5 Mini-D-sub MO

Control R terminal..... 3.5 Mini-D-sub MO

R signal..... High Active High Level 2.0 V

12 V trigger terminal..... 3.5 Mini-D-sub MO

12 V trigger output type..... 12 V, total 150 mA

RS-232C cable type..... 9-pin, cross type, female-female

S/O terminal..... 5 V, 150 mA

Network and Signal Specifications

LAN terminal..... 10BASE-T 100BASE-T

Power Requirements

Power requirements..... AC 120 V, 60 Hz

Power consumption..... 370 W

Standby..... 0.1 W

HDMI Setup Control On

..... 0.3 W HDMI Setup Control On

Dimensions

..... 435 mm x 185.6 mm H x 440.3 mm

17 3/16 in. x 7 5/16 in. H x 17 3/8 in.

Weight without package 17.4 kg 38.4 lb

Contents

MCACC Setup microphone 1

Remote control unit 1

AAA size C R03 dry cell batteries 2

iPod cable 1

AM loop antenna 1

FM wire antenna 1

Power cord

CD-ROM Manual

These operating instructions



Notes

- Specifications and the design are subject to possible modifications without notice, due to improvements.
- This product includes content from Avenue content licensed by C Corporation. Avenue is a registered trademark of C Corporation.

Manufactured under license from Dolby Laboratories. "Dolby", "Pro Logic", "Surround EX" and the double-D symbol are trademarks of Dolby Laboratories.

Manufactured under license under U.S. Patent Nos: 5,956,674, 5,974,380, 5,978,762, 6,487,535, 6,226,616, 7,212,872, 7,003,467, 7,272,567, 7,668,723, 7,392,195, 7,333,929, 7,548,853, 7,283,634, 7,853,022 & other U.S. and world-wide patents issued and pending. DTS-HD, the Symbol, & DTS-HD and the Symbol together are registered trademarks & DTS-HD Master Audio is a trademark of DTS, Inc. Product includes software. © DTS, Inc. All Rights Reserved.

THX, the THX logo and Select2 Plus are trademarks of THX Ltd. which are registered in some jurisdictions. All rights reserved. All other trademarks are the property of their respective owners.

Apple, AirPlay, the AirPlay logo, iPad, iPhone, iPod, iPod shuffle, iPod nano, iPod classic, iPod touch, iTunes and Mac are trademarks of Apple Inc., registered in the U.S. and other countries.

SIRIUS, XM and all related marks and logos are trademarks of Sirius XM Radio Inc. and its subsidiaries. All rights reserved.

ASICS FOR SERVICE

CHECK POINTS AFTER SERVICING

After servicing, please check the following items.

To keep the product quality after servicing, confirm recommended check points shown below.

N.	Project	Check points
1	Confirm whether the customer complain has been solved. If the customer complain occurs with the particular source, such as Dolby Digital, S, AAC, DTS and H.264, input it or the operation check.	The customer complain must not be reappeared. Video, Audio and operations must be normal.
2	Check the analog audio playback. Make the analog connections with a player.	Each channel audio and operations must be normal.
3	Check the digital audio playback. Make the digital connections with a player.	Each channel audio and operations must be normal.
4	Check surround playback. Select Surround mode and check the multichannel operations via the SP circuit.	Each channel audio and operations must be normal.
5	Check the video outputs. Connect with a player.	Video and operations must be normal.
6	Check the tuner AM and FM operations.	Audio and operations must be normal.
7	Check the sound from headphone output.	Sound must be normal, without noise.
8	Check the appearance of the product.	No scratches or dirt on its appearance after receiving it for service.

See the table below for the items to be checked regarding video and audio.

Video	Audio
Block noise	Distortion
Horizontal noise	Noise
Licker	Volume too low
Disturbed image video jumpiness	Volume too high
Too dark	Volume fluctuating
Too bright	Sound interrupted
Mottled color	


Cleaning




Before shipping out the product, be sure to clean the following positions by using the prescribed cleaning tools.

Part	Tool	Part No.	Remarks
Lens	Cleaning paper	-008	Refer to 9.4 CHASSIS SECTION.

PC LOCATIONS





NOTES: ● Parts marked by “NSP” are generally unavailable because they are not in our Master Spare Parts List.
 ● The $\triangle$ mark found on some component parts indicates the importance of the safety factor of the part.
 Therefore, when replacing, be sure to use parts of identical designation.

□ □ □ □ NSP. D □ □ □ □ □ □ □ □

P □ □ □ NSP.

□ □ □ □ NSP. D □ □ □ □ □ □ □ □

P □ □ □ NSP.

LIST OF ASSEMBLIES

	1..IR POWER AMP ASSY(SC-57)	AWH7030		NSP	1..INTERFACE REG ASSY	AWR7111
	1..IR POWER AMP ASSY(SC-55/SC-1526-K)	AWH7039			2..INTERFACE ASSY	AWX9805
NSP	1..IR BUFFER ASSY	AWM8249			2..IR REG ASSY	AWX9806
	2..IR BUFFER ASSY	AWX9793			2..B DIODE ASSY	AWX9808
	2..BUFFER GND ASSY	AWX9795			2..PRE BRIDGE ASSY	AWX9809
					2..A REG BRIDGE ASSY	AWX9810
NSP	1..PRIM DISPLAY ASSY(SC-57/SC-55)	AWM8250		NSP	2..PRIMARY SHIELD ASSY	AWX9811
	2..DISPLAY ASSY	AWX9796		NSP	2..BIND B CABLE ASSY	AWX9807
	2..VOL ASSY	AWX9797		NSP	2..FFC GUARD 2 ASSY	AWX9812
	2..POWER SW ASSY	AWX9798				
	2..PRIMARY ASSY	AWX9799		NSP	1..REG BRIDGE ASSY(SC-57)	AWR7112
	2..MIC HP ASSY	AWX9800			2..REG ASSY	AWX9813
	2..ENCODER ASSY	AWX9801			2..FRONT BRIDGE ASSY	AWX9814
	2..MIC HP GUARD ASSY	AWX9803			2..DISPLAY BRIDGE ASSY	AWX9815
	2..FAN CONNECT ASSY	AWX9804			2..F-IN BRIDGE ASSY	AWX9816
	2..BIND DM CABLE ASSY	AWX9863			2..MCH BRIDGE ASSY	AWX9818
					2..FB-CONNECT ASSY	AWX9819
					2..CONNECT ASSY	AWX9820
NSP	1..PRIM DISPLAY ASSY(SC-1526-K)	AWM8267			2..USB RECT ASSY	AWX9821
	2..DISPLAY ASSY	AWX9847			2..MULTI CH IN ASSY	AWX9857
	2..VOL ASSY	AWX9797		NSP	2..VREG GUARD ASSY	AWX9895
	2..POWER SW ASSY	AWX9901				
	2..PRIMARY ASSY	AWX9799		NSP	1..REG BRIDGE ASSY(SC-55/SC-1526-K)	AWR7117
	2..MIC HP ASSY	AWX9800			2..REG ASSY	AWX9813
	2..ENCODER ASSY	AWX9801			2..FRONT BRIDGE ASSY	AWX9814
	2..MIC HP GUARD ASSY	AWX9803			2..DISPLAY BRIDGE ASSY	AWX9815
	2..FAN CONNECT ASSY	AWX9804			2..F-IN BRIDGE ASSY	AWX9816
	2..BIND DM CABLE ASSY	AWX9863			2..FB-CONNECT ASSY	AWX9819
					2..CONNECT ASSY	AWX9820
NSP	1..AUDIO COMPOSITE ASSY(SC-57)	AWR7106			2..USB RECT ASSY	AWX9821
	2..D-AUDIO BRIDGE ASSY	AWX9769		NSP	2..VREG GUARD ASSY	AWX9895
	2..D-DAC BRIDGE ASSY	AWX9935				
	2..A-DAC BRIDGE ASSY	AWX9936			1..FRONT HDMI USB ASSY	AWX9749
	2..AUDIO ASSY	AWX9790				
	2..COMPOSITE ASSY	AWX9791			1..IR INTERFACE ASSY	AWX9792
NSP	1..AUDIO COMPOSITE ASSY(SC-55/SC-1526-K)	AWR7110			1..DAC HIGH ASSY(SC-57)	AWX9822
	2..D-AUDIO BRIDGE ASSY	AWX9769			1..DAC HIGH ASSY(SC-55/SC-1526-K)	AWX9860
	2..D-DAC BRIDGE ASSY	AWX9935				
	2..A-DAC BRIDGE ASSY	AWX9936			1..DIGITAL MAIN ASSY(SC-57)	AWX9827
	2..AUDIO ASSY	AWX9833			1..DIGITAL MAIN ASSY(SC-55/SC-1526-K)	AWX9824
	2..COMPOSITE ASSY	AWX9836				
					1..COMPONENT ASSY(SC-57)	AWX9866
					1..COMPONENT ASSY(SC-55/SC-1526-K)	AWX9865
					1..FM/AM TUNER UNIT	AXX7282

1.1 11 S LIST

111111 L111

A

N11 1		111 N1.	R11 1111
39P	C	1681	iagnosis or AU O ASS , R BU R ASS , R PO R AMP ASS , R R AC ASS
15P	C	1680	iagnosis or AU O ASS , R BU R ASS , R PO R AMP ASS , R R AC ASS
30P	30P board to board extension ig cable	1682	iagnosis or AL MA ASS , AU O ASS , AC H H ASS
28P	14P board to board extension ig cable	1763	iagnosis or AC H H ASS
23P	23P board to board extension ig cable	1761	iagnosis or AU O ASS , R BU R ASS , R PO R AMP ASS
20P	board to board extension ig cable	1677	iagnosis or AL MA ASS , COMPOS ASS
20P	14P board to board extension ig cable	1759	iagnosis or AL MA ASS , AU O ASS , R BU R ASS , R PO R AMP ASS , R R AC ASS
15P	7P board to board extension ig cable	1762	iagnosis or AL MA ASS , AU O ASS
5P	PH Housing Ass	1594	iagnosis or AU O ASS , R BU R ASS , R PO R AMP ASS , R R AC ASS

C

■

5

■

6

■

7

■

8

■

A

■

B

■

C

■

■

■

■

5

■

6

■

7

■


8


■

SC-57

LOC DIA RA


OVERALL IRIN DIA RA





- When ordering service parts, be sure to refer to PLO S and PAR S L S or PCB PAR S L S.
- The  mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
-  The power supply is shown with the marked box.

B DIODE ASSY (AWX9808)




MO	L	U1	U2	U4	U10	U11, U12	U13, U14	U15	U21, U22	U31, U32	U61, U62
SC-57 SC-55 SC-1526-K	U JCB CU J	R K1154 10A 125	-	R K1139 2A H 250	R K1149- 4A 125	R K1143- 1.25A 125	R K1142- 1A 125	R K1143- 1.25A 125	R K1143- 1.25A 125	R K1143- 1.25A 125	-

The  mark found on some component parts should be replaced with same parts as at registration authority and identical designation.


















MO	L	MA	RA S	AC COR
SC-57 SC-55	U JCB	A S7447-1 A S7438-1	A S7438-1	A 7111-
SC-1526-K	CU J	A S7438-1	A S7438-1	A 7111-

CAU O - OR CO U PRO C O A A S RSKO R ,
R PLAC H SAM P A RA SO US .




1/11 - 11/11) AL MAIN ASSY (SC-57/SC-55:AWX9827, SC-1526-K:AWX9824)


AA A-DAC BRIDGE ASSY (AWX9936)



SC-57



17





C





→ SF



DIGITAL

MSP

C

M P
Co

USB
MMA
C101

H	M
C1602	C1603


H M
R

0000




27.0MHz

SC-57




A

VIDEO LOC DIA RA




CO POSITE VIDEO LOC DIA RA



LOC DIA RA OR CO PONENT VIDEO LOC

A CO PONENT VIDEO LOC DIA RA



■

5

■

6

■

7

■

8

■

A

■

B

■

C

■

■

■

■

■

■

5

■

6

■

7


■

8

■


SC-57






LOC DIA RA OR POWER LOC ()

P P S D (A I N T P)







. DIA NOSIS

. DIA NOSIS LO C ART

NO POWER

This is just for general reference and does not include every single case.






NO L DISPLA


his is ust or general re erence and does not including ever single case.


A





NO SOUND

this is just a general reference and does not include every single case.










NO PICTURE

this is just a general reference and does not include every single case.




OTHER

This is just for general reference and does not include every single case.


A

IR V T




B

RS-232C




C

R Remote




IR SR



DIAGNOSTIC ALGORITHM LOCATIONS CART


1) Noise



NOTE Wiring number listed is the example of front L-ch

2) Diagnostic Method C-Section Error Section

Failure locating method from error symptom is available as diagnosis after product shutdown. Diagnosis flow Chart from error symptom due to Amplifier Section is shown here.



Cause of being B RR
When B-Power Supply voltage exceeds ~ 75
When B-Power Supply voltage falls below ~ 20

Cause of being OL
At Over Current detected not worked with no-load
At river C not Oscillated
At OB L detection Circuit Activated

Cause of being C
When C 7 or above is output in Audio Output Line

Cause of being MP RR
When MOS temperature exceeds approx. 95 degrees
When MOS temperature is suddenly increased

CIRCUIT DESCRIPTION

Power Amplifier Circuit Layout

A


Amplifier Circuit

Item	Power Amplifier	Driver Amplifier	Speaker Amplifier	Speaker Amplifier	Speaker Amplifier
Overheat detection	detects MOS temperature of amplifier output stage	detects when MP RR POR becomes L in case of the detecting temperature exceeds 95 C or rapid change of short circuit of speaker terminals. C3001 72pin	lashes O RH A. Shuts down when abnormality continues or more than 3 seconds.	Blinks L O L indicator.	Recoverable by power-on after shutdown in one minute.
		detects when MA MP port becomes below 1.9 at C thermistor detect circuit. C3001 2pin	an rotates by power-on.		MA MP voltage 5 -1.8 A LO 1.8 or less A H H
C detection	detects C of amplifier output after LP	detects when SP output exceeds C 7 and C RR port becomes L. C3001 80pin	MU on and Speaker Relay. lashes AMP RR. Shuts down when abnormality continues or more than 3 seconds.	Blinks A A C MCACC L	In case of detecting C abnormality during power-on sequence after the C was once detected. Recoverable by only C cancel. Refer to How to enter Release Mode.
			MU on and Speaker Relay. lashes AMP RR. Shuts down when abnormality continues or more than 3 seconds.	Blinks L O L indicator.	In case of detecting C abnormality during normal operation. Recoverable by power-on after 1 minute.
Abnormality detection	detects abnormal rotation of loose connector or lock when controlling the rotation	detects when A port becomes L. C3001 87pin	lashes A S OP. Shuts down when abnormality continues or more than 3 seconds.	Blinks iPod iPhone iPad L	Recoverable by power-on
Obel detection	Protects overcurrent of obel Resistance when high power output of higher re uenc continued	detects OL RR port becomes L. C3001 71pin	Shuts down	Blinks iPod iPhone iPad L	Recoverable by power-on
Overcurrent detection	Protects overcurrent of MOS in output stage when overcurrent flows at the output stage	detects OL RR port becomes L. C3001 71pin	Shuts down	Blinks iPod iPhone iPad L	Recoverable by power-on
Amplifier Power Supply failure detection	detects abnormal in the Amplifier Power Supply	detects B-Power Supply voltage exceeds 75 or falls below 20 and B RR port becomes L. C3001 84pin	Shuts down	Blinks A A C MCACC L	Recoverable by only C cancel. Refer to How to enter Release Mode.



Power Amplifier Circuit

Using Standby mode, simultaneously press and hold the U ↓ and MUL - O O O keys for 5 seconds.

R IR POWER AMP ASSY



R IR POWER AMP ASSY




Power Management (VDDERR)

I	P	D	S	E	I	R
USB power failure detection	Detection of failure in regulator circuit or external supply	Detected when USB voltage reaches 7 or higher, or 4.1 or lower and RR port is set to L	Shuts down		Blinks iPod	Restoration possible with Power On

VDDERR Control

FRONT HDMI USB ASSY



1. SERVICE MODE

1.1 TEST MODE

Press **D** to enter the test mode.

Press **P** to enter the test mode.

The numbers of detections or various protection processes are displayed.

Press **0** to set the power to this unit by setting the main volume level to ---dB and Multi- to 0.

During Standby mode, simultaneously press and hold **MUL** - **0** - **0** - **0** and **R** for 5 seconds to enter this mode.


Press **0** to set the power to this unit by setting the main volume level to ---dB and Multi- to 0.

Key operation	LED display
Press number of times C is detected.	C ***
Press number of times O RLOA is detected.	OL ***
Press number of times COMB A O is detected. Effects C and O RLOA simultaneously	COM ***
Press number of times A S OP is detected.	A ***
Press number of times AMP overheat is detected.	S MP ***
Press number of times Digital Power abnormality is detected.	RR ***
Press number of times BR power supply overheat is detected.	B MP ***
Press number of times BR power supply failure is detected.	B RR ***

Press **P** to enter the test mode.

- ↓ U Ke
- ↑ U Ke
- ← PR S Ke
- PR S Ke

This function does not work
on this model.




□□□□□□□□

C C S he unction or making the H M output terminal to output 1 kH s uare wave. the s uare wave is output, the C C line is considered to be normal.

A S he unction or making the A to be orced to rotate.


PARTE

Quando si rimuove il pannello posteriore 57U, i punti indicati di seguito devono essere collegati a terra. Prima di girare l'unità ON, assicurarsi di collegare i punti indicati con la carcassa. Oppure, si può cortocircuitare i punti di collegamento sulla superficie saldata, utilizzando pezzi di filo.



STRUMENTI E MATERIALI

A ABA1011	B ABA1207	C ABA7078	D BB 30P060 CC
E BM 30P040 B	B BP 30P080 B	B CB 30P080 B	C BP 30P100 C



注意事項

1. 本マニュアルに示す写真やイラストは、本製品の修理に共通の手順を示しています。
2. 以下の診断手順に従って修理を行う場合は、以下の部品やサービスが必要です。

39P	C	1681	
15P	C	1680	
30P	30P board to board extension	ig cable	1682
28P	14P board to board extension	ig cable	1763
23P	23P board to board extension	ig cable	1761
20P	20P board to board extension	ig cable	1677
20P	14P board to board extension	ig cable	1759
15P	7P board to board extension	ig cable	1762
5P	PH Housing Ass		1594

(注) 本製品の修理には、上記の部品やサービスが必要です。

準備作業

ボナネットの取り外し

ボナネットを取り外すには、16本のネジを取り外します。

ボナネットのネジを取り外す位置は、図に示す位置です。

図に示す位置のネジを取り外します。





ケーブルの取り外し

1. Release the 15P CC A 7745 from the two PCB binders.
2. Disconnect the three connectors.
3. Release the two cables from the Cord Clamper HL.
4. Remove the three screws. BB 30P060 CC
5. Remove the 15P CC A 7745 from the M C HP UAR ASS.

15P CC A 7745 is fixed with the double side tape 10 x 110mm.

ケーブルの取り付け


- *1 PCB binder tilt in the direction of the blue arrow.
- *2 15P C A 7745 don't touch cable from Power trans former.
- *3 Don't touch cables to iode.




- 6 Release the jumper wires from the three PCB binders.

注意事項

- *1 Jumper wire A 7753 from SPLA ASS don't touch J7657 and J7904 or the SPLA BR ASS .
- *2 don't touch the 39P C A 7753 to a top o screw.
- *3 Bind as not to touch 39P C A 7753 and Jumper wire A 7753 .




- 7 Remove the two screws. BB 30P080 B
- 8 Remove the two screws. ABA1193



Bottom view



- 9 Remove the three screws. BB 30P080 CC
- 10 Unhook the two hooks.
- 11 Remove the front Section.



op view

注意事項

Connect the two connectors and arrange the unit as shown in the photo.



Remove the Bonnet 85 b removing the 16 screws.

When you perform diagnosis on the side-B of AU O ASS, please refer to last part of Step, Remove the Bonnet 85 b removing the 16 screws.

Remove the Bonnet 85 b removing the 16 screws.

Remove the Bonnet 85 b removing the 16 screws.

- 1 Cut the Binder.
- 2 Release the cables from the two PCB binders.
- 3 Remove the 39P C A 7746 b disconnect the two connectors.
- 4 Disconnect the three connectors.
- 5 Remove the screw. BB 30P060 CC




Remove the Bonnet 85 b removing the 16 screws.

- *1 H M Cable and 5P Housing ASS A 7748 bind together inside.
- *2 Attention to stable cables as shown in the photo.

- 6 Remove the 15P C A 7725 b disconnect the two connectors.
- 7 Release the upper wire A 7746 from COMPO ASS from hook of the R UAR ASS.
- 8 Release the upper wires from two PCB binders.
- 9 Disconnect the connector.

Remove the Bonnet 85 b removing the 16 screws.



- *1 Twist PCB binder around the upper wire A 7746 so that it does not contact B-CO C ASS or plate.
- *2 Our upper wires don't contact.
- *3 PCB binder tilt in the direction of the blue arrow and pull the upper wire A 7745 from AU O ASS to the opposite direction blue arrow.




- 10 Remove the PR BR ASS .
- 11 Release the umper wire A 7750 rom PR MAR ASS rom PCB binder.

注意事項


- *1 Pass the umper wire A 7750 rom PR MAR ASS under the R ASS .
- *2 PCB binder tilt in the direction o the blue arrow.



- 12 Remove the six Cushion Circle 14B.





- 13 Remove the six screws. BP 30P100 C
- 14 Remove the AC inlet b removing the two screws. CB 30P080 B
- 15 Remove the three screws. BP 30P080 B
- 16 Remove the 21 screws. ABA1011
- 17 Remove the Rear Section.



注意事項 Also disconnect the umper wire A 7747 rom R AC ASS rom the COMPO ASS .

注意事項


- *1 Bind umper wire A 7747 rom R AC ASS , using the PCB binder.



□□□□ D□□□□□□□□

- 1 Arrange the unit as shown in the photo.
- 2 Insert the Insulation Sheet.
- 3 Connect the Rear Panel 57U to the Under Base 85 round and point of the R PO R AMP ASS.


Refer to the □□ □□□□ P□□□□□ or the point of the R PO R AMP ASS.



- 4 Attach the PR BR ASS.
- 5 Connect the two pair board to board extension ig cables. 1761 (PRE BRIDGE CN6951 <-> IR BUFFER CN6801)


N□□□□ In case of using 1761 with the this condition, only using a left side connector on the ig board.

- 6 Disconnect the connector.
- 7 Connect the 5P PH Housing ASS ig cable. 1594 (AUDIO ADX7745 <-> REG CN7502)



- 8 Connect the 39P CC ig cable. 1681
(DIGITAL MAIN CN601 <-> DISPLAY BRIDGE CN7651)
- 9 Connect the 15P CC ig cable. 1680
(AUDIO CN2503 <-> FRONT BRIDGE CN7724)


front



- 10 Connect the two pair board to board extension ig cables. 1759
(DIGITAL MAIN CN602 <-> CONNECT CN7802)
(DIGITAL MAIN CN603 <-> CONNECT CN7801)

N In case of diagnosis by this situation, do not connect H M Cable from RO H M USB ASS to prevent breakdown of H M connector.
If the H M connection is necessary, use another normal H M Cable and connect it to AL MA ASS without an stress from H M Cable.

front




N When diagnosing, it is not necessary to connect A cable A CO C ASS C 5931.

N When diagnosing, it is not necessary to connect A cable A CO C ASS C 5931.

*1 PCB binder tilt in the direction of the blue arrow.

*2 This upper wire don't touch upper and screw.

front



IR PO ER A P ASS

Remove the Rear Section.

A Refer to the **R** **S**


IR C

- 1 Cut the Binder.
- 2 Remove the two screws. ABA1011
- 3 Remove the PR MAR ASS .

N



*1 After the upper wire is bounded, pull the extra length to the direction indicated by the blue arrow.

B



- 4 disconnect the two connectors.
- 5 Remove the RO BR ASS rom the two PCB Holder, using Pliers.


C



- 6 Cut the Binder.
- 7 Remove the seven screws.
AM 30P060 C
- 8 Disconnect the two connectors and then remove the R Cover 85 with our ass s.

N

o attach the R Cover 85 in the correct position, refer to step 9 and subsequent steps in it,  **IR A**  .




Attach the connectors securely.



- C

- ront

- 5 Attach the PR MAR ASS, using the two screws ABA1011.
- 6 Connect the Rear Panel 57U to the Under Base 85 round and point o the R PO R AMP ASS.
- Re er to the □□ □□□□ P□□□□□.




□□□□ R□□ □□□ □□ IR A□ □□□□□□□□□□

- 1 isconnect the two pair board to board extension ig cables 1761 and remove the PR MAR ASS and RO BR ASS.

Re er to the steps 3 to 1 o
□□□□□ D□□□□□□□□□□

- 2 isconnect the six extension ig cables.
Re er to the steps 10 to 5 o
□□□□□ D□□□□□□□□□□

- 3 isconnect the six connectors.





- 4 isconnect the connector.


- 5 Release the 5P Housing ASS rom the Cord Clamper HL.

N□□□ □□ □□□□□ □□□□□


*1 on t touch cables to iode.



6 Arrange the unit as shown in the photo.




7 Set up the main unit part as shown in the photo, and remove six screws.
BP 30P080



8 Remove the R Amplifier Block.

Refer to the **Amplifier Block** or the installation procedure of the R Amplifier Block.




DAC ASS

Remove the Bonnet 85 b removing the 16 screws.


Remove the AC BR ASS

- 1 Remove the - AC BR ASS .
- 2 Remove the A- AC BR ASS .

ront




- 3 Remove the screw. BM 30P040 B
- 4 Remove the five screws. BP 30P080 B
- 5 Remove the five screws. ABA1011
- 6 Remove the AC inlet b removing the two screws. CB 30P080 B




- 7 Release the upper wire from PCB binder.
- 8 Cut the Binder.

Remove the PCB binder


- *1 PCB binder tilt in the direction of the blue arrow.
- *2 After the upper wire is bounded, pull the extra length to the direction indicated by the blue arrow.



- 9 Remove the two screws. ABA1011
- 10 Remove the PR MAR ASS .
- 11 Remove the two Push Rivet. A C7071
- 12 Remove the Push Rivet. A C7071 SC-57 U JCB onl
- 13 Disconnect the connector. SC-57 U JCB onl
- 14 Remove the PR MAR SH L ASS .




15 Remove the AC H H ASS .




□□□□ D□□□□□□□□

- 1 Attach the PR MAR ASS , using the two screws ABA1011 .
- 2 Connect the two pair board to board extension ig cables. 1682
(DAC HIGH CN2102 <-> DIGITAL MAIN CN9003)
(DAC HIGH CN2101 <-> DIGITAL MAIN CN9002)
- 3 Connect the two pair board to board extension ig cables. 1763
(DAC HIGH CN2103 <-> AUDIO CN2502)
(DAC HIGH CN2104 <-> AUDIO CN3001)



ront

- 4 Insert the Insulation Sheet.
- 5 Connect the AC H H ASS to the Rear Panel 57U ground.
- Refer to the 



DIITAL MAIN ASS


Remove the Bonnet 85 b removing the 16 screws.

Remove the Screws

- 1 Cut the Binder.
- 2 Release the cables from the two PCB binders.
- 3 Disconnect the connector.
- 4 Remove the screw. BB 30P060 CC

Remove the Screws


- *1 H M Cable and 5P Housing ASS
A 7748 bind together inside.



- 5 Release the upper wire A 7746 from COMPO ASS from hook of the R UAR ASS.
- 6 Release the upper wire from PCB binder.

Remove the Screws


- *1 Twist PCB binder around the upper wire A 7746 so that it does not contact B-CO C ASS or plate.



- 7 disconnect the two connectors.
- 8 disconnect the two connectors and then remove the CO C ASS .
- 9 disconnect the connector.

注意事項 作業手順 確認事項



- *1 Bind umper wire A 7747 rom R AC ASS , using the PCB binder.



- 10 Remove the - AC BR ASS .
- 11 Remove the A- AC BR ASS .
- 12 Remove the -AU O BR ASS .
- 13 Release the umper wire rom PCB binder.
- 14 Remove the two Push Rivet. A C7071

注意事項 作業手順 確認事項


- *1 PCB binder tilt in the direction o the blue arrow.




- 15 Release the umper wire A 7750 rom PR MAR ASS rom PCB binder.

注意事項 作業手順 確認事項


- *1 Pass the umper wire A 7750 rom PR MAR ASS under the R ASS .
- *2 PCB binder tilt in the direction o the blue arrow.





- 16 Remove the nine screws. BM 30P040 B
- 17 Remove the nine screws. BP 30P080 B
- 18 Remove the two Hex head Screws. ABA7078
- 19 Remove the three screws. ABA1011
- 20 Remove the three screws. ABA1011 SC-57 U JCB onl




- 21 Lift the AL MA ASS from the PR MAR SH L ASS side.
- 22 Disconnect the two connectors and then remove the AL MA ASS.




- 23 Remove the two Ion Rivet. A C7406 SC-57 U JCB onl
- 24 Remove the two screws. BB 30P060 CC SC-57 U JCB onl
- 25 Remove the . Main Shield 85. SC-57 U JCB onl



- 26 Arrange the AL MA ASS as shown in the photo.
- 27 Insert the Insulation Sheet.
- 28 Remove the AC H H ASS.




- 29 Disconnect the connector and then remove the COMPO ASS.



ITAL
AIN ASS

- 1 Attach the COMPO ASS to the AL MA ASS.
- 2 Attach the CO C ASS to the R AC ASS.
- 3 Connect the two pair board to board extension ig cables. 1759 (DIGITAL MAIN CN602 <-> CONNECT CN7802) (DIGITAL MAIN CN603 <-> CONNECT CN7801)
- 4 Connect the two pair board to board extension ig cables. 1677 (COMPONENT CN8303 <-> CONPOSITE CN3601)

In case of using 1677 with this condition, only using either of connector on the ig board.



- 5 Connect the two pair board to board extension ig cables. 1762
(DIGITAL MAIN CN1503 <-> AUDIO CN3901)
(DIGITAL MAIN CN1502 <-> AUDIO CN2861)

- 6 Connect the two pair board to board extension ig cables. 1763
(DAC HIGH CN2103 <-> AUDIO CN2502)
(DAC HIGH CN2104 <-> AUDIO CN3001)


7P 15P board to board extension ig cable 1762

- 7 Connect the two pair board to board extension ig cables. 1682
(DAC HIGH CN2102 <-> DIGITAL MAIN CN9003)
(DAC HIGH CN2101 <-> DIGITAL MAIN CN9002)

- 8 Insert the Insulation Sheet.


- 9 Connect the AL MA ASS and the AC H H ASS to the Rear Panel 57U ground.

Refer to the □□ □□□□ □□□□□□.



- N**□□□□ In case of diagnosing AL MA ASS
b this situation, do not connect H M Cable from RO H M USB ASS to prevent breakdown of H M connector.
the H M connection is necessary, use another normal H M Cable and connect it to AL MA ASS without an stress from H M Cable.

- N**□□□□B placing the AC H H ASS on the AL MA ASS from the above status, it is possible to perform diagnosis both on the AC H H ASS and the side-B of AU O ASS simultaneously.




Assembly of the R Amplifier Block

Note: The attachment positioning of the R Amplifier block relates to sound quality of the unit. If assembled in the wrong steps, sound quality would deteriorate. Please assemble it correctly following the procedure shown below.


When you removed only the R Cover 85, perform from step 9.

- 1 Allocate the R Amplifier block from which the R Cover 85 is removed. Do not fix it with screws.
- 2 Connect the six connectors.





- 3 Temporarily attach the Rear Panel 57U with other ass to the Under Base 85, using the three screws. ABA1011

Note: Fix the ALMA ASS to the hook of the Right Angle 85.




- 4 Temporarily attach the R Box 85 to the Rear Panel 57U, using the two screws. ABA1011
- 5 Attach the R Amplifier block to the Under Base 85, using the six screws. BP 30P080



- 6 Remove the five screws. ABA1011
- 7 Remove the Rear Panel 57U.

A




B


- 8 Allocate the R Cover 85 with our ass. Do not fix it with screws.
- 9 Connect the two connectors.

NOTE: It is difficult to connect the two connectors of the R BU R ASS, at first remove the A R BR ASS and then try to connect them.


C



- 10 Remove the PR BR ASS from Rear Section.




- 11 Temporarily attach the Rear Panel 57U with other ass. to the Under Base 85, using the three screws. ABA1011
- 12 Temporarily attach the R Cover 85 to the Rear Panel 57U, using the two screws. ABA1011




- 13 Attach the R Cover 85 to the R Box 85 from upper face, using the three screws.
AM 30P060 C

NOTE Secure the screws for fixing the R Cover 85 without using the electric screwdriver, but manually.



- 14 Remove the five screws ABA1011 from the Rear Panel 57U.
Refer to the step 12 11
- 15 Remove the Rear Panel 57U.
- 16 Attach the R Cover 85 to the R Box 85 completely, using the four screws.
AM 30P060 C
- 17 Attach the binder.



- 18 Attach the RO BR ASS and PR MAR ASS.
Refer to the step 5 to 1 of IR C

1. EAC SETTING AND ADJUSTMENT

1.1 ADJUSTMENT REQUIRED WHEN THE UNIT IS REPAIRED OR REPLACED

A ■ 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100

SPLA ASS

8.3 R O R

AL MA ASS

8.2 HO O SA A LOA H S US
BACKUP U C O H USB M MOR

Other assemblies

o ad ustment re uired

B

■ 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100

AL MA ASS

o ad ustment re uired
he part listed below is difficult to replace as a discrete component part. When the part listed in the table is defective, replace whole Ass .

C101 UP 61283 1-407LU2A

C903 S 9233AC U

C905 S 9387C U

C1204 88 2750

C1212 MA H5PS5162 R-S5C-K

C1212 SUB K4 51163 -HC 7

JA1501 CKS5712-A

C1602 S 9136C U

C1603 S 9136C U

C9002 810K013B KB400-K

C9702 810K013B KB400-K

C9203 LA 8700C-A

C9204 M860

C9205 A 7346-A

C9509 MM1701 H

C9510 JM2846 L3-33

C

R PO R AMP ASS

o ad ustment required
he part listed below is difficult to replace as a discrete component part. When the part listed in the table is defective, replace whole Ass .

4101,4102 R 6775MPB

4201,4202 R 6775MPB

4301,4302 R 6775MPB

4401,4402 R 6775MPB

4501,4502 R 6775MPB

4601,4602 R 6775MPB

4701,4702 R 6775MPB

4801,4802 R 6775MPB

4901,4902 R 6775MPB

Other assemblies

o ad ustment re uired

his model is capable of saving the set values stored in the MA Ucom of AL MA ASS in the USB and loading them in a new AL MA ASS .
 Note that MA Ucom should normally operate to enable this function.

When replacing AL MA ASS , execute the above mentioned processes.

The following items can be saved. Data other than these can be saved.

Contents to save	Destination to save
Last memory or turning ON the Main power and power supply Last memory or inputting the Main , 2 and 3 Setting or controlling H M Remote control Setting or R remote control S O Setup Setting or network Standby Data to be saved upon the operation of protection circuit	Ucom
Settings or HM Preset Memory , favorite, Recently played, etc.	BridgeCo C

As the data saved by Ucom is on the SPLA ASS , the data cannot be deleted unless Ass is replaced at the same time.

The USB memory to be used should meet the following requirements.

- Compatible with USB Mass storage Class
- With a file system of FAT32

The files are to be saved in the following format: Model number backup version.extension
 Example SC-57 BK01.avr

The AV file is saved in the USB.

- Insert the usable USB memory into the USB terminal when the main device is on.
- Enter the S R C MO and select USB BAK ◀ HOL ▶ with ↑↓ keys.
 See 6.1 S MO or how to enter the S R C MO .
- Select USB BAK ◀ SA ▶ with ⇐⇒ keys and press R .
- Saving in the USB starts and the main device automatically goes on after the normal completion COMPL is displayed.
- Remove the USB and saving is finished.

- If the following errors occur after SA is executed, error message will be displayed and SA will be stopped and the power will be turned off.
 - Connecting to USB device
 - Short capacity of USB device
 - Error during writing in the USB device Read Only or defective Sector, etc.
- If the same file name exists in the USB, overwriting will be automatically executed.

The AV file is loaded from the USB.

- Insert the USB with the saved file into the USB terminal when the main device is on.
- Enter the S MO and select USB BAK ◀ HOL ▶ with ↑↓ keys.
 See 6.1 S MO or how to enter the S MO .
- Select USB BAK ◀ LOA ▶ with ⇐⇒ keys and press R .
- Saving in the main device starts and it automatically goes on after the normal completion COMPL is displayed.
- Remove the USB and loading is finished.

- If the following errors occur after LOA is executed, error message will be displayed and LOA will be stopped and the power will be turned off.
 - No setting file
 - Mismatching between the setting file and the specification of the ARC Remote type to be loaded back
 - Error due to Checksum, Signature Check, and Size Check
 - Connecting to USB device during reading of the setting file

Precautions

- Files are stored in Root of USB memory.
 - Files are read from Root of USB memory.
 - ⇒ To make operations such as moving files, be sure to assign the saved file in Root of the USB memory.
- Also please be careful not to assign .avr in multiple numbers.

- The time and date of updating or saved file is fixed to 2010.01.01 00:00.
- In principle, please implement Load without making of actor default settings.
 - o Load from actor default settings status, please take caution on the following points

Please be sure to check the H/M control setting or the user before performing of actor default settings.

Since the H/M control setting of default settings is OFF, turn ON the H/M control setting and Load after performing of actor default settings in the checked user setting is OFF.

Load is executed with the setting ON, the assignment information of each H/M input will be cleared.

Procedures of turning ON the H/M control setting
⇒ HOM M U ⇒ 4.S stem Setup ⇒ 4e.H M Setup ⇒ Control ON

2. REGION INITIALIZATION

This is the function to write Region information by using a USB Memory.
Automatic start-up is conducted with PO R O if the Region information is not written.
This work is carried out when SPLA ASS is replaced.

Precautions

- Please copy the R O file of the same model number and the point of destination with the object set to the route director of USB Memory.
 - o Copy only the R O file to the USB memory. Never copy to other files.

Precautions


Please be sure to use the R O file of the same model number and the point of destination with the object set.
If you make a mistake, it is impossible to rewrite. Replacement of SPLA ASS is required again.

Key operation	LED display
Plug in the AC cord. o Region information	
	
Power On Automaticall	P O R O
	
Start up finished	
Function initial display	S R O
	
Connect USB Memory. Loading finished correctly	
Region writing finished	S C - 5 7 U J C B

Precautions

- Connect an AC cord after replacing SPLA ASS. Power turns ON automatically.
- S R O is displayed several seconds after PO R O is displayed on the front panel. Standby status or R O file writing.
- Automatic writing starts when USB memory prepared by Preparation 1 is inserted. Agree of several seconds.
- The written model number is displayed after the normal completion of R O file writing. 14 characters, maximum.
- Pull out the AC cord.

A



B


□□□□P□□□□□□

↓ U ke

↑ U ke


← PR S ke


→ PR S ke



*** displa ed instead o number indicates the process while the version is obtained. ait or a while until the version is displa ed.

C



Ke operation	L displa
UP A L searching completed 	Updating process * Updating. 20
SP UP A completed 	Updating process * Updating. 40
BridgeCo C UP A completed 	Updating process * Updating. 60
MA com MMA UP A completed 	Updating process * Updating. 80
SUB com UP A completed 	Update completion displa * Updating. 100
5 Second 	
Power turns o automaticall . All O O isconnect the USB M MOR .	

Update time is luctuated b contents o the update. t will take about 20 minutes at the maximum.
Actual time is rom 2 minutes to 15 minutes.
ime re uired or updating varies, because onl the programs that re uire updating will be updated.




nter UP A PA L mode and check that the programs have been updated.

1 2 3 4 EXPLODED VIEW AND PARTS LIST

- NOTES:
- Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
 - The  mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
 - Screws adjacent to  mark on product are used for disassembly.
 - For the applying amount of lubricants or glue, follow the instructions in this manual. (In the case of no amount instructions, apply as you think it appropriate.)

PACK IN SECTION



() PAC IN SECTION PARTS LIST

Part No.	Description	Part No.	Part No.	Description	Part No.
1	30P iPod Cable	A 7136	11	Caution Sheet SP,	ARM7083
2	AC Power Cord	A 7111	12	Operating nstructions C -ROM	See Contrast table 2 A
3	M ire Antenna	A H7030	SP 13	arrant Card	See Contrast table 2
4	Packing Pad	AHA7494	14	Remote Control Unit S L M U A	7612
5	Packing Pad R	AHA7495	15	Batter oor	A 8047
6	Packing Case	See Contrast table 2	16	Packing Sheet	RHC1023
SP 7	Pol eth lene Bag	AH 7117	SP 17	r Cell Batter R3	M1051
8	MCACC Setup Microphone	APM7009	SP 18	Serial Label S	R 2017
9	Operating nstructions n	See Contrast table 2	19	AM Loop Antenna	B3004
10	Operating nstructions r	See Contrast table 2			

() CONTRAST TA LE

SC-57 U JCB, SC-55 U JCB and SC-1526-K CU J are constructed the same except or the following

Part No.	Description	SC-57 U JCB	SC-55 U JCB	SC-1526-K CU J
6	Packing Case	AH 8722	AH 8728	AH 8729
9	Operating nstructions n	ARB7459	ARB7459	ARB7461
10	Operating nstructions r	ot used	ot used	ARC8004
12	Operating nstructions C -ROM	ARU7006	ARU7023	ARU7016
SP 13	arrant Card	AR 7007	AR 7007	ot used



(C) ETERIOR SECTION PARTS LIST

Part No.	Description	Part No.	Part No.	Description	Part No.
1	M C HP UAR ASS	A 9803	26	Push Rivet	A C7071
2	A CO C ASS	A 9804	27	op Beam 85 M L	A 7726
3	R R ASS	A 9806	28	Lisence Label	AR 7419
4	B O ASS	A 9808	29	Bonnet 85 BO	A 8050
SP 5	C UAR 2 ASS	A 9812	SP 30	Mini Clamp	C1597
6	SPLA BR ASS	A 9815	31	Screw Steel	ABA1011
7	- BR ASS	A 9816	32	Screw 3 x 10B Steel	ABA1193
8	USB R C ASS	A 9821	33	Screw 4 x 12	ABA7109
⚠ 9	Power rans ormer	See Contrast table 2	34	Cup Screw 3 x 8 CC	ABA7149
⚠ 10	use U13, U14 1A	R K1142	35	Screw	BB 30P080 CC
⚠ 11	use U11, U12, U15 1.25A	R K1143	36	Screw	BB 30P060 CC
⚠ 12	use U10 4A	R K1149	37	Screw	BC 40P060 B
13	15P C J0002	A 7745	38	Screw	BP30P090 CC
14	39P C J0015	A 7746	39	Screw	B 30P180 C
15	4P Housing ASS 0020	A 7755	40	Screw	BB 30P080 B
16	4P Housing ASS 0025	A 7757	41	oothed Lock asher	H40
17	2P Housing ASS 0024	A 7758	SP 42	Binder BK-1	CA-BK1
18	3P Housing ASS 0023	A 7759			
19	3P Housing ASS	A 7766			
20	7P Housing ASS 0022	A 7767			
21	Cord Clamper HL	A C7653			
22	Cushion 11 x 7	A 7092			
23	PCB Mold PP	AMR2533			
24	nsulator	AMR7198			
SP 25	Panel Sta 85 M L	A 7684			

(C) CONTRAST TABLE

SC-57 U JCB, SC-55 U JCB and SC-1526-K CU J are constructed the same except for the following

Part No.	Description	SC-57 U JCB	SC-55 U JCB	SC-1526-K CU J
⚠ 9	Power rans ormer	A S7447	A S7438	A S7438

10



() REAR SECTION PARTS LIST


Part No.	Description	Part No.	Part No.	Description	Part No.
1	-AU O BR ASS	A 9769	21	Cushion Circle 14B	A 7081
2	AU O ASS	See Contrast table 2	22	terminal Screw	AK -031
3	COMPOS ASS	See Contrast table 2	23	Rear Panel 57U M L	See Contrast table 2
4	- AC BR ASS	A 9935	24	Right Angle 85 M L	A 7687
5	A- AC BR ASS	A 9936	25	. Main Shield 85 M L	See Contrast table 2
6	PR BR ASS	A 9809	SP 26	PC Support	See Contrast table 2
7	PR MAR SH L ASS	A 9811	SP 27	Serial Label S	R 2017
SP 8	B B CABL ASS	A 9807	28	Screw Steel	ABA1011
9	MCH BR ASS	See Contrast table 2	29	Screw 3 x 6B Steel	ABA1207
10	CO C ASS	A 9820	30	Screw	BB 30P060 CC
11	MUL CH ASS	See Contrast table 2	31	Screw	BM 30P040 B
SP 12	R UAR ASS	A 9895	32	Screw	BP 30P080 B
13	AC H H ASS	See Contrast table 2	33	Screw	BP 30P100 C
14	AL MA ASS	See Contrast table 2	34	Screw	CB 30P080 B
15	COMPO ASS	See Contrast table 2	35	Push Rivet	A C7071
16	AM M uner Unit	A 7282	36	Ion Rivet	See Contrast table 2
17	15P C 60 J0003	A 7725	SP 37	Binder BK-1	CA-BK1
18	9P C J0007	A 7748	38	Hex head Screw 2.85 7 BS	ABA7078
19	Locking Spacer PLS	See Contrast table 2			
20	SP Sheet 85 PC	A C7651			

() CONTRAST TABLE

SC-57 U JCB, SC-55 U JCB and SC-1526-K CU J are constructed the same except for the following

Part No.	Description	SC-57 U JCB	SC-55 U JCB	SC-1526-K CU J
2	AU O ASS	A 9790	A 9833	A 9833
3	COMPOS ASS	A 9791	A 9836	A 9836
9	MCH BR ASS	A 9818	ot used	ot used
11	MUL CH ASS	A 9857	ot used	ot used
13	AC H H ASS	A 9822	A 9860	A 9860
14	AL MA ASS	A 9827	A 9824	A 9824
15	COMPO ASS	A 9866	A 9865	A 9865
19	Locking Spacer PLS	A C7643	ot used	ot used
23	Rear Panel 57U M L	A C8599	A C8605	A C8606
25	. Main Shield 85 M L	A K7162	ot used	ot used
SP 26	PC Support	C1749	ot used	ot used
36	Ion Rivet	A C7406	ot used	ot used

C ASSIS SECTION



(C) C ASSIS SECTION PARTS LIST


Part No.	Description	Part No.	Part No.	Description	Part No.
1	R PO R AMP ASS	See Contrast table 2	26	PCB Mold PP	AMR7536
2	R BU R ASS	A 9793	27	Heat Sink Spacer PLS	AMR7568
3	BU R ASS	A 9795	SP 28	Under Base 85 M L	A A7236
4	PR MAR ASS	A 9799	SP 29	R Box 85 M L	A 7061
5	B M CABL ASS	A 9863	SP 30	R Cover 85 M L	A 7062
6	R AC ASS	A 9805	31	R ASS Plate 85 M	A 7688
7	A R BR ASS	A 9810	32	Center Beam 85 M L	A 7689
8	R ASS	A 9813	SP 33	Heat Sink 85 AL	A H7234
9	RO BR ASS	A 9814	34	rans rame 85 M L	A 7685
10	B-CO C ASS	A 9819	35	Screw Steel	ABA1011
11	R R AC ASS	A 9792	36	Screw 3 x 12	ABA1052
⚠ 12	C an Motor	A M7040	37	Screw 3 x 11.6	ABA7146
⚠ 13	use U4 2A	R K1139	38	Screw	AM 30P060 C
⚠ 14	use U21, U22, U31, U32 1.25A	R K1143	39	Screw	BB 30P060 CC
⚠ 15	use U1 10A	R K1154	40	Screw	BB 30P180 CC
16	19P C J0004	A 7747	41	Screw	BP 30P080
17	Cushion 5 x 8	A B7397	42	Screw	B 30P150 CC
18	Cushion 3 20 x 35	A B7406	43	Screw	BB 30P060 C
19	amper Bushing 83	A B7425	SP 44	Binder BK-1	CA-BK1
20	Radiation Sheet	A B7428	SP 45	PCB Holder	P 2100
SP 21	PCB Spacer	A C1446			
22	PCB Spacer 3 x 12	A C7080			
23	nsulating Sheet	A C7654			
24	PCB Mold PP	AMR2533			
25	nsulator C PLS	AMR7523			

(C) CONTRAST TABLE

SC-57 U JCB, SC-55 U JCB and SC-1526-K CU J are constructed the same except or the following

Part No.	Description	SC-57 U JCB	SC-55 U JCB	SC-1526-K CU J
1	R PO R AMP ASS	A H7030	A H7039	A H7039

FRONT SECTION



NOTE * Please pay attention not to hurt Panel Base 55U when you remove the front Panel.

NOTE * Please tape up at our 4 places to protect Panel Base 55U as shown on the photograph when you remove the front Panel.


Left side



Right side



NOTE * Double Side tape 10mm x 30mm fixing position on front Panel



() FRONT SECTION PARTS LIST

Part No.	Description	Part No.	Part No.	Description	Part No.
1	SPLA ASS	See Contrast table 2	21	Cushion Circle 6B	A 7083
2	OL ASS	A 9797	22	Cushion 11 x 7	A 7092
3	PO R S ASS	See Contrast table 2	SP 23	Panel Base 55U PLS	AMB8041
4	M C HP ASS	A 9800	24	oor Sha t 60 PLS	AMR7531
5	CO R ASS	A 9801	25	oor Base 85 PLS	AMR7565
6	RO H M USB ASS	A 9749	26	oor Panel 57U AL	See Contrast table 2
7	5P C J0006	A 7749	27	ront Panel AL	See Contrast table 2
8	39P C J0019	A 7753	28	amper ASS 240 L	A A7156
9	H M Cable	A 7732	29	P O R Badge AL	See Contrast table 2
10	5P Housing ASS 0026	A 7748	30	Screw	BB 30P080 B
11	OL Knob L 85 AL	AAA7064	31	Screw	BP 30P080
12	S B B L 85 ASS	AA 7804	32	ut	K90 C
13	ilter 07KU PC	See Contrast table 2			
14	ispla Panel	See Contrast table 2			
15	Power Ring L 85 PLS	AAK8571			
16	Ring	ABH7213			
17	oor Spring SUS	ABK7061			
18	arth Spring 81 SUS	ABK7067			
19	arth Spring 85 SUS	ABK7070			
20	OL Stabili er L 85	A C7644			

() CONTRAST TABLE

SC-57 U JCB, SC-55 U JCB and SC-1526-K CU J are constructed the same except for the following

Part No.	Description	SC-57 U JCB	SC-55 U JCB	SC-1526-K CU J
1	SPLA ASS	A 9796	A 9796	A 9847
3	PO R S ASS	A 9798	A 9798	A 9901
13	ilter 07KU PC	AAK8443	AAK8443	AAK8459
14	ispla Panel	AAK8567	AAK8567	AAK8573
26	oor Panel 57U AL	A B7562	A B7562	A B7563
27	ront Panel AL	A B7565	A B7568	A B7569
29	P O R Badge AL	AM1159	AM1159	AM1158




A AUDIO ASSY (1/3)
(SC-57 : AWWX9790)
(SC-55/SC-1526-K: AWWX9833)

AA C 3794


AD C 7724

A C 3774

A C 3722



- when ordering service parts, be sure to refer to PLO S and PAR SLS or PCB PAR SLS.
- the $\triangle$ mark on some component parts indicates the importance of the safety factor of the part. hereore, when replacing, be sure to use parts of identical designation.
- the power supply is shown with the marked box.





- When ordering service parts, be sure to refer to PLO S and PAR S L S or PCB PAR S L S .
- The  mark found on some component parts indicates the importance of the safety factor of the part. Here, when replacing, be sure to use parts of identical designation.
- The power supply is shown with the marked box.

AA C 3792

A C 5775

A-a	A-b
-----	-----

CONNECTOR

92

1

2

3


4


SC-57

AC

C 3785

PU S L C OR





A


B

C

A-a A-b

[illegible]

PR BU R




Component parts should be replaced
station authorized or identical

1. R S S ORS
Unit k-kΩ, M-MΩ or Ω unless otherwise noted.
Rated Power 1/10W unless otherwise noted.
tolerance J 5% unless otherwise noted.
2125 RS1 8S
2. CAPAC ORS
O MARK
O marked Ceramic Capacitors are CKSR B.
O marked Electrolytic Capacitors are C A S and SA series
CH CCSRCH C H C H S unless otherwise noted.
Unit p-p or u-u unless otherwise noted.
Ratings Capacitance unless otherwise noted.
1000p or less CCSRCH Over 1000p CKSR B
3. M O Mount

AUDIO ASSY (2/3)

(SC-57 : AWX9790)
(SC-55/SC-1526-K : AWX9833)



he Δ mark ound on some component parts should be replaced
with same parts sa et regulation authori ed o identical
designation.




□□.□ DAC □□□ ASS (□□□)

A

B

C




100

SC-57

C





he mark ound on some component parts
should be replaced with same parts
sa et regulation authori ed o
identical designation.

1. R S S ORS
Unit k-kΩ, M-MΩ or Ω unless otherwise noted.
Rated Power 1 16w unless otherwise noted.
tolerance J 5 unless otherwise noted.

2. CAPAC ORS
marked Capacitors are C A or CKSR B or CKS
CH CCSRCH or CCSSCH
Unit p-p or u-u unless otherwise noted.
Ratings Capacitance unless otherwise noted.

3. M Mount



A



C 1501


A N E PLODED VIE S AND PARTS LIST

ELECTRICAL PARTS LIST.




B

C



DIGITAL MAIN ASSY (1/11)
(SC-57 : AWX9827)
(SC-55/SC-1526-K : AWX9824)







DIGITAL MAIN ASSY (1/11)
(SC-57 : AWP9827)
(SC-55/SC-1526-K: AWP9824)

1 2 3 4

DIITAL AIN ASSI ()

	A 9727 MH S J	A 9824 ML CU	A 9825 SH CU	A 9826 SL CU	A 9827 MH CU	A 9920 SH S	SL S	A 9921 SH J	A 9920 ML S J
C618	1000 50	1000 50	1000 50	1000 50	1000 50	1000 50		1000 50	100 50
C650	1000 50	1000 50	1000 50	1000 50	1000 50	1000 50		1000 50	100 50
C652	1000 50	1000 50	0.1u 16	0.1u 16	1000 50	1000 50		1000 50	100 50
C657	0.1u 16	0.1u 16	1000 50	1000 50	0.1u 16	0.1u 16		0.1u 16	0.1u 16
C658	0.1u 16	0.1u 16	1000 50	1000 50	0.1u 16	0.1u 16		0.1u 16	0.1u 16
C661	1000 50	1000 50	0.1u 16	0.1u 16	1000 50	1000 50		1000 50	100 50
C671	1000 50	1000 50	0.1u 16	0.1u 16	1000 50	1000 50		1000 50	100 50
C672	0.1u 16	1000 50	1000 50	1000 50	0.1u 16	0.1u 16		0.1u 16	0.1u 16
C677	3300 50	3300 50	3300 50	3300 50	3300 50	3300 50		3300 50	3300 50
R610	1M	M	M	M	M	M		1M	M
R615	10	10	0	0	10	0		0	10
R616	1M	M	M	M	M	M		1M	M
R624	10	10	0	0	0	0		0	10
R625	10	10	0	0	10	10		10	10
R638	100	58	58	58	100	58		100	100
R657	10	0	0	0	10	10		10	10
R666	M	M	100	100	M	100		M	100
R687	M	M	100	100	M	100		M	100
R688	M	M	100	100	M	100		M	100
R716	10	10	0	0	10	10		10	10
R723	10	10	0	0	10	10		10	10
R725	10	10	0	0	10	10		10	10

	A 9727 MH S J	A 9824 ML CU	A 9825 SH CU	A 9826 SL CU	A 9827 MH CU	A 9920 SH S	SL S	A 9921 SH J	A 9920 ML S J
C206	0.1u 16	0.1u 16	M	M	0.1u 16	M		M	0.1u 16
C758	100 50	100 50	M	M	100 50	M		M	100 50
C759	0.1u 16	0.1u 16	M	M	0.1u 16	M		M	0.1u 16
R652	100	100	M	M	100	M		M	100
R656	100	100	M	M	100	M		M	100
R685	100	100	M	M	100	M		M	100
R702	100	100	M	M	100	M		M	100
R703	100	100	M	M	100	M		M	100
R704	47k	47k	M	M	47k	M		M	47k
R710	47k	47k	M	M	47k	M		M	47k
R711	47k	47k	M	M	47k	M		M	47k
R712	47k	47k	M	M	47k	M		M	47k
R715	47k	47k	M	M	47k	M		M	47k
R722	100	100	M	M	100	M		M	100
R724	100	100	M	M	100	M		M	100
R728	100	100	M	M	100	M		M	100
R729	100	100	M	M	100	M		M	100
C601	C74 HC 08A K51	C74 HC 08A K51	M	M	C74 HC 08A K51	M		M	C74 HC
C607	C74 HC 08A K51	C74 HC 08A K51	M	M	C74 HC 08A K51	M		M	C74 HC
K 601	1948-A	1948-A	M	M	1948-A	M		M	1948-




	A 9727 MH S J	A 9824 ML CU	A 9825 SH CU	A 9826 SL
C687	M	M	0.1u 16	0.1u 16
C688	M	M	0.1u 16	0.1u 16
C689	M	M	0.1u 16	0.1u 16
R776	M	M	47k	47k
R778	M	M	5.6k	5.6k
R780	M	M	47k	47k
R783	M	M	47k	47k
R785	M	M	5.6k	5.6k
R786	M	M	2.7k	2.7k
C 604	M	M	KM000 AZL	KM000 AZL
C 605	M	M	KM000 AZL	KM000 AZL
C 606	M	M	KM000 AZL	KM000 AZL
607	M	M	R 4983	R 4983
608	M	M	R 4983	R 4983
609	M	M	R 4983	R 4983
P616	M	M	S PO	S PO
P617	M	M	S PO	S PO
P689	M	M	S PO	S PO
P690	M	M	S PO	S PO
P691	M	M	S PO	S PO


MC CU	A 9025 SH CU	9026 BL CU	A 9027 MH CU	A 9030 SH S	BL S	A 9031 SH J	A 9050 ML S J
	0.1u 16	0.1u 16	M	0.1u 16		0.1u 16	M
	0.1u 16	0.1u 16	M	0.1u 16		0.1u 16	M
	0.1u 16	0.1u 16	M	0.1u 16		0.1u 16	M
	47k	47k	M	47k		47k	M
	5.6k	5.6k	M	5.6k		5.6k	M
	47k	47k	M	47k		47k	M
	47k	47k	M	47k		47k	M
	5.6k	5.6k	M	5.6k		5.6k	M
	2.7k	2.7k	M	2.7k		2.7k	M
	KM000 AZL	KM000 AZL	M	KM000 AZL		KM000 AZL	M
	KM000 AZL	KM000 AZL	M	KM000 AZL		KM000 AZL	M
	KM000 AZL	KM000 AZL	M	KM000 AZL		KM000 AZL	M
	R 4983	R 4983	M	R 4983		R 4983	M
	R 4983	R 4983	M	R 4983		R 4983	M
	R 4983	R 4983	M	R 4983		R 4983	M
	S PQ	S PQ	M	S PQ		S PQ	M
	S PQ	S PQ	M	S PQ		S PQ	M
	S PQ	S PQ	M	S PQ		S PQ	M
	S PQ	S PQ	M	S PQ		S PQ	M
	S PQ	S PQ	M	S PQ		S PQ	M

DIITAL ASS ()


A



B



C




has a mark on some component parts should be replaced with same parts as registered with authority.

O 1. M O MOU

All 1u 10 is CH1246-A.

	A 9727 MH S	A 9823 ML CU	A 9823 SH CU	A 9823 SL CU	A 9827 MH CU	A 9920 SH S	A
C991	CH1277-A	200u4	200u4	200u4	CH1277-A	200u4	220
C998	ACH7306-A	M	M	M	ACH7306-A	M	10
C1008	100u 50	470p 50	470p 50	470p 50	470p 50	470p 50	25
C1011	100u 50	100u 50	100u 50	100u 50	100u 50	100u 50	100
C1031	CH1234-A	100u 16	100u 16	100u 16	CH1234-A	100u 16	100
R903	10	10	0	0	10	0	0
R908	10	10	0	0	10	0	0
R910	10	10	0	0	10	0	0
R914	10	10	0	0	10	0	0
R1038	10	10	0	0	10	0	0
R1077	10	10	0	0	10	0	0

DIGITAL MAIN ASSY (3/11) **(SC-57 : AWX9827)** **(SC-55/SC-1526-K: AWX9824)**



A


B


C

A

B

C






DIGITAL MAIN ASSY (4/11) **(SC-57 : AWX9827)** **(SC-55/SC-1526-K : AWX9824)**

△ mark found on some component
 parts should be replaced with same
 parts as at regulation authority ed
 identical designation.

All 1u 10 is CH1246-A.

	C1205	C1305
A 9727 MH S J	1000p 50	CH1277-A
A 9828 ML	1000p 50	220u 4
A 9828 SH CU	1000p 50	220u 4
A 9828 SL CU	1000p 50	220u 4
A 9827 MH CU	1000p 50	CH1277-A
A 9828 SH S	SL S	220u 4
A 9828 SH J	1000p 50	220u 4



DIITAL AIN ASS ()

A

B

C

C BS
C CB
C CR
ideo Signal Route

C 8302

C 8301

	A 9727 MH S J	A 9824 ML CU	A 9825 SH CU	A 9826 SL CU	A 9827 MH CU	A 9930 SH S . SL S	A 9931 SH J	A 9950 ML S J
C1724	100p 50	100p 50	M	M	100p 50	M	M	100p 50
C1727	100p 50	100p 50	M	M	100p 50	M	M	100p 50
C1770	100u 16	M	M	M	100u 16	M	M	M
R1724	10	0	0	0	10	0	0	10
R1725	10	10	0	0	10	0	0	10

SC-57

118




DIGITAL MAIN ASSY (5/11) (SC-57 : AWX9827) (SC-55/SC-1526-K: AWX9824)

A

B


C




A


B

C



C






	A	9727 MH S J	A	9824 ML CU	A	9825 SH CU	A	9826 SL CU	A	9827 MH CU	A	9930 SH S	SL S	A	9931 SH J	A	9950 ML S J
CR101	10p 50				M	M			10p 50	M			M				10p 50
CR105	10p 50			10p 50			27p 50		10p 50			10p 50					10p 50
CR106	10p 50			10p 50			27p 50		10p 50			10p 50					10p 50
CR154	0.1u 50			0.1u 50		M	M		0.1u 50		M						0.1u 50
CR155	1000p 50			1000p 50		M	M		1000p 50		M						1000p 50
CR609	0			0		M	M		0		M						0
CR686	0			0		M	M		0		M						0
CR903	120		33		33		33		33		120		33				10
RR100	47		47		47		47		47		M		M				47
RR101	0					M	M		0		M		M				0
RR104	18		22		22		22		18		22		22				18
RR111	10		0		0		0		10		0		10				10
RR703	M		M		0		0		M		0		0				M
RR704	M		M		0		0		M		0		0				M
RR705	M		M		0		0		M		0		0				M
RR706	M		M		0		0		M		0		0				M
RR710	0		0		M		M		0		M		0				0
RR711	47k		47k		M		M		47k		M		M				47k
RR743	10		10		M		M		10		M		10				10
RR749	47		47		M		M		47		M		M				47
RR750	47		47		M		M		47		M		M				47
RR751	47		47		M		M		47		M		M				47
RR752	47		47		M		M		47		M		M				47
RR753	47		47		M		M		47		M		M				47
RR754	47		47		M		M		47		M		M				47
RR756	47k		47k		M		M		47k		M		M				47k
RR756	1k		1k		M		M		1k		M		1k				1k
RR757	47k		47k		M		M		47k		M		M				47k
RR759	47		47		M		M		47		M		M				47
RR761	1k		1k		M		M		1k		M		1k				1k
RR762	1k		1k		M		M		1k		M		1k				1k
LR704	L1129-A		L1129-A		M		M		L1129-A		M		M				L1129-A
CR703	M 25L1606 MZ-12		M 25L1606 MZ-12		M		M		M 25L1606 MZ-12		M		M				M 25L1606 MZ-12



A

B

C






DIGITAL MAIN ASSY (9/11)

(SC-57 : AWX9827)
(SC-55/SC-1526-K : AWX9824)

A

B

C








the mark found on some component parts should be replaced with same parts as at registration authority or identical designation.

1. M O MOU

All 1u 10 is CH1246-A.

DIGITAL MAIN ASSY (10/11)
(SC-57 : AWX9827)
(SC-55/SC-1526-K: AWX9824)



	A 9727 MH S J	A 9824 ML CU	A 9825 SH CU	A 9826 SL CU	A 9827 MH CU	A 9930 SH S SL S	A 9931 SH J	A 9950 ML S J
C9537	CH1234-A	M	M	M	CH1234-A	M	M	M
C9545	1000u 16	1000u 16	1000u 10	1000u 10	1000u 16	1000u 10	1000u 16	1000u 16
C9546	1000u 16	1000u 16	1000u 10	1000u 10	1000u 16	1000u 10	1000u 16	1000u 16
C9547	6800p 25	1000p 50	1000p 50	1000p 50	6800p 25	1000p 50	1000p 50	1000p 50
C9553	4700p 50	1000p 50	1000p 50	1000p 50	4700p 50	1000p 50	1000p 50	1000p 50
C9562	100p 50	100p 50	1000p 50	1000p 50	100p 50	M	100p 50	M
C9565	4700p 50	1500p 50	1500p 50	1500p 50	1500p 50	1500p 50	1500p 50	1500p 50
C9566	10p 50	10p 50	1000p 50	1000p 50	10p 50	10p 50	10p 50	10p 50
C9570	6800p 25	1000p 50	1000p 50	1000p 50	1000p 50	1000p 50	6800p 25	6800p 25
C9577	ACH7309-A	M	M	M	M	M	M	ACH7309-A
C9578	ACH7314-A	M	M	M	M	M	M	ACH7314-A
C9621	0.1u 16	100p 50	0.1u 16	0.1u 16	100p 50	0.1u 16	0.1u 16	0.1u 16
C9623	10p 50	10p 50	0.1u 16	0.1u 16	10p 50	10p 50	10p 50	10p 50
C9625	10p 50	10p 50	0.1u 16	0.1u 16	10p 50	10p 50	10p 50	10p 50
C9629	10p 50	10p 50	0.1u 16	0.1u 16	10p 50	10p 50	10p 50	10p 50
C9643	10p 50	10p 50	0.1u 16	0.1u 16	10p 50	10p 50	10p 50	10p 50
C9662	100p 50	100p 50	0.1u 16	0.1u 16	100p 50	100p 50	100p 50	100p 50
C9667	10p 50	10p 50	0.1u 16	0.1u 16	10p 50	10p 50	10p 50	10p 50
C9696	10p 50	10p 50	M	M	10p 50	M	10p 50	10p 50
C9696	22p 50	22p 50	0.1u 16	0.1u 16	22p 50	22p 50	22p 50	22p 50
C9697	100p 50	100p 50	0.1u 16	0.1u 16	100p 50	100p 50	100p 50	100p 50
R9514	3.6M	4.7M	4.7M	3.6M	3.6M	3.6M	3.6M	3.6M
R9518	82	1.5k	1.5k	1.5k	82	1.5k	1.5k	1.5k
R9519	330	1.5k	1.5k	1.5k	330	1.5k	1.5k	1.5k
R9520	7.5k	33k	33k	33k	7.5k	33k	33k	33k
R9521	8.2k	16k	16k	16k	6.2k	16k	16k	16k
R9522	3.3k	15k	15k	15k	3.3k	15k	15k	15k
R9531	9.1k	33k	33k	33k	33k	33k	9.1k	33k
R9532	5.6k	12k	12k	12k	12k	12k	5.6k	12k
R9533	6.8k	24k	24k	24k	24k	24k	6.8k	24k
R9534	470	2.4k	2.4k	2.4k	2.4k	2.4k	470	2.4k
R9535	300	1.1k	1.1k	1.1k	1.1k	1.1k	300	1.1k
R9536	M	0	0	0	0	0	M	M
R9540	M	0	0	0	0	0	M	M
R9542	M	0	0	0	0	0	M	M
R9543	M	0	0	0	0	0	M	M
R9555	M	0	0	0	0	0	M	M
R9564	M	0	0	0	0	0	M	M

DI ITAL AIN ASS ()

DIGITAL MAIN ASSY (11/11)

(SC-57 : AWX9827)
(SC-55/SC-1526-K: AWX9824)

R O ABL or AL MA ASS 5 11

A	9727 MH S J	A	9824 ML CU.	A	9825 SH CU	A	9826 SL CU	A	9827 MH CU.	A	9930 SH S .	SL S	A	9931 SH J	A	9950 ML S J
C1602	1000p 50		1000p 50		1000p 50	M			1000p 50		1000p 50		1000p 50		1000p 50	
C1606	CH1201-A		CH1201-A		CH1201-A	M			CH1201-A		CH1201-A		CH1201-A		CH1201-A	
C1618	1u 10		1u 10		1u 10	M			1u 10		1u 10		1u 10		1u 10	
C1619	470p 50		470p 50		470p 50	M			470p 50		470p 50		470p 50		470p 50	
C1620	1u 10		1u 10		1u 10	M			1u 10		1u 10		1u 10		1u 10	
C1621	470p 50		470p 50		470p 50	M			470p 50		470p 50		470p 50		470p 50	
C1622	1u 10		1u 10		1u 10	M			1u 10		1u 10		1u 10		1u 10	
C1623	330p 50		330p 50		330p 50	M			330p 50		330p 50		330p 50		330p 50	
C1624	0.1u 16		0.1u 16		0.1u 16	M			0.1u 16		0.1u 16		0.1u 16		0.1u 16	
C1625	470p 50		470p 50		470p 50	M			470p 50		470p 50		470p 50		470p 50	
C1626	1u 10		1u 10		1u 10	M			1u 10		1u 10		1u 10		1u 10	
C1627	470p 50		470p 50		470p 50	M			470p 50		470p 50		470p 50		470p 50	
C1629	100p 50		100p 50		100p 50	M			100p 50		100p 50		100p 50		100p 50	
C1631	0.1u 16		0.1u 16		0.1u 16	M			0.1u 16		0.1u 16		0.1u 16		0.1u 16	
C1635	0.1u 16		0.1u 16		0.1u 16	M			0.1u 16		0.1u 16		0.1u 16		0.1u 16	
C1638	100p 50		100p 50		100p 50	M			100p 50		100p 50		100p 50		100p 50	
C1639	470p 50		470p 50		470p 50	M			470p 50		470p 50		470p 50		470p 50	
C1642	0.1u 16		0.1u 16		0.1u 16	M			0.1u 16		0.1u 16		0.1u 16		0.1u 16	
C1643	0.1u 16		0.1u 16		0.1u 16	M			0.1u 16		0.1u 16		0.1u 16		0.1u 16	
C1645	470p 50		470p 50		470p 50	M			470p 50		470p 50		470p 50		470p 50	
C1647	0.01u 25		0.01u 25		0.01u 25	M			0.01u 25		0.01u 25		0.01u 25		0.01u 25	
C1649	100p 50		100p 50		100p 50	M			100p 50		100p 50		100p 50		100p 50	
C1656	CH1201-A		CH1201-A		CH1201-A	M			CH1201-A		CH1201-A		CH1201-A		CH1201-A	
C1657	1u 10		1u 10		1u 10	M			1u 10		1u 10		1u 10		1u 10	
C1658	470p 50		470p 50		470p 50	M			470p 50		470p 50		470p 50		470p 50	
C1659	0.1u 16		0.1u 16		0.1u 16	M			0.1u 16		0.1u 16		0.1u 16		0.1u 16	
C1660	1000p 50		1000p 50		1000p 50	M			1000p 50		1000p 50		1000p 50		1000p 50	
C1661	100p 50		100p 50		100p 50	M			100p 50		100p 50		100p 50		100p 50	
C1663	1000p 50		1000p 50		1000p 50	M			1000p 50		1000p 50		1000p 50		1000p 50	
C1665	100u 16		100u 16		100u 16	M			100u 16		100u 16		100u 16		100u 16	
C1667	470p 50		470p 50		470p 50	M			470p 50		470p 50		470p 50		470p 50	
C1671	10p 50		10p 50		10p 50	M			10p 50		10p 50		10p 50		10p 50	
C1672	ACH7306-A		M		M	M			ACH7306-A		M		M		M	
C1673	ACH7306-A		M		M	M			ACH7306-A		M		M		M	
C1675	C 1066-A		C 1066-A		C 1066-A	M			C 1066-A		C 1066-A		C 1066-A		C 1066-A	
C1677	C 1066-A		C 1066-A		C 1066-A	M			C 1066-A		C 1066-A		C 1066-A		C 1066-A	
C1679	C 1066-A		C 1066-A		C 1066-A	M			C 1066-A		C 1066-A		C 1066-A		C 1066-A	
C1681	C 1066-A		C 1066-A		C 1066-A	M			C 1066-A		C 1066-A		C 1066-A		C 1066-A	
C1684	C 1066-A		C 1066-A		C 1066-A	M			C 1066-A		C 1066-A		C 1066-A		C 1066-A	
C1687	C 1066-A		C 1066-A		C 1066-A	M			C 1066-A		C 1066-A		C 1066-A		C 1066-A	
C1688	1u 16		1u 16		1u 16	M			1u 16		1u 16		1u 16		1u 16	
C1690	C 1066-A		C 1066-A		C 1066-A	M			C 1066-A		C 1066-A		C 1066-A		C 1066-A	
C1692	C 1066-A		C 1066-A		C 1066-A	M			C 1066-A		C 1066-A		C 1066-A		C 1066-A	
C1694	1u 16		1u 16		1u 16	M			1u 16		1u 16		1u 16		1u 16	
C1698	10p 50		10p 50		10p 50	M			10p 50		10p 50		10p 50		10p 50	
C1699	330p 50		330p 50		330p 50	M			330p 50		330p 50		330p 50		330p 50	
C1700	0.1u 16		0.1u 16		0.1u 16	M			0.1u 16		0.1u 16		0.1u 16		0.1u 16	
C1703	100p 50		100p 50		100p 50	M			100p 50		100p 50		100p 50		100p 50	
R1610	22		22		22	M			22		22		22		22	
R1624	47		47		47	M			47		47		47		47	
R1627	10		10		10	M			10		10		10		10	
R1632	4.7k		4.7k		4.7k	M			4.7k		4.7k		4.7k		4.7k	
R1635	10		10		10	M			10		10		10		10	
R1639	10		10		10	M			10		10		10		10	
R1641	10		10		10	M			10		10		10		10	
R1644	10		10		10	M			10		10		10		10	
R1647	1k		1k		1k	M			1k		1k		1k		1k	
R1649	470		470		470	M			470		470		470		470	
R1651	4.7k		4.7k		4.7k	M			4.7k		4.7k		4.7k		4.7k	
R1653	1.8k		1.8k		1.8k	M			1.8k		1.8k		1.8k		1.8k	
R1655	1.8k		1.8k		1.8k	M			1.8k		1.8k		1.8k		1.8k	
R1664	1.2k		1.2k		1.2k	M			1.2k		1.2k		1.2k		1.2k	
R1665	15k		15k		15k	M			15k		15k		15k		15k	
R1670	47k		47k		47k	M			47k		47k		47k		47k	
R1672	0		0		0	M			0		0		0		0	
R1679	0		0		0	M			0		0		0		0	
R1681	10		10		10	M			10		10		10		10	
R1686	10		10		10	M			10		10		10		10	
R1687	10		10		10	M			10		10		10		10	
R1688	10		10		10	M			10		10		10		10	
R1689	10		10		10	M			10		10		10		10	
L1602	L1129-A		L1129-A		L1129-A	M			L1129-A		L1129-A		L1129-A		L1129-A	
L1606	L1129-A		L1129-A		L1129-A	M			L1129-A		L1129-A		L1129-A		L1129-A	
L1608	A L7010-A		A L7010-A		A L7010-A	M			A L7010-A		A L7010-A		A L7010-A		A L7010-A	
L1613	A H7064-A		A H7064-A		A H7064-A	M			A H7064-A		A H7064-A		A H7064-A		A H7064-A	
L1614	A H7064-A		A H7064-A		A H7064-A	M			A H7064-A		A H7064-A		A H7064-A		A H7064-A	
L1615	A H7064-A		A H7064-A		A H7064-A	M			A H7064-A		A H7064-A		A H7064-A		A H7064-A	
L1616	A H7064-A		A H7064-A		A H7064-A	M			A H7064-A		A H7064-A		A H7064-A		A H7064-A	
L1619	C 1528-A		C 1528-A		C 1528-A	M			C 1528-A		C 1528-A		C 1528-A		C 1528-A	
C1803	S 9136C U		S 9136C U-2		S 9136C U-2	M			S 9136C U		S 9136C U		S 9136C U		S 9136C U	
C1806	AA 4614A U-2		AA 4614A U-2		AA 4614A U-2	M			AA 4614A U-2		AA 4614A U-2		AA 4614A U-2		AA 4614A U-2	
C1807	C7SH32 US1		C7SH32 US1		C7SH32 US1	M			C7SH32 US1		C7SH32 US1		C7SH32 US1		C7SH32 US1	
1602	RK 5.1K B2		RK 5.1K B2		RK 5.1K B2	M			RK 5.1K B2		RK 5.1K B2		RK 5.1K B2		RK 5.1K B2	
JA1602	AKP7268-A		AKP7268-A		AKP7268-A	M			AKP7268-A		AKP7268-A		AKP7268-A		AKP7268-A	
P1603	S PO		S PO		S PO	S PO			S PO		S PO		S PO		S PO	
P1604	S PO		S PO		S PO	S PO			S PO		S PO		S PO		S PO	
P1609	S PO		S PO		S PO	S PO			S PO		S PO		S PO		S PO	
P1610	S PO		S PO		S PO	S PO			S PO		S PO		S PO		S PO	
P1612	S PO		S PO		S PO	S PO			S PO		S PO		S PO		S PO	

R O ABL or AL MA ASS 8 11

A	9727 MH S J	A	9824 ML CU.	A	9825 SH CU	A	9826 SL CU	A	9827 MH CU.	A	9930 SH S	SL S	A	9931 SH J	A	9950 ML S J
C9708	0.1u 16		0.1u 16		M	M			0.1u 16		M		M		0.1u 16	
C9709	100p 50		100p 50		M	M			100p 50		M		M		100p 50	
C9710	0.1u 16		0.1u 16		M	M			0.1u 16		M		M		0.1u 16	
C9711	1000p 50		1000p 50		M	M			1000p 50		M		M		1000p 50	
C9712	0.1u 16		0.1u 16		M	M			0.1u 16		M		M		0.1u 16	
C9713	100p 50		100p 50		M	M			100p 50		M		M		100p 50	
C9714	1000p 50		1000p 50		M	M			1000p 50		M		M		1000p 50	
C9715	0.1u 16		0.1u 16		M	M			0.1u 16		M		M		0.1u 16	
C9720	10p 50		10p 50		M	M			10p 50		M		M		10p 50	
C9721	0.1u 16		0.1u 16		M	M			0.1u 16		M		M		0.1u 16	
C9723	0.1u 16		0.1u 16		M	M			0.1u 16		M		M		0.1u 16	
C9724	10p 50		10p 50		M	M			10p 50		M		M		10p 50	
C9725	1000p 50		1000p 50		M	M			1000p 50		M		M		1000p 50	
C9726	0.1u 16		0.1u 16		M	M			0.1u 16		M		M		0.1u 16	
C9727	220p 4		220p 4		M	M			220p 4		M		M		220p 4	
C9756	0.1u 16		0.1u 16		M	M			0.1u 16		M		M		0.1u 16	
C9757	100p 50		100p 50		M	M			100p 50		M		M		100p 50	
C9758	0.1u 16		0.1u 16		M	M			0.1u 16		M		M		0.1u 16	
R9719	75		75		M	M			75		M		M		75	
R9720	75		75		M	M			75		M		M		75	
R9723	33		33		M	M			33		M		M		33	
R9726	75		75		M	M			75		M		M		75	
R9727	75		75		M	M			75		M		M		75	
R9765	M		M		M	M			M						0	
R9768	M		M		M	M			M		0				0	
C9701	S42S16400 -6 L		S42S16400 -6 L		M	M			S42S16400 -6 L		M		M		S42S16400 -6 L	


R O ABL or AL MA ASS 6 11

	A 9727 MH S „J	A 9824 ML CU	A 9825 SH CU	A 9826 SL CU	A 9827 MH CU	A 9930 SH S „ SL S	A 9931 SH J	A 9950 ML S „J
C1509	1000u 16	1000u 16	1000u 10	1000u 10	1000u 16	1000u 10	1000u 10	1000u 16
C1518	10p 50	10p 50	M	M	10p 50	M	M	10p 50
C1533	100p 50	100p 50	M	M	100p 50	100p 50	100p 50	100p 50
C1545	M	M	M	M	M	M	M	M
C1546	M	M	M	M	M	M	M	M
C1820	100p 50	100p 50	330p 50	330p 50	100p 50	100p 50	100p 50	100p 50
C1824	100p 50	100p 50	470p 50	470p 50	100p 50	100p 50	100p 50	100p 50
C1835	220p 50	220p 50	470p 50	470p 50	220p 50	470p 50	470p 50	220p 50
C1836	47u 16	M	M	M	47u 16	M	M	M
C1847	100u 16	M	M	M	100u 16	M	100u 16	100u 16
C1852	0.1u 16	0.1u 16	M	M	0.1u 16	M	M	0.1u 16
C1853	330p 50	330p 50	M	M	330p 50	M	M	330p 50
C1855	270p 50	270p 50	330p 50	330p 50	270p 50	270p 50	270p 50	270p 50
R1506	M	M	M	M	M	M	0	0
R1512	10	10	0	0	10	10	10	10
R1513	10	10	0	0	10	10	10	10
R1514	M	M	M	M	M	M	0	0
R1518	M	M	M	M	M	M	0	0
R1523	10	10	0	0	10	10	M	10
R1545	10	10	0	0	10	10	M	10
R1546	10	10	0	0	10	10	M	10
R1801	100	100	M	M	100	M	M	100
R1803	47k	47k	100k	100k	47k	47k	47k	47k
R1804	15	10	10	10	15	10	10	15
R1834	82	100	100	100	100	82	100	82
R1835	82	100	100	100	100	82	100	82
R1836	M	47	47	47	47	M	M	M
R1880	M	M	0	0	M	0	0	M
R1881	M	M	0	0	0	0	M	M
R1897	100	100	M	M	100	M	M	100
R1898	100	100	M	M	100	M	M	100
R1899	150	150	M	M	150	M	M	150
R1900	0	0	M	M	0	M	M	0
R1901	100	100	M	M	100	M	M	100
R1902	150	150	M	M	150	M	M	150
R1905	8.2	10	10	10	8.2	10	8.2	10
R1912	470	470	M	M	470	M	M	470
R1913	150	150	M	M	150	M	M	150
R1914	1k	1k	M	M	1k	M	M	1k
R1915	150	150	M	M	150	M	M	150
R1924	M	M	0	0	M	0	0	M
R1925	M	M	0	0	M	10	10	M
R1940	100	100	47	47	100	47	47	100
R1971	100k	100k	M	M	100k	M	M	100k
L1801	L1128-A	M	M	M	L1128-A	L1128-A	L1128-A	L1128-A
L1814	L1129-A	L1129-A	M	M	L1129-A	M	M	L1129-A
C1813	C74 HC157 K	C74 HC157 K	M	M	C74 HC157 K	M	M	C74 HC157 K
L509	L A124 UB	L A124 UB	M	M	L A124 UB	M	M	L A124 UB

R O ABL or AL MA ASS 8 11

	A 9727 MH S „J	A 9824 ML CU	A 9825 SH CU	A 9826 SL CU	A 9827 MH CU	A 9930 SH S „ SL S	A 9931 SH J	A 9950 ML S „J
C9702	CH1234-A	100u 16	M	M	CH1234-A	M	M	CH1234-A
C9703	220u 4	220u 4	M	M	220u 4	M	M	220u 4
C9704	0.1u 16	0.1u 16	M	M	0.1u 16	M	M	0.1u 16
C9705	0.1u 16	0.1u 16	M	M	0.1u 16	M	M	0.1u 16
C9706	1000p 50	1000p 50	M	M	1000p 50	M	M	1000p 50
C9707	10p 50	10p 50	M	M	10p 50	M	M	10p 50
C9716	0.1u 16	0.1u 16	M	M	0.1u 16	M	M	0.1u 16
C9717	100p 50	100p 50	M	M	100p 50	M	M	100p 50
C9718	0.1u 16	0.1u 16	M	M	0.1u 16	M	M	0.1u 16
C9719	1000p 50	1000p 50	M	M	1000p 50	M	M	1000p 50
C9728	1u 10	1u 10	M	M	1u 10	M	M	1u 10
C9729	0.1u 16	0.1u 16	M	M	0.1u 16	M	M	0.1u 16
C9730	330p 50	330p 50	M	M	330p 50	M	M	330p 50
C9731	0.1u 16	0.1u 16	M	M	0.1u 16	M	M	0.1u 16
C9732	0.1u 16	0.1u 16	M	M	0.1u 16	M	M	0.1u 16
C9733	470p 50	470p 50	M	M	470p 50	M	M	470p 50
C9734	470p 50	470p 50	M	M	470p 50	M	M	470p 50
C9735	0.01u 25	0.01u 25	M	M	0.01u 25	M	M	0.01u 25
C9736	0.1u 16	0.1u 16	M	M	0.1u 16	M	M	0.1u 16
C9737	0.1u 16	0.1u 16	M	M	0.1u 16	M	M	0.1u 16
C9738	0.1u 16	0.1u 16	M	M	0.1u 16	M	M	0.1u 16
C9739	0.1u 16	0.1u 16	M	M	0.1u 16	M	M	0.1u 16
C9740	100p 50	100p 50	M	M	100p 50	M	M	100p 50
C9741	470p 50	470p 50	M	M	470p 50	M	M	470p 50
C9742	100p 50	220p 50	M	M	220p 50	M	M	100p 50
C9743	470p 50	470p 50	M	M	470p 50	M	M	470p 50
C9744	0.1u 16	0.1u 16	M	M	0.1u 16	M	M	0.1u 16
C9745	0.1u 16	0.1u 16	M	M	0.1u 16	M	M	0.1u 16
C9746	100p 50	100p 50	M	M	100p 50	M	M	100p 50
C9747	1000p 50	1000p 50	M	M	1000p 50	M	M	1000p 50
C9748	0.1u 16	0.1u 16	M	M	0.1u 16	M	M	0.1u 16
C9749	470p 50	470p 50	M	M	470p 50	M	M	470p 50
C9750	0.1u 16	0.1u 16	M	M	0.1u 16	M	M	0.1u 16
C9751	100p 50	470p 50	M	M	470p 50	M	M	100p 50
C9752	0.1u 16	0.1u 16	M	M	0.1u 16	M	M	0.1u 16
C9753	470p 50	470p 50	M	M	470p 50	M	M	470p 50
C9759	0.1u 16	0.1u 16	M	M	0.1u 16	M	M	0.1u 16
C9760	470p 50	470p 50	M	M	470p 50	M	M	470p 50
R9701	47	47	M	M	47	M	M	47
R9702	0	0	M	M	0	M	M	0
R9707	M	M	0	0	M	0	0	M
R9708	M	M	0	0	M	0	0	M
R9709	M	M	0	0	M	0	0	M
R9714	22	22	M	M	22	M	M	22
R9715	22	22	M	M	22	M	M	22
R9716	22	22	M	M	22	M	M	22
R9717	22	22	M	M	22	M	M	22
R9718	22	22	M	M	22	M	M	22
R9721	0	0	M	M	0	M	M	0
R9722	47	47	M	M	47	M	M	47
R9724	47	47	M	M	47	M	M	47
R9725	47	47	M	M	47	M	M	47
R9728	47k	47k	M	M	47k	M	M	47k
R9729	47	47	M	M	47	M	M	47
R9730	470	470	M	M	470	M	M	470
R9731	10	10	M	M	10	M	M	10
R9733	47	47	M	M	47	M	M	47
R9734	47	47	M	M	47	M	M	47
R9735	47	47	M	M	47	M	M	47
R9736	47	47	M	M	47	M	M	47
R9737	47	47	M	M	47	M	M	47
R9738	47	47	M	M	47	M	M	47
R9739	22	22	M	M	22	M	M	22
R9740	56	56	M	M	56	M	M	56
R9741	22	22	M	M	22	M	M	22
R9742	100	100	M	M	100	M	M	100
R9743	47	47	M	M	47	M	M	47
R9744	47	47	M	M	47	M	M	47
R9746	100	100	M	M	100	M	M	100
R9747	100	100	M	M	100	M	M	100
R9748	100	100	M	M	100	M	M	100
R9758	1M	1M	M	M	1M	M	M	1M
R9764	1M	1M	M	M	1M	M	M	1M
R9766	M	M	M	M	M	0	0	M
R9767	M	M	M	M	M	0	0	M
R9769	M	M	M	M	M	0	0	M
R9770	M	M	M	M	M	0	0	M
L9701	A L7010-A	A L7010-A	M	M	A L7010-A	M	M	A L7010-A
L9702	A L7010-A	A L7010-A	M	M	A L7010-A	M	M	A L7010-A
L9703	L1128-A	L1128-A	M	M	L1128-A	M	M	L1128-A
L9705	L1128-A	L1128-A	M	M	L1128-A	M	M	L1128-A

INTERFACE ASS




A



134

4



A






C

C

C 8303

C




	AWX9768- /J	AWX9791- /J	AWX9836- /J
JA3605	AKB7231-A	AKB7232-A	AKB7231-A



1. R S S ORS
 Unit k-Ω, M-M Ω or Ω unless
 otherwise noted.
 Rated Power 1 10w unless
 otherwise noted.
 olerance J 5 unless
 otherwise noted.
 2. CAPAC ORS
 Unit p-p or u-u unless
 otherwise noted.
 Ratings capacit oltage
 unless otherwise noted.
 CH CCSRCH
 O MARK CKSR B
 3. M, o Mount

AWX9836- /J
AKB7229-A
AKB7229-A
AKB7229-A

AWX9836- /J
0.1u/50
0.1u/50
180p/50
0
58
1k
100
100
2.2k
220
NM
220
AKB7231-A
LSA1576UB (QRS)
H1C01FU (YGR)



Ω unless
unless
SS
SS
oltage
f.
B

COMPOSITE ASSY


(SC-57 :AWX9791)
(SC-55/SC-1526-K:AWX9836)

A

B


C

A



B

C



DISPLAY ASSY
(SC-57/SC-55 :AWX9796)
(SC-1526-K :AWX9847)

A

E


C




141

L

VOL ASSY
(AWX9797)



POWER SW ASSY
(SC-57/SC-55 :AWX9798)
(SC-1526-K :AWX9901)



	AWX9798 -	AWX9901 -
C3401	220p/50	NM
R3401	150	NM
D3402	SLR343BC4T (JKLM)	NM
Q3401	LTC143EUB	NM

O

1.R S S ORS
Unit k-k Ω, M-M Ω or Ω unless otherwise noted.
Rated power 1/10 unless otherwise noted.
tolerance J ±5 unless otherwise noted.


2,CAPAC ORS
Unit p-p or μ or unless otherwise noted.
Ratings Capacit μ oltage unless otherwise noted.
B CKSR B CH CCSRCH A C A J C J

3, M o mount

N

ENCODER ASSY
(AWX9801)

JH3003



- O
- 1.R

S S ORS

Unit k-k Ω , M-M Ω or Ω unless otherwise noted.

Rated power 1 10 unless otherwise noted.

olerance J $\pm$ 5 unless otherwise noted.
- 2.CAPAC


ORS

Unit p-p , or μ unless otherwise noted.


Ratings Capacit μ oltage unless otherwise noted.
3. M

o mount

IR BUFFER ASSY (AWX9793)



P BUFFER GND ASSY
(AWX9795)




O
C 6802

O
C 6803

O 1. R S S ORS Unit: k-k Ω, M-M Ω or Ω unless otherwise noted. Rated Power: 1/16w unless otherwise noted. tolerance: J 5% unless otherwise noted. 2. CAPAC ORS Unit: p-p or u-u unless otherwise noted. Ratings: Capacitance voltage unless otherwise noted. B CKSR B,CH CCSRCH 3. M o Mount		
1608 S	2125 S	3216 S
RS1 16S R 1 16S	RS1 10S RS1 8S	RS1 8S RS1 4SA
CCSR CKSR	CCS CKS	CCS CKS

IR INTERFACE ASSY (AWX9792)



C



IR PO ER A P ASS ()



A

C 3890

B

C 3880

C



Audio Signal Route




he Δ mark found on some component parts should be replaced with same parts as et regulation authori ed o identical designation.

1608 S	RS1 16S	2125 S	RS1 10S	3216 S	RS1 8S
	R 116S		RS1 8S		RS1 4SA
CCSR	CKSR		CCS		CCS
			CKS		CKS

1. R S S ORS
Unit k-k, M-M, μ or Ω unless otherwise noted.
Rated Power: 1 W unless otherwise noted.
Clearance: J 5 unless otherwise noted.
2. CAPAC ORS
Unit p-p, μ or μ unless otherwise noted.
Ratings: Capacitance, voltage, unless otherwise noted.
B C KSR B, B C K S B S C K S B, C H C C KSR
HA C HA, L C HA L
3. M o Mount


SC-57

150




IR POWER ASS ()



A



B



C



Audio Signal Route

The mark found on some component parts should be replaced with same parts as set regulation authorized or identical designation.

1. R S S ORS
Unit k-a, Ω, M-M Ω or Ω unless otherwise noted.
Rated Power 1/10W unless otherwise noted.
tolerance J 5 unless otherwise noted.
2. CAPAC ORS
Unit p-p or u-u unless otherwise noted.
Ratings Capacitance unless otherwise noted.
B C K S R B B C K S B S B C K S B C C S R D H
HA C HA L C HA L
3. M, C Mount



A



SP	AK	R	RM	AL	4P
					JA4301
	AWH7030				AKE7149-B
	AWH7037				AKE7147-B
	AWH7038				AKE7149-B
	AWH7039				AKE7141-A
	AWH7040				AKE7143-A
	AWH7041				AKE7141-A
	AWH7042				AKE7147-B
	AWH7043				AKE7143-A

IR POWER ASS ()

1


2

3

4


A

C 3860









B

C 3850




C



he mark found on some component parts should be replaced with same parts as et regulation authori ed o identical designation.

1. R S S ORS Unit k-k (2), M-M (3) or (4) unless otherwise clearance J 5 unless otherwise
2. CAPAC ORS Unit p-p or u-u unless otherwise Ratings Capacit otage u B CSH B B CSH B S B HA C HA L C HA L
3. M o Mount



R 154

SC-57

1


2

3


4

IR PO ER A P ASS ()


A



B



C






IR POWER AMP ASSY (5/6)

(SC-57 : AWH7030)
(SC-55/SC-1526-K : AWH7039)

A

B


C







he Δ mark ound on some component parts should be replaced with same parts sa et regulation authori ed o identical designation.

1. R S S ORS
Unit s-A, M-M (L) or U unless otherwise noted.
Rated Power 11w unless otherwise noted.
Clearance J S unless otherwise noted.
2. CAPAC ORS
Unit p-p or u-u unless otherwise noted.
Ratings: Capacit cttage unless otherwise noted.
B CKSR B, B CKS B.S B CKS B, CH CCSRCH
HA C HA L, LC HA L
S, M, o Mount

➔ Audio Signal Route





he Δ mark found on some component parts should be replaced with same parts as set regulation authorized of identical designation.

1. R S S ORS
Unit K=Q, M=MI or Q unless otherwise noted.
Rated Power 1 16w unless otherwise noted.
olerance J 5 unless otherwise noted.

2. CAPAC ORS
Unit p-p or u-u unless otherwise noted.
Ratings Capacitance unless otherwise noted.
B CKSR B, B CKS B, S B CKS B, CH CCSRCH
HA C HA, L C HA L

3. M o Mount

1608 S	
	RS1 16S R 1 16S
	CCSR CKSR

A

Output Power Stage and LP filter


R 1111

159

CO AR

S PRIMARY ASSY (AWX9799)

Heat Sink or 50
A H7224-A
with BB 30P080 CC



Power Suppl or
S A B 5.6

5R6


A 7750-A

C 9501


1	VA1
TF7046-A	NM
TF7050-A	TND10V-511KB00AAA0
TF7046-A	NM
TF7050-A	NM
TF7046-A	NM
TF7050-A	NM

T PRIMARY SHIELD ASSY (AWX9811)

E C 7762



he mark ound on some component parts should be replaced
with same parts sa et regulation authori ed o identical
designation.



	AWX9799 (CU)	AWX9848 (SY)	AWX9849 (J)	AWX9850 (DLPW)	AWX9851 (F)	AWX9852 (A)
C81	ACE7013-A	NM	ACE7013-A	NM	ACE7013-A	NM
CN81	B2P3-VH	NM	B2P3-VH	NM	NM	NM
CN82	NM	B3P5-VH	NM	B3P5-VH	B3P5-VH	B3P5-VH
H71	AKR1004-A	AKR1004-A	NM	AKR1004-A	AKR1004-A	AKR1004-A
H72	AKR1004-A	AKR1004-A	NM	AKR1004-A	AKR1004-A	AKR1004-A
H73	NM	NM	AKR7004-A	NM	NM	NM
H74	NM	NM	AKR7004-A	NM	NM	NM
JA71	ADX7464-B	ADX7464-B	ADX7513-A	ADX7464-B	ADX7464-B	ADX7464-B
JA71_1	ADX7464-B	ADX7464-B	ADX7513-A_1	ADX7464-B_1	ADX7464-B_1	ADX7464-B_1
JV81	JUMPER	JUMPER	JUMPER	NM	JUMPER	NM
JV82	JUMPER	JUMPER	JUMPER	NM	JUMPER	NM
JV83	JUMPER	JUMPER	JUMPER	NM	JUMPER	NM
KN2	VNE1948-A	VNE1948-A	VNE1948-A	NM	VNE1948-A	NM
S81	NM	NM	NM	AKX7020-A	NM	AKX7020-A


ASS S1



er Suppl or AU O

**U REG ASSY
(AWX9813)**

A



JH7502
1040-A

JH7602
M

CAU	O	-	OR	CO	U	PRO	C	O	A	A	S	RSKO	R	,
R	PLAC				H	SAM	P	A	RA		SO	US	.	

9

he Δ mark ound on some component parts should be replaced
with same parts sa et regulation authori ed o identical
designation.

O


1. R S S ORS
Unit k-k Ω, M-M Ω or Ω unless
otherwise noted.
Rated Power 1 16w unless
otherwise noted.
clearance J 5 unless
otherwise noted.
MU R 1 4MU

2. CAPAC ORS
Unit p-p or u-u unless
otherwise noted.
Ratings Capacitance
unless otherwise noted.


CH CCSRCH, C LA C LA
P C S P, AK C AK
OMARK CKSR B or C A

3. M o Mount

Power Supply	or		
	12	R	R



Power Supply	or	
	UCOM	0



AD JP7725

-15

-23.5




-15

SC-57

U




IR REG ASSY (AWX9806)



 **B DIODE ASSY
(AWX9808)**


MA RA S



CAU O - OR CO U PRO C O A A S R SKO R ,
R PLAC H SAM P A RA SO US .

1. R S S ORS
 Unit k-k Ω , M-M Ω or Ω unless
 otherwise noted.
 Rated Power 1 10w unless
 otherwise noted.
 tolerance J 5 unless
 otherwise noted.
 MU R 1 4MU
 3216 RS1 4SA unless
 otherwise noted.
 2. CAPAC ORS
 Unit p-p or u-u unless
 otherwise noted.
 Ratings Capacitance tolerance
 unless otherwise noted.
 C LA C LA
 3. M o Mount


CONNECT ASSY (AWX9820)



O

1. R S S ORS
Unit k-k Ω , M-M Ω or Ω unless
otherwise noted.
Rated Power 1 16w unless
otherwise noted.
tolerance J 5 unless
otherwise noted.
2. CAPAC ORS
Unit p-p or u-u unless
otherwise noted.
Ratings Capacit voltage
unless otherwise noted.
3. M o Mount

FB-CONNECT ASSY (AWX9819)




➔ Audio Signal Route


	A 9819	A 9966
C7693	27p 50	M
C7694	330p 50	M
C7696	27p 50	M
C7697	330p 50	M

- O**
1. R S S ORS
Unit k-k Ω, M-M Ω or Ω unless otherwise noted.
Rated Power 1 16w unless otherwise noted.
tolerance J 5 unless otherwise noted.
 2. CAPAC ORS
Unit p-p or u-u unless otherwise noted.
Ratings Capacit voltage unless otherwise noted.
 3. M o Mount

**PRE BRIDGE ASSY
(AWX9809)**




**AA A-DAC BRIDGE ASSY
(AWX9936)**



	AWX9771	AWX9936
C3794	NM	0.01u/50
C3798	NM	0.01u/50
C3800	NM	0.1u/50

A D-AUDIO BRIDGE ASSY
(AWX9769)




A 000
C 3901

A 000
C 2861

O
1. R S S ORS
Unit k-k Ω , M-M Ω or Ω unless
otherwise noted.
Rated Power: 1 10w unless
otherwise noted.
oleranee J 5 unless
otherwise noted.
2. CAPAC ORS
Unit p-p or u-u unless
otherwise noted.
Ratings Capacit oltag
unless otherwise noted.
CH CC SRCH
O MARK CKSR B
3. M o Mount

AC D-DAC BRIDGE ASSY
(AWX9935)



A 000
C 2102

A 000
C 2101

A 000
C 2501

	AWX9770	AWX9935
C3785	NM	0.1u/50
C3786	NM	0.01u/50
C3787	NM	100p/50

AD



JH7722
M



- AD

AE **DISPLAY BRIDGE ASSY**
(AWX9815)

A



JH7651
1040-A

JH7652
1040-A

JH7653
M

- O
1. R S S ORS
Unit k-kΩ, M-MΩ or Ω unless
otherwise noted.
Rated Power 1 16w unless
otherwise noted.
tolerance J 5 unless
otherwise noted.
2. CAPAC ORS
Unit p-p or u-u unless
otherwise noted.
Ratings Capacitance tolerance
unless otherwise noted.
3. M o Mount

A



C 3472

9

JP3001

JH7661
1040-A

- ideo Signal Route
- Audio Signal Route

A



B

C

MCH BRIDGE ASSY (SC-57:AWX9818)

A 000
C 2510

E C 7761




O

1. R S S ORS
Unit k- Ω , M-M Ω or Ω unless
otherwise noted.
Rated Power 1/16w unless
otherwise noted.
tolerance J 5% unless
otherwise noted.
2. CAPAC ORS
Unit p-p or u-u unless
otherwise noted.
Ratings Capacitance voltage
unless otherwise noted.
3. M o Mount


A

A REG BRIDGE ASS'Y
(AWX9810)




AI

MIC HP GUARD ASSY
(AWX9803)




A

FAN CONNECT ASSY
(AWX9804)




A

BIND DM CABLE ASSY
(AWX9863)




AL

BIND B CABLE ASSY
(AWX9807)



A

FFC GUARD2 ASSY
(AWX9812)



AN

VREG GUARD ASSY
(AWX9895)




1. R S S ORS
Unit k-Ω, M-M Ω or Ω unless
otherwise noted.
Rated Power 1 16w unless
otherwise noted.
tolerance J 5 unless
otherwise noted.
2. CAPAC ORS
Unit p-p or u-u unless
otherwise noted.
Ratings Capacit voltage
unless otherwise noted.
3. M o Mount

PC CONNECTION DIAGRAM

AUDIO ASSY

SIDE A

A AUDIO ASSY



SC-57

Diagram illustrating the correct orientation of a chip part on a P.C. board. The chip is placed on the underside of the board, with its pins facing away from the board. Labels include "SIDE A" on the top, "SIDE B" on the bottom, "P.C. Board", and "Chip Part".

A

C

A

A



A

E

9




AC C 3781

(ANP7787-B)


1

C 1501 **C** 3003 **JA**905 **D** C 3652



SIDE A

A

E MULTI CH IN ASSY**T** C 5751


B

C


SIDE

A

C FRONT HDMI USB ASSY




D USB RECT ASSY



SIDE A


A

INTERFACE ASSY



SIDE ☐

INTERFACE ASSY



7025
7026

C

SIDE ☐


A

B

C

C 7003

C 7004



(ANP7785-A)

7001

7002 7003
7005

7012
7010
7008

7014 7013
7016
7015

7024
7023

7022
7021

7011

C 1723

C 8301

C 8301

AO

COMPO

Ass

C8302 C8401

8305

C8301

8402

8501 8401

C8501

8301

8303

8302

C8601

8603 8605

8604

A P7788-A

SC-57

SIDE ☐


A

B


C

3302

C 8301




COMPOSITE ASSY



SIDE □

SIDE □

I COMPOSITE ASSY



SIDE




DISPLAY ASSY

A

C

B

C




C 3003



MIC HP ASSY


C

C 3472



(ANP7784-B)

SC-57




(ANP7784-B)


SIDE A

SIDE A


L VOL ASSY



POWER SW ASSY




N ENCODER ASSY




SIDE □

SIDE □


A

L VOL ASSY

B

□ POWER SW ASSY

C


N ENCODER ASSY**L** **□** **N****L** **□** **N**

IR USER ASS

SIDE A

SIDE A


IR BUFFER ASSY



(ANP7783-A)


SIDE

IR INTERFACE ASSY



SIDE

P BUFFER GND ASSY




P

P

SC-57

211

A



A P7771-C

SIDE

A

IR POWER AMP ASSY

C 4900

C 4800

C 4300

C 4400

C 4500

C

C4202

B

C4203


4207
4205
4206
4210
4208

C

4026
4024
4025

4204
4015
4033
4034

4912
4312
4512



SC-57

R


214

SIDE 

A

B

C



(ANP7771-C)

00.00 PRI AR ASS


SIDE A

A

S PRIMARY ASSY

B

C



C

C1

A




SIDE

A

S PRIMARY ASSY

B

C




C

SIDE 

A

B

C



(ANP7784-B)

71

C52

SC-57

5

6


7

8


S

SIDE A

T PRIMARY SHIELD ASSY



U REG ASSY




SIDE A

A

B

C




U

SIDE A

SIDE A

IR REG ASSY

AD C 7723 R C 4003



(ANP7785-A)

R C 4004

R C 4002

A C 5931

SC-57

V

224

V

SIDE □

SIDE □

A

V IR REG ASSY


C 7271

C 7281

C

7206
7203
7205
7204
7207

7242



C 7201

C 7291

C 7241

C 7251

(ANP7785-A)

V


V

SC-57

225

B DIODE ASSY


MA RA S



SIDE

SIDE

B DIODE ASSY




1 2 3 4

CONNECT ASSY

SIDE A

SIDE A


CONNECT ASSY




SIDE A

SIDE A

FB-CONNECT ASSY



PRE BRIDGE ASSY



230




SC-57


SIDE A

A

AA A-DAC BRIDGE ASSY



A D-AUDIO BRIDGE ASSY



A





C



233

SIDE


AC D-DAC BRIDGE ASSY**AD FRONT BRIDGE ASSY**

AC AD

SIDE A

A


A MCH BRIDGE ASSY




B

C

A A REG BRIDGE ASS'Y




AI MIC HP GUARD ASSY



SIDE A


A



C 7671


A C 2510

B



JP5775

(ANP7785-A)

U C 7502

(ANP7784-B)

C


SIDE

A

B


C

AI MCH BRIDGE ASSY




C 7671

AI A REG BRIDGE ASS'Y




JP5775

AI MIC HP GUARD ASSY



SIDE


A



C 7672

(ANP7786-B)


B



C 5775

(ANP7785-A)

C




(ANP7784-B)

00.00 0AN CONNECT00 IND D0 00 IND 0 CA LE000C 0 UARD0 000 VRE0 0 UARD ASS0S


SIDE A

SIDE A


AI FAN CONNECT ASSY




A BIND DM CABLE ASSY




AL BIND B CABLE ASSY



A FFC GUARD2 ASSY



AN VREG GUARD ASSY




A **A** **AL** **A** **AN**

A **A** **AL** **A** **AN**


SIDE □

SIDE □


A FAN CONNECT ASSY




AL BIND B CABLE ASSY




A BIND DM CABLE ASSY



AN VREG GUARD ASSY



A FFC GUARD2 ASSY



A **A** **AL** **A** **AN**

A **A** **AL** **A** **AN**

PC PARTS LIST

NOTES: ● Parts marked by “NSP” are generally unavailable because they are not in our Master Spare Parts List.

● The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.

● When ordering resistors, first convert resistance values into code form as shown in the following examples.

Ex.1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47 k ohm (tolerance is shown by J = 5%, and K = 10%).

560 Ω $\rightarrow$ $56 \times 10^1 \rightarrow$ 561.....RD1/4PU $\begin{bmatrix} 5 \\ 6 \end{bmatrix} \begin{bmatrix} 1 \end{bmatrix} J$

47 k Ω $\rightarrow$ $47 \times 10^3 \rightarrow$ 473.....RD1/4PU $\begin{bmatrix} 4 \\ 7 \end{bmatrix} \begin{bmatrix} 3 \end{bmatrix} J$

0.5 Ω $\rightarrow$ R50.....RN2H $\begin{bmatrix} R \end{bmatrix} \begin{bmatrix} 5 \\ 0 \end{bmatrix} K$

1 Ω $\rightarrow$ 1R0.....RS1P $\begin{bmatrix} 1 \end{bmatrix} \begin{bmatrix} R \end{bmatrix} \begin{bmatrix} 0 \end{bmatrix} K$

Ex.2 When there are 3 effective digits (such as in high precision metal film resistors).

5.62 k Ω $\rightarrow$ $562 \times 10^1 \rightarrow$ 5621.....RN1/4PC $\begin{bmatrix} 5 \\ 6 \end{bmatrix} \begin{bmatrix} 2 \end{bmatrix} \begin{bmatrix} 1 \end{bmatrix} F$

PC PARTS LIST

PC PARTS LIST

PC PARTS LIST

PC PARTS LIST

LIST OF ASSEMBLIES

1..IR POWER AMP ASSY(SC-57) AWH7030
1..IR POWER AMP ASSY(SC-55/SC-1526-K) AWH7039

NSP 1..IR BUFFER ASSY AWM8249
2..IR BUFFER ASSY AWW9793
2..BUFFER GND ASSY AWW9795

NSP 1..PRIM DISPLAY ASSY(SC-57/SC-55) AWM8250
2..DISPLAY ASSY AWW9796
2..VOL ASSY AWW9797
2..POWER SW ASSY AWW9798
2..PRIMARY ASSY AWW9799
2..MIC HP ASSY AWW9800
2..ENCODER ASSY AWW9801
2..MIC HP GUARD ASSY AWW9803
2..FAN CONNECT ASSY AWW9804
2..BIND DM CABLE ASSY AWW9863

NSP 1..PRIM DISPLAY ASSY(SC-1526-K) AWM8267
2..DISPLAY ASSY AWW9847
2..VOL ASSY AWW9797
2..POWER SW ASSY AWW9901
2..PRIMARY ASSY AWW9799
2..MIC HP ASSY AWW9800
2..ENCODER ASSY AWW9801
2..MIC HP GUARD ASSY AWW9803
2..FAN CONNECT ASSY AWW9804
2..BIND DM CABLE ASSY AWW9863

NSP 1..AUDIO COMPOSITE ASSY(SC-57) AWR7106
2..D-AUDIO BRIDGE ASSY AWW9769
2..D-DAC BRIDGE ASSY AWW9935
2..A-DAC BRIDGE ASSY AWW9936
2..AUDIO ASSY AWW9790
2..COMPOSITE ASSY AWW9791

NSP 1..AUDIO COMPOSITE ASSY(SC-55/SC-1526-K) AWR7110
2..D-AUDIO BRIDGE ASSY AWW9769
2..D-DAC BRIDGE ASSY AWW9935
2..A-DAC BRIDGE ASSY AWW9936
2..AUDIO ASSY AWW9833
2..COMPOSITE ASSY AWW9836

PC PARTS LIST

NSP 1..INTERFACE REG ASSY AWR7111
2..INTERFACE ASSY AWW9805
2..IR REG ASSY AWW9806
2..B DIODE ASSY AWW9808
2..PRE BRIDGE ASSY AWW9809
2..A REG BRIDGE ASSY AWW9810
2..PRIMARY SHIELD ASSY AWW9811
NSP 2..BIND B CABLE ASSY AWW9807
NSP 2..FFC GUARD 2 ASSY AWW9812

NSP 1..REG BRIDGE ASSY(SC-57) AWR7112
2..REG ASSY AWW9813
2..FRONT BRIDGE ASSY AWW9814
2..DISPLAY BRIDGE ASSY AWW9815
2..F-IN BRIDGE ASSY AWW9816
2..MCH BRIDGE ASSY AWW9818
2..FB-CONNECT ASSY AWW9819
2..CONNECT ASSY AWW9820
2..USB RECT ASSY AWW9821
2..MULTI CH IN ASSY AWW9857
NSP 2..VREG GUARD ASSY AWW9895

NSP 1..REG BRIDGE ASSY(SC-55/SC-1526-K) AWR7117
2..REG ASSY AWW9813
2..FRONT BRIDGE ASSY AWW9814
2..DISPLAY BRIDGE ASSY AWW9815
2..F-IN BRIDGE ASSY AWW9816
2..FB-CONNECT ASSY AWW9819
2..CONNECT ASSY AWW9820
2..USB RECT ASSY AWW9821
NSP 2..VREG GUARD ASSY AWW9895

1..FRONT HDMI USB ASSY AWW9749
1..IR INTERFACE ASSY AWW9792
1..DAC HIGH ASSY(SC-57) AWW9822
1..DAC HIGH ASSY(SC-55/SC-1526-K) AWW9860

1..DIGITAL MAIN ASSY(SC-57) AWW9827
1..DIGITAL MAIN ASSY(SC-55/SC-1526-K) AWW9824

1..COMPONENT ASSY(SC-57) AWW9866
1..COMPONENT ASSY(SC-55/SC-1526-K) AWW9865

1..FM/AM TUNER UNIT AXX7282

A

AUDIO ASS

A AUDIO ASS A AUDIO ASS AUDIO ASS AUDIO ASS AUDIO ASS AUDIO ASS AUDIO ASS AUDIO ASS AUDIO ASS AUDIO ASS

Item	Source Description	Audio Description	Audio Description
	JA2501 Pin Jack 4p	AKB7218	KB3017
	JA2502 2p Pin Jack	AKB7234	AKB7233
	JA2503 Pin Jack 4p	AKB7218	KB3017
	JA2504 Pin Jack 4p	AKB7218	KB3017
	JA2951 Pin Jack 4p	AKB7218	KB3017
	JA3101 Pin Jack 4p	AKB7218	KB3017
	JA3102 RCA Jack	AKB7237	AKB7236
	JA3201 Pin Jack 6p	AKB7221	KB3037
	JA3202 2p Pin Jack	AKB7234	AKB7233
	C 2510 18p Socket	AKP7123	ot used
	R3951	ot used	RS1 10SR473J
	R3952	ot used	RS1 10SR473J
	R3953	ot used	RS1 10SR473J
	R3954	ot used	RS1 10SR473J
	R3955	ot used	RS1 10SR473J
	R3956	ot used	RS1 10SR473J
	R3957	ot used	RS1 10SR473J
	R3958	ot used	RS1 10SR473J

B

DAC I ASS

A AUDIO ASS A AUDIO ASS AUDIO ASS AUDIO ASS AUDIO ASS AUDIO ASS AUDIO ASS AUDIO ASS AUDIO ASS AUDIO ASS

Item	Source Description	Audio Description	Audio Description
	JA2008 RCA Jack	AKB7235	AKB7173

F

DITAL AIN ASS

A AUDIO ASS A AUDIO ASS AUDIO ASS AUDIO ASS AUDIO ASS AUDIO ASS AUDIO ASS AUDIO ASS AUDIO ASS AUDIO ASS

Item	Source Description	Audio Description	Audio Description
	R9518	RS1 16SS82R0	RS1 16SS1501
	R9519	RS1 16SS331J	RS1 16SS152J
	R9520	RS1 16SS7501	RS1 16SS3302
	R9521	RS1 16SS622J	RS1 16SS163J
	R9522	RS1 16SS3301	RS1 16SS1502
	C140	CH1277	C 221M4
	C156	CH1268	C 101M4
	C995	CH1277	C 221M4
	C996	ACH7306	ot used
	C1031	CH1234	C 101M16
	C1355	CH1277	C 221M4
	C1672	ACH7306	ot used
	C1673	ACH7306	ot used
	C1770	C 101M16	ot used
	C1836	C 470M16	ot used
	C1847	C 101M16	ot used
	C9004	CH1234	C 101M16
	C9537	CH1234	ot used
	C9547	CKSS B682K25	CCSSCH102J50
	C9553	CKSS B472K50	CCSSCH102J50
	C9588	C H S 103J16	ot used
	C9593	ACH7306	ot used
	C9608	C H S 103J16	ot used
	C9702	CH1234	C 101M16

H CO PONENT ASS

A 000000 000 A 000000 000 0000000000 000 000 0 000000000000 000000 0000

A

0 000	S 000000 D 000000000	A 000000	A 000000
	JA8301 6p Pin Jack Au JA8302 3p Pin Jack Au JA8304 3p Pin Jack Au JA8305 3p Pin Jack Au C8394	AKB7225 AKB7228 AKB7228 AKB7228 CCSRCH470J50	AKB7224 AKB7227 AKB7227 AKB7227 ot used

I CO POSITE ASS

A 000000 000 A 000000 000 0000000000 000 000 0 000000000000 000000 0000

B

0 000	S 000000 D 000000000	A 000000	A 000000
	JA3601 2p Pin Jack JA3602 2p Pin Jack JA3603 2p Pin Jack JA3604 1p Pin Jack JA3605 1p Pin Jack R3616 C3608 C3610	AKB7230 AKB7230 AKB7230 AKB7232 AKB7232 RS1 10SR68R0 CKSR B104K16 CKSR B104K16	AKB7229 AKB7229 AKB7229 AKB7231 AKB7231 RS1 10SR68R0 CKSR B104K50 CKSR B104K50

K DISPLA ASS

A 000000 000 A 000000 000 0000000000 000 000 0 000000000000 000000 0000

C

0 000	S 000000 D 000000000	A 000000	A 000000
	3207 3210 3211 3212 3213 3204 3206 3208 3210 3212 R3068 R3079 R3095 R3114 R3211 R3212 R3213 R3214 R3241 R3242 R3243 R3244 R3245 R3356 C3048 C3218 C3338	L C124 UB L C124 UB L C124 UB L C124 UB L C124 UB SLR343BC4 JKLM SLR343BC4 JKLM SLR343BC4 JKLM SLR343BC4 JKLM SLR343BC4 JKLM RS1 10SR102J ot used RS1 10SR101J ot used ot used ot used ot used ot used ot used RS1 10SR151J RS1 10SR151J RS1 10SR151J RS1 10SR151J RS1 10SR151J RS1 10SR101J CCSRCH100 50 CCSRCH470J50 CCSRCH100 50	ot used ot used ot used ot used ot used SLR-343 C P SLR-343 C P SLR-343 C P SLR-343 C P ot used ot used RS1 10SR0R0J ot used RS1 10SR0R0J RS1 10SR0R0J RS1 10SR0R0J RS1 10SR0R0J RS1 10SR0R0J RS1 10SR681J RS1 10SR681J RS1 10SR681J RS1 10SR681J ot used ot used ot used ot used ot used ot used

M

PO ER S ASS

A 3401 3402 R3401 C3401 A 3401 3402 R3401 C3401

	S 3401 3402 R3401 C3401	A L C143 UB SLR343BC4 JKLM RS1 10SR151J CCSRCH221J50	A ot used ot used ot used ot used

R

IR PO ER A P ASS

A JA4101 Sp eriminal 6-p v0 JA4301 Sp eriminal 4-p v0 JA4501 Sp eriminal 4-p v0 JA4901 Sp eriminal 4-p v0 JA5101 Sp eriminal 4-p v0 A AK 7150 AK 7149 AK 7149 AK 7149 AK 7149 AK 7142 AK 7141 AK 7141 AK 7141 AK 7141

	S JA4101 Sp eriminal 6-p v0 JA4301 Sp eriminal 4-p v0 JA4501 Sp eriminal 4-p v0 JA4901 Sp eriminal 4-p v0 JA5101 Sp eriminal 4-p v0	A AK 7150 AK 7149 AK 7149 AK 7149 AK 7149	A AK 7142 AK 7141 AK 7141 AK 7141 AK 7141

PC PARTS LIST OR SCHEMATIC UNLESS OTHERWISE NOTED

N. D

P.N.

N. D

P.N.

A

AUDIO ASS

JP 3001 HOUSING

ADX7745

SEMICONDUCATORS

IC 2501,3273	BD3473KS2
IC 2661,2751,2801	NJM4565MD
IC 2701	TC4066BFN
IC 2702	UPC4570G2-A
IC 3101,3151,3201,3251	NJM4580V
IC 3221	TC4052BFN
IC 3271,3272	NJM4580V
Q 2721,2853,3221,3222	LTC124EUB
Q 2722	LTA124EUB
Q 2803,2951,2971,3101	IMX25
Q 2852	LSA1576UB
Q 3001	2SD1858X
Q 3002	2SB1237X
Q 3102,3151,3152,3201	IMX25
Q 3202,3251,3252,3271	IMX25
Q 3272,3274-3276	IMX25
Q 3901	2SD1664
D 2691,2692,2701,2702	1SS302
D 2851,2852	1SS352
D 3001,3002	HZU7R5(B2)
D 3902	UDZS5R6(B)
D 3903	UDZS3R3(B)

ISCELLANEOUS

JA 2501,2503,2504 PIN JACK(4P)	AKB7218
JA 2502,3202 2P PIN JACK	AKB7234
JA 2951,3101 PIN JACK(4P)	AKB7218
JA 3102 RCA JACK	AKB7237
JA 3201 PIN JACK(6P)	AKB7221
RY 2851 RELAY	CSR1031
CN2501 3P SOCKET	XKP3072
CN2502 B TO B CONNECTOR	AKP7269
CN2503 15P CONNECTOR	52044-1545
CN2510 18P SOCKET	AKP7123
CN2861 15P SOCKET	XKP3078
CN3001 14P SOCKET	AKP7248
CN3051 23P SOCKET	XKP3082
CN3901 7P SOCKET	XKP3074
CN3902 CONNECTOR	9604S-09C

RESISTORS

R 2687	RS1/8SQ105J
R 2688	RS1/8SQ152J
R 2819,2820	RD1/4MUF330J
R 3031	RS1/8SQ475J
R 3032	RS1/8SQ562J
Other Resistors	RS1/10SR###J

CAPACITORS

C 2505,2506,2525,2526	CEAK220M50
C 2545,2546,2587,2588	CEAK220M50
C 2565,2566,2663,2664	CEAK100M50
C 2609,2610,2731,2732	CEAK220M50
C 2669,2670,2817,2818	CEAK470M25
C 2671,2672	CKSRYB822K50
C 2673-2676	CCSRCH122J50
C 2677,2678,2707,2708	CEAK100M50
C 2679,2680,3903,3906	CEAK101M16
C 2683,2699,2803,2804	CKSRYB103K50
C 2693,2694,2828,2836	ACH1479
C 2695,2696,2709-2712	CFHXSQ103J16
C 2697,2698,2700,2703	CCSRCH101J50
C 2704,2759,2829,2830	CCSRCH101J50
C 2751-2758,2760,2826	CEAK100M50
C 2763,2764,2815,2816	CFHXSQ103J16
C 2801,2802,2805,2806	CEAT1R0M50
C 2807,2808	CCSRCH221J50
C 2819,2820	CEAT471M16
C 2821,2822,3167,3225	CCSRCH100D50
C 2827,2903,2904,2907	CEAK100M50
C 2832,2852,2853,3914	CCSRCH101J50
C 2834,2835,3055,3056	CFHXSQ103J16
C 2851	CEAK101M35
C 2863-2866,3073,3075	CKSRYB104K50
C 2908,3025,3026	CEAK100M50
C 2981,2983,3007,3008	CKSRYB103K50
C 3001,3002	CEAK2R2M50
C 3011,3012,3909	CCSRCH331J50
C 3021,3904,3907,3947	CKSRYB103K50

□ □ □ □ N. D □ □ □ □ □ □ □ □

P □ □ □ N.

□ □ □ □ N. D □ □ □ □ □ □ □ □

P □ □ □ N.

C 3053,3054
C 3074,3076,3077,3192
C 3078,3191,3291,3905
C 3103,3104,3153,3154
C 3105,3106,3155,3205

ACH1480
CCSRCH471J50
CKSRYB104K50
CFHXSQ103J16
CEAK220M50

R 2022,2263,2472
R 2026,2470
R 2028
R 2048,2084,2085,2087
R 2049,2053,2086,2088

RS1/16SS221J
RS1/16SS471J
RS1/16SS1002F
RS1/16SS470J
RS1/16SS101J

C 3203,3204,3221,3222
C 3206,3255,3256,3275
C 3253,3254,3273,3274
C 3276,3926,3927
C 3292,3935,3948

CFHXSQ103J16
CEAK220M50
CFHXSQ103J16
CEAK220M50
CCSRCH471J50

R 2064-2067,2094,2095
R 2089,2115,2119,2238
R 2121,2125,2126,2431
R 2200-2203,2227,2228
R 2222

RS1/16SS100J
RS1/16SS101J
RS1/16SS100J
RS1/16SS0R0J
RS1/16SS183J

C 3901
C 3908,3911-3913
C 3915-3917,3919-3921
C 3918,3934
C 3928,3929

CCSRCH270J50
CCSRCH100D50
CCSRCH100D50
CKSRYB104K50
CFHXSQ103J16

R 2230,2234,2235,2239
R 2240
R 2285,2286,2289-2291
R 2432
R 2433-2435,2437-2439

RS1/16SS0R0J
RS1/16SS470J
RS1/16SS0R0J
RS1/16SS100J
RS1/16SS101J

C 3946
C 3951
C 3952-3954

CCSRCH100D50
CCSRCH101J50
CEAK100M50

R 2440,2446-2450
R 2441,2442,2471,2480
R 2469
R 2473,2474
R 2481,2485,2487,2488

RS1/16SS0R0J
RS1/16SS101J
RS1/16SS331J
RS1/16SS102J
RS1/16SS101J

R 2489

RS1/16SS151J

R 2490

RS1/16SS820J

R 2491,2493

RS1/8SQ105J

R 2492

RS1/8SQ474J

R 2498,2499

RS1/8SQ225J

Other Resistors

RS1/10SR###J

B DAC □ □ □ ASS □

SEMICONDUCATORS

IC 2001
IC 2003,2005-2007,2018
IC 2004,2016
IC 2010
IC 2011-2014,2017

AK4118AEQ
RNB4580F
TC74LCX08FK
TC74VHC08FK
AK4480EF



IC 2015
IC 2106

NJM2880U1-33
TC74VHC126FK



IC 2181

NJM2872BF33



IC 2183

NJM2845DL1-05

IC 2401,2402,2451

NJM4565MD

IC 2431

PCM1804DB

IC 2471

AK4388ET

D 2130

1SS302

D 2201-2203

1SS352

D 2431,2432

1SS301

D 2433,2434

1SS300

ISCELLANEOUS

L 2004-2010 CHIP SOLID INDUCTOR
L 2012-2018 CHIP SOLID INDUCTOR
L 2020,2021 CHIP SOLID INDUCTOR
L 2102,2431 CHIP SOLID INDUCTOR
L 2442,2471 CHIP SOLID INDUCTOR

QTL1013
QTL1013
QTL1013
QTL1013
QTL1013

L 2472,2473 INDUCTOR
JA 2002-2004 OPT. LINK IN
JA 2006 OPT OUT MODULE
JA 2008 RCA JACK
JA 2101 SOCKET

CTF1379
AKS7001
AKS7007
AKB7235
BKP1127

KN2201-2203 SCREW PLATE
CN2101,2102 SOCKET(30PL)
CN2103 B TO B CONNECTOR
CN2104 14P SOCKET

VNE1948
BKP1047
AKP7269
AKP7248

RESISTORS

R 2007-2010,2012,2016
R 2017,2020,2128,2195
R 2018,2116-2118,2120
R 2019
R 2021,2023-2025,2027

RS1/16SS101J
RS1/16SS0R0J
RS1/16SS220J
RS1/16SS680J
RS1/16SS101J

CAPACITORS

C 2002,2005,2124,2126
C 2003,2006,2009-2016
C 2017,2030,2059,2089
C 2018,2021,2024,2440
C 2019,2029,2032,2046

CKSRYB103K50
CKSRYB104K50
CEAK221M16
CEAK101M16
CCSSCH331J50

C 2020,2023,2028,2033
C 2022,2054
C 2025,2295,2490-2499
C 2026,2065,2066
C 2034,2041,2074,2075

CKSSYB104K16
CCSSCH101J50
CCSRCH100D50
CKSRYB474K16
CCSRCH102J50

C 2042-2045,2076,2078
C 2047,2056,2106,2176
C 2048,2049,2080,2081
C 2055
C 2057

CCSRCH331J50
CKSSYB104K16
CFHXSQ103J16
CEAK102M16
CKSSYB103K25

C 2058,2193
C 2070,2071,2086,2087
C 2073,2105,2122,2131
C 2077,2079,2218,2221
C 2082,2083,2098,2099

CKSQYB225K10
CFHXSQ472J16
CKSRYB104K50
CCSRCH221J50
CEAK100M50

C 2090,2091,2107,2108
C 2092-2095,2109-2111
C 2096,2097,2114,2115
C 2102,2103,2120,2121
C 2112,2174,2430

CCSRCH102J50
CCSRCH331J50
CFHXSQ103J16
CFHXSQ472J16
CCSSCH331J50

C 2113,2223,2235,2237
C 2116,2117,2239,2247
C 2127,2128,2451,2452
C 2129,2130,2178,2183
C 2132,2135,2136,2139

CCSRCH331J50
CEAK100M50
CEAT220M50
CKSRYB103K50
CKSRYB104K50

NO. DESCRIPTIONPART NO.

NO. DESCRIPTIONPART NO.

C 2133,2138,2140,2142	CEAK470M25
C 2134,2137,2159,2161	CEAK221M16
C 2141,2144,2146,2148	CKSRYB104K50
C 2143,2145,2147,2149	CEAK470M25
C 2150,2152,2154,2156	CKSRYB104K50
C 2151,2153,2155,2157	CEAK470M25
C 2158,2160,2162,2164	CKSRYB104K50
C 2163,2165,2209,2213	CEAK221M16
C 2166,2168,2170,2172	CKSRYB104K50
C 2167,2169,2171,2173	CEAK470M25
C 2179,2184,2187,2432	CEAK101M35
C 2180,2194,2199,2208	CKSRYB104K50
C 2182	CKSQYB225K16
C 2188,2190,2192,2195	CKSRYB103K50
C 2191,2196,2197,2238	CFHXSQ103J16
C 2207,2271,2455,2456	CCSRCH471J50
C 2211,2256,2260,2266	CCSRCH101J50
C 2212,2217,2220,2224	CKSRYB104K50
C 2215,2219,2228,2231	CEAK470M25
C 2222,2225,2229,2232	CCSRCH221J50
C 2226,2230,2282,2284	CKSRYB104K50
C 2233,2251,2252,2434	CKSRYB103K50
C 2236,2246	CCSRCH102J50
C 2240,2244	CFHXSQ472J16
C 2242,2248,2281,2283	CCSRCH331J50
C 2243,2411,2412,2415	CFHXSQ103J16
C 2253-2255,2258	CCSRCH221J50
C 2257,2259,2265,2445	CCSRCH330J50
C 2261-2264,2267-2270	CCSRCH221J50
C 2272,2413,2414	CCSRCH101J50
C 2273-2276,2301,2379	CCSRCH221J50
C 2277,2278	CCSSCH100D50
C 2289,2291	CCSRCH331J50
C 2290,2292,2433,2435	CKSRYB104K50
C 2381,2384,2387,2388	CCSRCH221J50
C 2393,2396,2399,2475	CCSRCH221J50
C 2401,2402	CKSRYB104K16
C 2403,2404	DCH1201
C 2405-2408	CEAK100M50
C 2416	CFHXSQ103J16
C 2429	CKSSYB104K16
C 2436,2437,2473,2474	CEAK470M25
C 2438,2441-2443,2446	CKSRYB104K50
C 2439,2464,2476,2478	CKSRYB103K50
C 2453,2454	CCSRCH391J50
C 2457,2458,2472,2480	CKSRYB104K50
C 2459,2460	CEAT100M50
C 2477	CKSRYB105K16
C 2481,2483,2484	CCSSCH471J50
C 2482	CKSRYB103K50
C 2489	CCSRCH330J50

C FRONT PANEL ASSY

SEMICONDUCATORS

IC 8001	S-24CS02AFT
IC 8002	TC7MB3257FK
IC 8003	CXB1443R
IC 8004	S-1132B33-U5
IC 8101	TPS2557DRB
IC 8102	BD9329EFJ
Q 8001-8003	LTC114YUB
Q 8102	LSC4081UB
D 8004	1SS301
D 8104	RKZ5.6KG(B2)

MISCELLANEOUS

L 8001,8002,8018 INDUCTOR	CTF1473
L 8010,8101,8102 CHIP BEADS	ATL7010
L 8012-8017,8019 FERRITE BEAD	CTF1528
L 8020 FERRITE BEAD	CTF1528
L 8103 CHOKE COIL	CTH1486
JA 8001 HDMI JACK	AKP7268
JA 8003 HDMI JACK	AKP7267
JA 8101 USB CONNECTOR	DKB1106
KN8001,8101 EARTH TERMINAL	AKF7002
CN 8004 5P CONNECTOR	VKN1374
CN8101 CONNECTOR	AKM1276
8002 PCB BINDER	VEF1040
JP 8101 HOUSING	ADX7760

RESISTORS

R 8028	RS1/16SS4701F
R 8033	RS1/8SQ105J
R 8035-8038	RS1/16SS1000F
R 8108,8109	RS1/16SS2202F
R 8117	RS1/16SS2200F
R 8118	RS1/16SS8201F
R 8120	RS1/16SS1801F
R 8122-8124	RS1/8SQ0R0J
Other Resistors	RS1/16SS###J

CAPACITORS

C 8010	CCSSCH331J50
C 8011,8016,8019,8021	CKSSYB104K16
C 8020,8027,8028	CCSSCH471J50
C 8022,8035,8037,8065	CCSSCH102J50
C 8023,8025,8026,8031	CKSSYB104K16
C 8024,8101,8127	CCSSCH101J50
C 8033,8038,8042,8044	CKSSYB104K16
C 8041	CEVW101M16
C 8043	CKSSYB102K50
C 8045,8046,8102,8106	CKSRYB104K50
C 8064	CKSSYB104K16
C 8066,8071	CCSSCH102J50
C 8069	CCSSCH330J50
C 8076	CEAK101M16
C 8083	CKSSYB103K25
C 8104	CEAK221M16
C 8105,8107	CCSRCH101J50
C 8108	CKSRYB102K50
C 8110,8111	CCG1236
C 8115,8116	CKSRYB104K50

□ □ □ □ N□. D□□□□□□□□

P□□□N□.

□ □ □ □ N□. D□□□□□□□□

P□□□N□.

C 8117
C 8119,8126
C 8121,8122
C 8125

CCSRCH222J50
CCSRCH100D50
ACG1128
CCSRCH331J50

IC 610,1806
IC 611,1809
IC 613
IC 903
IC 905

TC74VHC126FK
TC74VHCT125AFK
TC74VHC08FK
SII9233ACTU
SII9387CTU

IC 907
IC 909
IC 1201,1203,1218
IC 1202
IC 1204

TC74VHC541FK
ADV7181CBSTZ
TC7SZ125FU
TC74LCX541FK
88DE2750

IC 1205-1211,1215
IC 1212
⚠ IC 1216
⚠ IC 1505
IC 1602,1603

TC74VCX541FK
H5PS5162GFR-S5C
LP2996M
BD2224G
SII9136CTU

⚠ IC 1604,1813,1814
IC 1605,1606
IC 1607
IC 1608,1804
IC 1802

TC74VHC157FK
AAT4614AIGU-2
TC7SH32FUS1
TC7SZ08FU
TC7WZ08FK

IC 1803
IC 1808
IC 1815,1816
IC 1817
IC 9001,9003,9701

ICS87002BM-05
TC7WHU04FK
TC74LCX157FK
TC74VHC125FK
IS42S16400F-6TL

IC 9002,9702
IC 9004
IC 9005
IC 9006
IC 9201

D810K013BZKB400
AYW7356
TC7WGU04FK
TC7SHU04FUS1
IS42S16160C-6TL

⚠ IC 9202
IC 9203
IC 9204
NSP IC 9205
⚠ IC 9501

BD2226G
LAN8700C-AEZG
DM860
AYW7355
S-1172B10-U5

⚠ IC 9502,9503,9505,9506
⚠ IC 9504,9511,9513
⚠ IC 9507
⚠ IC 9508
⚠ IC 9509

S-1172B12-U5
S-1170B50UC-OUJ
MB39C011A
S-1170B25UC-OTK
MM1701WH

⚠ IC 9510
⚠ IC 9512
⚠ IC 9514
IC 9703
Q 601

NJM2846DL3-33
NJM2872BF33
S-1172B12-U5
AYW7349
RN4983

Q 604,1502-1505,1507
Q 903
Q 1501,9001,9002,9004
Q 1506,1722-1728
Q 1509

LTA124EUB
HN1K02FU
LTC114YUB
LSA1576UB
LTA124EUB

Q 1729-1731,9504,9506
⚠ Q 9501,9502
⚠ Q 9503
⚠ Q 9505
D 601

LSC4081UB
SH8M12
RZQ045P01
RTQ040P02
RB501V-40

D 901,903,904
D 1601,1602
D 9504

1SS301
RKZ5.1KG(B2)
1SS352

D US RECT ASS

SEMICONDUCATORS

⚠ D 3651

D5SBA60(B)

ISCELLANEOUS

H 3651,3652 FUSE CLIP
KN3651 EARTH TERMINAL
CN3651 3P TOP POST
CN3652 2P TOP POST
JH 3651,3652 PCB BINDER

AKR1004
AKF7002
B3B-EH
B2B-EH
VEF1040

RESISTORS

R 3652
Other Resistors

RS1/4SA105J
RS1/8SQ###J

CAPACITORS

C 3651
C 3661
C 3662
C 3663
C 3664

CFTLA104J50
CKSRYB104K50
CCSRCH101J50
CCSRCH331J50
CCSRCH100D50

C 3665,3666
C 3667

CEAK472M16
CKSRYB103K50

E ULTIC IN ASS

ISCELLANEOUS

JA 7761,7762 PIN JACK(4P)
KN7761 SCREW PLATE
CN7761 18P SOCKET
CN7762 5P SOCKET

AKB7218
VNE1948
AKP7123
XKP3073

RESISTORS

All Resistors

RS1/10SR###J

CAPACITORS

C 7765,7766,7771,7772
C 7777,7778,7783,7784
C 7785,7788
C 7786,7789

CEAK220M50
CEAK220M50
CKSRYB104K50
CCSRCH471J50

F DIITAL IN ASS

SEMICONDUCATORS

IC 101
IC 104
IC 401
IC 403,404
IC 601,607,612,1502

UPD61283F1-407LU2A
NJM12904V
AYW7354
H5DU2562GTR-J3C
TC74VHCT08AFKS1

IC 602
IC 603
IC 604
IC 605,1504
IC 608

341S2164
PE7008A
PDJ019A
TC7SH08FUS1
TC74VHCT541AFK

⚠
⚠
⚠

5	6	7	8
□ □ □ □ N. D □ □ □ □ □ □ □ □	P □ □ □ N.	□ □ □ □ N. D □ □ □ □ □ □ □ □	P □ □ □ N.
ISCELLANEOUS		RESISTORS	
L 103 INDUCTOR	LCTC150K2125	R 106,107,1205-1207	RAB4CQ221J
L 105,601-606 CHIP BEADS	VTL1129	R 114,141	RS1/10SR43R0D
L 607 CHIP BEADS	VTL1132	R 145,146	RS1/10SR1000D
L 901,905,906,918 CHIP BEADS	ATL7010	R 150,165,407,408	RAB4CQ103J
L 902-904,907,913 CHIP BEADS	VTL1129	R 193,1765	RS1/16SS4700F
L 917,919,1201,1202 CHIP BEADS	VTL1129	R 198,200,293,294	RS1/16SS1001F
L 921 INDUCTOR	CTF1547	R 229,238,239,247	RAB4CQ473J
L 922,1210,1607,1608 CHIP BEADS	ATL7010	R 261,269,273,288	RAB4CQ473J
L 1204-1209,1211-1216 CHIP BEADS	VTL1129	R 303,1060,1061,1515	RS1/10SR0R0J
L 1220,1503,1601,1602 CHIP BEADS	VTL1129	R 409,424-426	RAB4CQ560J
L 1501 FILTER	CTF1703	R 415-420,431-434	RAB4CQ103J
L 1502,1504 CHIP BEADS	VTL1134	R 435,436,441,442	RAB4CQ220J
L 1604-1606,1620,1802 CHIP BEADS	VTL1129	R 448-450,455	RAB4CQ330J
L 1609-1616 COIL	ATH7064	R 460-462,467,1041	RAB4CQ330J
L 1617 CHIP BEADS	VTL1126	R 468-470,487,1279	RAB4CQ220J
L 1618,1619 FERRITE BEAD	CTF1528	R 478,1235,9227	RAB4CQ472J
L 1722-1724 INDUCTOR	ATL7033	R 608,609,998,1000	RAB4CQ0R0J
L 1725-1727 INDUCTOR	ATL7035	R 611-614,641,701	RAB4CQ101J
L 1728 INDUCTOR	LCTC100K2125	R 615,624,988,1228	RAB4CQ100J
L 1729-1731 INDUCTOR	LCTC4R7K2125	R 680,956,1216,1217	RAB4CQ473J
L 1803,1806,1808-1811 CHIP BEADS	VTL1129	R 957,1242-1245,1248	RAB4CQ470J
L 1805 INDUCTOR	CTF1786	R 966,970,980,983	RAB4CQ680J
L 1814-1818,9001,9005 CHIP BEADS	VTL1129	R 999,1025,1201,1204	RAB4CQ680J
L 9002,9003,9205,9206 CHIP BEADS	ATL7010	R 1001,1336-1341	RAB4CQ0R0J
L 9004,9010,9703,9705 CHIP BEADS	VTL1128	R 1032,1292	RS1/8SQ105J
L 9007,9201,9202,9204 CHIP BEADS	VTL1129	R 1047-1049,1236,1250	RAB4CQ330J
L 9207-9210,9212-9214 CHIP BEADS	VTL1129	R 1202,1208,1277,1284	RAB4CQ151J
L 9215,9216 COIL	ATH7082	R 1214,1215	RAB4CQ221J
L 9501,9502,9507,9510 CHIP BEADS	ATL7010	R 1221,1222,1251-1256	RAB4CQ473J
L 9503,9511-9513,9704 CHIP BEADS	VTL1129	R 1227,1229	RS1/10SR101J
L 9506 INDUCTOR	ATH7087	R 1234,1238,1240,1261	RAB4CQ100J
L 9509 INDUCTOR	ATH7086	R 1249,9006,9011,9012	RAB4CQ470J
L 9701,9702 CHIP BEADS	ATL7010	R 1258-1260,1262,1270	RAB4CQ473J
F 102,103,107,108 EMI FILTER	DTL1106	R 1263	RAB4CQ100J
JA 901-907,1601,1602 HDMI JACK	AKP7268	R 1264-1269,1275,9209	RAB4CQ330J
JA 1501 CONNECTOR	CKS5712	R 1271,1274,1278,1283	RAB4CQ473J
JA 9201 USB CONNECTOR	DKB1106	R 1287,1614-1617,1622	RAB4CQ473J
JA 9202 RJ45 CONNECTOR	AKN7115	R 1288,1289,1291	RAB4CQ151J
KN 601,602 SCREW PLATE	VNE1948	R 1550,1755,1776,9523	RS1/10SR0R0J
X 602,901 CRYSTAL	ASS7092	R 1625,1633,1642,1645	RAB4CQ473J
X 902 CRYSTAL	ASS7111	R 1650,1651	RS1/16SS4701F
X 1201 CRYSTAL	ASS7114	R 1742-1744,1749,1751	RS1/16SS2200F
X 1801 CRYSTAL OSCILLATOR	ASS7102	R 1752,1754	RS1/16SS2200F
X 1802 CRYSTAL OSCILLATOR	ASS7101	R 1753,1777,1778	RS1/16SS56R0F
X 9001 RESONATOR	CSS1795	R 1756-1758	RS1/16SS5601F
CN 601 39P CONNECTOR	VKN2098	R 1767,1769,1771	RS1/16SS3300D
CN 602,1722,1723 20P SOCKET	AKP7249	R 9007-9010,9715-9718	RAB4CQ220J
CN 603 14P SOCKET	AKP7248	R 9016-9019,9021,9024	RAB4CQ470J
CN 1501 CONNECTOR	AKM1276	R 9026,9028,9029,9031	RAB4CQ470J
CN 1502 15P SOCKET	XKP3078	R 9040,9043,9048,9049	RAB4CQ470J
CN 1503 7P SOCKET	XKP3074	R 9050,9748	RAB4CQ101J
CN 9002,9003 SOCKET(30PL)	BKP1047	R 9211	RAB4CQ330J
CN 9501 CONNECTOR	B7B-EH	R 9215,9216	RAB4CQ680J
JH 9501,9502 PCB BINDER	VEF1040	R 9226,9232,9233,9236	RAB4CQ470J
P 601 POLYSWITCH	NANOSMDC035F	R 9234,9235	RAB4CQ121J

□ □ □ □ N. D □ □ □ □ □ □ □ □

P □ □ □ N.

□ □ □ □ N. D □ □ □ □ □ □ □ □

P □ □ □ N.

R 9237,9240,9724,9725
R 9254
R 9264-9266,9268
R 9285
R 9290-9292,9294

RAB4CQ470J
RAB4CQ103J
RAB4CQ473J
RS1/16SS1242F
RS1/16SS49R9F

C 436
C 439,618,624,631
C 442,619,620,627
C 445-447,607,610
C 608,611,621,629

CEVW101M4
CCSSCH331J50
CCSSCH102J50
CKSSYB104K16
CCSSCH100D50

R 9312
R 9514,9515
R 9518
R 9520
R 9522

RS1/16SS3001F
RS1/8SQ475J
RS1/16SS82R0D
RS1/16SS7501D
RS1/16SS3301D

C 609,655,929,967
C 613,615-617,622
C 614,625,653,667
C 626,628,632,637
C 630,634,651,679

CEVW101M16
CKSSYB104K16
CKSSYB103K25
CKSSYB104K16
CCSSCH100D50

R 9524,9526,9528-9530
R 9531
R 9533
R 9534
R 9536,9538-9540,9542

RS1/10SR0R0J
RS1/16SS3302D
RS1/16SS2402D
RS1/16SS2401D
RS1/8SQ0R0J

C 633,635,639,641
C 638,640,642-645
C 646,663,914
C 647,648,696,713
C 649,650,657,658

CCSSCH102J50
CKSSYB104K16
CEVW470M4
CCSSCH331J50
CCSSCH102J50

R 9543,9555,9564
R 9548
R 9550,9551
R 9719,9720,9726,9727
R 9729,9733,9744

RS1/8SQ0R0J
RS1/4SA105J
RS1/10SR0R0J
RAB4CQ750J
RAB4CQ470J

C 652,654,661,662
C 660,682,690-692
C 664,671,675,676
C 665,949
C 666,943

CKSSYB104K16
CCSSCH101J50
CKSSYB104K16
CCSSCH8R0D50
CCSSCH9R0D50

Other Resistors

RS1/16SS###J

C 670,672,674,677
C 680,681,686,759
C 685,956,980,1043
C 693,1040,1363,1530
C 697,705-708,717

CCSSCH102J50
CKSSYB104K16
CKSSYB103K25
CCSSCH221J50
CCSSCH101J50

CAPACITORS

C 104,107,108,115
C 105,109,111,113
C 106,110,117,131
C 112,126,199,424
C 114,118,168,411

CKSSYB104K16
DCH1246
CCSSCH102J50
DCH1201
CKSSYB103K25

C 698-701,704
C 703,741-746,755
C 718,720,721,751
C 726,902,904,906
C 727-731,740

CCSSCH102J50
CCSSCH100D50
CCSSCH101J50
CCSSCH331J50
CCSSCH102J50

C 116,119,120,122
C 121,127,128,130
C 123,166,194,430
C 124,125,129,133
C 132,141,151,171

CKSSYB104K16
DCH1246
CEVW101M4
CKSSYB104K16
CCSSCH102J50

C 748-750,753,754
C 752,924,938,993
C 756,757,911,937
C 758,917,933,934
C 908,920,923,936

CCSSCH102J50
CCSSCH101J50
CCSSCH102J50
CCSSCH100D50
CCSSCH331J50

C 134,139,143,144
C 135-138,145,146
C 140,995,1355
C 142,147,175,423
C 149,152-155,159

DCH1246
CKSSYB104K16
VCH1277
CCSSCH331J50
CKSSYB104K16

C 913,918,945,946
C 916,928,950,951
C 919,921,922,925
C 926,1529
C 931,935,940,944

CCSSCH471J50
DCH1246
CKSSYB104K16
CEVW470M6R3
CKSSYB104K16

C 150,623,636,659
C 156
C 157,158,167,169
C 162,1031,9004,9537
C 170,177,187,401

CCSSCH101J50
VCH1268
DCH1246
VCH1234
DCH1246

C 941,953,957,971
C 942,997,1021,1062
C 947,948,954,955
C 952,958,959,961
C 960,962,964,965

CCSSCH331J50
CCSSCH100D50
CKSSYB104K16
CCSSCH471J50
CKSSYB104K16

C 172,178,184,185
C 173,406,433,604
C 174,176,190,402
C 186,1526,1527
C 188,195,196,200

CKSSYB104K16
CCSSCH100D50
CCSSCH102J50
CEVW100M16
CKSSYB104K16

C 963,979,982,983
C 968,974,977,981
C 969,975,987,999
C 972,973,976,989
C 978,9008

CCSSCH471J50
CKSSYB104K16
DCH1246
CCSSCH102J50
CCSSCH330J50

C 198,9245,9607
C 201,203,204,403
C 404,408,410,413
C 407,409,417,428
C 412,415,420,441

CKSQYB225K16
CKSSYB104K16
DCH1246
CKSSYB104K16
CCSSCH102J50

C 984,988,994,1001
C 991,1025,1064,1075
C 996,1672,1673,9593
C 1000,1002,1004,1006
C 1003,1005,1007,1009

CKSSYB104K16
CEVW101M16
ACH7306
CCSSCH471J50
CKSSYB104K16

C 414,416,418,421
C 419,432,438,606
C 422,431,434,437
C 425,915,927,1048
C 429,435,440,443

DCH1246
CKSSYB103K25
DCH1246
DCH1201
CKSSYB104K16

C 1008,1010,1069,1212
C 1012,1018,1026,1032
C 1013,1023,1029,1219
C 1014,1015,1027,1033
C 1024,1030,1035,1037

CCSSCH471J50
CKSSYB104K16
CCSSCH331J50
CCSSCH101J50
CCSSCH102J50

5	6	7	8
□ □ □ □ N□. D□□□□□□□□	P□□□N□.	□ □ □ □ N□. D□□□□□□□□	P□□□N□.
C 1028,1036,9105,9106	CCSSCH270J50	C 1646,1647,9040,9202	CKSSYB103K25
C 1034,1038,1039,1047	CKSSYB104K16	C 1651,1657,1695,1696	DCH1246
C 1041,1231,1246,1256	CCSSCH101J50	C 1652,1655,1658,1666	CCSSCH471J50
C 1044	CKSSYB823K10	C 1667,1709,1824,1825	CCSSCH471J50
C 1045,1054,1056,1270	CKSSYB103K25	C 1674-1681,1683-1685	VCG1066
C 1046,1049,1070,1215	CCSSCH102J50	C 1687,1689-1692	VCG1066
C 1050-1052,1055,1057	CKSSYB104K16	C 1694,1839	CKSRYB105K16
C 1059,1061,1067,1068	CKSSYB104K16	C 1700,1710,1736-1742	CKSSYB104K16
C 1060,1063,1065,1074	DCH1201	C 1702,1703,1756,1807	CCSSCH101J50
C 1071,1072,1206,1210	CKSSYB104K16	C 1722,1723,1729,9013	CCSSCH102J50
C 1079,1214,1349-1351	DCH1246	C 1731,9009,9034,9037	CCSSCH100D50
C 1203,1207,1208,1358	CEVW221M4	C 1732-1735,9226,9228	DCH1201
C 1205,1211,1228,1230	DCH1201	C 1743-1745	CCSSCH7R0D50
C 1209,1357,1664,1665	CEVW101M16	C 1746-1748	CCSSCH5R0C50
C 1213,1218,1223,1224	CKSSYB104K16	C 1749-1751,1760-1762	CCSSCH180J50
C 1216,1237,1361,1410	CCSSCH100D50	C 1752,1770,1821,1832	CEVW101M16
C 1221,1298,1345	CCSSCH471J50	C 1753-1755	CCSSCH4R0C50
C 1222,1686,1688,1693	CKSRYB105K16	C 1757-1759,1842	CCSSCH470J50
C 1225,1227,1252,1274	CCSSCH102J50	C 1763	CCSSCH560J50
C 1226,1244,1248,1251	CCSSCH331J50	C 1764-1766	CCSSCH390J50
C 1229,1236,1238,1240	CKSSYB104K16	C 1767-1769,1809,1812	CKSSYB104K16
C 1243,1253-1255,1267	CKSSYB104K16	C 1806,1819,9001,9075	CKSRYB104K50
C 1257,1311,1323,1388	CCSSCH331J50	C 1810,1813,1820,1829	CCSSCH331J50
C 1268,1278,1286,1322	CCSSCH101J50	C 1817,1828,1834,1840	CKSSYB104K16
C 1272,1276,1282,1285	CKSSYB104K16	C 1818,9571	CCSRCH102J50
C 1289,1296,1297,1305	CKSSYB104K16	C 1835,9003,9038,9039	CCSSCH471J50
C 1294,1299,1325,1333	CCSSCH102J50	C 1836	CEVW470M16
C 1313,1326	CCSSCH150J50	C 1841,1845,1853,1855	CCSSCH331J50
C 1318,1319,1324,1328	CKSSYB104K16	C 1846,1852,1854,1858	CKSSYB104K16
C 1334,1341-1343,1362	CKSSYB104K16	C 1847,9563,9600	CEVW101M16
C 1339,1392,1393,1426	CCSSCH101J50	C 1859,1861,1863,9015	CCSSCH331J50
C 1346,1347,1359,1381	CCSSCH102J50	C 1860,1862,9002,9006	CKSSYB104K16
C 1352-1354,1428,1605	DCH1201	C 9007,9010,9012,9014	CKSSYB104K16
C 1364-1366,1371,1389	CCSSCH471J50	C 9011,9019,9046,9053	CCSSCH101J50
C 1367-1370,1380,1384	CKSSYB104K16	C 9016,9021,9022,9026	CCSSCH102J50
C 1385,1390,1391,1394	CKSSYB104K16	C 9017,9018,9020,9023	CKSSYB104K16
C 1395,1401,1411,1424	CCSSCH102J50	C 9025,9028,9031,9033	CKSSYB104K16
C 1398,1408,1409,1425	CKSSYB104K16	C 9027,9048,9051,9055	CCSSCH102J50
C 1427,9005,9029,9067	CEVW221M4	C 9030,9583,9589,9684	DCH1246
C 1431,1503,1507,1508	CKSSYB104K16	C 9032,9076,9214,9249	CCSSCH331J50
C 1432,1506,1511,1613	CCSSCH331J50	C 9035,9036,9041-9045	CKSSYB104K16
C 1501,1628,1629,1636	CCSSCH101J50	C 9047,9049,9052	CKSSYB104K16
C 1502,1510,1518-1520	CCSSCH100D50	C 9050,9079,9085	CCSSCH100D50
C 1505,1808,1811,9201	CCG1222	C 9054,9056,9069,9070	CCSSCH471J50
C 1509,9545,9546	CEAK102M16-P35	C 9057,9061,9062,9064	CCSSCH102J50
C 1528,1614,1624	CKSSYB104K16	C 9058-9060,9063,9066	CKSSYB104K16
C 1531,9065,9742	CCSSCH221J50	C 9068,9071,9073,9080	CKSSYB104K16
C 1534,1671,1697,1698	CCSSCH100D50	C 9072,9074,9077,9081	CCSSCH471J50
C 1540-1544,1654,1660	CCSSCH102J50	C 9086,9087,9204,9250	CCSSCH101J50
C 1601,1602,1662,1663	CKSSYB102K50	C 9088-9091,9093-9098	CCSSCH100D50
C 1606,1650,1656	DCH1201	C 9100,9102-9104,9312	CCSSCH100D50
C 1608,1610,1612,1616	DCH1246	C 9203,9205,9207,9210	CKSSYB104K16
C 1609,1611,1615,1617	CCSSCH471J50	C 9206,9208,9209,9211	CCSSCH102J50
C 1618,1620,1622,1626	DCH1246	C 9212,9213,9216,9219	CKSSYB104K16
C 1619,1621,1625,1627	CCSSCH471J50	C 9215,9232,9235,9238	CCSSCH102J50
C 1623,1633,1699,1701	CCSSCH331J50	C 9217,9520,9574,9576	CEVW221M4
C 1630-1632,1634,1635	CKSSYB104K16	C 9220,9222,9287,9289	CCSSCH471J50
C 1637,1639,1644,1645	CCSSCH471J50	C 9221,9227,9229,9231	CKSSYB104K16
C 1638,1648,1649,1661	CCSSCH101J50	C 9223,9282,9283,9594	CKSSYB103K25
C 1640-1643,1653,1659	CKSSYB104K16	C 9230,9233,9236,9239	DCH1201

□ □ □ □ N. D □ □ □ □ □ □ □ □

P □ □ □ N.

□ □ □ □ N. D □ □ □ □ □ □ □ □

P □ □ □ N.

A

C 9234,9237,9240,9242 CKSSYB104K16
C 9241,9243,9246,9253 CCSSCH102J50
C 9244,9248,9252,9254 CKSSYB104K16
C 9247 CEVW221M10
C 9251,9267,9293,9507 CCSSCH331J50

■

C 9255,9257,9263,9265 CCSSCH102J50
C 9256,9258,9260,9262 CKSSYB104K16
C 9259,9261,9581,9584 CCSSCH101J50
C 9264,9266,9268,9270 CKSSYB104K16
C 9269,9271,9273,9275 CCSSCH102J50

B

C 9272,9274,9276,9278 CKSSYB104K16
C 9277,9279,9281,9310 CCSSCH102J50
C 9284,9285,9510,9512 CCG1222
C 9286,9288,9290,9292 CKSSYB104K16
C 9291,9295,9733,9734 CCSSCH471J50

■

C 9294,9313-9328,9504 CKSSYB104K16
C 9298-9300,9538,9557 BCG1059
C 9302 CKSSYB223K16
C 9311,9505,9529,9562 CCSSCH102J50
C 9501,9513,9514,9522 CCSSCH100D50

C

C 9506,9528,9591,9601 CKSSYB104K16
C 9517,9519,9524,9526 CCG1222
C 9532,9534,9539,9550 CCG1222
C 9533,9598,9602,9672 CCSSCH100D50
C 9543,9544,9556,9561 CKSRYB104K50

■

C 9547 CKSSYB682K25
C 9553 CKSSYB472K50
C 9555,9559 CKSSYB473K16
C 9558,9573,9575,9685 BCG1059
C 9565 CKSSYB152K50

C 9566,9568,9570,9579 CCSSCH102J50
C 9569,9572,9582,9590 CCG1222
C 9580,9585,9586,9597 CCSSCH102J50
C 9588,9608 CFHXSQ103J16
C 9592,9595,9709,9713 CCSSCH101J50

■

C 9596 CEVW331M6R3
C 9599,9617,9706,9711 CCSSCH102J50
C 9603,9605,9612,9614 CCG1222
C 9606,9616,9621-9645 CKSSYB104K16
C 9609,9682,9703,9727 CEVW221M4

C 9647-9671,9692-9697 CKSSYB104K16
C 9674,9676,9679,9681 CCG1222
C 9686,9707,9724 CCSSCH100D50
C 9702 VCH1234
C 9704,9705,9708,9710 CKSSYB104K16

■

C 9712,9715,9716,9718 CKSSYB104K16
C 9714,9717,9719,9720 CCSSCH102J50
C 9721,9723,9726,9729 CKSSYB104K16
C 9725,9740,9747,9755 CCSSCH102J50
C 9728 DCH1246

C 9730 CCSSCH331J50
C 9731,9732,9736-9739 CKSSYB104K16
C 9735 CKSSYB103K25
C 9741,9743,9749,9751 CCSSCH471J50
C 9744,9745,9748,9750 CKSSYB104K16

C 9746 CCSSCH101J50
C 9752,9756-9759 CKSSYB104K16
C 9753,9760 CCSSCH471J50
C 9754 CKSRYB104K50



INTERFACE ASSY

SEMICONDUCATORS

Q 7001-7003,7011,7025 LTC124EUB
Q 7005,7012,7021,7026 LSA1576UB
Q 7008,7010 2SA1036K
Q 7016 LTA114TUB
Q 7022 RSR015P03

Q 7023,7024 LSC4081UB
D 7002,7003,7023,7024 1SS352
D 7004 1SS301
D 7006,7011 HZU5R1(B2)
D 7007,7009 1SS357

D 7008,7010 SIM-20STS1
D 7021 RB411D

ISCELLANEOUS

L 7001 CHIP SOLID INDUCTOR ATL7002
L 7002-7007 CHIP SOLID INDUCTOR QTL1013
JA 7001,7003,7004 JACK AKN-209
JA 7002 MINI JACK QKN1013
JA 7005 JACK VKB1243

KN 7001 SCREW PLATE VNE1948
KN 7005-7007 EARTH TERMINAL AKF7002
CN 7002,7005 7P PLUG KM200IB7
CN 7003 13P PLUG XKP3066
CN 7004 21P PLUG XKP3070

CN 7006 CONNECTOR 9604S-19C
CN 7007 17P PLUG XKP3068
CN 7008 15P PLUG XKP3067
JH 7001 PCB BINDER VEF1040
JP 7001 HOUSING ADX7747

U 7001 REMOTE RECEIVER UNIT GP1UE284QKC1

RESISTORS

R 7108,7109 RS1/8SQ105J
Other Resistors RS1/10SR###J

CAPACITORS

C 7002-7005,7014,7021 CCSSCH100D50
C 7006,7012,7024,7080 CCSSCH102J50
C 7007,7011,7015,7017 CKSRYB104K50
C 7009,7010,7013,7016 CKSRYB103K50
C 7019,7081,7083,7085 CKSRYB104K50

C 7020,7022,7027,7126 CKSRYB103K50
C 7025,7029 CCSSCH471J50
C 7026,7100,7110,7122 CCSSCH100D50
C 7028 CEAK101M16
C 7082,7084,7096,7125 CCSSCH102J50

C 7095 CEAK100M50
C 7097,7114,7124 CKSRYB104K50
C 7101,7115-7119 CCSSCH101J50
C 7108 CEAK470M25
C 7111,7113 CCSSCH331J50

C 7112,7123 CEAK221M16
C 7120,7121 CKSQYB105K25
C 7134 CCSSCH100D50

□ □ □ □ N. D □ □ □ □ □ □ □ □

P □ □ □ N. □



CO PONENT ASS

SE I CONDUCTORS

IC 8301	NJW1327FU1
IC 8401	NJM2505AF
IC 8501	PDC162A
IC 8601	HIN202EIBNZ
Q 8301,8604	LSA1576UB
Q 8302,8501,8603	LSC4081UB
Q 8303,8605	LTC114EUB
Q 8401	2SD1664
Q 8402	2SB1132
D 8301,8302,8601,8605	1SS352
D 8401	1SS302
D 8404,8408	UDZS3R9(B)

ISCELLANEOUS

L 8501 CHIP COIL	LCYA330J2520
JA 8301 6P PIN JACK AU	AKB7225
JA 8302,8304,8305 3P PIN JACK AU	AKB7228
JA 8601 9P D-SUB SOCKET	AKP7256
X 8501 CRYSTAL RESONATOR	ASS7080
CN 8301-8303 20P PLUG	AKM7171
CN 8401 PLUG(2P)	KM200NA2L
JP 8402 HOUSING	ADX7746

RESISTORS

R 8301-8309	RS1/10SR75R0F
R 8310,8312,8314,8316	RS1/10SR68R0F
R 8318,8320	RS1/10SR68R0F
R 8417	RS1/8SQ105J
R 8418	RS1/8SQ561J
Other Resistors	RS1/10SR###J

CAPACITORS

C 8301,8302,8383,8417	CEAK101M16
C 8303,8319,8320,8333	CCSRCH102J50
C 8304,8306,8308,8314	CKSRYB104K50
C 8305,8307,8309,8310	DCH1201
C 8311,8312,8330,8331	CKSRYB103K50
C 8313,8315,8317,8318	DCH1201
C 8316,8323,8325,8327	CKSRYB104K50
C 8321,8322,8324,8326	DCH1201
C 8328,8336,8337,8344	CKSRYB104K50
C 8334,8378,8389,8403	CCSRCH102J50
C 8335,8376,8377,8379	CCSRCH100D50
C 8338,8339,8360,8402	CKSRYB103K50
C 8340	CKSQYB105K25
C 8341-8343,8345,8346	DCH1201
C 8347,8349,8395,8401	CKSRYB104K50
C 8348,8404,8405,8409	DCH1201
C 8354,8355,8381,8382	CKSRYB105K16
C 8358,8359,8394	CCSRCH470J50
C 8384,8385,8388	CKSRYB473K50
C 8386	CKSRYB562K50
C 8387,8390	CKSRYB105K16
C 8406,8407,8503,8509	CCSRCH101J50
C 8408,8410,8413,8415	CCSRCH102J50
C 8414	DCH1201
C 8418,8520,8521,8613	CEAK101M16
C 8419,8420	CEAK221M16

□ □ □ □ N. D □ □ □ □ □ □ □ □

P □ □ □ N. □

C 8421,8422,8501,8513	CCSRCH102J50
C 8504,8505	CCSRCH5R0C50
C 8506,8508	CCSRCH240J50
C 8507,8510	CCSRCH122J50
C 8511,8512,8614	CCSRCH101J50
C 8515,8601,8607	CKSRYB103K50
C 8522,8523,8602	CKSRYB104K50
C 8604-8606	CKSRYB104K50
C 8608	CCSRCH471J50
C 8610	CCSRCH331J50
C 8611,8612,8617,8619	CCSRCH100D50



CO POSITE ASS

SE I CONDUCTORS

Q 3601,3604,3605,3608	LSA1576UB
Q 3602,3603,3606,3607	HN1C01FU

ISCELLANEOUS

JA 3601-3603 2P PIN JACK	AKB7230
JA 3604,3605 1P PIN JACK	AKB7232
CN 3601 20P SOCKET	AKP7249

RESISTORS

R 3606,3609,3627	RS1/10SR68R0F
R 3616	RS1/10SR68R0D
R 3629-3632	RS1/10SR75R0F
Other Resistors	RS1/10SR###J

CAPACITORS

C 3602,3603,3605,3606	CKSRYB104K50
C 3607,3618-3620	CCSRCH181J50
C 3608,3610	CKSRYB104K16
C 3612,3613,3615,3616	CKSRYB104K50
C 3614,3617	CCSRCH102J50
C 3621-3624	CEAK101M16



IC P ASS

SE I CONDUCTORS

IC 3471	NJM4565MD
Q 3451	LTC124EUB
D 3473-3475	RKZ5.1KG(B2)

ISCELLANEOUS

JA 3471 JACK	VKB1243
JA 3472 JACK	AKB7219
JA 3476 HEADPHONE JACK	XKB3066
KN 3471,3472 EARTH TERMINAL	AKF7002
CN 3472 CONNECTOR	9604S-15C
JH 3471 PCB BINDER	VEF1040

RESISTORS

R 3495	RS1/10SR75R0F
Other Resistors	RS1/10SR###J

CAPACITORS

C 3451,3452	CKSRYB822K50
C 3460	DCH1165
C 3473	CKSRYB471K50
C 3475,3479,3494	CCSRCH101J50
C 3476,3477	CCSRCH330J50

□ □ □ □ N. D. □ □ □ □ □ □ □ □

P. □ □ □ N.

□ □ □ □ N. D. □ □ □ □ □ □ □ □

P. □ □ □ N.

C 3478,3483,3484
C 3480
C 3481,3482,3486,3496
C 3485
C 3488

CEAT100M50
DCH1201
CKSBYB103K50
CKSBYB105K16
CKSBYB223K50

C 3103,3105,3202,3204
C 3208
C 3209
C 3211
C 3213

CKSBYB104K50
CEAK221M16
CKSBYB105K16
ACH7272
CEAK101M16

C 3490
C 3495
C 3497

CKSBYB102K50
CKSBYB104K50
CCSRCH331J50

C 3214,3216,3217
C 3215,3218
C 3303,3405
C 3304,3307
C 3305,3308,3328

CCSRCH221J50
CCSRCH470J50
CCSRCH102J50
CKSBYB104K50
CEAK470M50

C 3311-3326
C 3327
C 3335-3337,3341
C 3338,3340,3343
C 3339

CCSRCH471J50
CEAK101M35
CKSBYB103K50
CCSRCH100D50
CCSRCK2R0C50

K DISPLA ASS

SE I CONDUCTORS

IC 3001
IC 3002
IC 3003
IC 3201
Q 3004

PDC199A8
S-80848CNMC-B89
S-1200B33-M5
PE5615A
2SK2034

Q 3203-3207,3210-3213
D 3002
D 3003,3006
D 3004,3008
D 3005

LTC124EUB
RB751V-40
1SS302
1SS301
1SS300

D 3204,3206,3208,3210
D 3212

SLR343BC4T(JKLM)
SLR343BC4T(JKLM)

ISCELLANEOUS

L 3001 CHIP SOLID INDUCTOR
KN3201 FL HOLDER(FE)
V 3301 FL TUBE DISPLAY
S 3001-3019 SWITCH
X 3001 CRYSTAL OSCILLATOR

ATL7002
VNF1096
AAV7115
ASG7029
CSS1653

X 3201 CERAMIC RESONATOR
CN3001 3P CONNECTOR
CN3003 5P CONNECTOR

VSS1142
VKN2098
VKN1820

RESISTORS

All Resistors

RS1/10SR###J

ISCELLANEOUS

JH 3002 4P CABLE HOLDER
JH 3003,3004 3P CABLE HOLDER
JP 3001 HOUSING
JP 3002 JUMPER WIRE
JP 3003,3004 JUMPER WIRE

51048-0400
51048-0300
ADX7753
D20PYY0410E
D20PYY0310E

U 3201 REMOTE RECEIVER UNIT

GP1UE274XKC1

CAPACITORS

C 3002,3009,3013,3014
C 3003,3007,3020,3021
C 3004,3005
C 3006,3302
C 3008,3010,3043,3205

CKSBYB104K50
CKSBYB105K16
CCSRCH120J50
CKSBYB471K50
CCSRCH471J50

C 3011,3042
C 3012
C 3015,3016
C 3017
C 3018,3035,3045

CCSRCH101J50
CKSBYB472K50
CKSBYB473K50
CCSRCH150J50
CKSBYB103K50

C 3022,3212,3221-3223
C 3023,3025,3027,3038
C 3039
C 3048,3058,3101,3207
C 3102,3104,3201,3306

CCSRCH102J50
CKSBYB104K50
ACH7268
CCSRCH100D50
CKSBYB102K50

L VOL ASS

ISCELLANEOUS

S 3371 ROTARY ENCODER
CN3371 3P JUMPER CONNECTOR

ASX7049
52147-0310

CAPACITORS

C 3371,3372

CKSBYB103K50

M POWER S ASS

SE I CONDUCTORS

Q 3401
D 3402

LTC143EUB
SLR343BC4T(JKLM)

ISCELLANEOUS

S 3401 SWITCH
CN3401 4P JUMPER CONNECTOR

VSG1024
52147-0410

RESISTORS

All Resistors

RS1/10SR###J

CAPACITORS

C 3401
C 3402

CCSRCH221J50
CKSBYB104K16

N ENCODER ASS

ISCELLANEOUS

S 3501 ROTARY ENCODER
CN3501 3P JUMPER CONNECTOR

ASX7051
52147-0310

RESISTORS

All Resistors

RS1/10SR###J

CAPACITORS

C 3501,3502

CKSBYB103K50

0000 N. D000000000

P000N.

OIR UER ASS

SE I CONDUCTORS

IC 6801,6821,6841,6861	UPC4570G2-A
IC 6881,6901,6921,7451	UPC4570G2-A
IC 7471	UPC4570G2-A
IC 7491	TC4053BFN

I ISCELLANEOUS

KN6801 WRAPPING TERMINAL	CKF1089
CN6801 23P SOCKET	XKP3082
CN6802,6803 23P PLUG	XKP3071

RESISTORS

R 6802,6803,6822,6823	RS1/10SR1002F
R 6806,6807,6826,6827	RS1/10SR3902F
R 6817,6818,6837,6838	RS1/8SQ225J
R 6842,6843,7452,7453	RS1/10SR1002F
R 6846,6847,6866,6867	RS1/10SR3902F
R 6857,6858,6877,6878	RS1/8SQ225J
R 6864,6865,6884,6885	RS1/10SR1302F
R 6886,6887,6906,6907	RS1/10SR3902F
R 6897,6898,6917,6918	RS1/8SQ225J
R 6904,6905,6924,6925	RS1/10SR1302F
R 6926,6927,7456,7457	RS1/10SR3902F
R 6937,6938,7467,7468	RS1/8SQ225J
R 7472,7473	RS1/10SR1002F
R 7476,7477	RS1/10SR3902F
R 7487,7488	RS1/8SQ225J
R 7491,7492	RS1/8SQ105J
Other Resistors	RS1/10SR###J

CAPACITORS

C 6801,6802,6821,6822	CFHXSQ103J16
C 6807,6808,6827,6828	ACG7106
C 6841,6842,6861,6862	CFHXSQ103J16
C 6847,6848,6867,6868	ACG7106
C 6866,6866,6906,6926	CCSRCH331J50
C 6881,6882,6901,6902	CFHXSQ103J16
C 6887,6888,6907,6908	ACG7106
C 6921,6922,7451,7452	CFHXSQ103J16
C 6927,6928,7457,7458	ACG7106
C 7471,7472,7494,7497	CFHXSQ103J16
C 7477,7478	ACG7106
C 7495	CCSRCH100D50

P UER ND ASS

I ISCELLANEOUS

KN6961 SCREW PLATE	VNE1948
KN6962 SCREW PLATE(MTL)	ANG7591

QIR INTERACE ASS

I ISCELLANEOUS

CN3801,3802 23P SOCKET	XKP3082
CN3810,3850,3890 5P SOCKET	XKP3073
CN3820,3830,3840,3860 5P SOCKET	KP200IB5L
CN3870,3880 5P SOCKET	KP200IB5L

0000 N. D000000000

P000N.

RIR POER A P ASS

SE I CONDUCTORS

IC 4001	BU7262SFVM
IC 4004	TC74VHC08FK
IC 4005	HA17431GLTPA
IC 4007	BU4094BCFV
IC 4100,4200,4300,4400	TLC0711DR

⚠ IC 4101,4201,4301,4401	IRS20957SPBF
⚠ IC 4103,4203,4302,4403	NJM2830U1-12
IC 4202,4402,4602,4702	UPC4570G2-A
IC 4204,4404,4604,4704	NJM12904V
IC 4500,4600,4700,4800	TLC0711DR

⚠ IC 4501,4601,4701,4801	IRS20957SPBF
⚠ IC 4502,4603,4703,4803	NJM2830U1-12
IC 4802,5101	UPC4570G2-A
IC 4804	NJM12904V
IC 4900	TLC0711DR

⚠ IC 4901	IRS20957SPBF
⚠ IC 4903	NJM2830U1-12
IC 4905	TC7SH08FUS1
Q 4000,4002,4003,4017	LTC124EUB
Q 4001,4020,4026,4107	LSA1576UB

Q 4004,4006,4008,4010	LTA124EUB
Q 4005,4007,4009,4011	RT1N140M
Q 4012,4013,4035	HN1A01FU
Q 4014,4016,4027-4029	HN1C01FU
Q 4015,4021-4023,4025	LSC4081UB

Q 4018,4031,4033	LTA124EUB
Q 4019,4032,4112,4312	RT1N140M
Q 4024	2SC3906K
Q 4030,4034,4036,4105	LTC124EUB
Q 4037,4038,4103,4104	LSC4081UB

⚠ Q 4100,4200,4300,4400	2SD2704K
Q 4101,4102,4201,4202	IRF6775MPBF
Q 4106,4205,4206,4305	LTC124EUB
Q 4108,4113,4203,4204	LSC4081UB
Q 4110,4210,4310,4410	2SA1514K

Q 4111,4122,4207,4211	LSA1576UB
Q 4120,4220,4720	2SA1163
Q 4121,4221,4721	2SC2713
Q 4208,4213,4303,4304	LSC4081UB
Q 4222,4307,4311,4407	LSA1576UB

⚠ Q 4301,4302,4401,4402	IRF6775MPBF
Q 4306,4405,4406,4505	LTC124EUB
Q 4308,4403,4404,4408	LSC4081UB
Q 4411,4507,4511,4607	LSA1576UB
Q 4500,4600,4700,4800	2SD2704K

⚠ Q 4501,4502,4601,4602	IRF6775MPBF
Q 4503,4504,4508,4603	LSC4081UB
Q 4506,4605,4606,4705	LTC124EUB
Q 4510,4610,4710,4810	2SA1514K
Q 4512,4712,4912,5012	RT1N140M

Q 4604,4608,4703,4704	LSC4081UB
Q 4611,4707,4711,4722	LSA1576UB
⚠ Q 4701,4702,4801,4802	IRF6775MPBF
Q 4706,4805,4806,4905	LTC124EUB
Q 4708,4713,4803,4804	LSC4081UB

□ □ □ □ N. D. □ □ □ □ □ □ □ □

P □ □ □ N.

□ □ □ □ N. D. □ □ □ □ □ □ □ □

P □ □ □ N.

A



Q 4807,4811,4907,4911 LSA1576UB
Q 4808,4903,4904,4908 LSC4081UB
Q 4900 2SD2704K
Q 4901,4902 IRF6775MPBF
Q 4906 LTC124EUB

Q 4910 2SA1514K
Q 5101 LSC4081UB
D 4005,4016,4110,4119 1SS352
D 4011,4012 1SS301
D 4013,4014,4018,4019 RKZ24KG(B2)

D 4015,4020 RKZ27KG(B)
D 4017,4021 RKZ18KG(B2)
D 4027-4031 RKZ4.7KG(B2)
D 4101,4201,4301,4401 RB751V-40
D 4103,4111,4203,4211 1SS302

B

D 4108,4109,4208,4209 RF101L2S
D 4116,4216,4316,4416 RB161VA-20
D 4117,4217,4317,4417 RF051VA2S
D 4118,4218,4318,4418 CMH07
D 4120,4210,4219,4220 1SS352

C

D 4308,4309,4408,4409 RF101L2S
D 4310,4319,4410,4419 1SS352
D 4311,4411,4511,4611 1SS302
D 4501,4601,4701,4801 RB751V-40
D 4508,4509,4608,4609 RF101L2S

D

D 4510,4519,4610,4619 1SS352
D 4516,4616,4716,4816 RB161VA-20
D 4517,4617,4717,4817 RF051VA2S
D 4518,4618,4718,4818 CMH07
D 4703,4711,4811,4911 1SS302

E

D 4708,4709,4808,4809 RF101L2S
D 4710,4712,4719,4720 1SS352
D 4810,4819,4910,4919 1SS352
D 4901 RB751V-40
D 4908,4909 RF101L2S

D 4916 RB161VA-20
D 4917 RF051VA2S
D 4918 CMH07
D 5009,5109 1SS352

ISCELLANEOUS

L 4000 CHIP SOLID INDUCTOR QTL1013
L 4100,4200,4300,4400 OTHER COIL ATH7090
L 4500,4600,4700,4800 OTHER COIL ATH7090
L 4900 OTHER COIL ATH7090
JA 4101 SP TERMINAL 6-P(V0) AKE7150

JA 4301,4501 SP TERMINAL 4-P(V0) AKE7149
JA 4901,5101 SP TERMINAL 4-P(V0) AKE7149
KN 4100,4200,4300,4400 SCREW PLATE VNE1948
KN 4500,4900 SCREW PLATE VNE1948
KN 4502,4901 EARTH TERMINAL AKF7002

KN 4511-4518 WRAPPING TERMINAL CKF1089
RY 4100,4300,4500,4700 RELAY ASR7001
RY 4900,5000 RELAY ASR7001
CN 4000 CONNECTOR 9604S-19C
CN 4002 PLUG(2P) KM200NA2

CN 4003 PLUG(4P) KM200NA4
CN 4004 PLUG(7P) KM200NA7
CN 4100,4300,4400,4600 5P PLUG KM200IB5
CN 4200,4500,4900 5P PLUG XKP3062
CN 4700,4800 5P PLUG KM200IB5

RESISTORS

R 4057 RS1/8SQ471J
R 4060 RS1/10SR5602F
R 4061 RS1/10SR3302F
R 4100,4101,4200,4201 RN1/16SE5600D
R 4102,4103,4202,4203 RN1/16SE5601D

R 4104,4105,4204,4205 RN1/16SE3301D
R 4107,4146,4147,4187 ACN7180
R 4111,4119,4122,4123 RS1/10SR1001F
R 4115,4133,4215,4233 ACN7192
R 4116,4216,4316,4416 ACN7185

R 4120,4220,4320,4420 RS1/10SR2200F
R 4125,4126,4225,4226 ACN7187
R 4128,4228,4328,4428 RS1/4SA223J
R 4129,4229,4329,4429 RS1/8SQ182J
R 4130,4230,4330,4430 RS1/8SQ822J

R 4131,4231,4331,4431 RS1/8SQ472J
R 4132,4232,4332,4432 RS1/8SQ562J
R 4134,4234,4334,4434 RS1/8SQ103J
R 4135,4235,4335,4435 RS1/8SQ752J
R 4136,4236,4336,4436 RS1/8SQ242J

R 4137,4141,4237,4241 ACN7194
R 4138,4238,4338,4438 RS1/8SQ4R7J
R 4139,4239,4339,4439 RS1/8SQ100J
R 4140,4240,4340,4440 ACN7165
R 4142,4143,4242,4243 ACN7189

R 4145,4169,4245,4269 RS1/10SR1202F
R 4148,4248,4348,4448 RS1/10SR3301F
R 4150,4250,4350,4450 RS1/10SR1000F
R 4151,4251,4351,4451 ACN7191
R 4154,4254,4354,4454 ACN7186

R 4155,4255,4355,4455 RS1/10SR4702F
R 4156,4256,4356,4456 RS1/10SR5601F
R 4163,4263,4363,4463 RS1/10SR3901F
R 4166,4266,4366,4466 RS1/10SR1002F
R 4167,4211,4219,4222 RS1/10SR1001F

R 4168,4268,4368,4468 RS1/10SR2202F
R 4176,4180,4276,4280 ACN7195
R 4181,4281,4381,4481 NTCG104KF104FB
R 4188,4207,4246,4247 ACN7180
R 4195-4198,4295-4298 RS1/8SQR47J



R 4223,4267,4311,4319 RS1/10SR1001F
R 4287,4288,4307,4346 ACN7180
R 4300,4301,4400,4401 RN1/16SE6800D
R 4302,4303,4402,4403 RN1/16SE5601D
R 4304,4305,4404,4405 RN1/16SE3301D

R 4315,4333,4415,4433 ACN7192
R 4322,4323,4367,4411 RS1/10SR1001F
R 4325,4326,4425,4426 ACN7187
R 4337,4341,4437,4441 ACN7194
R 4342,4343,4442,4443 ACN7189

R 4345,4369,4445,4469 RS1/10SR1202F
R 4347,4387,4388,4407 ACN7180
R 4395-4398,4495-4498 RS1/8SQR47J
R 4419,4422,4423,4467 RS1/10SR1001F
R 4446,4447,4487,4488 ACN7180

N. D

N. D

P

R 4500,4501,4600,4601

R 4502,4503,4602,4603

R 4504,4505,4604,4605

R 4507,4546,4547,4587

R 4511,4519,4522,4523

R 4515,4533,4615,4633

R 4516,4616,4716,4816

R 4520,4620,4720,4820

R 4525,4526,4625,4626

R 4528,4628,4728,4828

R 4529,4629,4729,4829

R 4530,4630,4730,4830

R 4531,4631,4731,4831

R 4532,4632,4732,4832

R 4534,4634,4734,4834

R 4535,4635,4735,4835

R 4536,4636,4736,4836

R 4537,4541,4637,4641

R 4538,4638,4738,4838

R 4539,4639,4739,4839

R 4540,4640,4740,4840

R 4542,4543,4642,4643

R 4545,4569,4645,4669

R 4548,4648,4748,4848

R 4550,4650,4750,4850

R 4551,4651,4751,4851

R 4554,4654,4754,4854

R 4555,4655,4755,4855

R 4556,4656,4756,4856

R 4563,4663,4763,4863

R 4566,4666,4766,4866

R 4567,4611,4619,4622

R 4568,4668,4768,4868

R 4581,4681,4781,4881

R 4588,4607,4646,4647

R 4595-4598,4695-4698

R 4623,4667,4711,4719

R 4687,4688,4707,4746

R 4700,4701

R 4702,4703,4802,4803

R 4704,4705,4804,4805

R 4715,4733,4815,4833

R 4722,4723,4767,4811

R 4725,4726,4825,4826

R 4737,4741,4837,4841

R 4742,4743,4842,4843

R 4745,4769,4845,4869

R 4747,4787,4788,4807

R 4776,4780

R 4795-4798,4895-4898

R 4800,4801,4900,4901

R 4819,4822,4823,4867

R 4846,4847,4887,4888

R 4902,4903

R 4904,4905

R 4907,4946,4947,4987

R 4911,4919,4922,4923

R 4915,4933

R 4916

R 4920

RN1/16SE5600D

RN1/16SE5601D

RN1/16SE3301D

ACN7180

RS1/10SR1001F

ACN7192

ACN7185

RS1/10SR2200F

ACN7187

RS1/4SA223J

RS1/8SQ182J

RS1/8SQ822J

RS1/8SQ472J

RS1/8SQ562J

RS1/8SQ103J

RS1/8SQ752J

RS1/8SQ242J

ACN7194

RS1/8SQ4R7J

RS1/8SQ100J

ACN7165

ACN7189

RS1/10SR1202F

RS1/10SR3301F

RS1/10SR1000F

ACN7191

ACN7186

RS1/10SR4702F

RS1/10SR5601F

RS1/10SR3901F

RS1/10SR1002F

RS1/10SR1001F

RS1/10SR2202F

NTCG104KF104FB

ACN7180

RS1/8SQR47J

RS1/10SR1001F

ACN7180

RN1/16SE5600D

RN1/16SE5601D

RN1/16SE3301D

ACN7192

RS1/10SR1001F

ACN7187

ACN7194

ACN7189

RS1/10SR1202F

ACN7180

ACN7195

RS1/8SQR47J

RN1/16SE6800D

RS1/10SR1001F

ACN7180

RN1/16SE5601D

RN1/16SE3301D

ACN7180

RS1/10SR1001F

ACN7192

ACN7185

RS1/10SR2200F

R 4925,4926

R 4928

R 4929

R 4930

R 4931

R 4932

R 4934,5011-5013,5020

R 4935

R 4936

R 4937,4941

R 4938

R 4939

R 4940

R 4942,4943

R 4945,4969

R 4948

R 4950

R 4951

R 4954

R 4955

R 4956

R 4963,5001

R 4966

R 4967

R 4968

R 4981

R 4988,5003-5005,5026

R 4995-4998

R 5000

R 5006-5009

R 5014,5015,5022,5023

R 5016,5017,5024,5025

R 5018,5019

R 5021

R 5059,5159

R 5083-5087

Other Resistors

ACN7187

RS1/4SA223J

RS1/8SQ182J

RS1/8SQ822J

RS1/8SQ472J

RS1/8SQ562J

RS1/8SQ472J

RS1/8SQ103J

ACN7194

RS1/8SQ4R7J

RS1/8SQ100J

ACN7165

ACN7189

RS1/10SR1202F

RS1/10SR3301F

RS1/10SR1000F

RS1/10SR5601F

RS1/10SR3901F

RS1/10SR3901F

RS1/10SR1002F

RS1/10SR1001F

RS1/10SR2202F

NTCG104KF104FB

ACN7180

RS1/8SQR47J

RS1/10SR1001F

RS1/10SR4702F

RS1/8SQ223J

RS1/8SQ473J

RS1/8SQ104J

RS1/8SQ103J

ACN7180

RS1/8SQ105J

RS1/10SR###J

CAPACITORS

C 4006,4026,4035,4042

C 4007,4009,4011-4019

C 4008,4010,4036,4052

C 4021,4044-4051,4056

C 4022,4025,4040,4112

C 4023

C 4024,4116,4166,4167

C 4027,4030,4041,4043

C 4028,4151,4155,4156

C 4053,4065,4066

C 4054,4055,4077,4185

C 4057-4062

C 4063

C 4064,4086,4091,4103

C 4073,4074,4109,4121

C 4078,4079,4180,4182

C 4080,4120,4123,4220

C 4081,4082

C 4087,4183,4184,4283

C 4088,4092-4094,4096

CKSRYB104K50

CCSRCH331J50

ACH7321

CCSRCH331J50

CCG1255

CCG1236

ACH1479

CCSRCH100D50

CKSRYB103K50

ACH7321

CCSRCH100D50

ACH7305

ACH7311

CKSRYB104K50

CFHXSQ103J16

ACE7090

CFHXSQ102J50

ACG7106

CCSRCH471J50

CCSRCH331J50

□ □ □ □ N. D. □ □ □ □ □ □ □ □

P. □ □ □ N. □

□ □ □ □ N. D. □ □ □ □ □ □ □ □

P. □ □ □ N. □

C 4097,5001-5005
C 4098,4099
C 4100,4200,4300,4400
C 4101,4201,4301,4401
C 4108,4208,4308,4408

CCSRCH331J50
CCSRCH102J50
CFTLA104J2A
CFTLA474J2A
ACH7320

C 4680,4682,4780,4782
C 4703,4713,4724,4752
C 4709,4714,4721,4722
C 4715,4812,4815,4912
C 4737,4825,4830,4837

ACE7090
CKSRYB104K50
CFHXSQ103J16
CCG1255
CCG1288

C 4113,4124,4152,4153
C 4115,4212,4215,4312
C 4119,4219,4319,4419
C 4122,4209,4221,4222
C 4125,4130,4137,4225

CKSRYB104K50
CCG1255
ACG7104
CFHXSQ103J16
CCG1288

C 4749,4750,4849,4850
C 4753,4758,4803,4813
C 4755,4756,4851,4855
C 4759,4760,4859,4860
C 4761,4775,4861,4875

ACH7359
CKSRYB104K50
CKSRYB103K50
ACG7107
ACG7105

C 4127,4227,4327,4427
C 4134,4234,4334,4434
C 4135,4235,4335,4435
C 4149,4150,4249,4250
C 4159,4160,4259,4260

DCH1330
CCSQCH101J50
ACG7103
ACH7359
ACG7107

C 4766,4767,4816,4866
C 4786
C 4808,4908
C 4809,4821,4822,4909
C 4823,4920,4923

ACH1479
CCSRCH100D50
ACH7320
CFHXSQ103J16
CFHXSQ102J50

C 4161,4175,4261,4275
C 4186,4285,4286,4785
C 4203,4213,4224,4252
C 4216,4266,4267,4316
C 4223,4320,4323,4420

ACG7105
CCSRCH100D50
CKSRYB104K50
ACH1479
CFHXSQ102J50

C 4824,4852,4853,4858
C 4856,4951,4955,4956
C 4867,4916,4966,4967
C 4880,4882,4980,4982
C 4900

CKSRYB104K50
CKSRYB103K50
ACH1479
ACE7090
CFTLA104J2A

C 4230,4237,4325,4330
C 4251,4255,4256,4351
C 4253,4258,4303,4313
C 4280,4282,4380,4382
C 4284,4783,4784

CCG1288
CKSRYB103K50
CKSRYB104K50
ACE7090
CCSRCH471J50

C 4901
C 4903,4913,4924,4952
C 4915
C 4919
C 4921,4922,5102,5103

CFTLA474J2A
CKSRYB104K50
CCG1255
ACG7104
CFHXSQ103J16

C 4309,4321,4322,4409
C 4315,4412,4415,4512
C 4324,4352,4353,4403
C 4337,4425,4430,4437
C 4349,4350,4449,4450

CFHXSQ103J16
CCG1255
CKSRYB104K50
CCG1288
ACH7359

C 4925,4930,4937
C 4927
C 4934
C 4935
C 4949,4950

CCG1288
DCH1330
CCSQCH101J50
ACG7103
ACH7359

C 4355,4356,4451,4455
C 4359,4360,4459,4460
C 4361,4375,4461,4475
C 4366,4367,4416,4466
C 4413,4424,4452,4453

CKSRYB103K50
ACG7107
ACG7105
ACH1479
CKSRYB104K50

C 4953,5101
C 4959,4960
C 4961,4975
C 5080,5082,5180,5182
C 5106

CKSRYB104K50
ACG7107
ACG7105
ACE7090
CKSRYB224K25

C 4421,4422,4509,4521
C 4423,4520,4523,4620
C 4456,4551,4555,4556
C 4458,4503,4513,4524
C 4467,4516,4566,4567

CFHXSQ103J16
CFHXSQ102J50
CKSRYB103K50
CKSRYB104K50
ACH1479

C 4480,4482,4580,4582
C 4500,4600,4700,4800
C 4501,4601,4701,4801
C 4508,4608,4708,4728
C 4515,4612,4615,4712

ACE7090
CFTLA104J2A
CFTLA474J2A
ACH7320
CCG1255

C 4519,4619,4719,4819
C 4522,4609,4621,4622
C 4525,4530,4537,4625
C 4527,4627,4727,4827
C 4534,4634,4734,4834

ACG7104
CFHXSQ103J16
CCG1288
DCH1330
CCSQCH101J50

C 4535,4635,4735,4835
C 4549,4550,4649,4650
C 4552,4553,4603,4613
C 4559,4560,4659,4660
C 4561,4575,4661,4675

ACG7103
ACH7359
CKSRYB104K50
ACG7107
ACG7105

C 4616,4666,4667,4716
C 4623,4720,4723,4820
C 4624,4652,4653,4658
C 4630,4637,4725,4730
C 4651,4655,4656,4751

ACH1479
CFHXSQ102J50
CKSRYB104K50
CCG1288
CKSRYB103K50

S PRI AR ASS

SE I CONDUCTORS

⚠ IC 1
⚠ IC 52
Q 71
⚠ D 1
⚠ D 2

MIP4150MD
NJM1431AF
2SD2704K
D2SB60A
RD2ALF-A1

⚠ D 3
⚠ D 4
⚠ D 50
D 71,72

1SS403
RB751V-40
SBT250-06J
1SS352

I ISCELLANEOUS

⚠ L 1 LINE FILTER
L 51 COIL
⚠ L 71 LINE FILTER
H 1,2,71,72 FUSE CLIP
⚠ JA 71 AC INLET ASSY

ATF7046
ATH7080
XTF3004
AKR1004
ADX7464

KN 1,2 SCREW PLATE
KN 50,52 EARTH TERMINAL
⚠ RY 71 POWER RELAY
⚠ T 1 POWER TRANSFORMER
⚠ CN 81 CONNECTOR

VNE1948
AKF7002
ASR7034
ATK7003
B2P3-VH

□□□□ N. □□□□□□□□□□		P □□□ N.	
0	HEAT SINK(AL)	ANH7224	
0	SCREW	BBZ30P080FCC	
0	HEAT SINK(AL)	ANH7223	
JP 51	HOUSING	ADX7750	
 PC 1	PHOTO COUPLER	TL781(GR)	

RESISTORS

	R 1,12	RS2LMF683J
	R 9-11	ACN7173
	R 14	RS1/10SR1001F
	R 53	RS1/10SR1202F
	R 54	RS1/10SR7500F
	R 56	RS1/10SR1002F
	R 57	ACN7180
	R 59	RS1/8SQ365J
	R 74	RS1/8SQ105J
	Other Resistors	RS1/10SR###J

CAPACITORS

⚠	C 1	ACE7043
	C 3	ACH7342
⚠	C 4	ACE7089
⚠	C 5	ACG7102
	C 6	CKSQYB105K25
	C 7	ACH7370
	C 8,53,56	CKSRYB104K50
	C 9	CCSRCH100D50
	C 10	CEAK2R2M2A
	C 13	CCSRCH102J50
⚠	C 18,20	VCG1046
	C 52	BCH1044
	C 58	ACH7369
	C 61	CCSRCH101J50
⚠	C 71,81	ACE7013
⚠	C 73	ACG7039
	C 74,75	CCSRCH220J50

T **PRI** **AR** **S** **IELD ASS**

ISCELLANEOUS

KN5751	SCREW PLATE	VNE1948
CN5751	5P PLUG	XKP3062

U RE ASS

SEMI CONDUCTORS

⚠	IC 7501,7611	NJM78M12FA
⚠	IC 7502	NJM79M12FA
⚠	IC 7521	NJM78M06FA
⚠	IC 7601	NJM78M05FA
⚠	IC 7602	NJM79M05FA
⚠	D 7501-7504,7521,7522	1SR154-400
	D 7505,7506,7523,7603	1SS357
⚠	D 7601	D3SBA60(B)
	D 7604,7614	1SS357
⚠	D 7611-7613,7621-7623	1SR154-400
	D 7624,7627	RKZ5.1KG(B2)
	D 7625	PTZ22(B)

□ □ □ □ N. D. □ □ □ □ □ □ □ □	P. □ □ □ N.
□ ISCELLANEOUS	
H 7501-7504,7601-7604 FUSE CLIP	AKR1004
CN 7501,7601 5P TOP POST	B5B-EH
CN 7502 PLUG(5P)	KM200NA5
CN 7602 PLUG(7P)	KM200NA7
CN 7603 PLUG(4P)	KM200NA4

ISCELLANEOUS

H 7501-7504,7601-7604 FUSE CLIP	AKR1004
CN 7501,7601 5P TOP POST	B5B-EH
CN 7502 PLUG(5P)	KM200NA5
CN 7602 PLUG(7P)	KM200NA7
CN 7603 PLUG(4P)	KM200NA4

7502 PCB BINDER	VEF1040
! P 7521.7522 PROTECTOR(1.5A)	AEK7011

RESISTORS

R 7621,7640	RS1/10SR473J
R 7622	RD1/4MUF391J
R 7628	RS1/8SQ105J
Other Resistors	RS1/4SA###J

CAPACITORS

C 7501,7511	CEAK332M25
C 7504-7506,7525,7526	CFTLA394J50
C 7507,7508,7623	CEAK221M35
C 7521	CEAK222M25
C 7522	CCSRCH330J50
C 7523	CEAK221M16
C 7601	CEAK472M16
C 7602	CEAK222M16
C 7603,7604,7613,7626	CKSRYB103K50
C 7605,7606,7624	CEAK101M16
C 7609	CFTLA394J50
C 7611	CEAK102M35
C 7612	CEAK471M35
C 7614	CEAK100M50
C 7621	ACH7358
C 7622	CEAK101M35
C 7625	CEAK470M50
C 7628,7632	CCSRCH102J50
C 7629	CFTLA104J50
C 7634-7637,7640,7641	CKSRYB104K50

VIR REASS

SEMI CONDUCTORS

⚠	IC 7251	NJM78M12FA
⚠	IC 7252	NJM79M12FA
⚠	IC 7271	NJM78M05FA
⚠	IC 7272	NJM79M05FA
	Q 7203 7204 7207 7221	LTC124EUB

	Q 7205,7206	LTA124EUB
⚠	Q 7211,7241	2SD1763A
⚠	Q 7212	2SB1186A
	Q 7222	LTA143EUB
	Q 7242	LSC4081UB

⚠	D 7201-7204,7241-7244	1SR154-400
	D 7211,7212,7215,7216	1SR154-400
	D 7213,7214	HZU7R5(B1)
	D 7245	1SS352
	D 7247	UDZS16(B)
⚠	D 7251-7254,7271-7274	1SR154-400
	D 7255,7256,7275,7276	1SS357

N. D

P. N.

N. D

P. N.

ISCELLANEOUS

H 7201-7204,7241,7242 FUSE CLIP
H 7251-7254 FUSE CLIP
CN 7201 8P TOP POST
CN 7241 PLUG(2P)
CN 7251 PLUG(7P)

AKR1004
AKR1004
B8B-EH
KM200NA2
KM200NA7

CN 7271 PLUG(4P)
CN 7281,7291 PLUG(3P)
JH 7251-7253 PCB BINDER

KM200NA4
KM200NA3
VEF1040

RESISTORS

R 7211,7213
R 7241
R 7245,7246,7259,7273
R 7255,7256
R 7258

RD1/4MUF102J
RS1/4S102J
RS1/4SA105J
RS1/8SQ100J
RS1/4SA822J

R 7260
R 7272
R 7274
Other Resistors

RS1/8SQ105J
ACN7180
RS1/4SA331J
RS1/10SR###J

CAPACITORS

C 7200,7240,7250,7270
C 7201,7202
C 7213-7215,7219,7245
C 7217,7218,7242,7253
C 7221,7246

CFTLA394J50
CEAK102M16
CEAK100M50
CKSRYB103K50
CEAK470M25

C 7222
C 7241,7251,7252
C 7247
C 7248,7281,7282
C 7254,7273,7274

CCSRCH102J50
CEAK222M25
CCSRCH100D50
CCSRCH101J50
CKSRYB103K50

C 7255,7256
C 7271,7272
C 7275,7276
C 7277,7278,7289,7290
C 7291

CEAK221M35
CEAK222M16
CEAK221M16
CCSRCH331J50
CFTLA394J50

C 7298

CCSRCH221J50

W DIODE ASS**SEMICONDUCATORS**

D 7400,7401

LN6SB60-4003

ISCELLANEOUS

CN 7400 PLUG
7400,7401 HEAT SINK B
7402,7403 SCREW

CKS-556
ANH1021
IBZ30P080FCC

RESISTORS

R 7402
R 7403,7404
Other Resistors

RD1/4MUF100J
ACN7180
RS1/4SA###J

CAPACITORS

C 7400,7401
C 7402,7403

ACH7319
CFTLA104J2A

X CONNECT ASS**ISCELLANEOUS**

CN 7801 14P PLUG
CN 7802 20P PLUG
CN 7803 13P SOCKET
CN 7804 21P SOCKET

AKM7170
AKM7171
XKP3077
XKP3081

RESISTORS

R 7808-7827
Other Resistors

RS1/10SR100J
RS1/8SQ###J

CAPACITORS

C 7813,7816

CCSRCH100D50

Y CONNECT ASS**ISCELLANEOUS**

CN 7681 7P SOCKET
CN 7682 17P SOCKET
CN 7683 7P PLUG
CN 7684 17P PLUG

KP200IB7L
XKP3079
KM200IB7
XKP3068

RESISTORS

All Resistors

RS1/10SR###J

CAPACITORS

C 7693,7696
C 7694,7697
C 7699,7702

CCSRCH270J50
CCSRCH331J50
CKSRYB103K50

Z PRE RID E ASS**ISCELLANEOUS**

CN 6951,6952 23P PLUG

XKP3071

AA A DAC RID E ASS**ISCELLANEOUS**

CN 3791,3792 14P PLUG
CN 3793,3794 B TO B CONNECTOR

AKM7170
AKM7176

CAPACITORS

C 3794,3798
C 3800

CKSRYB103K50
CKSRYB104K50

AB D AUDIO RID E ASS**ISCELLANEOUS**

CN 3771,3772 7P PLUG
CN 3773,3774 15P PLUG

XKP3063
XKP3067

AC D DAC RID E ASS**ISCELLANEOUS**

CN 3781-3784 PLUG (30P)
CN 3785 3P PLUG

BKM1035
XKP3061

5	6
□ □ □ □ N. D □ □ □ □ □ □ □ □	P □ □ □ N.
CAPACITORS	
C 3781	CCSRCH100D50
C 3785	CKSRYB104K50
C 3786	CKSRYB103K50
C 3787	CCSRCH101J50

AD FRONT RID E ASS

ISCELLANEOUS	
CN7721 7P SOCKET	KP200IB7L
CN7722 17P SOCKET	XKP3079
CN7723 PLUG(3P)	KM200NA3
CN7724 CONNECTOR	9604S-15C

RESISTORS	
All Resistors	RS1/10SR###J

ISCELLANEOUS	
JH 7721 PCB BINDER	VEF1040
JP 7725 7P HOUSING ASSY	ADX7729

CAPACITORS	
C 7721,7724	CCSRCH101J50
C 7722,7725	CCSRCH102J50

AE DISPLA RID E ASS

ISCELLANEOUS	
CN7651,7652 39P CONNECTOR	VKN2097
JH 7651,7652 PCB BINDER	VEF1040

RESISTORS	
R 7655-7657	RS1/10SR0R0J
Other Resistors	RS1/8SQ###J

CAPACITORS	
C 7651,7904,7912,7919	CCSRCH100D50
C 7924	CCSRCH100D50

AF IN RID E ASS

ISCELLANEOUS	
CN7661 15P SOCKET	XKP3078
CN7662 7P SOCKET	KP200IB7L
CN7663 CONNECTOR	9604S-15C
CN7664 L-PLUG(7P)	KM200NA7L
JH 7661 PCB BINDER	VEF1040

RESISTORS	
R 7667	RS1/4SA105J
Other Resistors	RS1/10SR###J

CAPACITORS	
C 7175	CCSRCH101J50

AG C RID E ASS

ISCELLANEOUS	
CN7671,7672 18P PLUG	AKM7050

7	8
□ □ □ □ N. D □ □ □ □ □ □ □ □	P □ □ □ N.
AH A RE RID E ASS	
ISCELLANEOUS	
CN5775 PLUG(5P)	KM200NA5
JH 5775,5776 PCB BINDER	VEF1040
JP 5775 HOUSING	ADX7773

AI IC P UARD ASS

ISCELLANEOUS	
JH 5921,5924 PCB BINDER	VEF1040

AJ AN CONNECT ASS

ISCELLANEOUS	
CN5931,5932 PLUG(3P)	KM200NA3
JH 5931,5932 PCB BINDER	VEF1040

AK IND D CA LE ASS

ISCELLANEOUS	
JH 3506 PCB BINDER	VEF1040

AL IND CA LE ASS

BIND B CABLE ASSY has no service parts.

AM C UARD ASS

FFC GUARD2 ASSY has no service parts.

AN VRE UARD ASS

VREG GUARD ASSY has no service parts.

FM/AM TUNER UNIT

FM/AM TUNER UNIT has no service parts.