


Pioneer

Service Manual



VSX-1127-K

ORDER NO.
RRV4307

AV Receiver

VSX-1127-K

VSX-1122-K

VSX-60

VSX-1027-K

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Model	Type	Power Requirement	Remarks
VSX-1127-K	CUXE	AC 120 V	
VSX-1122-K	CUXESM	AC 120 V	
VSX-60	UXECB	AC 120 V	
VSX-1027-K	CUXE	AC 120 V	



PIONEER CORPORATION 1-1, Shin-ogura, Saiwai-ku, Kawasaki-shi, Kanagawa 212-0031, Japan

PIONEER ELECTRONICS (USA) INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.

PIONEER EUROPE NV Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium

PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 253 Alexandra Road, #04-01, Singapore 159936

©PIONEER CORPORATION 2012

K-MZV MAR. 2012 Printed in Japan

SAFETY INFORMATION



This service manual is intended for qualified service technicians; it is not meant for the casual do-it-yourselfer. Qualified technicians have the necessary test equipment and tools, and have been trained to properly and safely repair complex products such as those covered by this manual.

Improperly performed repairs can adversely affect the safety and reliability of the product and may void the warranty. If you are not qualified to perform the repair of this product properly and safely, you should not risk trying to do so and refer the repair to a qualified service technician.

WARNING

This product may contain a chemical known to the State of California to cause cancer, or birth defects or other reproductive harm.

Health & Safety Code Section 25249.6 - Proposition 65


(FOR USA MODEL ONLY)

1. SAFETY PRECAUTIONS

The following check should be performed for the continued protection of the customer and service technician.

LEAKAGE CURRENT CHECK

Measure leakage current to a known earth ground (water pipe, conduit, etc.) by connecting a leakage current tester such as Simpson Model 229-2 or equivalent between the earth ground and all exposed metal parts of the appliance (input/output terminals, screwheads, metal overlays, control shaft, etc.). Plug the AC line cord of the appliance directly into a 120 V AC 60 Hz outlet and turn the AC power switch on. Any current measured must not exceed 0.5 mA.



AC Leakage Test

ANY MEASUREMENTS NOT WITHIN THE LIMITS OUTLINED ABOVE ARE INDICATIVE OF A POTENTIAL SHOCK HAZARD AND MUST BE CORRECTED BEFORE RETURNING THE APPLIANCE TO THE CUSTOMER.

2. PRODUCT SAFETY NOTICE

Many electrical and mechanical parts in the appliance have special safety related characteristics. These are often not evident from visual inspection nor the protection afforded by them necessarily can be obtained by using replacement components rated for voltage, wattage, etc. Replacement parts which have these special safety characteristics are identified in this Service Manual.

Electrical components having such features are identified by marking with a ⚠ on the schematics and on the parts list in this Service Manual.

The use of a substitute replacement component which does not have the same safety characteristics as the PIONEER recommended replacement one, shown in the parts list in this Service Manual, may create shock, fire, or other hazards.

Product Safety is continuously under review and new instructions are issued from time to time. For the latest information, always consult the current PIONEER Service Manual. A subscription to, or additional copies of, PIONEER Service Manual may be obtained at a nominal charge from PIONEER.

CONTENTS

SAFETY INFORMATION.....	2	
1. SERVICE PRECAUTIONS.....	5	
1.1 NOTES ON SOLDERING	5	A
1.2 NOTES ON REPLACING PARTS	5	
1.3 SERVICE NOTICE.....	5	
2. SPECIFICATIONS.....	6	
3. BASIC ITEMS FOR SERVICE	9	
3.1 CHECK POINTS AFTER SERVICING	9	
3.2 JIGS LIST	9	
3.3 PCB LOCATIONS	10	
4. BLOCK DIAGRAM	12	
4.1 OVERALL WIRING DIAGRAM	12	
4.2 AUDIO BLOCK DIAGRAM.....	14	
4.3 D-AUDIO BLOCK DIAGRAM	16	B
4.4 D-VIDEO BLOCK DIAGRAM	18	
4.5 VIDEO BLOCK DIAGRAM.....	20	
4.6 POWER SUPPLY BLOCK DIAGRAM.....	22	
5. DIAGNOSIS	24	
5.1 TROUBLESHOOTING	24	
5.2 ERROR INDICATIONS	32	
5.3 DETECTION CIRCUIT	33	
5.4 IC INFORMATION	35	
6. SERVICE MODE	38	
6.1 TEST MODE.....	38	
6.2 DEFAULT SETTINGS	40	
7. DISASSEMBLY	41	
8. EACH SETTING AND ADJUSTMENT	48	C
8.1 ADJUSTMENT REQUIRED WHEN THE UNIT IS REPAIRED OR REPLACED	48	
8.2 USB BACKUP.....	49	
8.3 UPDATING OF THE FIRMWARE	51	
8.4 IDLE CURRENT ADJUSTMENT	54	
9. EXPLODED VIEWS AND PARTS LIST.....	56	
9.1 PACKING SECTION	56	
9.2 EXTERIOR SECION.....	58	
10. SCHEMATIC DIAGRAM	62	
10.1 AUDIO ASSY	62	
10.2 AMP7 ASSY (1/2)	64	
10.3 AMP7 ASSY (2/2)	66	D
10.4 MAIN ASSY	68	
10.5 D-MAIN ASSY (1/10)	70	
10.6 D-MAIN ASSY (2/10)	72	
10.7 D-MAIN ASSY (3/10)	74	
10.8 D-MAIN ASSY (4/10)	76	
10.9 D-MAIN ASSY (5/10)	78	
10.10 D-MAIN ASSY (6/10)	80	
10.11 D-MAIN ASSY (7/10)	82	
10.12 D-MAIN ASSY (8/10)	84	
10.13 D-MAIN ASSY (9/10)	86	
10.14 D-MAIN ASSY (10/10)	88	
10.15 IR ASSY.....	90	E
10.16 VIDEO ASSY	92	
10.17 BRG ASSY	94	
10.18 FRONT and POWER ASSYS	96	
10.19 MIC, FVIDEO and HP ASSYS	98	
10.20 G-L, G-R, WG-A, WG-B, CCG and BTCNT ASSYS.....	99	
10.21 FHDMI and F-USB ASSYS.....	100	
10.22 SMPS ASSY	102	
10.23 BT ASSY.....	104	

11. PCB CONNECTION DIAGRAM106

11.1 AUDIO ASSY106

11.2 AMP7 ASSY108

11.3 MAIN ASSY.....110

11.4 D-MAIN ASSY.....114

11.5 IR ASSY118

11.6 VIDEO ASSY120

11.7 BRG ASSY.....122

11.8 FRONT, POWER, MIC, FVIDEO and HP ASSYS124

11.9 G-L, G-R, WG-A and WG-B ASSYS128

11.10 CCG and BTCNT ASSYS129

11.11 FHDMI and F-USB ASSYS.....130

11.12 BT ASSY131

11.13 SMPS ASSY132

12. PCB PARTS LIST134

1. SERVICE PRECAUTIONS

1.1 NOTES ON SOLDERING

- For environmental protection, lead-free solder is used on the printed circuit boards mounted in this unit.
Be sure to use lead-free solder and a soldering iron that can meet specifications for use with lead-free solders for repairs accompanied by reworking of soldering.
- Compared with conventional eutectic solders, lead-free solders have higher melting points, by approximately 40 °C.
Therefore, for lead-free soldering, the tip temperature of a soldering iron must be set to around 373 °C in general, although the temperature depends on the heat capacity of the PC board on which reworking is required and the weight of the tip of the soldering iron.

Do NOT use a soldering iron whose tip temperature cannot be controlled.

Compared with eutectic solders, lead-free solders have higher bond strengths but slower wetting times and higher melting temperatures (hard to melt/easy to harden).

The following lead-free solders are available as service parts:

- Parts numbers of lead-free solder:
GYP1006 1.0 in dia.
GYP1007 0.6 in dia.
GYP1008 0.3 in dia.

1.2 NOTES ON REPLACING PARTS

The part listed below is difficult to replace as a discrete component part.
When the part listed in the table is defective, replace whole Assy.

Assy Name	Parts that is Difficult to Replace			
	Ref No.	Function	Part No.	Remarks
D-MAIN Assy	JA1601, JA9601-JA9607	HDMI Connector	—————	JACK with Cu-through-hole & SMD type
	JA9201	USB Connector	—————	JACK with Cu-through-hole & 6 pin
	JA9202	LAN Connector	—————	JACK with Cu-through-hole & 10 pin
	IC9520	D-MAIN 3.3V Power Supply IC	—————	IC with heat-pad
	IC9521	D-MAIN 3.3V Power Supply IC	—————	IC with heat-pad
	IC9522	D-MAIN 1.8V Power Supply IC	—————	IC with heat-pad
	IC9002	DSP IC	—————	IC with heat-pad
	IC1204	VIDEO FORMAT CONVERTER	—————	IC BGA type
	IC1212	DDR IC	—————	IC BGA type
	IC9203	LAN PHY IC	—————	IC with heat-pad
	IC9204	NETWORK MEDIA PROCESSOR	—————	IC BGA type
	IC1602	HDMI Tx	—————	IC with heat-pad
	IC903	HDMI Rx	—————	IC with heat-pad
F-USB Assy	IC9602	HDMI SW IC	—————	IC with heat-pad
	IC805	USB 5V SW IC	—————	IC with heat-pad
	IC1307	USB 5V SW Power Supply IC	—————	IC with heat-pad

1.3 SERVICE NOTICE

- Discharging**
For more detail, please refer to "7. DISASSEMBLY - 1. Discharging".
- Notes on Ground Points Connection**
For more detail, please refer to "7. DISASSEMBLY - 2. Notes on Ground Points Connection".

2. SPECIFICATIONS

■ VSX-1127-K, VSX-1027-K

Amplifier section

Continuous average power output of 90 watts* per channel, min., at 8 ohms, from 20 Hz to 20 000 Hz with no more than 0.08 %** total harmonic distortion.

Front (stereo) 90 W + 90 W
Power output (1 kHz, 6 Ω, 1 %, 1 ch driven) 165 W
Guaranteed speaker impedance 6 Ω to 16 Ω

* Measured pursuant to the Federal Trade Commission's Trade Regulation rule on Power Output Claims for Amplifiers

** Measured by Audio Spectrum Analyzer

Audio Section

Input (Sensitivity/Impedance)

LINE 315 mV/47 kΩ
Signal-to-Noise Ratio (IHF, short circuited, A network)

LINE 100 dB

Signal-to-Noise Ratio [EIA, at 1 W (1 kHz)]

LINE 81 dB

Tuner Section

Frequency Range (FM) 87.5 MHz to 108 MHz

Antenna Input (FM) 75 Ω unbalanced

Frequency Range (AM) 530 kHz to 1700 kHz

Antenna (AM) Loop antenna (balanced)

Video Section

Signal level

Composite Video 1 Vp-p (75 Ω)

Component Video Y: 1.0 Vp-p (75 Ω), PB/PR: 0.7 Vp-p (75 Ω)

Corresponding maximum resolution

Component Video 1080p (1125p) (Video convert off)

Digital In/Out Section

HDMI terminal 19-pin (Not DVI)

HDMI output type 5 V, 100 mA

USB terminal USB2.0 High Speed (Type A) 5 V, 2.1 A

iPod terminal USB, and Video (Composite)

ADAPTER PORT terminal 5 V, 100 mA

WIRELESS LAN ADAPTER terminal 5 V, 600 mA

Integrated Control Section

Control (IR) terminal Ø 3.5 Mini-jack (MONO)

IR signal High Active (High Level: 2.0 V)

Network Section

LAN terminal 10 BASE-T/100 BASE-TX

Miscellaneous

Power requirements AC 120 V, 60 Hz

Power consumption 550 W

In standby 0.2 W (HDMI Setup – Control : OFF)

0.3 W (HDMI Setup – Control : ON)

Dimensions 435 mm (W) x 168 mm (H) x 362.5 mm (D)

(17 3/16 in. (W) x 6 5/8 in. (H) x 14 5/16 in. (D))

Weight (without package)

VSX-1127 9.9 kg (21.8 lb)

VSX-1027 9.8 kg (21.6 lb)

Note

- Specifications and the design are subject to possible modifications without notice, due to improvements.
- This product includes FontAvenue® fonts licensed by NEC Corporation. FontAvenue is a registered trademark of NEC Corporation.

■ VSX-60

Amplifier section

Continuous average power output of 90 watts* per channel, min., at 8 ohms, from 20 Hz to 20 000 Hz with no more than 0.08 %** total harmonic distortion.

Front (stereo) 90 W + 90 W
Guaranteed speaker impedance 6 Ω to 16 Ω

* Measured pursuant to the Federal Trade Commission's Trade Regulation rule on Power Output Claims for Amplifiers

** Measured by Audio Spectrum Analyzer

Audio Section

Input (Sensitivity/Impedance)

LINE 315 mV/47 kΩ

Output (Level/Impedance)

REC 315 mV/2.2 kΩ

Signal-to-Noise Ratio (IHF, short circuited, A network)

LINE 100 dB

Signal-to-Noise Ratio [EIA, at 1 W (1 kHz)]

LINE 81 dB

Tuner Section

Frequency Range (FM) 87.5 MHz to 108 MHz

Antenna Input (FM) 75 Ω unbalanced

Frequency Range (AM) 530 kHz to 1700 kHz

Antenna (AM) Loop antenna (balanced)

Video Section

Signal level

Composite Video 1 Vp-p (75 Ω)

Component Video Y: 1.0 Vp-p (75 Ω), PB/PR: 0.7 Vp-p (75 Ω)

Corresponding maximum resolution

Component Video 1080p (1125p) (Video convert off)

Digital In/Out Section

HDMI terminal 19-pin (Not DVI)

HDMI output type 5 V, 100 mA

USB terminal USB2.0 High Speed (Type A) 5 V, 2.1 A

iPod terminal USB, and Video (Composite)

ADAPTER PORT terminal 5 V, 100 mA

WIRELESS LAN ADAPTER terminal 5 V, 600 mA

Integrated Control Section

Control (IR) terminal Ø 3.5 Mini-jack (MONO)

IR signal High Active (High Level: 2.0 V)

12 V Trigger terminal Ø 3.5 Mini-jack (MONO)

12 V Trigger output type 12 V, Total 150 mA

RS-232C cable type 9-pin, cross type, female-female

Network Section

LAN terminal 10 BASE-T/100 BASE-TX

Miscellaneous

Power requirements.....AC 120 V, 60 Hz
Power consumption550 W
In standby.....0.2 W (HDMI Setup – Control : OFF)
0.3 W (HDMI Setup – Control : ON)
Dimensions.....435 mm (W) x 168 mm (H) x 362.5 mm (D)
(17 3/16 in. (W) x 6 5/8 in. (H) x 14 5/16 in. (D))
Weight (without package).....9.9 kg (22 lb)

Note

- Specifications and the design are subject to possible modifications without notice, due to improvements.
- This product includes FontAvenue® fonts licensed by NEC Corporation. FontAvenue is a registered trademark of NEC Corporation.

■ VSX-1122-K

Amplifier section

Continuous average power output of 90 watts* per channel, min., at 8 ohms, from 20 Hz to 20 000 Hz with no more than 0.08 %** total harmonic distortion.

Front (stereo)	90 W + 90 W
Power output (1 kHz, 6 Ω, 1 %, 1 ch driven)	165 W
Guaranteed speaker impedance	6 Ω to 16 Ω

* Measured pursuant to the Federal Trade Commission's Trade Regulation rule on Power Output Claims for Amplifiers

** Measured by Audio Spectrum Analyzer

Audio Section

Input (Sensitivity/Impedance)	
LINE.....	315 mV/47 kΩ
Signal-to-Noise Ratio (IHF, short circuited, A network)	
LINE.....	100 dB
Signal-to-Noise Ratio [EIA, at 1 W (1 kHz)]	
LINE.....	81 dB

Tuner Section

Frequency Range (FM) 87.5 MHz to 108 MHz
Antenna Input (FM)..... 75 Ω unbalanced
Frequency Range (AM) 530 kHz to 1700 kHz
Antenna (AM) Loop antenna (balanced)

Video Section

Signal level
Composite Video 1 Vp-p (75 Ω)
Component Video..... Y: 1.0 Vp-p (75 Ω), PB/PR: 0.7 Vp-p
(75 Ω)

Corresponding maximum resolution
Component Video.....1080p (1125p) (Video convert off)

Digital In/Out Section

HDMI terminal	19-pin (Not DVI)
HDMI output type.....	5 V, 100 mA
USB terminal	USB2.0 High Speed (Type A) 5 V, 2.1 A
iPod terminal.....	USB, and Video (Composite)
ADAPTER PORT terminal.....	5 V, 100 mA
WIRELESS LAN ADAPTER terminal	5 V, 600 mA

Integrated Control Section

Control (IR) terminal $\varnothing$ 3.5 Mini-jack (MONO)
IR signal..... High Active (High Level: 2.0 V)

Network Section

LAN terminal..... 10 BASE-T/100 BASE-TX

Miscellaneous

Power requirements.....AC 120 V, 60 Hz
Power consumption550 W
In standby.....0.2 W (HDMI Setup – Control : OFF)
0.3 W (HDMI Setup – Control : ON)
Dimensions..... 435 mm (W) x 168 mm (H) x 362.5 mm (D)
(17 3/16 in. (W) x 6 5/8 in. (H) x 14 5/16 in. (D))
Weight (without package).....9.9 kg (22 lb)


Note

- Specifications and the design are subject to possible modifications without notice, due to improvements.
- This product includes FontAvenue® fonts licensed by NEC Corporation. FontAvenue is a registered trademark of NEC Corporation.


Manufactured under license from Dolby Laboratories. "Dolby", "Pro Logic", "Surround EX", and the double-D symbol are trademarks of Dolby Laboratories.

Manufactured under license under U.S. Patent Nos: 5,956,674; 5,974,380; 6,226,616; 6,487,535; 7,212,872; 7,333,929; 7,392,195; 7,272,567 & other U.S. and worldwide patents issued & pending. DTS-HD, the Symbol, & DTS-HD and the Symbol together are registered trademarks & DTS-HD Master Audio is a trademark of DTS, Inc. Product includes software.
© DTS, Inc. All Rights Reserved.


A ■ Accessories



Power cord
(L068125130010-IL)
(VSX-60 only)



Microphone
(for Auto MCACC setup)
(APM7010)



iPod cable
(L308102013030-IL)



AM loop antenna
(E601019000010-IL)



FM wire antenna
(E605010140010-IL)



Remote control (AXD7664)
(8300766400010-IL)



Dry cell batteries
(AAA size IEC R03) x2

Warranty card

Quick start guide
(VSX-1127-K, VSX-1027-K: 5707000006590-IL)
(VSX-1122-K: 5707000006580-IL)
(VSX-60: 5707000006600-IL)

Safety Brochure

Operating instructions (CD-ROM)
(VSX-1127-K, VSX-1027-K: 6517000000550-IL)
(VSX-1122-K: 6517000000540-IL)
(VSX-60: 6517000000560-IL)

3. BASIC ITEMS FOR SERVICE

3.1 CHECK POINTS AFTER SERVICING

Items to be checked after servicing

To keep the product quality after servicing, confirm recommended check points shown below.

No.	Procedures	Check points
1	Confirm whether the customer complain has been solved. If the customer complain occurs with the particular source, such as Dolby Digital, DTS, AAC, DVD-A and HDMI, input it for the operation check.	The customer complain must not be reappeared. Video, Audio and operations must be normal.
2	Check the analog audio playback. (Make the analog connections with a DVD player.)	Each channel audio and operations must be normal.
3	Check the digital audio playback. (Make the digital connections with a DVD player.)	Each channel audio and operations must be normal.
4	Check surround playback. (Select Surround mode and check the multichannel operations via the DSP circuit.)	Each channel audio and operations must be normal.
5	Check the video outputs. (Connect with a DVD player.)	Video and operations must be normal.
6	Check the tuner (AM and FM) operations.	Audio and operations must be normal.
7	Check the sound from headphone output.	Sound must be normal, without noise.
8	Check the appearance of the product.	No scratches or dirt on its appearance after receiving it for service.

See the table below for the items to be checked regarding video and audio.

Item to be checked regarding video	Item to be checked regarding audio
Block noise	Distortion
Horizontal noise	Noise
Flicker	Volume too low
Disturbed image (video jumpiness)	Volume too high
Too dark	Volume fluctuating
Too bright	Sound interrupted
Mottled color	

3.2 JIGS LIST

Jigs List

Jig Name	Part No.	Remarks
13P extension jig cable	GGD1740	Diagnosis (AMP7 Assy ↔ AUDIO Assy)
3P extension jig cable	GGD1741	Diagnosis (AMP7 Assy ↔ MAIN Assy)
Board to board extension jig cable	GGD1736	Diagnosis (D-MAIN Assy ↔ BRG Assy)
Board to board extension jig cable	GGD1798	Diagnosis (D-MAIN Assy ↔ IR Assy)
Board to board extension jig cable	GGD1799	Diagnosis (D-MAIN Assy ↔ IR Assy)
Conversion jig	GGD1802	Diagnosis (D-MAIN Assy ↔ BRG Assy)
Conversion jig	GGD1803	Diagnosis (D-MAIN Assy ↔ IR Assy)


Lubricants and Glues List



Name	Part No.	Remarks
Silicon grease	GEM1057	Refer to "9.2 EXTERIOR SECTION".
Silicon adhesive	GYA1011 (KE40RTV-W)	Refer to "9.2 EXTERIOR SECTION".

1 2 3 4

3.3 PCB LOCATIONS




NOTES: ● Parts marked by “NSP” are generally unavailable because they are not in our Master Spare Parts List.
 ● The ⚠ mark found on some component parts indicates the importance of the safety factor of the part.
 Therefore, when replacing, be sure to use parts of identical designation.


LIST OF ASSEMBLIES

Mark	Symbol and Description	VSX-1127-K/CUXE	VSX-1122-K/CUXESM	VSX-60/UXECB	VSX-1027-K/CUXE
NSP	1..PCB TTL ASSY MAIN	7025HK1110020-IL	7025HK1110010-IL	7025HK1110030-IL	7025HK1109010-IL
	2..MAIN ASSY	7028071711010-IL	7028071711010-IL	7028071711040-IL	7028071711010-IL
	2..VIDEO ASSY	7028071712020-IL	7028071712070-IL	7028071712040-IL	7028071712070-IL
	2..G-L ASSY	7028071713040-IL	7028071713040-IL	7028071713040-IL	7028071713040-IL
	2..G-R ASSY	7028071714040-IL	7028071714040-IL	7028071714040-IL	7028071714040-IL
	2..WG-A ASSY	7028071715040-IL	7028071715040-IL	7028071715040-IL	7028071715040-IL
	2..WG-B ASSY	7028071716040-IL	7028071716040-IL	7028071716040-IL	7028071716040-IL
NSP	1..PCB TTL ASSY DMAIN	7025HK1110021-IL	7025HK1110011-IL	7025HK1110031-IL	7025HK1109011-IL
	2..D-MAIN ASSY	7028071752020-IL	7028071752040-IL	7028071752040-IL	7028071752070-IL
NSP	1..PCB TTL ASSY FRONT	7025HK1110022-IL	7025HK1110012-IL	7025HK1110032-IL	7025HK1109012-IL
	2..FRONT ASSY	7028071721050-IL	7028071721010-IL	7028071721040-IL	7028071721060-IL
	2..POWER ASSY	7028071722010-IL	7028071722010-IL	7028071722040-IL	7028071722010-IL
	2..MIC ASSY	7028071723040-IL	7028071723040-IL	7028071723040-IL	7028071723040-IL
	2..FVIDEO ASSY	7028071724040-IL	7028071724040-IL	7028071724040-IL	7028071724040-IL
	2..HP ASSY	7028071725040-IL	7028071725040-IL	7028071725040-IL	7028071725040-IL
NSP	1..PCB TTL ASSY AUDIO	7025HK1110023-IL	7025HK1110013-IL	7025HK1110033-IL	7025HK1109013-IL
	2..AUDIO ASSY	7028071741050-IL	7028071741010-IL	7028071741040-IL	7028071741010-IL
NSP	1..PCB TTL ASSY IR	7025HK1110024-IL	7025HK1110014-IL	7025HK1110034-IL	7025HK1109014-IL
	2..IR ASSY	7028071771010-IL	7028071771010-IL	7028071771040-IL	7028071771010-IL
	2..SMPS ASSY	7028071772010-IL	7028071772010-IL	7028071772040-IL	7028071772010-IL
	2..BRG ASSY	7028071773040-IL	7028071773040-IL	7028071773040-IL	7028071773070-IL
	2..BTCNT ASSY	7028071774040-IL	7028071774040-IL	7028071774040-IL	7028071774040-IL
	2..CCG ASSY	7028071775040-IL	7028071775040-IL	7028071775040-IL	7028071775040-IL
NSP	1..PCB TTL ASSY AMP7	7025HK1110025-IL	7025HK1110015-IL	7025HK1110035-IL	7025HK1109015-IL
	2..AMP7 ASSY	7028071731040-IL	7028071731040-IL	7028071731040-IL	7028071731040-IL
NSP	1..PCB TTL ASSY FHDMI	7025HK1110026-IL	7025HK1110016-IL	7025HK1110036-IL	Not used
	2..FHDMI ASSY	7028071791040-IL	7028071791040-IL	7028071791040-IL	Not used
NSP	1..PCB TTL ASSY F-USB	7025HK1110027-IL	7025HK1110017-IL	7025HK1110037-IL	7025HK1109017-IL
	2..F-USB ASSY	7028071761020-IL	7028071761020-IL	7028071761020-IL	7028071761020-IL
NSP	1..PCB TTL ASSY BT	7025HK1110028-IL	7025HK1110018-IL	7025HK1110038-IL	7025HK1109018-IL
	2..BT ASSY	7028070231010-IL	7028070231010-IL	7028070231010-IL	7028070231010-IL

4. BLOCK DIAGRAM


4.1 OVERALL WIRING DIAGRAM






-1127-K,
-1122-K,
-60
Y

4.2 AUDIO BLOCK DIAGRAM





4.3 D-AUDIO BLOCK DIAGRAM

D-MAIN ASSY

A


B

C


D


E


F



SPDIF → AMCLK → I2S → SYSCLK → FLG
 I2S BCK, LRCK








4.5 VIDEO BLOCK DIAGRAM


A

D D-MAIN ASSY



B


BACK



C

D


K FVIDEO ASSY



E

F

— TMDs
 — Video BUS
 — Analog Video



A

B

C

D

E

F

△






5. DIAGNOSIS

5.1 TROUBLESHOOTING


A No Power

This is just for general reference and does not including every single case.




No FL Display


This is just for general reference and does not including every single case.



A No Sound

This is just for general reference and does not including every single case.





A

B

Speaker C (S SB SP-B etc) ch
(Front LR is OK)

Check SP System menu is appropriate
and connected speakers are not
selected [No] on SP Setting menu.

No

Change SP System and SP
Setting to correct setting.

Yes

Check Selection of Speaker system
by [SPEAKERS] key on front panel
is correct.

No

Change SP selection to correct
setting by [SPEAKER] key.

Yes

Check relay operating of problem ch.
(refer to schematic diagram and Relay
Control Check flow for Front ch)

SP-B no sound

Yes

Select Surround mode to
EX. STEREO in Advanced Surround.

Input analog signals to analog in
(e.g. CD), SP selection should be
"SP:B ON", check SBR, SBL channels.

C

Check signals of problem channel on
AMP7 Assy CP401 pins 3 (SL), 5 (C),
7 (SR), 11 (SBL), 13 (SBR) signals.

Yes

Check and repair AMP circuit of
problem channels
or replace the AMP7 Assy.

No

Check signals on BRG Assy CN2107
pins 9 (SR), 11 (SL), 13 (SW),
15 (C), 17 (SBR), 19 (SBL) signals.

Yes

Replace AUDIO Assy or
their peripheral circuit.

No

Check signals on BRG Assy CN2110
pins 5, 7, 9, 11, 13, 15 signals.
(Pin assign is same as CN2107)

Yes

Repair IC2742, IC2704, IC2782
and their peripheral circuit
or replace the BRG Assy.

No

Input PCM to COAX in or OPT in,
set Auto Surround.
Is Front LR SP output sound is OK?

Yes

Replace the D-MAIN Assy.

No

Repair IC1801 and its peripheral
circuit or replace the D-MAIN Assy.

Speaker System Menu	
Setup name	Output sound
Speaker B	SP-B
Normal (SB/FH)	Front High or SB
Normal (SB/FW)	Front Wide or SB

If Speaker System is "Normal (SB/FH)" or
"Normal (SB/FW)" and speaker setting by
SPEAKER key is "SP: SB ON", there is no
sound from FH or FW.


D

E

F


C

C



D

A




B

No Picture

This is just for general reference and does not including every single case.

C



D

E

F

Others

This is just for general reference and does not including every single case.

12V Trig



No

RS-232C



No

IR



Yes

No



5.2 ERROR INDICATIONS

Error Indications When an Abnormality in The Amplifier System is Detected

[Purpose]

Errors upon detection of abnormalities in the amp system are indicated.

[Error Indications]


Item	FL Display	LED Flashes	NG Count.	Detection Method	Process After Detection	Description / Remarks
"AMP DC" ("DC output from SP term") detection	Flashing "AMP ERR" for 3 seconds	ADVANCED MCACC LED	DC	XDCERR (Pin 80 of IC3004) Detect "L"	1) Muting on, speaker relay off. 2) "AMP ERR" flashing 3) Shutdown after 3 seconds. 4) "ADVANCED MCACC" LED flashing 5) Power on is not acceptable.	To detect high DC output from amplifier damage (defect status). A process to protect speakers (for protection of connected external devices). For checking, refer to "How to enter release mode" below. If the DC detection port become "H" for 3 seconds, the unit will returns to normal condition automatically.
"AMP overload" detection.	N/A	iPod iPhone iPad LED	OL	XOLERR (Pin 71 of IC3004) Detect "L"	1) Muting on, speaker relay off. 2) Shutdown immediately. 3) "iPod iPhone iPad" LED flashing 4) Power on is acceptable.	To detect overloading (abnormal status) with low-load driving or a short circuit of the speaker terminals (for protection of the amplifier).
"Over Heat" detection.	Flashing "AMP OVERHEAT" for 3 seconds	FL OFF LED	STMP	TEMPERR5 (Pin 72 of IC3004) Detect "H" (REDI_DET)	1) Muting on, speaker relay off. 2) "OVERHEAT" flashing 3) Shutdown after 3 seconds. 4) "FL OFF" LED flashing 5) Power on is acceptable after 1 minute.	To detect overheat of inner temperature.
"Abnormality DC voltage of the Digital power supply" detection	N/A	iPod iPhone iPad LED	DERR	XVDDERR (Pin 70 of IC3004) Detect "L"	1) Muting on, speaker relay off. 2) Shutdown immediately. 3) "iPod iPhone iPad" LED flashing 4) Power on is acceptable.	To detect the abnormality voltage of Digital power supply circuit for the D-MAIN Assy.
"USB Overload" detection	"Over Current" No Flashing	N/A	N/A	USB ERR (VCO0) (Pin K2 of IC9204 (DM860A)) Detect "H"	1) Bass Power off 2) Display "Over Current"	To detect the connected USB device is overload. (over 2.1 A)
"BT Adapter overload" detection.	"ADP OVERLOAD" No Flashing	N/A	N/A	BTOL (MIL_CRS) (Pin R14 of IC9204 (DM860A)) Detect "H"	1) Adapter port power off 2) Display "ADP OVERLOAD"	To detect the connected Blue Tooth Adapter device is overload. (over 100 mA)
"HDCP of HDMI Error" detection	Flashes "HDCP ERROR" for 5 seconds	N/A	N/A	Read Register value	1) Display "HDCP ERROR"	The monitor does not support HDCP type or is in standby mode. (Warning indication for HDMI Simplay)
"Analog Input Over" detection	"OVER" Icon lights 1 second	N/A	N/A	DSP firmware Detect	While the Icon lights 1 second, when there is no ANALOG INPUT OVER detection, the Icon stops lighting and returns to normal display.	To detect the over-input of the analog audio to the A/D converter. When the Icon lights frequently, output level of the source equipment is high and a sound is distorted. Turn on the Analog Att switch.
Analog POWER SUPPLY Error	N/A	FL OFF LED	XPRT	XPROTECT (Pin 83 of IC3004)	1) Muting on, speaker relay off. 2) Shutdown immediately. 3) "FL OFF" LED flashing 4) Power on is acceptable after 1 minute.	Power-on impossible for 1 min.
"Over Heat" detection	N/A (VOL LEVEL)	N/A	N/A	TEMP L (TR_DET) (Pin 81 of IC3004)	VOL 3 dB down	After this error is detected, the system interrupts the OVER HEAT detection for 2 minutes.
"WiFi Over Current" detection	WLAN POW ERR	N/A	N/A	XWUSB ERR (Pin 45 of IC3004)	WUSBPOW is set to L.	To detect the connected WiFi Adapter device is overload. (over 600 mA)

[How to Enter Release Mode]

During Standby mode, simultaneously press and hold the "TUNE ↓" and "MULTI-ZONE ON/OFF" keys for 5 seconds.

E

A [2] TEMP Protection Circuit




5.4 IC INFORMATION


■ J171132900010-IL (VIDEO ASSY: IC1001)

IC, MONITOR SW

• Pin Arrangement (Top view)




A • Block Diagram



■ (J005251601010S-IL) (D-MAIN ASSY: IC9004)

IC, MEMORY FLASH

• Pin Arrangement (Top view)



• Pin Function

PIN NO.	PIN NAME	I/O	FUNCTION
1	/CS	I	Chip Select Input
2	DO (IO ₁)	I/O	Data Output (Data Input Output 1)* ¹
3	/WP (IO ₂)	I/O	Write Protect Input (Data Input Output 2)* ²
4	GND		Ground
5	DI (IO ₀)	I/O	Data Input (Data Input Output 0)* ¹
6	CLK	I	Serial Clock Input
7	/HOLD (IO ₃)	I/O	Hold Input (Data Input Output 3)* ²
8	VCC		Power Supply

*1 IO₀ and IO₁ are used for Dual and Quad instructions

*2 IO₀ – IO₃ are used for Quad instructions

6. SERVICE MODE

6.1 TEST MODE

[1] Detected protection history

[Purpose]

The numbers of detections for various protection processes are displayed.






[How to enter]

During Standby mode, simultaneously press and hold "MULTI-ZONE ON/OFF" and "ENTER" keys for 5 seconds to enter this mode. Turn off the power to this unit by setting the main volume level to "---dB" and Multi-zone to "OFF".

[How to exit]

Turning off the power or pressing the RETURN key returns to the normal mode.

[Basic operations]

Key operation	FL display
Display number of times DC is detected.	DC : ***
 	
Display number of times OVERLOAD is detected.	OL : ***
 	
Display number of times COMBINATION is detected. (Detects DC and OVERLOAD simultaneously)	COM : ***
 	
Display number of times Power abnormality is detected.	XPRT : ***
 	
Display number of times AMP overheat is detected.	STMP : ***
 	
Display number of times Digital Power abnormality is detected.	DERR : ***
 	
Resetting the number of times error is detected.	RESET ◀HOLD▶
 	

Front Panel Key


[↓] : TUNE key

[↑] : TUNE key

[←] : PRESET key

[→] : PRESET key

Resetting the number of times error is detected

Key operation	FL display
 	RESET ◀CLEAR?▶
	RESET ◀RESET▶
Continued	

Key operation	FL display
Display accumulated time & RESET. ↓ ↑	1 2 3 4 5 h 2 0 m ◀ H L D ▶
Display CEC(TEST) state. ↓ ↑	CEC ◀ OFF ▶
Display FAN(TEST) state. This function does not work on this model. ↓ ↑	FAN ◀ OFF ▶
USB Backup state ↓ ↑	USB BAK ◀ HOLD ▶
Display Model Name/Destination state. ↓ ↑	VSX-1127/CUXE
Change cyclically	

[Description]

CEC TEST : The function for making the HDMI output terminal to output 4 Hz square wave. If the square wave is output, the CEC line is considered to be normal.

FAN TEST : The function for making the FAN to be forced to rotate.

Resetting the accumulated time

Key operation	FL display
◀ ▶	1 2 3 4 5 h 2 0 m ◀ CL ? ▶
[ENTER]	0 h 0 0 m ◀ RST ▶
Continued	

Display CEC(TEST) state.

Key operation	FL display
◀ ▶	CEC ◀ ON ▶
Change cyclically	

Note:

In case of US models, [USB Backup] function is not implemented with the first firmware. Before performing the backup function, please check the unit version. If small version number of Main com (EMMA) is smaller than 157, please update to the latest version. If that is 157 or over (e.g. [1-157076014091]), the backup function is implemented.

Saving and Loading of USB backup state.

Key operation	FL display
◀ ▶	(A/V Receiver → USB) USB BAK ◀ SAVE ? ▶
◀ ▶	(USB → A/V Receiver) USB BAK ◀ LOAD ? ▶
Change cyclically	

Key operation	FL display
[ENTER]	PLEASE WAIT
SAVE or LOAD is completed. ↓ 5 sec Power OFF (All zone OFF)	COMPLETE

6.2 DEFAULT SETTINGS

A Default system settings

Setting		Default
Digital Video Converter		ON
SPEAKERS		SB/FH
Speaker System		Normal(SB/FH)
Speaker Setting	Front	SMALL
	Center	SMALL
	FH/FW	SMALL
	Surr	SMALL
	SB	SMALLx2
	SW	YES
Surround Position		IN REAR
Crossover		80 Hz
X-Curve		OFF
DIMMER		Brightest
HDMI		
HDMI Audio		Amp
Control		OFF
Control Mode		--- (OFF)
ARC (Audio Return Channel)		--- (OFF)
PQLS		--- (AUTO)
Standby Through		OFF
DSP		
Power On Level		LAST
Volume Limit		OFF
Mute Level		FULL
Phase Control		ON
Auto Sound Retriever	iPod/USB, INTERNET RADIO, SiriusXM, PANDORA, MEDIA SERVER, FAVORITES, ADAPTER PORT input function	ON
	Other input functions	OFF
Sound Delay		0.0 frame
Dual Mono		CH1
DRC		AUTO
SACD Gain		0 dB
LFE Attenuate		0 dB
Auto delay		OFF
Digital Safety		OFF
Effect Level	ExtendedStereo	90
	Other modes	50
PL II Music Options	Center Width	3
	Dimension	0
	Panorama	OFF
Neo:6 Options	Center Image	Neo:6 CINEMA: 10 Neo:6 MUSIC: 3
	Height Gain	MID
All Inputs	Listening Mode (2 ch/multi ch)	AUTO SURROUND
	Listening Mode (Headphones)	STEREO
MCACC		
MCACC Position Memory		M1: MEMORY 1
Channel Level (M1 to M6)		0.0 dB
Speaker Distance (M1 to M6)		10'00"
Standing Wave (M1 to M6)	ATT of all channels/filters	0.0 dB
	SWch Wide Trim	0.0 dB
EQ Data (M1 to M6)	All channels/bands	0.0 dB
	EQ Wide Trim	0.0 dB

Default input settings

Input function	Input Terminals		
	HDMI	Audio	Component
BD	(BD)		
DVD	IN 1	COAX-1	IN 1
SAT/CBL	IN 2	COAX-2 <a>	●
DVR/BDR	IN 3	OPT-2 <a>	●
HDMI 4	IN 4		
HDMI 5	IN 5 		
HDMI 6 <a>	IN 6		
INTERNET RADIO			
SiriusXM			
PANDORA			
MEDIA SERVER			
FAVORITES			
iPod/USB			
TV		OPT-1	
CD		ANALOG-1 <c>	
TUNER			
ADAPTER PORT			

- a VSX-1127 only.
- b Located on the front panel for the VSX-1127.
- c Only the **TV** and **CD** inputs can be assigned to **ANALOG-1**.

Resetting the system

Use this procedure to reset all the receiver's settings to the factory default. Use the front panel controls to do this.

Set MULTI-ZONE to **MULTI ZONE OFF**.

- Disconnect the iPod and USB memory device from the receiver beforehand.
- Set the **Control** with HDMI to **OFF**.

- 1 **Switch the receiver into standby.**
- 2 **While holding down ENTER on the front panel, press  STANDBY/ON.**

The display shows **RESET ◀ NO ▶**.

- 3 **Select 'RESET' using PRESET  / , then press ENTER on the front panel.**

The display shows **RESET? OK**.

- 4 **Press ENTER to confirm.**

OK appears in the display to indicate that the receiver has been reset to the factory default settings.

- Note that all settings will be saved, even if the receiver is unplugged.

7. DISASSEMBLY

Note:



- (1) Even if the unit shown in the photos and illustrations in this manual may differ from your product, the procedures described here are common.
- (2) For performing the diagnosis shown below, the following jigs for service is required:
 - 13P extension jig cable (GGD1740)
 - 3P extension jig cable (GGD1741)
 - Board to board extension jig cable (GGD1736) + Conversion jig (GGD1802)
 - Board to board extension jig cable (GGD1798) + Conversion jig (GGD1803)
 - Board to board extension jig cable (GGD1799)

1. Discharging

[1] MAIN Assy Capacitor (C55, C58)

[Procedures]


- (1) Unplug the power cord.
- (2) Disconnect the 10P connector from CP403 of the AMP7 Assy between CN3 of the MAIN Assy.
- (3) Connect +B and -B terminal of the D7, using resistor leads with 47 - 100 ohms (2 W or higher), for discharging.
 - * Discharging time: 30 - 60 seconds, depending on the level of resistance.
- (4) Check that the voltage between the +B and -B terminals is less than 1 V, using a tester.
 - * Be sure to connect the GND terminal of the tester to the chassis.
 - * If the voltage is still 1 V or higher, repeat Step (3).



[2] FL-30 V Capacitor

[Procedures]

- (1) Unplug the power cord.
- (2) Connect pin 1 (-30V) and GND terminal ① of CP3001 on the FRONT Assy, using resistor leads with 47-100 ohms (2 W or higher), for discharging.
 - * Discharging time: 5 - 10 seconds, depending on the level of resistance.
- (3) Check that the voltage between the -30V terminal is less than 1 V, using a tester.
 - * Be sure to connect the GND terminal of the tester to the chassis.
 - * If the voltage is still 1 V or higher, repeat Step (2).




2. Notes on Ground Points Connection

[Note]

During repair, before checking the MAIN Assy, etc., with the rear chassis removed, be sure to connect the GND terminal of the main capacitor to the back chassis (speaker chassis), as shown below, then connect the power cord.

**Without grounding connection, the protection circuit will be activated.
After repairing, be sure to remove the ground wire before reassembling.**




3. Disassembly

[1] Front Panel Section

Remove the cabinet by removing the 10 screws.

(1) Remove the five screws. (BBZ30P080FTB)




• Bottom view

(2) Remove the one screw.


(BBZ30P080FTC)

(3) Remove the three screws.

(1500001206010-IL)




(4) Unhook the two hooks.



(5) Arrange the front panel section as shown in the photo below.

Front panel section




A [2] Heatsink Section

Caution: Heatsink section in work becomes hot, and be careful with it.

Remove the cabinet by removing the 10 screws.

(1) Remove the three screws. (BBZ30P080FTC)




• Bottom view




(2) Remove the four screws. (BBZ30P080FTC)

(3) Cut the two binders.





(4) Remove the two screws. (BBZ30P080FTC)



(5) Remove the WG-A and CCG Assemblies.



- (6) Disconnect the six connectors.
 (7) Remove the Heatsink section.



- (8) As shown, arrange the Heatsink section over the WG-A Assy.
 (9) Re-connect the four connectors.
 (10) Connect the two extension jig cables.



A [3] D-MAIN Assy

Remove the cabinet by removing the 10 screws.


- (1) Remove the five screws. (BBT30P100FTB)
- (2) Remove the seven screws. (BSZ30P040FTB)



• Rear view


- (3) Disconnect the five B to B connectors. (CN603, 607, 901, 1504, 1801)
- (4) Remove the D-MAIN Assy.

• HDMI cable styling



Note:



Make styling so that tension does not hang to the HDMI connector.



- (5) Connect the five extension jig cables.
- (6) Arrange the D-MAIN Assy in the photo below.
- (7) Insert any insulation sheet.

Note:

Confirm that a B to B connector of BRG Assy is connected to AUDIO Assy tightly.




[4] MAIN Assy

Remove the cabinet by removing the 10 screws.


[4-1] Back chassis, D-MAIN Assy

- (1) Remove the 15 screws. (BBT30P100FTB)
- (2) Remove the seven screws. (BSZ30P040FTB)
- (3) Remove the D-MAIN Assy.
(See procedure [3].)



[4-2] MAIN Assy

- (1) Remove the four screws. (BBZ30P180FTC)
- (2) Remove the six screws. (BBZ30P080FTC)
- (3) Cut the four binders.
- (4) Remove the MAIN Assy with back chassis.



8. EACH SETTING AND ADJUSTMENT

A



- If the adjustment is shifted or if it becomes necessary to readjust because of part replacement, etc., perform the adjustment as described below.
- Any value changed in Adjustment mode will be stored in memory as soon as it is changed. Before readjustment, take note of the original values for reference in case you need to restore the original settings.
- Use a stable AC power supply.

B

8.1 ADJUSTMENT REQUIRED WHEN THE UNIT IS REPAIRED OR REPLACED

When any of the following assemblies is replaced

C

AMP7 Assy	➡	"8.4 IDLE CURRENT ADJUSTMENT" (All channel)
D-MAIN Assy	➡	"8.2 USB BACKUP"
Other assemblies	➡	No adjustment required

When any of the following parts is replaced

D

AMP7 Assy	➡	"8.4 IDLE CURRENT ADJUSTMENT" (Only channel of replacement parts)
Other assemblies	➡	No adjustment required

E

Note:
Some parts on D-MAIN and F-USB Assemblies can not be replaced due to using heat-pad connection between the board. Please refer to [1.2 NOTES ONREPLACING PARTS], when the parts listed in the table is defective, replace whole Assy.

F

8.2 USB BACKUP

[Introduction]

This model is capable of saving the set values stored in the MAIN Ucom of D-MAIN Assy in the USB and loading them in a new D-MAIN Assy. (Note that MAIN Ucom should normally operate to enable this function.)
When replacing D-MAIN Assy, execute the above mentioned processes.

[Data that can be saved/cannot be saved]

The following **data can not be saved**. Data other than these can be saved.

Contents to save	Destination to save
Last memory for turning ON/OFF the Main power and power supply for ZONE2 Last memory for inputting the Main power, ZONE2 Setting for controlling HDMI Remote control ID Setting for Network Standby Data to be save upon the operation of protection circuit Standby Through setting	EVENT Ucom
Settings for HMG Favorite, Recently played, Repeat	BridgeCo IC

(As the data saved by EVENT Ucom is on the FRONT Assy, the data cannot be deleted unless Assy is replaced at the same time.)

[Requirements for USB memory]

USB memory to be used should meet the following requirements.

- Compatible with USB Mass storage Class
- With a file system of FAT (FAT32)

[File saving format]

Files are to be saved in the following format:

Example: VSX-1127_BK01.avr

[How to save in the USB memory from AV amplifier]

1. Insert the usable USB memory into the USB terminal when the main device is off.
2. Enter the SERVICE MODE and select [USB BAK ◀ HOLD ▶] with ↑↓ keys.
(See [6.1 TEST MODE] for how to enter the SERVICE MODE.)
3. Select [USB BAK ◀ SAVE? ▶] with ⇐⇒ keys and press [ENTER].
Note: The system cannot execute SAVE, LOAD until start is completed of BridgeCo.
4. Saving in the USB starts and the main device automatically goes off after the normal completion ([COMPLETE] is displayed.).
5. Remove the USB and saving is finished.

*1. If the following errors occur after "SAVE" is executed, error message will be displayed and "SAVE" will be stopped and the power will be turned off.

- Ejecting of USB device
- Short capacity of USB device
- Error during writing in the USB device (Read Only or defective Sector, etc.)

*2. If the same file name exists in the USB, overwriting will be automatically executed.

[How to write into AV amplifier from the USB memory]

1. Insert the USB with the saved file into the USB terminal when the main device is off.
2. Enter the TEST MODE and select [USB BAK ◀ HOLD ▶] with ↑↓ keys.
(See [6.1 TEST MODE] for how to enter the TEST MODE.)
3. Select [USB BAK ◀ LOAD? ▶] with ⇐⇒ keys and press [ENTER].
4. Saving in the main device starts and it automatically goes off after the normal completion ([COMPLETE] is displayed.).
5. Remove the USB and loading is finished.

* If the following errors occur after "LOAD" is executed, error message will be displayed and "LOAD" will be stopped and the power will be turned off.

- No setting file
- Mismatching between the setting file and the specification of the A/V RECEIVER type to be loaded back
- Error due to Checksum, Signature Check, and Size Check
- Ejecting of USB device (during reading of the setting file)

A Precautions

- Files are stored in Root of USB memory.
- Files are read from Root of USB memory.
 - ⇒ To make operations such as moving files, be sure to assign the saved file in Root of the USB memory.
- The time and date of updating for saved file is fixed to "2006/03/08 20:01."
- In principle, please implement Load without making of factory default settings.
- To Load from factory default settings status, please take caution on the following points;

Please be sure to check the HDMI control setting for the user before performing of factory default settings.
 Since the HDMI control setting of default settings is ON, turn OFF the HDMI control setting and Load after performing of factory default settings if the checked user setting is OFF.
 (If Load is executed with the setting ON, the assignment information for each HDMI input will be cleared.)

Procedures for turning OFF the HDMI control setting


⇒ HOME MENU ⇒ 4.System Setup ⇒ e.HDMI Setup ⇒ Control OFF

Note:

In case of US models, [USB Backup] function is not implemented with the first firmware.
 Before performing the backup function, please check the unit version. If small version number of Main com (EMMA) is smaller than 157, please update to the latest version.
 If that is 157 or over (e.g. [1-157076014091]), the backup function is implemented.

8.3 UPDATING OF THE FIRMWARE

Workflow



MAIN com (EMMA), SUB com (EVENT), DSP Flash ROM and BridgeCo IC Update by USB Memory and the Confirmation of the Version

● UPDATE PANEL Mode (Version update)


[Preparations]

1. Copy the UPDATE FILE to the root directory of the USB Memory.
Note: NEVER copy several UPDATE FILES to the root directory of the USB Memory.
Copy only the corresponding UPDATE FILE.
2. Turn off the power to this unit by setting Multi-Zone to "OFF".
3. Connect the USB Memory to the USB terminal (A type) of the front panel.

[Procedure]


1. While holding down "TUNE↑" key on the front panel, press "STANDBY ON/OFF" key and moves to the **UPDATE PANEL mode**.
2. The updating process is as follows.

A



Front Panel Key

[↓] : TUNE key
 [↑] : TUNE key
 [←] : PRESET key
 [→] : PRESET key




B

C


Do not do time-out during update panel indication.
 It takes about 45 seconds till version of the BridgeCo is displayed.
 Meanwhile, version of the BridgeCo is displayed with ***.

D



E

F



Update time is fluctuated by contents of the update. It will take about 26 minutes at the maximum.
(Actual time is from 3 minutes to 26 minutes.)

Time required for updating varies, because only the programs that require updating will be updated.

[Confirmation]

Enter UPDATE PANEL mode and check that the programs have been updated.


8.4 IDLE CURRENT ADJUSTMENT



When any component parts which are within the red square on the following circuit diagram are replaced, the idle current adjustment of that channel is required. (Idle current adjustment for another channel is not required.)

However, when any capacitors are replaced, the adjustment is not required.

(The following circuit diagram is for SL channel, but another channel also has same circuit diagram and same adjustment is required)



Channel	Measurement Points	Adjustment Points	Procedure
FL	TP404 pin 1 (+) TP404 pin 3 (-)	VR404	① Turn on the power. ② Perform aging for one minute. ③ Connect a digital voltmeter to the measurement point. ④ Turn the adjustment VR so that the voltage becomes in $2.0 \text{ mV} \pm 0.2 \text{ mV}$. (Condition : No signal and no load)
FR	TP402 pin 1 (+) TP402 pin 3 (-)	VR402	
C	TP403 pin 1 (+) TP403 pin 3 (-)	VR403	
SL	TP401 pin 1 (+) TP401 pin 3 (-)	VR401	
SR	TP405 pin 1 (+) TP405 pin 3 (-)	VR405	
SBL	TP406 pin 1 (+) TP406 pin 3 (-)	VR406	
SBR	TP407 pin 1 (+) TP407 pin 3 (-)	VR407	

• Adjustment points and measurement points.... see fig.1.

B AMP7 ASSY

SIDE A




Fig.1

■

5

■

6

■

7

■

8

■

A

■

B

■

C

■

D

■

E

■

F

■

5

■

6

■

7

■

8

■



VSX-1127-K

9. EXPLODED VIEWS AND PARTS LIST

- NOTES:
- Parts marked by “NSP” are generally unavailable because they are not in our Master Spare Parts List.
 - The  mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
 - Screws adjacent to ▼ mark on product are used for disassembly.
 - For the applying amount of lubricants or glue, follow the instructions in this manual. (In the case of no amount instructions, apply as you think it appropriate.)

9.1 PACKING SECTION

Poly bag packing style



(1) PACKING SECTION PARTS LIST


<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>
⚠	1 Power Cord	See Contrast table (2)
	2 Remote Control	8300766400010-IL
	3 AM Loop Antenna	E601019000010-IL
	4 FM Wire Antenna	E605010140010-IL
	5 Microphone (for Auto MCACC setup)	APM7010
	6 iPod Cable	L308102013030-IL
	7 Operating Instructions (CD-ROM)	See Contrast table (2)
	8 Quick Start Guide	See Contrast table (2)
	9 Box, Gift	See Contrast table (2)
	10 Cushion, Snow	6230212914000-IL
	11 PE, Sheet	6327040059000-IL
NSP	12 Warranty Sheet	See Contrast table (2)
NSP	13 Label	VRW1629

(2) CONTRAST TABLE

VSX-1127-K/CUXE, VSX-1122-K/CUXESM, VSX-60/UXECB and VSX-1027-K/CUXE are constructed the same except for the following:

Mark	No.	Symbol and Description	VSX-1127-K /CUXE	VSX-1122-K /CUXESM	VSX-60 /UXECB	VSX-1027-K /CUXE
⚠	1	Power Cord	Not used	Not used	L068125130010-IL	Not used
	7	Operating Instructions (CD-ROM)	6517000000550-IL	6517000000540-IL	6517000000560-IL	6517000000550-IL
	8	Quick Start Guide	57070000006590-IL	57070000006580-IL	57070000006600-IL	57070000006590-IL
	9	Box, Gift	6007211820110-IL	6007211820100-IL	6007211820120-IL	6007211820150-IL
NSP	12	Warranty Sheet	ARY7156	ARY7156	ARY7007	ARY7156

9.2 EXTERIOR SECTION





(1) EXTERIOR SECION SECTION PARTS LIST


	<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>	<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>
A	1	MAIN Assy	See Contrast table (2)	46	Window Lower	See Contrast table (2)
	2	VIDEO Assy	See Contrast table (2)	47	Knob	5080212431000-IL
	3	G-L Assy	7028071713040-IL	48	Button	See Contrast table (2)
	4	G-R Assy	7028071714040-IL	49	5 Key Button	5090214561000-IL
	5	WG-A Assy	7028071715040-IL	50	10 Key Button	5090214571000-IL
B	6	WG-B Assy	7028071716040-IL	51	CN, Wire	See Contrast table (2)
	7	D-MAIN Assy	See Contrast table (2)	52	•••••	
	8	FRONT Assy	See Contrast table (2)	53	Screw	BBT30P100FTB
	9	POWER Assy	See Contrast table (2)	54	Screw	BBT40P080FTB
	10	MIC Assy	7028071723040-IL	55	Screw	BBZ30P080FTB
C	11	FVIDEO Assy	7028071724040-IL	56	Screw	BBZ30P080FTC
	12	HP Assy	7028071725040-IL	57	Screw	BBZ30P180FTC
	13	AUDIO Assy	See Contrast table (2)	58	Screw	BSZ30P040FTB
	14	IR Assy	See Contrast table (2)	59	Screw Tapping Assy	B018230141H11-IL
	15	SMPS Assy	See Contrast table (2)	60	Screw, Tap Tite	B020230063B10-IL
D	16	BRG Assy	See Contrast table (2)	61	Screw, Tap Tite	1500001206010-IL
	17	BTCNT Assy	7028071774040-IL	62	Screw	B028940101B11-IL
	18	CCG Assy	7028071775040-IL	63	Screw	1500001456010-IL
	19	AMP7 Assy	7028071731040-IL	64	Screw	See Contrast table (2)
	20	FHDMI Assy	See Contrast table (2)			
E	21	F-USB Assy	7028071761020-IL			
	22	BT Assy	7028070231010-IL			
	23	Cord Assy	See Contrast table (2)			
	24	Socket, power AC	See Contrast table (2)			
	25	Power Trans 1021U	8200960611050-IL			
F	26	Transistor	J5011560Y0000-IL			
	27	Semi, TR/GE NPN 2SC	J502396400010-IL			
	28	Transistor	J5032390Y0000-IL			
	29	HDMI Conn-Cable	See Contrast table (2)			
	30	Cable, Flat Card 1.0M	N711392412880-IL			
G	31	Pioneer Badge	See Contrast table (2)			
	32	Sheet	1210210235000-IL			
	33	F Input Sheet	See Contrast table (2)			
	34	Cabinet	3007211846000-IL			
	35	Front Panel	See Contrast table (2)			
H	36	Back Chassis	See Contrast table (2)			
	37	Foot (PLS)	4000210391000-IL			
	38	Bracket	4010056906010-IL			
	39	Bracket SMPS	4010214886000-IL			
	40	Cushion	4050211605000-IL			
I	41	Screw Cover	4050211745100-IL			
	42	Support	4070001601010-IL			
	43	Front Input Cover	4317215111030-IL			
	44	Front HDMI Plate1122	See Contrast table (2)			
	45	Window Display U	See Contrast table (2)			

(2) CONTRAST TABLE

VSX-1127-K/CUXE, VSX-1122-K/CUXESM, VSX-60/UXECB and VSX-1027-K/CUXE are constructed the same except for the following:

Mark	No.	Symbol and Description	VSX-1127-K /CUXE	VSX-1122-K /CUXESM	VSX-60 /UXECB	VSX-1027-K /CUXE
	1	MAIN Assy	7028071711010-IL	7028071711010-IL	7028071711040-IL	7028071711010-IL
	2	VIDEO Assy	7028071712020-IL	7028071712070-IL	7028071712040-IL	7028071712070-IL
	7	D-MAIN Assy	7028071752020-IL	7028071752040-IL	7028071752040-IL	7028071752070-IL
	8	FRONT Assy	7028071721050-IL	7028071721010-IL	7028071721040-IL	7028071721060-IL
	9	POWER Assy	7028071722010-IL	7028071722010-IL	7028071722040-IL	7028071722010-IL
	13	AUDIO Assy	7028071741050-IL	7028071741010-IL	7028071741040-IL	7028071741010-IL
	14	IR Assy	7028071771010-IL	7028071771010-IL	7028071771040-IL	7028071771010-IL
	15	SMPS Assy	7028071772010-IL	7028071772010-IL	7028071772040-IL	7028071772010-IL
	16	BRG Assy	7028071773040-IL	7028071773040-IL	7028071773040-IL	7028071773070-IL
	20	FHDMI Assy	7028071791040-IL	7028071791040-IL	7028071791040-IL	Not used
⚠	23	Cord Assy	L068125101710-IL	L068125101710-IL	Not used	L068125101710-IL
⚠	24	Socket, power AC	Not used	Not used	G430040560021-IL	Not used
	29	HDMI Conn-Cable	ADX7777	ADX7777	ADX7777	Not used
	31	Pioneer Badge	XAM3006	XAM3006	PAM1791	XAM3006
	33	F Input Sheet	1217211162040-IL	1217211162040-IL	1217211162050-IL	1217211792000-IL
	35	Front Panel	3067215111020-IL	3067215111010-IL	3067215121010-IL	3067215491000-IL
	36	Back Chassis	3207214216200S-IL	3207214216000S-IL	3207214216300S-IL	3207214206100S-IL
	44	Front HDMI Plate1122	4470212466000-IL	4470212466000-IL	4470212466000-IL	Not used
	45	Window Display U	5077213113040-IL	5077213113040-IL	5077213113050-IL	5077213113040-IL
	46	Window Lower	5077213123090-IL	5077213123090-IL	50772131230B0-IL	5077213123090-IL
	48	Button	5090213741100-IL	5090213741100-IL	5098214551000-IL	5090213741100-IL
	51	CN, Wire	Not used	Not used	L000800020220-IL	Not used
	64	Screw	Not used	Not used	CBZ30P080FTB	Not used

- When ordering service parts, be sure to refer to "EXPLODED VIEWS and PARTS LIST" or "PCB PARTS LIST".
- The mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- : The power supply is shown with the marked box.




G CN2107

G CN2203

G CN2112

A AUDIO ASSY

(VSX-1127-K: 7028071741050-IL)
(VSX-1122-K: 7028071741010-IL)
(VSX-60: 7028071741040-IL)
(VSX-1027-K: 7028071741010-IL)




B 1/2 CP401


VSX-1127-K

A

10.2 AMP7 ASSY (1/2)



B 1/2 AMP7 ASSY (7028071731040-IL)



10.3 AMP7 ASSY (2/2)

A

B


C

D


E

F

B 2/2



B2/2 AMP7 ASSY (7028071731040-IL)



(SBL) : Audio Signal Route (Surround Back L ch)

10.4 MAIN ASSY

A

B

C

D

E

F

FROM MAIN TRANS



C

68

SPEAKER TERMINAL

- NOTES
1. Resistor values are indicated in ohms unless otherwise specified. [k = 1,000 m = 1,000,000]
 2. Capacitor values are indicated in microfarads unless otherwise specified. [p = micro-microfarads]
 3. : These resistor are to be segregated from printed wiring board or other accessible parts.
- CAUTION
- Safety precaution to be followed during servicing
- 1) Since those parts marked with one critical parts for safety use only the one described in the parts list.
 - 2) Before returning the set to the customer make appropriate leakage current or resistance measurements to determine the exposed parts are properly insulated from the supply circuit.

J-MODEL OPTION



R CP601


B 1/2 CP406

B 1/2 CP404

B 2/2 CP405

B 1/2 CP403

VSX-1127-K



A

B

C

D

E

F

70





AWX1200: FY13 AVR SEL-LOW
AWX9957: VSX-1127/CU,VSX-1122/SY,/DL
AWX1223: VSX-1027/CU,VSX-922/SY,/F,/DL,/PW,/A,VSA-922/J
AWX1228: VSX-1122/CU,VSX-60/I

	AM1150	AM5007	AM11223	AM12028
C101	1009/4	ACW1352-1	ACW1352-1	ACW1352-1
C104	1006/4	ACW1352-1	ACW1352-1	ACW1352-1
C105	1009/50	HN	HN	HN
C107	1006/4	ACW1352-1	ACW1352-1	ACW1352-1
C108	1009/50	1009/50	1009/50	1009/50
C110	1009/4	ACW1352-1	ACW1352-1	ACW1352-1
C116	1006/4	ACW1352-1	ACW1352-1	ACW1352-1
C119	1309/50	1009/50	1009/50	1009/50
C120	0.01/25	0.10/16	0.10/16	0.10/16
C121	0.01/25/25	1009/50	1009/50	1009/50
C122	4709/50	1009/50	1009/50	1009/50
C123	0.01/25	0.0470/16	0.0470/16	0.0470/16
C124	0.01/25	4709/50	4709/50	4709/50
C126	0.01/25	0.01/25	0.01/25	0.01/25
C127	0.01/25	0.01/25	0.01/25	0.01/25
C129	4709/50	1009/50	1009/50	1009/50
C144	1309/50	1009/50	1009/50	1009/50
C145	1009/50	1009/50	1009/50	1009/50
C146	1009/50	1009/50	1009/50	1009/50
C149	1309/50	1009/50	1009/50	1009/50
C172	1309/50	1009/50	1009/50	1009/50
C175	0.01/25	0.01/25	0.01/25	0.01/25
C176	1309/50	1009/50	1009/50	1009/50
C184	1009/50	99/50	99/50	99/50
C187	79/50	99/50	99/50	99/50
C206	4709/50	1009/50	1009/50	1009/50
C207	1009/50	1009/50	1009/50	1009/50
C208	HN	1009/50	1009/50	1009/50
C209	HN	1009/50	1009/50	1009/50
C210	HN	4709/50	4709/50	4709/50
C211	HN	4709/50	4709/50	4709/50
C212	1009/50	1009/50	1009/50	1009/50
C213	HN	4709/50	4709/50	4709/50
C214	HN	1009/50	1009/50	1009/50
C215	1009/50	1009/50	1009/50	1009/50
C216	HN	1009/50	1009/50	1009/50
C217	HN	1009/50	1009/50	1009/50
C218	HN	1009/50	1009/50	1009/50
C219	HN	1009/50	1009/50	1009/50
C220	HN	1009/50	1009/50	1009/50
C221	HN	4709/50	4709/50	4709/50
C222	4709/50	4709/50	4709/50	4709/50
C223	4709/50	4709/50	4709/50	4709/50
C224	4709/50	4709/50	4709/50	4709/50
C225	4709/50	4709/50	4709/50	4709/50
C226	4709/50	4709/50	4709/50	4709/50
C227	4709/50	4709/50	4709/50	4709/50
C228	4709/50	4709/50	4709/50	4709/50
C229	4709/50	4709/50	4709/50	4709/50
C230	4709/50	4709/50	4709/50	4709/50
C231	4709/50	4709/50	4709/50	4709/50
C232	4709/50	4709/50	4709/50	4709/50
C233	4709/50	4709/50	4709/50	4709/50
C234	4709/50	4709/50	4709/50	4709/50
C235	4709/50	4709/50	4709/50	4709/50
C236	4709/50	4709/50	4709/50	4709/50
C237	4709/50	4709/50	4709/50	4709/50
C238	4709/50	4709/50	4709/50	4709/50
C239	4709/50	4709/50	4709/50	4709/50
C240	4709/50	4709/50	4709/50	4709/50
C241	4709/50	4709/50	4709/50	4709/50
C242	4709/50	4709/50	4709/50	4709/50
C243	4709/50	4709/50	4709/50	4709/50
C244	4709/50	4709/50	4709/50	4709/50
C245	4709/50	4709/50	4709/50	4709/50
C246	4709/50	4709/50	4709/50	4709/50
C247	4709/50	4709/50	4709/50	4709/50
C248	4709/50	4709/50	4709/50	4709/50
C249	4709/50	4709/50	4709/50	4709/50
C250	4709/50	4709/50	4709/50	4709/50
C251	4709/50	4709/50	4709/50	4709/50
C252	4709/50	4709/50	4709/50	4709/50
C253	4709/50	4709/50	4709/50	4709/50
C254	4709/50	4709/50	4709/50	4709/50
C255	4709/50	4709/50	4709/50	4709/50
C256	4709/50	4709/50	4709/50	4709/50
C257	4709/50	4709/50	4709/50	4709/50
C258	4709/50	4709/50	4709/50	4709/50
C259	4709/50	4709/50	4709/50	4709/50
C260	4709/50	4709/50	4709/50	4709/50
C261	4709/50	4709/50	4709/50	4709/50
C262	4709/50	4709/50	4709/50	4709/50
C263	4709/50	4709/50	4709/50	4709/50
C264	4709/50	4709/50	4709/50	4709/50
C265	4709/50	4709/50	4709/50	4709/50
C266	4709/50	4709/50	4709/50	4709/50
C267	4709/50	4709/50	4709/50	4709/50
C268	4709/50	4709/50	4709/50	4709/50
C269	4709/50	4709/50	4709/50	4709/50
C270	4709/50	4709/50	4709/50	4709/50
C271	4709/50	4709/50	4709/50	4709/50
C272	4709/50	4709/50	4709/50	4709/50
C273	4709/50	4709/50	4709/50	4709/50
C274	4709/50	4709/50	4709/50	4709/50
C275	4709/50	4709/50	4709/50	4709/50
C276	4709/50	4709/50	4709/50	4709/50
C277	4709/50	4709/50	4709/50	4709/50
C278	4709/50	4709/50	4709/50	4709/50
C279	4709/50	4709/50	4709/50	4709/50
C280	4709/50	4709/50	4709/50	4709/50
C281	4709/50	4709/50	4709/50	4709/50
C282	4709/50	4709/50	4709/50	4709/50
C283	4709/50	4709/50	4709/50	4709/50
C284	4709/50	4709/50	4709/50	4709/50
C285	4709/50	4709/50	4709/50	4709/50
C286	4709/50	4709/50	4709/50	4709/50
C287	4709/50	4709/50	4709/50	4709/50
C288	4709/50	4709/50	4709/50	4709/50
C289	4709/50	4709/50	4709/50	4709/50
C290	4709/50	4709/50	4709/50	4709/50
C291	4709/50	4709/50	4709/50	4709/50
C292	4709/50	4709/50	4709/50	4709/50
C293	4709/50	4709/50	4709/50	4709/50
C294	4709/50	4709/50	4709/50	4709/50
C295	4709/50	4709/50	4709/50	4709/50
C296	4709/50	4709/50	4709/50	4709/50
C297	4709/50	4709/50	4709/50	4709/50
C298	4709/50	4709/50	4709/50	4709/50
C299	4709/50	4709/50	4709/50	4709/50
C300	4709/50	4709/50	4709/50	4709/50
C301	4709/50	4709/50	4709/50	4709/50
C302	4709/50	4709/50	4709/50	4709/50
C303	4709/50	4709/50	4709/50	4709/50
C304	4709/50	4709/50	4709/50	4709/50
C305	4709/50	4709/50	4709/50	4709/50
C306	4709/50	4709/50	4709/50	4709/50
C307	4709/50	4709/50	4709/50	4709/50
C308	4709/50	4709/50	4709/50	4709/50
C309	4709/50	4709/50	4709/50	4709/50
C310	4709/50	4709/50	4709/50	4709/50
C311	4709/50	4709/50	4709/50	4709/50
C312	4709/50	4709/50	4709/50	4709/50
C313	4709/50	4709/50	4709/50	4709/50
C314	4709/50	4709/50	4709/50	4709/50
C315	4709/50	4709/50	4709/50	4709/50
C316	4709/50	4709/50	4709/50	4709/50
C317	4709/50	4709/50	4709/50	4709/50
C318	4709/50	4709/50	4709/50	4709/50
C319	4709/50	4709/50	4709/50	4709/50
C320	4709/50	4709/50	4709/50	4709/50
C321	4709/50	4709/50	4709/50	4709/50
C322	4709/50	4709/50	4709/50	4709/50
C323	4709/50	4709/50	4709/50	4709/50
C324	4709/50	4709/50	4709/50	4709/50
C325	4709/50	4709/50	4709/50	4709/50
C326	4709/50	4709/50	4709/50	4709/50
C327	4709/50	4709/50	4709/50	4709/50
C328	4709/50	4709/50	4709/50	4709/50
C329	4709/50	4709/50	4709/50	4709/50
C330	4709/50	4709/50	4709/50	4709/50
C331	4709/50	4709/50	4709/50	4709/50
C332	4709/50	4709/50	4709/50	4709/50
C333	4709/50	4709/50	4709/50	4709/50
C334	4709/50	4709/50	4709/50	4709/50
C335	4709/50	4709/50	4709/50	4709/50
C336	4709/50	4709/50	4709/50	4709/50
C337	4709/50	4709/50	4709/50	4709/50
C338	4709/50	4709/50	4709/50	4709/50
C339	4709/50	4709/50	4709/50	4709/50
C340	4709/50	4709/50	4709/50	4709/50
C341	4709/50	4709/50	4709/50	4709/50
C342	4709/50	4709/50	4709/50	4709/50
C343	4709/50	4709/50	4709/50	4709/50
C344	4709/50	4709/50	4709/50	4709/50
C345	4709/50	4709/50	4709/50	4709/50
C346	4709/50	4709/50	4709/50	4709/50
C347	4709/50	4709/50	4709/50	4709/50
C348	4709/50	4709/50	4709/50	4709/50
C349	4709/50	4709/50	4709/50	4709/50
C350	4709/50	4709/50	4709/50	4709/50
C351	4709/50	4709/50	4709/50	4709/50
C352	4709/50	4709/50	4709/50	4709/50
C353	4709/50	4709/50	4709/50	4709/50
C354	4709/50	4709/50	4709/50	4709/50
C355	4709/50	4709/50	4709/50	4709/50
C356	4709/50	4709/50	4709/50	4709/50
C357	4709/50	4709/50	4709/50	4709/50
C358	4709/50	4709/50	4709/50	4709/50
C359	4709/50	4709/50	4709/50	4709/50
C360	4709/50	4709/50	4709/50	4709/50
C361	4709/50	4709/50	4709/50	4709/50
C362	4709/50	4709/50	4709/50	4709/50
C363	4709/50	4709/50	4709/50	4709/50
C364	4709/50	4709/50	4709/50	4709/50
C365	4709/50	4709/50	4709/50	4709/50
C366	4709/50	4709/50	4709/50	4709/50
C367	4709/50	4709/50	4709/50	4709/50
C368	4709/50	4709/50	4709/50	4709/50
C369	4709/50	4709/50	4709/50	4709/50
C370	4709/50	4709/50	4709/50	4709/50
C371	4709/50	4709/50	4709/50	4709/50
C372	4709/50	4709/50	4709/50	4709/50
C373	4709/50	4709/50	4709/50	4709/50
C374	4709/50	4709/50	4709/50	4709/50
C375	4709/50	4709/50	4709/50	4709/50
C376	4709/50	4709/50	4709/50	4709/50
C377	4709/50	4709/50	4709/50	4709/50
C378	4709/50	4709/50	4709/50	4709/50
C379	4709/50	4709/50	4709/50	4709/50
C380	4709/50	4709/50	4709/50	4709/50
C381	4709/50	4709/50	4709/50	4709/50
C382	4709/50	4709/50	4709/50	4709/50
C383	4709/50	4709/50	4709/50	4709/50
C384	4709/50	4709/50	4709/50	4709/50
C385	4709/50	4709/50	4709/50	4709/50
C386	4709/50	4709/50	4709/50	4709/50
C387	4709/50	4709/50	4709/50	4709/50

D 2/10, 7/10, 8/10

10.6 D-MAIN ASSY (2/10)

D 2/10 D-MAIN ASSY

(VSX-1127-K: 7028071752020-IL)

(VSX-1122-K: 7028071752040-IL)

(VSX-60: 7028071752040-IL)

(VSX-1027-K: 7028071752070-IL)

D 1/10,7/10,8/10

D 3/10-10/10

B

C


D

E

F

D 2/10

72



The Δ mark found on some component parts should be replaced with same parts (safety regulation authorized) of identical designation.


Δ 印の部品は、指定部品（安全規格適合部品）を必ず使用すること。


AW0100	AW0101	AW0102	AW0103
C000	100p/10	AC07337-1	AC07337-1
C001	100p/10	AC07337-1	AC07337-1
C002	100p/10	AC07337-1	AC07337-1
C003	100p/10	AC07337-1	AC07337-1
C004	100p/10	AC07337-1	AC07337-1
C005	100p/10	AC07337-1	AC07337-1
C006	100p/10	AC07337-1	AC07337-1
C007	100p/10	AC07337-1	AC07337-1
C008	100p/10	AC07337-1	AC07337-1
C009	100p/10	AC07337-1	AC07337-1
C010	100p/10	AC07337-1	AC07337-1
C011	100p/10	AC07337-1	AC07337-1
C012	100p/10	AC07337-1	AC07337-1
C013	100p/10	AC07337-1	AC07337-1
C014	100p/10	AC07337-1	AC07337-1
C015	100p/10	AC07337-1	AC07337-1
C016	100p/10	AC07337-1	AC07337-1
C017	100p/10	AC07337-1	AC07337-1
C018	100p/10	AC07337-1	AC07337-1
C019	100p/10	AC07337-1	AC07337-1
C020	100p/10	AC07337-1	AC07337-1
C021	100p/10	AC07337-1	AC07337-1
C022	100p/10	AC07337-1	AC07337-1
C023	100p/10	AC07337-1	AC07337-1
C024	100p/10	AC07337-1	AC07337-1
C025	100p/10	AC07337-1	AC07337-1
C026	100p/10	AC07337-1	AC07337-1
C027	100p/10	AC07337-1	AC07337-1
C028	100p/10	AC07337-1	AC07337-1
C029	100p/10	AC07337-1	AC07337-1
C030	100p/10	AC07337-1	AC07337-1
C031	100p/10	AC07337-1	AC07337-1
C032	100p/10	AC07337-1	AC07337-1
C033	100p/10	AC07337-1	AC07337-1
C034	100p/10	AC07337-1	AC07337-1
C035	100p/10	AC07337-1	AC07337-1
C036	100p/10	AC07337-1	AC07337-1
C037	100p/10	AC07337-1	AC07337-1
C038	100p/10	AC07337-1	AC07337-1
C039	100p/10	AC07337-1	AC07337-1
C040	100p/10	AC07337-1	AC07337-1
C041	100p/10	AC07337-1	AC07337-1
C042	100p/10	AC07337-1	AC07337-1
C043	100p/10	AC07337-1	AC07337-1
C044	100p/10	AC07337-1	AC07337-1
C045	100p/10	AC07337-1	AC07337-1
C046	100p/10	AC07337-1	AC07337-1
C047	100p/10	AC07337-1	AC07337-1
C048	100p/10	AC07337-1	AC07337-1
C049	100p/10	AC07337-1	AC07337-1
C050	100p/10	AC07337-1	AC07337-1
C051	100p/10	AC07337-1	AC07337-1
C052	100p/10	AC07337-1	AC07337-1
C053	100p/10	AC07337-1	AC07337-1
C054	100p/10	AC07337-1	AC07337-1
C055	100p/10	AC07337-1	AC07337-1
C056	100p/10	AC07337-1	AC07337-1
C057	100p/10	AC07337-1	AC07337-1
C058	100p/10	AC07337-1	AC07337-1
C059	100p/10	AC07337-1	AC07337-1
C060	100p/10	AC07337-1	AC07337-1
C061	100p/10	AC07337-1	AC07337-1
C062	100p/10	AC07337-1	AC07337-1
C063	100p/10	AC07337-1	AC07337-1
C064	100p/10	AC07337-1	AC07337-1
C065	100p/10	AC07337-1	AC07337-1
C066	100p/10	AC07337-1	AC07337-1
C067	100p/10	AC07337-1	AC07337-1
C068	100p/10	AC07337-1	AC07337-1
C069	100p/10	AC07337-1	AC07337-1
C070	100p/10	AC07337-1	AC07337-1
C071	100p/10	AC07337-1	AC07337-1
C072	100p/10	AC07337-1	AC07337-1
C073	100p/10	AC07337-1	AC07337-1
C074	100p/10	AC07337-1	AC07337-1
C075	100p/10	AC07337-1	AC07337-1
C076	100p/10	AC07337-1	AC07337-1
C077	100p/10	AC07337-1	AC07337-1
C078	100p/10	AC07337-1	AC07337-1
C079	100p/10	AC07337-1	AC07337-1
C080	100p/10	AC07337-1	AC07337-1
C081	100p/10	AC07337-1	AC07337-1
C082	100p/10	AC07337-1	AC07337-1
C083	100p/10	AC07337-1	AC07337-1
C084	100p/10	AC07337-1	AC07337-1
C085	100p/10	AC07337-1	AC07337-1
C086	100p/10	AC07337-1	AC07337-1
C087	100p/10	AC07337-1	AC07337-1
C088	100p/10	AC07337-1	AC07337-1
C089	100p/10	AC07337-1	AC07337-1
C090	100p/10	AC07337-1	AC07337-1
C091	100p/10	AC07337-1	AC07337-1
C092	100p/10	AC07337-1	AC07337-1
C093	100p/10	AC07337-1	AC07337-1
C094	100p/10	AC07337-1	AC07337-1
C095	100p/10	AC07337-1	AC07337-1
C096	100p/10	AC07337-1	AC07337-1
C097	100p/10	AC07337-1	AC07337-1
C098	100p/10	AC07337-1	AC07337-1
C099	100p/10	AC07337-1	AC07337-1
C100	100p/10	AC07337-1	AC07337-1

VSX-1127-K



10.7 D-MAIN ASSY (3/10)





A

B

C

D

E

F

10.8 D-MAIN ASSY (4/10)

A

B

C

D


E

F

E CP513

D 4/10

76



VSX-1127-K


AWX1200: FY13 AVR SEL-LOW
 AWX9957: VSX-1127/CU,VSX-1122/SY/DL
 AWX1223: VSX-1027/CU,VSX-922/SY/F,DL/PW/A,VSA-922/J
 AWX1228: VSX-1122/CU,VSX-60/U

	AWX1200	AWX9957	AWX1223	AWX1228
C902	100p/50	NM	NM	NM
C908	NM	4700p/50	4700p/50	4700p/50
C909	NM	4700p/50	4700p/50	4700p/50
C914	47u/4	ACRT350-1	ACRT350-1	ACRT350-1
C921	0.01u/35	0.1u/16	0.1u/16	0.1u/16
C926	47u/4	ACRT350-1	ACRT350-1	ACRT350-1
C941	10p/50	7p/50	7p/50	7p/50
C949	10p/50	7p/50	7p/50	7p/50
C991	100u/4	ACRT350-1	ACRT350-1	ACRT350-1
C995	200u/4	ACRT350-1	ACRT350-1	ACRT350-1
C1025	100u/4	ACRT350-1	ACRT350-1	ACRT350-1
C1028	27p/50	10p/50	10p/50	10p/50
C1031	100u/4	ACRT350-1	ACRT350-1	ACRT350-1
C1036	27p/50	10p/50	10p/50	10p/50
C1042	100u/4	ACRT350-1	ACRT350-1	ACRT350-1
C1064	100u/4	ACRT350-1	ACRT350-1	ACRT350-1
C1075	100u/4	ACRT350-1	ACRT350-1	ACRT350-1
R929	NM	7p/50	7p/50	7p/50
R931	0	NM	NM	NM
R955	100	470	470	470
R1046	0	1K	1K	1K
Q901	68M012AR1	10K0012AR1	10K0012AR1	10K0012AR1
Q904	20A1576A(QRS)	20A1576A(QRS)	20A1576A(QRS)	20A1576A(QRS)
Q907	20A1576A(QRS)	20A1576A(QRS)	20A1576A(QRS)	20A1576A(QRS)
Q908	20A1576A(QRS)	20A1576A(QRS)	20A1576A(QRS)	20A1576A(QRS)
Q909	20C40R1-11(EF)	20C40R1(QRS)	20C40R1(QRS)	20C40R1(QRS)
Q910	20C40R1-11(EF)	20C40R1(QRS)	20C40R1(QRS)	20C40R1(QRS)
Q911	20C40R1-11(EF)	20C40R1(QRS)	20C40R1(QRS)	20C40R1(QRS)
U901	ASST111-A	ASST108-1	ASST108-1	ASST108-1
U902	ASST111-A	ASST108-1	ASST108-1	ASST108-1

D4/10 D-MAIN ASSY


(VSX-1127-K: 7028071752020-IL)
 (VSX-1122-K: 7028071752040-IL)
 (VSX-60: 7028071752040-IL)
 (VSX-1027-K: 7028071752070-IL)

Video Signal Route
 Video Signal Route (Y)
 Video Signal Route (Cb)
 Video Signal Route (Cr)




10.9 D-MAIN ASSY (5/10)

D 4/10




D 5/10 **D-MAIN ASSY**
 (VSX-1127-K: 7028071752020-IL)
 (VSX-1122-K: 7028071752040-IL)
 (VSX-60: 7028071752040-IL)
 (VSX-1027-K: 7028071752070-IL)



⚠ 印の部品は、指定部品（安全規格適合部品）を必ず使用すること。



(VSX-1127-K: 7028071752020-IL)
(VSX-1122-K: 7028071752040-IL)
(VSX-60: 7028071752040-IL)
(VSX-1027-K: 7028071752070-IL)



AWX1200: FY13 AVR SEL-LOW
AWX9957: VSX-1127/CU,VSX-1122/SY,/DL
AWX1223: VSX-1027/CU,VSX-922/SY,/F,/DL,/PW,/A,VSA-922/J
AWX1228: VSX-1122/CU,VSX-60/U

10.11 D-MAIN ASSY (7/10)

1

2

3

4

A

D 2/10-6/10,8/10-10/10

MASTER CLOCK SELECTOR

D 2/

B

C

D

E

F

G CN2110

D 9/10

D 4/10,6/10,8/10

D 2/10-6/10,8/10-10/10

D 7/10


VSX-1127-K

1

2

3

4



AWX1200: FY13 AVR SEL-LOW
 AWX9957: VSX-1127/CU,VSX-1122/SY/DL
 AWX1223: VSX-1027/CU,VSX-922/SY,F/DL/PW/A,VSA-922/J
 AWX1228: VSX-1122/CU,VSX-60/U

VSX-1127-K

10.12 D-MAIN ASSY (8/10)

A


B

C

D

E

F



D8/10

D8/10

VSX-1127-K

D 8/10 D-MAIN ASSY

(VSX-1127-K: 7028071752020-IL)
 (VSX-1122-K: 7028071752040-IL)
 (VSX-60: 7028071752040-IL)
 (VSX-1027-K: 7028071752070-IL)

AWX1200: FY13 AVR SEL-LOW
 AWX9957: VSX-1127/CU,VSX-1122/SY/DL
 AWX1223: VSX-1027/CU,VSX-922/SY,F/DL,PW/A,VSA-922/J
 AWX1228: VSX-1122/CU,VSX-60/U

	AWX1200	AWX9957	AWX1223	AWX1228
[C]1509	1000u/16	ACR7349-1	ACR7349-1	ACR7349-1
[C]1512	100	4700p/50	4700p/50	4700p/50
[C]1514	100	4700p/50	4700p/50	4700p/50
[C]1517	100	4700p/50	4700p/50	4700p/50
[C]1518	100p/50	100	100	100
[C]1519	100	100p/50	100p/50	100p/50
[C]1520	100	100p/50	100p/50	100p/50
[C]1521	100	4700p/50	4700p/50	4700p/50
[C]1522	100	100p/50	100	100
[C]1524	0.1u/16	100	100	100
[C]1525	100	100p/50	100p/50	100p/50
[C]1528	100p/50	100	100	100
[C]1529	100	4700p/50	4700p/50	4700p/50
[C]1531	100	4700p/50	4700p/50	4700p/50
[C]1534	100	1000p/50	1000p/50	1000p/50
[C]1538	100p/50	100	100	100
[C]1539	100p/50	100	100	100
[C]1541	100p/50	100	100	100
[C]1542	100	4700p/50	4700p/50	4700p/50
[C]1543	100	4700p/50	4700p/50	4700p/50
[C]1545	100p/50	100	100	100
[C]1546	100p/50	100	100	100
[C]1547	100p/50	100	100	100
[C]1550	100p/50	470p/50	470p/50	470p/50
[C]9850	100p/50	100	100	100
[C]9851	100p/50	100	100	100
[C]9852	100	100	100	100
[C]9853	100p/50	100	100	100
[C]9854	100p/50	100	100	100
[C]9855	100p/50	100	100	100
[C]9856	100p/50	100	100	100
[C]9857	100p/50	100	100	100
[C]9858	100p/50	100	100	100
[C]9859	100p/50	100	100	100
[C]9860	100p/50	100	100	100
[R]1523	10	100	100	100
[R]1526	10	100	100	100
[R]1528	10	100	100	100
[R]1530	10	100	100	100
[R]1531	10	100	100	100
[R]1534	100	100	100	100
[R]1539	10	100	100	100
[R]1548	100	100	100	100
[R]1549	100	100	100	100
[R]1550	100	100	100	100
[R]1557	100	10	10	10
[R]1558	100	10	10	10
[R]1559	10	10	10	10
[R]9811	10	100	100	100
[R]9850	10	100	100	100
[R]9851	10	100	100	100
[R]9852	10	100	100	100
[R]9853	10	100	100	100
[R]9854	10	100	100	100
[R]9855	10	100	100	100
[R]9856	10	100	100	100
[R]9857	10	100	100	100
[R]9858	100	100	100	100
[R]9859	100	100	100	100
[R]9860	10	10	10	10
[R]9861	100	10	10	10
[R]9862	100	10	10	10
[R]9863	100	10	10	10
[R]9864	100	10	10	10
[R]9865	100	10	10	10
[R]9866	100	10	10	10
[R]9867	100	10	10	10
[L]9861	VTLL129-A	100	100	100
[C]1504	TC7808P021	100	100	100
[C]1502	AS87072-A	100	100	100
[C]1503	AS87066-A	100	100	100
[C]1514	AKM7072-A	AKM7072-A	AKM7072-A	AKM7072-A
[Q]1501	RT13144N	DTA1240A	DTA1240A	DTA1240A
[Q]1502	RT13241M-11	DTA1240A	DTA1240A	DTA1240A
[Q]1503	RT13241M-11	DTA1240A	DTA1240A	DTA1240A
[Q]1504	RT13241M-11	DTA1240A	DTA1240A	DTA1240A
[Q]1505	DTA1240A	DTA1240A	DTA1240A	DTA1240A
[Q]1506	2BA1576A(QRS)	2BA1576A(QRS)	2BA1576A(QRS)	2BA1576A(QRS)
[Q]1507	RT13241M-11	100	100	100
[Q]1508	RT13241M-11	100	100	100
[Q]1509	RT13241M-11	100	100	100
[Q]1510	RT13241M-11	100	100	100
[Q]1511	RT13241M-11	100	100	100
[Q]1512	RT13241M-11	100	100	100
[Q]1513	RT13241M-11	100	100	100
[Q]1514	RT13241M-11	100	100	100
[Q]1515	RT13241M-11	100	100	100
[Q]1516	RT13241M-11	100	100	100
[Q]1517	RT13241M-11	100	100	100
[Q]1518	RT13241M-11	100	100	100
[Q]1519	RT13241M-11	100	100	100
[Q]1520	RT13241M-11	100	100	100
[Q]1521	RT13241M-11	100	100	100
[Q]1522	RT13241M-11	100	100	100
[Q]1523	RT13241M-11	100	100	100
[Q]1524	RT13241M-11	100	100	100
[Q]1525	RT13241M-11	100	100	100
[Q]1526	RT13241M-11	100	100	100
[Q]1527	RT13241M-11	100	100	100
[Q]1528	RT13241M-11	100	100	100
[Q]1529	RT13241M-11	100	100	100
[Q]1530	RT13241M-11	100	100	100
[Q]1531	RT13241M-11	100	100	100
[Q]1532	RT13241M-11	100	100	100
[Q]1533	RT13241M-11	100	100	100
[Q]1534	RT13241M-11	100	100	100
[Q]1535	RT13241M-11	100	100	100
[Q]1536	RT13241M-11	100	100	100
[Q]1537	RT13241M-11	100	100	100
[Q]1538	RT13241M-11	100	100	100
[Q]1539	RT13241M-11	100	100	100
[Q]1540	RT13241M-11	100	100	100
[Q]1541	RT13241M-11	100	100	100
[Q]1542	RT13241M-11	100	100	100
[Q]1543	RT13241M-11	100	100	100
[Q]1544	RT13241M-11	100	100	100
[Q]1545	RT13241M-11	100	100	100
[Q]1546	RT13241M-11	100	100	100
[Q]1547	RT13241M-11	100	100	100
[Q]1548	RT13241M-11	100	100	100
[Q]1549	RT13241M-11	100	100	100
[Q]1550	RT13241M-11	100	100	100
[Q]1551	RT13241M-11	100	100	100
[Q]1552	RT13241M-11	100	100	100
[Q]1553	RT13241M-11	100	100	100
[Q]1554	RT13241M-11	100	100	100
[Q]1555	RT13241M-11	100	100	100
[Q]1556	RT13241M-11	100	100	100
[Q]1557	RT13241M-11	100	100	100
[Q]1558	RT13241M-11	100	100	100
[Q]1559	RT13241M-11	100	100	100
[Q]1560	RT13241M-11	100	100	100
[Q]1561	RT13241M-11	100	100	100
[Q]1562	RT13241M-11	100	100	100
[Q]1563	RT13241M-11	100	100	100
[Q]1564	RT13241M-11	100	100	100
[Q]1565	RT13241M-11	100	100	100
[Q]1566	RT13241M-11	100	100	100

D 2/10-7/10,9/10,10/10

D 1/10,2/10,7/10

D 4/10,6/10,7/10

The Δ mark found on some component parts should be replaced with same parts (safety regulation authorized) of identical designation.
 Δ 印の部品は、指定部品（安全規格適合部品）を必ず使用すること。

D 8/10

VSX-1127-K

4



10.14 D-MAIN ASSY (10/10)

A





B

C




D

E


F



D 210,4/10,6/10,7/10,9/10



D 10/10



10.15 IR ASSY

D4/10 CN901

A

B

C

D

E

F

 : Video Signal Route
 : Video Signal Route (Y)
 : Video Signal Route (Cb)
 : Video Signal Route (Cr)

C550	
VSX-60	OTHER
10N-K	0

VSX-1127-K



10.16 VIDEO ASSY

A


B

C

D

E

F




F VIDEO ASSY

(VSX-1127-K: 7028071712020-IL)

(VSX-1122-K: 7028071712070-IL)

(VSX-60: 7028071712040-IL)

(VSX-1027-K: 7028071712070-IL)



C CP8

C CP9

VSX-1127-K

F

10.17 BRG ASSY

1

2

3

4

A

D7/10 CN1801


B

C

D

E

F



A CP12

G

1

2


3

4

G BRG ASSY

(VSX-1127-K, VSX-1122-K, VSX-60: 7028071773040-IL)
(VSX-1027-K: 7028071773070-IL)

D 7/10 CN1504



A CP13

A CP14



J CN3653

CN721

G

10.18 FRONT and POWER ASSYS

H FRONT ASSY (VSX-112
(VSX-112
(VSX-60:
(VSX-102



MODEL DISCRIMINATION							
MODEL	NAME	R ²	R SD	R ²	R SD	R ²	R SD
		R3021	R3022	R3025	R3026	R3027	R3028
927	NM	0.4(1)	0.4(1)	(1)	(1)	NM	NM
927	GEN(HOLX)	(1)	(1)	(1)	(1)	NM	NM
922	CHAXES	(1)	(1)	(1)	(1)	NM	NM
922	GEN(HOLX)	(1)	(1)	(1)	(1)	NM	NM
922	GEN(PHYS)	(1)	(1)	(1)	(1)	NM	NM
922	ALUS(PWVE)	(1)	(1)	(1)	(1)	NM	NM
922	ALUS(PWVE)	(1)	(1)	(1)	(1)	NM	NM
1122	CHAXES	0.4(1)	0.4(1)	(1)	(1)	NM	NM
1122	CHAXES	(1)	(1)	(1)	(1)	NM	NM
1122	GEN(HOLX)	(1)	(1)	(1)	(1)	NM	NM
1122	NACURE	(1)	(1)	(1)	(1)	NM	NM
1122	NACURE	0.4(1)	0.4(1)	(1)	(1)	NM	NM
1122	GEN(PHYS)	0.4(1)	0.4(1)	(1)	(1)	NM	NM
1122	ALUS(PWVE)	0.4(1)	0.4(1)	(1)	(1)	NM	NM

MODEL DISCRIMINATION							
NAME		PROJECT		MODEL		AREA	
MODEL	AREA	R3192	R3193	R3182	R3183	R3184	R3185
1107	NAUCUES	47K	NM	22K	38K	47K	NM
922	CHAVUES	47K	NM	47K	NM	38K	20K
922	CHAVEAS	47K	NM	47K	NM	22K	38K
922	GEN-HOLIES	47K	NM	47K	NM	38K	10K
922	GEN-ALPES	47K	NM	47K	NM	38K	22K
922	GEN-ALPES	47K	NM	10K	38K	38K	10K
922	EUSLYKJE	47K	NM	47K	NM	NM	47K
1122	CHAVEAS	47K	NM	NM	47K	47K	NM
1122	NAUCUES	47K	NM	NM	47K	47K	NM
1122	CHAVEAS	47K	NM	NM	47K	22K	38K
1122	GEN-HOLIES	47K	NM	NM	47K	38K	10K
1122	EUSLYKJE	47K	NM	NM	47K	NM	47K
1122	NAUCUES	47K	NM	32K	22K	47K	NM
1122	CHAVEAS	47K	NM	38K	15K	47K	NM

A




F

M G-L ASSY
(7028071713040-IL)


O WG-A ASSY
(7028071715040-IL)

Q CCG ASSY
(7028071775040-IL)




N G-R ASSY
(7028071714040-IL)

P WG-B ASSY
(7028071716040-IL)



R BT CNT ASSY (7028071774040-IL)



M N O P Q R



10.22 SMPS ASSY

A


B

C

D

E

F



※ OPTION TABLE

※ FUSE OPTION

USA/JAPAN/TAIWAN		OTHER	
F100	F101	F100	F101
3.15A	8A	3.15A	6.3A

	ZD108	ZD109	ZD110	ZD111	ZD113	ZD116	ZD119	ZD101	ZD103	ZD105	R101	R104
USA	MTZJ398	MTZJ398	MTZJ22B	JUMPER	JUMPER	JUMPER	JUMPER	MTZJ398	MTZJ398	MTZJ398	2M2 (5)	2M2 (5)
OTHER	1M (5)	1M (5)	MTZJ398	MTZJ398	MTZJ398	MTZJ398	MTZJ398	OPEN	OPEN	OPEN	OPEN	OPEN
JAPAN	MTZJ398	MTZJ398	JUMPER	JUMPER	JUMPER	JUMPER	JUMPER	MTZJ398	MTZJ398	MTZJ398	2M2 (5)	2M2 (5)
TAIWAN	MTZJ398	MTZJ398	MTZJ22B	JUMPER	JUMPER	JUMPER	JUMPER	MTZJ398	MTZJ398	MTZJ398	2M2 (5)	2M2 (5)

	VSX-60	VSX1122/UK	VSX1122/SY.DL	VSX1127	VSX922/SY.DL.FX.PW.JX	VSX922/AX	VS
R5	JUMPER	OPEN	JUMPER	OPEN	JUMPER	OPEN	C
LUG903.904	2P LUG	OPEN	2P LUG	OPEN	2P LUG	OPEN	C
CX100	OPEN	JE202B1T2	OPEN	JE202B1T2	OPEN	JE202B1T2	JE2

A



C

□

F

E

NOTES

1. Resistor values are indicated in ohms unless otherwise specified
[$k = 1.000 \quad m = 1.000.000$]
2. Capacitor values are indicated in microfarades unless otherwise specified.
[$\mu = \text{micro-microfarades}$]

3.  : These resistor are to be segregated from printed wiring board or other accessible parts.

CAUTION

Safety precaution to be followed during servicing




- 1] Since those parts marked with are critical parts for safety, use only the one described in the parts list
- 2] Before returning the set to the customer make appropriate leakage current or resistance measurements to determine the exposed parts are properly insulated from the supply circuit.

U

10.23 BT ASSY

V BT ASSY
(7028070231010-IL)



■

5

■

6

■

7

■

8

■

A

■

B

■

C

■

D

■

E

■

F

■

5

■

6

■

7

■

8

■

VSX-1127-K



11.1 AUDIO ASSY

SIDE A

NOTE FOR PCB DIAGRAMS :

1. The parts mounted on this PCB include all necessary parts for several destinations. For further information for respective destinations, be sure to check with the schematic diagram.


2. View point of PCB diagrams.

**SIDE A**

11.2 AMP7 ASSY

SIDE A


B AMP7 ASSY



Q408 Q407 Q444 Q443 Q432 Q431 Q456
Q412 Q448 Q436 Q431
Q401 Q437 Q425 Q434 Q460
Q404 Q409 Q410 Q440 Q445 Q446 Q428 Q433 Q434 Q452 Q457 Q449


SIDE B

B AMP7 ASSY




Q403 Q406 Q439 Q442 Q427 Q461 Q454
Q405

B



Q456 Q455 Q420 Q419 Q468 Q467 Q480 Q479
Q460 Q424 Q413 Q472 Q484
Q449 Q417 Q461 Q473
452 Q457 Q458 Q416 Q421 Q422 Q464 Q469 Q470 Q476 Q481 Q482

SIDE B




Q454 Q415 Q418 Q463 Q466 Q475 Q478

VSX-1127-K

SIDE A

MAIN ASSY

CP404



C



SIDE B

C MAIN ASSY

CP8

CP9

CP17

CP19

CP7

CN5

818

16

12

10

CP6

CP2

CP3

Q9-Q13 Q2-Q6

VSX-1127-K

SIDE B

A


B

C

D


E

F



SIDE A

D D-MAIN ASSY



D

SIDE B

A

B

C

D

F

F

D

117

5

6

7

8

CN601

JA9605

CN607

CN603

CN901

IC9508

IC104

Q101

Q906-Q911

IC9501

IC1216

902

Q9508

IC909

Q9602

Q9603

Q9504

Q9503

IC9508

IC104

Q101

Q906-Q911

IC9501

IC1216

902

Q9508

IC909

Q9602

Q9603

Q9504

Q9503


VSX-112

11.5 IR ASSY

SIDE A

SIDE A

IR ASSY




Q523
Q519 Q511 Q524
Q508
Q521

VSX-1127-K

SIDE B

SIDE B




Q530 Q529 Q528
Q527 Q526 Q525
Q533
Q532
Q531

Q504
Q502 Q503
Q507
IC501

E

119

SIDE A**G BRG ASSY****SIDE A**

SIDE B

SIDE B

G BRG ASSY

IC2802

IC2782

IC2704

IC2742

IC2762

Q8 Q1

CN2107

CN2203

CN2112

CN2110

CN2113

CN2111

CN2105

< MODEL OPTION >			
VSX-60/1022/1027 VSX-922/927			
R2903, R2904	47K	OPEN	
C2847, C2821	OPEN	OPEN	
C2845, C2819	3300P	OPEN	
R2921, R2863	3K3	OPEN	
R2931, R2881	1K	OPEN	
R2908, R2862	470	OPEN	
C2850, C2839	10N	OPEN	
C2844, C2817	4N7	OPEN	
C2846, C2816	10 ⁵ 0	OPEN	
C2832, C2838		OPEN	
R2880, R2932	100	OPEN	
R2958, R2908		OPEN	
IC2802	AZ4580	OPEN	

VSX-1127-K

G

123

SIDE A

POWER
TRANS

CP3501A VSX-1122/922/60 FRONT B'D STEP

POWER ASSY


J MIC ASSY

SIDE B

A

B

C




D


E

F

L HP ASSY




K FVIDEO ASSY



SIDE B


H FRONT ASSY



IC3001


Q3006 Q3013 Q3008 Q3015

I POWER ASSY



Q3010

J MIC ASSY









IC3652

11.9 G-L, G-R, WG-A and WG-B ASSYS



SIDE A

SIDE B



P WG-B ASSY


P WG-B ASSY




M N O P

SIDE A

SIDE A



Q CCG ASSY




R BTCNT ASSY


SIDE B

SIDE B

Q CCG ASSY



R BTCNT ASSY



Q R

11.11 FHDMI and F-USB ASSYS



SIDE A

SIDE A

A

S FHDMI ASSY

T F-USB ASSY



B

C



SIDE B

SIDE B

D

S FHDMI ASSY

T F-USB ASSY



E

F

S T

SIDE A





TR102

IC102

IC116

TR101

TR100

IC100


7028-07177-201-0S
SMPS B'D

VSX-1127-K

SIDE B

SIDE B

U SMPS ASSY



12. PCB PARTS LIST

NOTES: ● Parts marked by “NSP” are generally unavailable because they are not in our Master Spare Parts List.

- The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.

- When ordering resistors, first convert resistance values into code form as shown in the following examples.

Ex.1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47 k ohm (tolerance is shown by J = 5%, and K = 10%).

560 Ω $\rightarrow$ 56 $\times 10^1$ $\rightarrow$ 561 RD1/4PU $\begin{bmatrix} 5 \\ 6 \end{bmatrix} \begin{bmatrix} 1 \\ J \end{bmatrix}$
 47 k Ω $\rightarrow$ 47 $\times 10^3$ $\rightarrow$ 473 RD1/4PU $\begin{bmatrix} 4 \\ 7 \end{bmatrix} \begin{bmatrix} 3 \\ J \end{bmatrix}$
 0.5 Ω $\rightarrow$ R50 RN2H $\begin{bmatrix} R \end{bmatrix} \begin{bmatrix} 5 \\ 0 \end{bmatrix} K$
 1 Ω $\rightarrow$ 1R0 RS1P $\begin{bmatrix} 1 \\ R \end{bmatrix} \begin{bmatrix} 0 \\ K \end{bmatrix}$

Ex.2 When there are 3 effective digits (such as in high precision metal film resistors).

5.62 k Ω $\rightarrow$ 562 $\times 10^1$ $\rightarrow$ 5621 RN1/4PC $\begin{bmatrix} 5 \\ 6 \end{bmatrix} \begin{bmatrix} 2 \\ 1 \end{bmatrix} F$

- Meaning of the figures and others in the parentheses in the parts list.

Example) IC 301 is on the point (face A, 91 of x-axis, and 111 of y-axis) of the corresponding PC board.

IC 301 (A, 91, 111) IC NJM2068V

- SCHEMATIC DIAGRAM and PCB CONNECTION DIAGRAM $\rightarrow$ ● PCB PARTS LIST

BKT $\rightarrow$ none	BEAD $\rightarrow$ L	RLY $\rightarrow$ RY	SW $\rightarrow$ S
CLAMP $\rightarrow$ none	F $\rightarrow$ FU	RMC $\rightarrow$ U	VEC $\rightarrow$ S9***
W $\rightarrow$ none	FLT $\rightarrow$ V	RES $\rightarrow$ X	GND $\rightarrow$ KN
LUG $\rightarrow$ none	JACK $\rightarrow$ JA	XTAL $\rightarrow$ X9***	
P $\rightarrow$ none	JACK $\rightarrow$ JA9***	BD $\rightarrow$ L7***	
PACK $\rightarrow$ 9***	JK $\rightarrow$ JA	LED $\rightarrow$ D8***	
CP $\rightarrow$ CN	PT $\rightarrow$ T	Z $\rightarrow$ D9***	
CP $\rightarrow$ CN9***	REG $\rightarrow$ IC	ZD $\rightarrow$ D9***	
CX $\rightarrow$ CN9***	REG $\rightarrow$ IC9***	DZ $\rightarrow$ D9***	
FPC $\rightarrow$ CN9***			

LIST OF ASSEMBLIES

Mark	Symbol and Description	VSX-1127-K/CUXE	VSX-1122-K/CUXESM	VSX-60/UXECB	VSX-1027-K/CUXE
NSP	1..PCB TTL ASSY MAIN	7025HK1110020-IL	7025HK1110010-IL	7025HK1110030-IL	7025HK1109010-IL
	2..MAIN ASSY	7028071711010-IL	7028071711010-IL	7028071711040-IL	7028071711010-IL
	2..VIDEO ASSY	7028071712020-IL	7028071712070-IL	7028071712040-IL	7028071712070-IL
	2..G-L ASSY	7028071713040-IL	7028071713040-IL	7028071713040-IL	7028071713040-IL
	2..G-R ASSY	7028071714040-IL	7028071714040-IL	7028071714040-IL	7028071714040-IL
	2..WG-A ASSY	7028071715040-IL	7028071715040-IL	7028071715040-IL	7028071715040-IL
	2..WG-B ASSY	7028071716040-IL	7028071716040-IL	7028071716040-IL	7028071716040-IL
NSP	1..PCB TTL ASSY DMAIN	7025HK1110021-IL	7025HK1110011-IL	7025HK1110031-IL	7025HK1109011-IL
	2..D-MAIN ASSY	7028071752020-IL	7028071752040-IL	7028071752040-IL	7028071752070-IL
NSP	1..PCB TTL ASSY FRONT	7025HK1110022-IL	7025HK1110012-IL	7025HK1110032-IL	7025HK1109012-IL
	2..FRONT ASSY	7028071721050-IL	7028071721010-IL	7028071721040-IL	7028071721060-IL
	2..POWER ASSY	7028071722010-IL	7028071722010-IL	7028071722040-IL	7028071722010-IL
	2..MIC ASSY	7028071723040-IL	7028071723040-IL	7028071723040-IL	7028071723040-IL
	2..FVIDEO ASSY	7028071724040-IL	7028071724040-IL	7028071724040-IL	7028071724040-IL
	2..HP ASSY	7028071725040-IL	7028071725040-IL	7028071725040-IL	7028071725040-IL
NSP	1..PCB TTL ASSY AUDIO	7025HK1110023-IL	7025HK1110013-IL	7025HK1110033-IL	7025HK1109013-IL
	2..AUDIO ASSY	7028071741050-IL	7028071741010-IL	7028071741040-IL	7028071741010-IL
NSP	1..PCB TTL ASSY IR	7025HK1110024-IL	7025HK1110014-IL	7025HK1110034-IL	7025HK1109014-IL
	2..IR ASSY	7028071771010-IL	7028071771010-IL	7028071771040-IL	7028071771010-IL
	2..SMPS ASSY	7028071772010-IL	7028071772010-IL	7028071772040-IL	7028071772010-IL
	2..BRG ASSY	7028071773040-IL	7028071773040-IL	7028071773040-IL	7028071773070-IL
	2..BTCNT ASSY	7028071774040-IL	7028071774040-IL	7028071774040-IL	7028071774040-IL
	2..CCG ASSY	7028071775040-IL	7028071775040-IL	7028071775040-IL	7028071775040-IL
NSP	1..PCB TTL ASSY AMP7	7025HK1110025-IL	7025HK1110015-IL	7025HK1110035-IL	7025HK1109015-IL
	2..AMP7 ASSY	7028071731040-IL	7028071731040-IL	7028071731040-IL	7028071731040-IL
NSP	1..PCB TTL ASSY FHDMI	7025HK1110026-IL	7025HK1110016-IL	7025HK1110036-IL	Not used
	2..FHDMI ASSY	7028071791040-IL	7028071791040-IL	7028071791040-IL	Not used
NSP	1..PCB TTL ASSY F-USB	7025HK1110027-IL	7025HK1110017-IL	7025HK1110037-IL	7025HK1109017-IL
	2..F-USB ASSY	7028071761020-IL	7028071761020-IL	7028071761020-IL	7028071761020-IL
NSP	1..PCB TTL ASSY BT	7025HK1110028-IL	7025HK1110018-IL	7025HK1110038-IL	7025HK1109018-IL
	2..BT ASSY	7028070231010-IL	7028070231010-IL	7028070231010-IL	7028070231010-IL

CONTRAST OF PCB ASSEMBLIES

A AUDIO ASSY

7028071741050-IL, 7028071741040-IL and 7028071741010-IL are constructed the same except for the following:

Mark	Symbol and Description	7028071741050-IL	7028071741040-IL	7028071741010-IL
	IC2503 Electric VOL IC (2 ch)	BD3812F	BD3812F	Not used
	JA2102 Ter, RCA 2pin	G601206A0005Y-IL	G602421E0002Y-IL	G601206A0005Y-IL

C MAIN ASSY

7028071711010-IL and 7028071711040-IL are constructed the same except for the following:

Mark	Symbol and Description	7028071711010-IL	7028071711040-IL
	IC5 Liner Regulator IC	Not used	J126781200040-IL

D D-MAIN ASSY

7028071752020-IL, 7028071752040-IL and 7028071752070-IL are constructed the same except for the following:

Mark	Symbol and Description	7028071752020-IL	7028071752040-IL	7028071752070-IL
	IC1802 D/A Converter IC	AK4388ET	AK4388ET	Not used
	IC1803 Zero Delay Buffer	IDT6V60008DCG	Not used	Not used
	IC9207 IC	TC74VHC08FK	TC74VHC08FK	Not used
	JA1801 Pin Jack (2P)	G601206A0700Y-IL	G601206A0700Y-IL	Not used
	JA1802 Ter, RCA 1pin	Not used	Not used	G60011703000Y-IL
	JA1804 Module	E100216500010-IL	E100216500010-IL	Not used

E IR ASSY

7028071771010-IL and 7028071771040-IL are constructed the same except for the following:

Mark	Symbol and Description	7028071771010-IL	7028071771040-IL
	IC501 IC, Logic-interface	Not used	J046323200020-IL
	Q508, Q511, Q524 Semi, BRT/PNP RC	Not used	J502010300210-IL
	Q519, Q521, Q523 Semi, TR/GE PNP 2SA	Not used	J5001266G0050-IL
	JA501 CN. Wafer Interface	Not used	L103090090040-IL
	JA502 Jack, D3.5	Not used	G401PJ3080100-IL
	503 Bracket	4010210196100-IL	Not used

F VIDEO ASSY

7028071712020-IL, 7028071712070-IL and 7028071712040-IL are constructed the same except for the following:

Mark	Symbol and Description	7028071712020-IL	7028071712070-IL	7028071712040-IL
	IC1007 Character Generator	PDC162A	Not used	Not used
	X1003 Crystal	E80014R318080-IL	Not used	Not used
	JA1000 Ter, RCA 6pin	Not used	Not used	G603610A0032Y-IL
	JA1001 Ter, RCA 9pin	G607902AA133Y-IL	G607902AA133Y-IL	G607902AA151Y-IL
	JA1001 Ter, RCA 9pin	G607902AA151Y-IL	Not used	Not used

G BRG ASSY

7028071773040-IL and 7028071773070-IL are constructed the same except for the following:

Mark	Symbol and Description	7028071773040-IL	7028071773070-IL
	IC2802 IC, Linear OP	J121458001010-IL	Not used

H FRONT ASSY

7028071721050-IL, 7028071721010-IL, 7028071721040-IL and 7028071721060-IL are different in part number, they consist of the same components.

I POWER ASSY

7028071722010-IL and 7028071722040-IL are constructed the same except for the following:

Mark	Symbol and Description	7028071722010-IL	7028071722040-IL
	D3029 LED, Round	Not used	K500036001120-IL

U SMPS ASSY

7028071772010-IL and 7028071772040-IL are constructed the same except for the following:

Mark	Symbol and Description	7028071772010-IL	7028071772040-IL
	CN9100 Connector	L108396030010-IL	Not used

Mark No. Description Part No.

PARTS LIST (VSX-1127-K)

A AUDIO ASSY

SEMICONDUCTORS

IC 2501	BD3473KS2
IC 2502	J040406600010-IL
IC 2503	BD3812F
IC 2702,2704,2706	J121458001010-IL
Q 2401	J5023209Y0010-IL
Q 2402	J5001281Y0010-IL

MISCELLANEOUS

JA 2101 TER,RCA 6PIN	G603610A0001Y-IL
JA 2102 TER,RCA 2PIN	G601206A0005Y-IL
JA 2103 TER,RCA 4PIN	G602421E0046Y-IL

RESISTORS

R 374,377	C060033065050-IL
-----------	------------------

B AMP7 ASSY

SEMICONDUCTORS

Q 401,413,425,437	J5001024Y0050-IL
Q 407,408,417,419	J5000992F0050-IL
Q 412,424,436,448	J5023206Y0050-IL
Q 420,431,432,443	J5000992F0050-IL
Q 444,455,456,467	J5000992F0050-IL
Q 449,461,473	J5001024Y0050-IL
Q 460,472,484	J5023206Y0050-IL
Q 468,479,480	J5000992F0050-IL
D 9401,9404,9407,9410	K06005R134520-IL
D 9402,9403,9405,9406	K06004R344520-IL
D 9408,9409,9411,9412	K06004R344520-IL
D 9413,9416,9419	K06005R134520-IL
D 9414,9415,9417,9418	K06004R344520-IL
D 9420,9421	K06004R344520-IL

MISCELLANEOUS

VR 401-407 VR,SEMI CARBON MOLD	C541102315000-IL
400,401 BRACKET	4010210196100-IL

Mark No. Description Part No.

RESISTORS

⚠ R 406,450,494,537	F320184710050-IL
⚠ R 424,425,430,431	N113136647820-IL
R 443,487,530,573	C060047065060-IL
⚠ R 467,468,474,475	N113136647820-IL
R 493	C060033065050-IL
⚠ R 511,512,517,518	N113136647820-IL
⚠ R 554,555,561,562	N113136647820-IL
⚠ R 580,623,666	F320184710050-IL
⚠ R 597,598,603,604	N113136647820-IL
R 616,659,702	C060047065060-IL
⚠ R 640,641,646,647	N113136647820-IL
⚠ R 683,684,689,690	N113136647820-IL

CAPACITORS

C 419	D04010108C240-IL
-------	------------------

C MAIN ASSY

SEMICONDUCTORS

⚠ IC 1	J126781200040-IL
⚠ IC 2	J126791200060-IL
⚠ IC 3	J126780500110-IL
⚠ IC 4	J126790500070-IL
Q 14,15	J5023198Y0000-IL
Q 16	J5000992F0050-IL
Q 17	J5000916Y0050-IL
⚠ D 7	K047100600220-IL
⚠ D 10-13,23	K000400700220-IL
⚠ D 4912	K047604000020-IL
D 9002	K06005R144520-IL
D 9024,9025	K06012R044520-IL

MISCELLANEOUS

JA 1,2 TER,BOARD SCREW 8P	G614108V1010M-IL
JA 3 TER,BOARD SCREW 2P	G611201A0200Y-IL
JA 50 TUNER,FM/AM	E903004100780-IL
RY 2-6 RELAY	G680120502050-IL
CN 9007,9019 CN,WAFER	L109012511320-IL
CN 9008,9016-9018 CN.WAFER	L109012510920-IL

Mark	No.	Description	Part No.
	CN 9009	CN,WAFER	L109012511120-IL
	CN 9012	CN,WAFER	L109012511520-IL
	2	TERMINAL	3790040886000-IL
⚠	33,34	FUSE,MICRO	G658315250050-IL
RESISTORS			
	R 5,7,9,11		C060010065050-IL
	R 6,8,10,12		C060010066050-IL
	R 13,15,17		C060010065050-IL
	R 14,16,18		C060010066050-IL
	R 41,42		C060R22065050-IL
	R 25		C0605R6065050-IL
	R 64		C060022063050-IL
	R 66		C0604R7065050-IL
CAPACITORS			
	C 55,58		D040103089000-IL
	C 76		D040682083000-IL
	C 84,85		D040472084020-IL
	C 101		D04010108C240-IL
D MAIN ASSY			
SEMICONDUCTORS			
	IC 101		UPD61110GM-100UEVA
	IC 102,9201		J001982566010-IL
	IC 104,604,1808		TC7WHU04FK
	IC 603		PE7008A
	IC 608		TC74VHCT541AFK
	IC 610,1509,1806		TC74VHC126FK
	IC 611		TC74VHCT126AFK
	IC 612,1502		TC74VHCT08AFKS1
	IC 613,1601,1804,9003		TC74VHC08FK
	IC 614,701,9008,9208		TC7SH08FUS1
	IC 901,910		TC74LCX541FK
	IC 902,911		TC7SZ125FU
	IC 909		ADV7181CBSTZ
⚠	IC 1216		LP2996M
	IC 1403		J040740400270-IL
⚠	IC 1605		AAT4610BIGV-1
	IC 1801		AK4588VQ
	IC 1802		AK4388ET
	IC 1803		IDT6V60008DCG
	IC 1805		TC74VHC157FK
	IC 1807		J040740400270-IL
	IC 1812		TC7SZ126FU
	IC 9001		J001986466010-IL
	IC 9102		BU4094BCFV
⚠	IC 9202		BD2226G
	IC 9206		341S2162
	IC 9207		TC74VHC08FK
⚠	IC 9401,9511,9519		S-1170B50UC-OUJ
⚠	IC 9501		S-1172B10-U5
⚠	IC 9502,9518,9523		S-1172B12-E6
⚠	IC 9508		S-1170B25UC-OTK
⚠	IC 9515		S-1172B15-E6
⚠	Q 9503,9507,9516		J543045010060-IL
MISCELLANEOUS			
	JA 1801	PIN JACK (2P)	G601206A0700Y-IL
	JA 1803,1804	MODULE	E100216500010-IL
	KN 9801	BRACKET	4010210196100-IL
⚠	P 601	SW.POLY	G300003500010-IL

Mark	No.	Description	Part No.
<u>CAPACITORS</u>			
	C	1509	D040222081000-IL
<u>E IR ASSY</u>			
<u>MISCELLANEOUS</u>			
	JA	504,505 JACK,D3.5	G401PJ3080100-IL
	CN	9511 CN,WAFFER	L109012510920-IL
	CN	9512 CN,WAFFER	L109012511520-IL
	CN	9513 CN,WAFFER	L109012512720-IL
		501,503 BRACKET	4010210196100-IL
<u>F VIDEO ASSY</u>			
<u>SEMICONDUCTORS</u>			
	IC	1001	J171132900010-IL
	IC	1007	PDC162A
	IC	1008	NJM2505AF
	Q	910	J5023209Y0010-IL
<u>MISCELLANEOUS</u>			
	JA	1001 TER,RCA 9PIN	G607902AA151Y-IL
	JA	1001 TER,RCA 9PIN	G607902AA133Y-IL
	X	1003 CRYSTAL	E80014R318080-IL
<u>G BRG ASSY</u>			
<u>SEMICONDUCTORS</u>			
	IC	2704,2742,2762,2782	J121458001010-IL
	IC	2802	J121458001010-IL
<u>MISCELLANEOUS</u>			
	RY	701 RELAY	G680240202030-IL
	CN	2107,2110 CN,WAFFER	L109012512320-IL
	CN	2112 CN,WAFFER	L109012510920-IL
	CN	2113,2203 CN,WAFFER	L109012512120-IL
<u>RESISTORS</u>			
	R	720	C060010063050-IL
<u>H FRONT ASSY</u>			
<u>SEMICONDUCTORS</u>			
	IC	3001	PE5615A
	IC	3005	J126077004210-IL
⚠	IC	9103	J126111700041-IL
	Q	3011	J5001266G0050-IL
	D	3007,3009,3011,3013	K500052009011-IL
	D	9001	K06006R844520-IL
<u>MISCELLANEOUS</u>			
	V	3001 DISPLAY,FLT	K530166400010-IL
	S	3001-3015 SWITCH	G180501000010-IL
	S	3024 SW,ENCODER	G121125042011-IL
	X	3001 RESONATOR,CERAMIC	E830500000020-IL
	X	3002 CRYSTAL	E80015R000020-IL
		3000 FL HOLDER	4320211016000-IL
	U	3001 MODULE,REMOCON	E940349003810-IL
<u>RESISTORS</u>			
	R	3021,3022	C060R47065050-IL
	R	3025,3026	C060001065060-IL

Mark No. Description Part No.

A

I POWER ASSY

MISCELLANEOUS

S 3401 SWITCH G180501000010-IL
S 3501 SW,ENCODER G121125052011-IL

J MIC ASSY

SEMICONDUCTORS

IC 3652 J121458001010-IL

MISCELLANEOUS

JA 3654 JACK,D3.5 G401PJ354H40Y-IL

B

K FVIDEO ASSY

MISCELLANEOUS

JA 3656 TER,RCA 1PIN G600101HG000Y-IL

L HP ASSY

MISCELLANEOUS

JA 701 JACK,D6.5 G402PJ612AG1Y-IL

C

M G-L ASSY

There is no service parts.

N G-R ASSY

There is no service parts.

O WG-A ASSY

There is no service parts.

P WG-B ASSY

There is no service parts.

Q CCG ASSY

There is no service parts.

E

R BTCNT ASSY

MISCELLANEOUS

CN 602 CN.WAFER 2.0MM L101100041110-IL
600 BRACKET 4010210196100-IL

S FHDMI ASSY

SEMICONDUCTORS

IC 8202 PCA9517DGK

F

MISCELLANEOUS

JA 8202 CN.WAFER L109100190060-IL
JA 8203 CN.WAFER L109100190170-IL

Mark No. Description Part No.

T F-USB ASSY

MISCELLANEOUS

JA 600 CN,PLUG CONTACT G480040000180-IL

U SMPS ASSY

SEMICONDUCTORS

⚠ IC 100 K614123000010-IL
⚠ IC 102 J122258001010-IL
⚠ IC 116 J126243118010-IL
Q 9100-9102 J5023198Y0000-IL
⚠ D 100-102,104 K040540600030-IL

⚠ D 103 K120306005510-IL
D 105,106,109,110 K000400700220-IL
D 108 K050000015000-IL
D 9100,9102,9104,9106 K06022R044520-IL
D 9101,9103,9105,9108 K06039R044520-IL

D 9107,9110,9112,9117 K06022R044520-IL
D 9109,9115 K06039R044520-IL
D 9114 K06006R244520-IL
D 9118 K06022R044520-IL

MISCELLANEOUS

⚠ L 100 COIL,LINE FILTER D320201405510-IL
⚠ RY 101 RELAY G680050102020-IL
⚠ T 100 TRANS,SWITCHING E060283405510-IL
⚠ CN 9100 CONNECTOR L108396030010-IL
⚠ CN 9102 CN.WAFER 7.92MM L108011430210-IL

100,102 BRACKET 4010210196100-IL
⚠ FU 100 FUSE GLASS TUBE 20MM N751503151160-IL
⚠ FU 101 FUSE GLASS TUBE 20MM N751508001160-IL

RESISTORS

⚠ R 100 C060015564520-IL
⚠ R 101 C060022563520-IL
R 104 C060022563520-IL
⚠ R 105,113,115 C060010563520-IL

CAPACITORS

⚠ C 100 D02122407H010-IL
C 102 D04010108K000-IL
C 103 D00810207Q010-IL
⚠ C 104,105 D00847127H010-IL
C 106-108 D041562081001-IL

⚠ C 115,128 D00815248H010-IL
⚠ C 117 D008103589010-IL
C 131,133 D008103589010-IL

V BT ASSY

SEMICONDUCTORS

⚠ IC 600 BD2224G

MISCELLANEOUS

CN 601 CONNECTOR CKS5712
CN 603 CN.WAFER 2.0MM L101100031110-IL
601 BRACKET 4010210196100-IL