

Service Manual



XDJ-XZ

ORDER NO.
RRV4699

All-In-One DJ System

XDJ-XZ

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Model	Type	Power Requirement	Remarks
XDJ-XZ	AXJ	AC 220 V	
XDJ-XZ	LWSYXJ	AC 110 V to 240 V	
XDJ-XZ	UXJCB	AC 120 V	
XDJ-XZ	JXJ	AC 100 V	

THIS SERVICE MANUAL SHOULD BE USED TOGETHER WITH THE FOLLOWING MANUAL(S).

Model	Order No.	Remarks
XDJ-XZ	RRV4698	BLOCK DIAGRAM, EXPLODED VIEWS AND PARTS LIST etc.



Pioneer DJ Corporation

6F, Yokohama i-Mark Place, 4-4-5 Minatomirai, Nishi-ku, Yokohama, Kanagawa 220-0012 JAPAN

A



This service manual is intended for qualified service technicians; it is not meant for the casual do-it-yourselfer. Qualified technicians have the necessary test equipment and tools, and have been trained to properly and safely repair complex products such as those covered by this manual.

Improperly performed repairs can adversely affect the safety and reliability of the product and may void the warranty. If you are not qualified to perform the repair of this product properly and safely, you should not risk trying to do so and refer the repair to a qualified service technician.

B

Caution

Since the fuse may be neutral of the mains supply, disconnect the mains to de-energize the phase conductors.

C

D

E

F

CONTENTS

SAFETY INFORMATION.....	2	
10. SCHEMATIC DIAGRAM.....	5	
10.1 OVERALL WIRING DIAGRAM (1/2).....	5	A
10.2 OVERALL WIRING DIAGRAM (2/2).....	6	
10.3 MAIN ASSY (1/15).....	7	
10.4 MAIN ASSY (2/15).....	8	
10.5 MAIN ASSY (3/15).....	9	
10.6 MAIN ASSY (4/15).....	10	
10.7 MAIN ASSY (5/15).....	11	
10.8 MAIN ASSY (6/15).....	12	
10.9 MAIN ASSY (7/15).....	13	
10.10 MAIN ASSY (8/15).....	14	
10.11 MAIN ASSY (9/15).....	15	
10.12 MAIN ASSY (10/15).....	16	
10.13 MAIN ASSY (11/15).....	17	B
10.14 MAIN ASSY (12/15).....	18	
10.15 MAIN ASSY (13/15).....	19	
10.16 MAIN ASSY (14/15).....	20	
10.17 MAIN ASSY (15/15).....	21	
10.18 AUDIO ASSY (1/12).....	22	
10.19 AUDIO ASSY (2/12).....	23	
10.20 AUDIO ASSY (3/12).....	24	
10.21 AUDIO ASSY (4/12).....	25	
10.22 AUDIO ASSY (5/12).....	26	
10.23 AUDIO ASSY (6/12).....	27	
10.24 AUDIO ASSY (7/12).....	28	
10.25 AUDIO ASSY (8/12).....	29	C
10.26 AUDIO ASSY (9/12).....	30	
10.27 AUDIO ASSY (10/12).....	31	
10.28 AUDIO ASSY (11/12).....	32	
10.29 AUDIO ASSY (12/12).....	33	
10.30 MCIN ASSY.....	34	
10.31 MCTR ASSY.....	35	
10.32 USBA ASSY.....	36	
10.33 HPJK ASSY.....	37	
10.34 UCOM ASSY (1/3).....	38	
10.35 UCOM ASSY (2/3).....	39	
10.36 UCOM ASSY (3/3).....	40	
10.37 MIXER ASSY (1/3).....	41	D
10.38 MIXER ASSY (2/3).....	42	
10.39 MIXER ASSY (3/3).....	43	
10.40 EFSW ASSY.....	44	
10.41 CHF1 to CHF4 and CRFD ASSYS.....	45	
10.42 PAD1 ASSY (1/2).....	47	
10.43 PAD1 ASSY (2/2).....	48	
10.44 PAD2 ASSY (1/2).....	49	
10.45 PAD2 ASSY (2/2).....	50	
10.46 XPAD ASSY.....	51	
10.47 DCK1 ASSY (1/3).....	52	
10.48 DCK1 ASSY (2/3).....	53	E
10.49 DCK1 (3/3) and PWSW ASSYS.....	54	
10.50 DCK2 ASSY (1/3).....	55	
10.51 DCK2 ASSY (2/3).....	56	
10.52 DCK2 ASSY (3/3).....	57	
10.53 TMP1 ASSY.....	58	
10.54 TMP2 ASSY.....	59	
10.55 SER1 ASSY.....	60	
10.56 SER2 ASSY.....	61	
10.57 PLAY1 ASSY.....	62	
10.58 PLAY2 ASSY.....	63	
10.59 JLCD1 ASSY (1/2).....	64	
10.60 JLCD1 ASSY (2/2).....	65	F
10.61 JLCD2 ASSY (1/2).....	66	
10.62 JLCD2 ASSY (2/2).....	67	
10.63 JOG1 and JOG2 ASSYS.....	68	

A

B

C



D

E

F

10.64 LCDB ASSY (1/4).....	69
10.65 LCDB ASSY (2/4).....	70
10.66 LCDB ASSY (3/4).....	71
10.67 LCDB ASSY (4/4).....	72
10.68 SW POWER SUPPLY	73
10.69 VOLTAGES	74
10.70 WAVEFORMS	75
11. PCB CONNECTION DIAGRAM	76
11.1 MAIN ASSY	76
11.2 AUDIO ASSY	78
11.3 MCIN and MCTR ASSYS.....	80
11.4 USBA ASSY	82
11.5 HPJK ASSY	83
11.6 UCOM ASSY	84
11.7 MIXER ASSY	86
11.8 EFSW ASSY	88
11.9 CHF1 to CHF4 and CRFD ASSYS	89
11.10 PAD1 ASSY.....	91
11.11 PAD2 ASSY.....	92
11.12 XPAD ASSY	93
11.13 DCK1 and PWSW ASSYS	94
11.14 DCK2 ASSY	96
11.15 TMP1 and TMP2 ASSYS	98
11.16 SER1 and SER2 ASSYS	100
11.17 PLAY1 anbd PLAY2 ASSYS.....	101
11.18 JLCD1, JLCD2, JOG1 and JOG2 ASSYS	102
11.19 LCDB ASSY	104
11.20 SW POWER SUPPLY	106
12. PCB PARTS LIST	107

10. SCHEMATIC DIAGRAM




Note:
The 1 to 4 Assys of CHF Assys have the same circuitry, parts, and board shapes.
Only printed information is different, because their part numbers and wiring numbers are different.
They are handled similarly in their production management.
Therefore, either 1, 2, 3 or 4 Assy of the respective Assys is assembled in the respective place.

注意:
CHF の 1 から 4 は回路そのもの、使用部品、基板形状は同じです。
生産上は 1 から 4 の ASSY を管理していません。
このためそれぞれの場所には 1 から 4 のいずれかの ASSY が配置されています。

Note:
The 1 and 2 Assys of JLCD, PLAY, SER, TMP and JOG Assys have the same circuitry, parts, and board shapes.
Only printed information is different, because their part numbers and wiring numbers are different.
They are handled similarly in their production management.
Therefore, either 1 or 2 Assy of the respective Assys is assembled in the respective place.

注意:
JLCD, PLAY, SER, TMP, JOG の 1 と 2 は回路そのもの、使用部品、基板形状は同じです。
生産上は 1 と 4 の ASSY を管理していません。
このためそれぞれの場所には 1 と 2 のどちらかの ASSY が配置されています。




10. SCHEMATIC DIAGRAM 10.1 OVERALL WIRING DIAGRAM (1/2)

10.2 OVERALL WIRING DIAGRAM (2/2)

- When ordering service parts, be sure to refer to "EXPLODED VIEWS AND PARTS LIST" or "PCB PARTS LIST".
 - The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
 - Δ The power supply is shown with the marked box.
- 部品を発注する場合は、必ず「分解図と部品表」または「電気部品表」を参照してください。
 - Δ 印の部品は、安全上重要な部品です。
 - 交換するときは、安全および性能維持のため必ず指定の部品をご使用ください。
 - Δ 印は電源の供給源を示しています。


D MCTR ASSY (DWX4302)



C MCIN ASSY (DWX4300)




AF SW POWER SUPPLY (DWR1548)




F HPJK ASSY (DWX4301)




B (B 1/12-B 12/12) AUDIO ASSY (DWX4298)




AE (AE 1/4-AE 4/4) LCDB ASSY (DWX4291)



A (A 1/15-A 15/15) MAIN ASSY (DWX4287)



E USBA ASSY (DWX4294)



UCOM

A 1/15

MAIN	DWX4287
PCB	DNP2960


*RESISTORS
Indicated in Ω , $\pm$ % tolerance
unless otherwise noted. k:k Ω , M:M Ω

*CAPACITORS
Indicated in Capacity/Voltage(V)
unless otherwise noted. u: μ F, p:pF


A/2/15 MAIN ASSY (DWX4287)

PWR1


REGULATOR 3.3V=>1.1V(D)



DC/DC Converter 12V=>1.25V(D)




LED BL Driver



ALLOWANCE	LED	WPM
0.1mm	0.1mm	0.1mm
0.1mm	0.1mm	0.1mm
0.1mm	0.1mm	0.1mm
0.1mm	0.1mm	0.1mm
0.1mm	0.1mm	0.1mm

VOLTAGE DETECTION CIRCUIT



	Low Value	High Value
V+1R25D	0.7 V	3.3 V
V+5R2D	4.19V	7.1V
V+4R2D	-	5.16V
V+3R3D	2.31V	-

F DET	
H	Normal
L	Power failure

NOTES	
RM is No Mount	
RAB4C0***J	CE5V***K
RS1/16S***J	CE5V***K
RS1/16S***J	CE5V***K
RS1/8S***J	CE5V***K
RS1/8S***J	CE5V***K
RS1/16S***J	CE5V***K
RS1/16S***J	CE5V***K
RS1/16S***J	CE5V***K

*RESISTORS
Indicated in Ω, ±% tolerance
unless otherwise noted. k: kΩ, M: MΩ.

*CAPACITORS
Indicated in Capacity/Voltage(V)
unless otherwise noted. u: μF, p: pF


• The ⚠ mark found on some component parts indicates the importance of the safety factor of the part.
Therefore, when replacing, be sure to use parts of identical designation.
• 点印の部品は、安全上重要な部品です。
交換するときは、安全および性能維持のため必ず指定の部品をご使用ください。

MAIN	DW34287
PCB	DW34287

A/2/15

A/2/15

A 3/15 MAIN ASSY (DWX4287)



PWR2

A

B

C

D

E

F

G

H

A 3/15



MAIN DWX4287
PCB DWX2965

A 3/15

10.6 MAIN ASSY (4/15)

A 4/15 MAIN ASSY (DWX4287)

IMX PWR/DDR



*RESISTORS
Indicated in Ω , $\pm 5\%$ tolerance
unless otherwise noted. K: k Ω , M: M Ω .


*CAPACITORS
Indicated in Capacity/Voltage(V)
unless otherwise noted. u: μ F, p: pF

MAIN DWX4287
PCB DWX2960

A 4/15

A 5/15






*RESISTORS
Indicated in Ω , $\pm 5\%$ tolerance
unless otherwise noted. k:k Ω , M:M Ω .

*CAPACITORS
Indicated in Capacity/Voltage(V)
unless otherwise noted. u: μF , p:pF


A7/15 MAIN ASSY (DWX4287)

IMX LCD/KEY/USB/CLK/JIG



*RESISTORS
Indicated in Ω , $\pm 1\%$ tolerance
Unless otherwise noted. K: 10^3 , M: 10^6 .


*CAPACITORS
Indicated in Capacity/Voltage(V)
Unless otherwise noted. u: μF , p: pF



MAIN DWX4287
PCB DWX2960

A7/15

A 8/15



MAIN	DWX4287
PCB	DNP2960




BOOT MODE[10]		※0 : OPEN
00	Boot from fuses	
01	Serial downloader	
10	Boot from board settings (Board Default)	
11	Reserved	

NOTES		
NM is No Mount		
	RAB4CQ***J	 CKSSYB***K CKSRBY***K CKSQBY***K
	RS1/16SE***J RS1/10SR***J RS1/8SQ***J RS1/4SA***J	 CH CKSCH***J CCSRCH***J
	RS1/10SR***D, or RS1/16SE***D	 N CEVW***M
	RS1/10SR***F, or RS1/16SE***F	
	RN1/16SE***D	

*RESISTORS
Indicated in Ω , $\pm 5\%$ tolerance
unless otherwise noted. k:k Ω , M:M Ω .

*CAPACITORS
Indicated in Capacity/Voltage(V)
unless otherwise noted. u : μF , p : pF



A 10/15MAIN ASSY (DWX4287)



• The „A“ mark found on some component parts indicates the importance of the safety factor of the part.
Therefore, when replacing, be sure to use parts of identical designation.
• A印の部品は、安全上重要な部品です。
交換するときは、安全および性能維持のため必ず指定の部品をご使用ください。

MAIN	DWX4287
PCB	DWP2960


A 10/15



MAIN	DW4287
PCB	DW2286

A 11/15

A 12/15MAIN ASSY (DWX4287)



NOTES			
 RES 1/4 5% 100K	 RES1/16 5% 100K	 RES1/16 5% 100K	 RES1/16 5% 100K
 RES 1/4 5% 100K	 RES1/16 5% 100K	 RES1/16 5% 100K	 RES1/16 5% 100K
 RES 1/4 5% 100K	 RES1/16 5% 100K	 RES1/16 5% 100K	 RES1/16 5% 100K

*RESISTORS
Indicated in Ω , $\pm 5\%$ tolerance
unless otherwise noted. k:k Ω , M:M Ω .

*CAPACITORS
Indicated in Capacity/Voltage(V)
unless otherwise noted. u:nF, p:pF


MAIN	DWX4287
PCB	DNP2960

A 12/15

LAN HUB

A 12/15

10.15 MAIN ASSY (13/15)








Legend for components:
*RESISTORS: Indicated in Ω, kΩ tolerance unless otherwise noted. k: 10³, M: 10⁶.
*CAPACITORS: Indicated in Capacity/Tolerance (p: pF, n: nF, u: uF) unless otherwise noted. n: 10⁻⁹, p: 10⁻¹².

MAIN DWX4287
PCB DRP2960

A 13/15

A 14/15 MAIN ASSY (DWX4287)



*RESISTORS
Indicated in Ω, 5% tolerance
unless otherwise noted. k: kΩ, M: MΩ.

*CAPACITORS
Indicated in Capacity/Voltage(V)
unless otherwise noted. u: uF, p: pF

MAIN	DWX4287
SCB	DW22968

A 14/15

DSP 1/2

DSP (1/2)

DSP IC2501
D810X01302XB400

DSP IC2501
D810X01302XB400

DSP IC2501
D810X01302XB400

A 14/15

XDJ-XZ

A


24

A

1



11


B 1/12 AUDIO ASSY (DWX4298)



A 1/15 CN101


A 1/15 CN102




B 2/12 AUDIO ASSY (DWX4298)

```
BCLK
2.8224 MHz
```

LRCK
44.1 kHz



MCLK
22.5792 MHz



AUDIO	DWX4298
PCB	DNP2964


B 3/12

*CAPACITORS
Indicated in Capacity/Voltage (V)
unless otherwise noted. u : μF , p : pF

*RESISTORS
Indicated in Ω , $\pm$ tolerance
unless otherwise noted. k : $k\Omega$, M : $M\Omega$

B 4/12






AUDIO	DWX4298
PCB	DNP2964

B 7/12

MASTER




AUDIO	DWX4298
PCB	DNP2964

B 7/12

B 8/12 AUDIO ASSY (DWX4298)

BOOTH



BOOTH Lch

BOOTH Rch

*CAPACITORS Indicated in Capacity/Voltage(V) unless otherwise noted. u : uF, p : pF
*RESISTORS Indicated in Ohm tolerance unless otherwise noted. k : kOhm, M : MOhm


BOOTH OUT Signal (L ch)

AUDIO DWX4298
PCB DNP2964

B 8/12

XDJ-XZ

B 8/12


B 9/12**F** CN7701

B 9/12

*CAPACITORS
Indicated in Capacity/Voltage(V)
unless otherwise noted. u: μF , p: pF

*RESISTORS
Indicated in Ω , $\pm$ tolerance
unless otherwise noted. k: k Ω , M: M Ω .

B 10/12 AUDIO ASSY (DWX4298)




• The Δ mark found on some component parts indicates the importance of the safety factor of the part.
Therefore, when replacing, be sure to use parts of identical designation.
• Δ 印の部品は、安全上重要な部品です。
交換するときは、安全および性能維持のため必ず指定の部品をご使用ください。

※部品仕入れに際しては、必ずしもこの図面を参照してください。
※部品仕入れに際しては、必ずしもこの図面を参照してください。
※部品仕入れに際しては、必ずしもこの図面を参照してください。

AUDIO DWX4298
PCB DNP2964

B 10/12


POWER



XDJ-XZ

B11/12 AUDIO ASSY (DWX4298)

VOLTAGE DETECTION CIRCUIT



NOTES

NM means STANDBY

RS1/16SS***J

CKSSB***K

*CAPACITORS

Indicated in Capacity/Voltage(V) unless otherwise noted. u: μF , p: pF

*RESISTORS

Indicated in Ω , $\pm 5\%$ tolerance unless otherwise noted. k: $k\Omega$, M: $M\Omega$.AUDIO DWX4298
PCB DNP2964

B11/12

1 2 3 4 5 6 7 8

A

B

C

D

E

F

XDJ-XZ

MUTE

MAS VR MUTE

H MASTER MUTE ON
L MASTER MUTE OFF

ERP_xAMUTE

B 1/12
ERP_xAMUTE
1:8B

H MUTE OFF
L MUTE ON

NOTES

NM means STANDBY

RS1/16SS***J

CKSSVB***K

*CAPACITORS
Indicated in Capacity/Voltage(V)
unless otherwise noted. u: μ F, p: pF


*RESISTORS
Indicated in Ω , $\pm$ 5% tolerance
unless otherwise noted. k: k Ω , M: M Ω .


33

B 12/12



AUDIO DWX4298
PCB DNP2964

B 12/12





SUBA	DWM2724 /J
MCIN	DWX4300 /J
PCB	DNP2966



(MIC1) : MIC1 Signal
(MIC2) : MIC2 Signal

NOTES
NM means STANDBY
RS1/10SR***J


*CAPACITORS
Indicated in Capacity/Voltage(V)
unless otherwise noted. u : μF , p : pF
*RESISTORS
Indicated in Ω , $\pm 5\%$ tolerance
unless otherwise noted. k : k Ω , M : M Ω .

SUBA	DWM2724 /J
MCTR	DWX4302 /J
PCB	DNP2966

10.32 USBA ASSY

USBA ASSY (DWX4294)

USBA



*CAPACITORS
Indicated in Capacity/Voltage(V)
unless otherwise noted. u : μ F , p : pF

NOTES	
NM is No Mount	
	CKSSYB***K
	CCSSCH***J

PADA	DWM2719 /J
USBA	DWX4294 /J
PCB	DNP2962

A




C

D
























E

F


G1/3 UCOM ASSY (DWX4296)



G 2/3 UCOM ASSY (DWX4296)



UCOM BOARD IF1



G 2/3

ZX-rdXZ

9 8 7 6 5 4 3 2 1

The ⚠ mark found on some component parts indicates the importance of the safety factor of the part.
Therefore, when replacing, be sure to use parts of identical designation.
※ 点印の部品は、安全上重要な部品です。
交換するときは、安全および性能維持のため必ず指定の部品をご使用ください。


G 2/3



NOTES		
NM 1# No Mount		
	RAB4CQ***J	—+— CESSYB***K CCSSCH***
	R1/16S***J	1000p } CCSSCH***J 470p } 10p }
	R2/10S***J	
	R1/82Q***J	
	R1/45A***J	10p CCSSCH***D
	R1/10S***D, or R1/16S***D	
	R1/10S***F, or R1/16S***F	
		+—+ CESSY***M

UCOM	DWM2721 /J
	DMX4296 /J
PCB	DNP2963

H 1/3 MIXER ASSY (DWX4299)




*RESISTORS
Indicated in Ω, K, M, unless
otherwise noted. k: kΩ, M: MΩ.

*CAPACITORS
Indicated in Capacity (pF, nF, μF)
unless otherwise noted. n: nF, p: pF.

MIXER DWX4299 / 3
PCB DWX2965

H2/3 MIXER ASSY (DWX4299)




*RESISTORS
Indicated in Ω , $\text{k}\Omega$ tolerance
unless otherwise noted. k = 10^3 , M = 10^6 .

*CAPACITORS
Indicated in Capacity/Value(T)
unless otherwise noted. n = 10^{-9} , p = 10^{-12} .




MIXER
DW4299 / J
DW2965


H 3/3 MIXER ASSY (DWX4299)



EFSW ASSY (DWX4297)



UCOM	DWM2721 /3
PCB	DNX4297 /3
	DNF2943



REF:4901-5000

*RESISTORS
Indicated in Ω, 10 tolerance
unless otherwise noted. k=10³, M=10⁶.

*CAPACITORS
Indicated in Capacity/Voltage(V)
unless otherwise noted. u=10⁻⁶, p=10⁻⁹

SW	Is Not Mount
RES	RESISTOR
CAP	CAPACITOR


EFSW

XDJ-XZ

J


CHF1 ASSY (DWX4303)

CHF1



L CHF3 ASSY (DWX4305)


CHF3



PNL1	DWM2725 /J
CHF3	DWX4305 /J
PCB	DNP2967

M CHF4 ASSY (DWX4306)



CHF4



PNL2	Front DWM2726 /J
CHF4	DWX4306 /J
PCB	DNP2968

N CRFD ASSY (DWX4295)

CROSS FADER




*CAPACITORS
Indicated in Capacity/Voltage(V)
unless otherwise noted. u: μF , p: pF

*RESISTORS
Indicated in Ω , $\pm 5\%$ tolerance
unless otherwise noted. k: k Ω , M: M Ω .


PADA	DWM2719 /J
CRFD	DWX4295 /J
PCB	DNP2962

10.42 PAD1 ASSY (1/2)



XDU-XZ

0 2/2



PADA	DWM2720 /J
PAD1	DWX4292 /J
PCB	DNP2962

*CAPACITORS
Indicated in Capacity/Voltage(V)
unless otherwise noted. u: μF , p: pF

*RESISTORS
Indicated in Ω , $\pm 5\%$ tolerance
unless otherwise noted. k: $k\Omega$, M: $M\Omega$

NOTES

NM means STANDBY

 RS1/16SS***J

 CCSSYR***K

3



PADA	DWM2720 /J
PAD2	DWX4293 /J
PCB	DNP2962


*CAPACITORS
Indicated in Capacity/Voltage(V)
unless otherwise noted. u : μF , p : pF

*RESISTORS
Indicated in Ω , $\pm 5\%$ tolerance
unless otherwise noted. k : k Ω , M : M Ω .



Q



JOGA	DWM2719 /J
XPAD	DWX4290 /J
PCB	DNP2961

R 1/3

PNL1	DWM2725 /J
DCK1	DWX4309 /J
PCB	DNP2967



REF: 8101-8300

DCK1 KEY/VR

XDJ-XZ



R 2/3



PNL1	DWM2725 /J
------	------------

*RESISTORS
Indicated in Ω , $\pm 5\%$ tolerance
unless otherwise noted. k=hk, M=Mk.



R3/3 S






R 3/3 **S**

T 1/3 DCK2 ASSY (DWX4313)

DCK2 KEY/VR




REF:9001-9300




	NOTES NR Is No Mount  RES/100K***J  RES/40A***J  C8000***K  C8000***J							
*RESISTORS Indicated in Ω, ±5% tolerance unless otherwise noted. K:kΩ, M:MΩ. *CAPACITORS Indicated in Capacity/Voltage(V) unless otherwise noted. μ:μF, p:pF		<table><tr><td>PNL2</td><td>DWM2726 /J</td></tr><tr><td>DCK2</td><td>DWX4313 /J</td></tr><tr><td>PCB</td><td>DNP2968</td></tr></table>	PNL2	DWM2726 /J	DCK2	DWX4313 /J	PCB	DNP2968
PNL2	DWM2726 /J							
DCK2	DWX4313 /J							
PCB	DNP2968							

T 2/3



T 2/3




U

TMP1 ASSY (DWX4311)

Note:
The 1 and 2 Assys of TMP Assy have the same circuitry, parts, and board shapes.
Only printed information is different, because their part numbers and wiring numbers are different.
They are handled similarly in their production management.
Therefore, either 1 or 2 Assy of the respective Assys is assembled in the respective place.

注意:
TMP の 1 と 2 は回路そのもの、使用部品、基板形状は同じです。
生産上は 1 と 2 の ASSY を管理していません。
このためそれぞれの場所には 1 と 2 のどちらかの ASSY が配置されています。



*RESISTORS
Indicated in Ω , $\pm 5\%$ tolerance
unless otherwise noted. k: k Ω , M: M Ω .
*CAPACITORS
Indicated in Capacity/Voltage(V)
unless otherwise noted. u: μ F, p: pF

NOTES

NM is No Mount

RS1/10SR***J

CKSRVB***K

CCSRCH***J

REF:8351-8400

TMP1

XD-J-XZ

V TMP2 ASSY (DWX4315)

Note:

The 1 and 2 Assys of TMP Assy have the same circuitry, parts, and board shapes. Only printed information is different, because their part numbers and wiring numbers are different. They are handled similarly in their production management.


Therefore, either 1 or 2 Assy of the respective Assys is assembled in the respective place.

注意:

TMP の 1 と 2 は回路そのもの、使用部品、基板形状は同じです。

生産上は 1 と 2 の ASSY を管理していません。

このためそれぞれの場所には 1 と 2 のどちらかの ASSY が配置されています。



PNL2	DWM2726 /J
TMP2	DWX4315 /J
PCB	DNP2968

NOTES

NM is No Mount
 RS1/10SR***J
 CKSRVB***K
 CCSRCH***J

*RESISTORS
 Indicated in Ω , $\pm 5\%$ tolerance
 unless otherwise noted. k: k Ω , M: M Ω .
 *CAPACITORS
 Indicated in Capacity/Voltage (V)
 unless otherwise noted. u: μ F, p: pF

REF:9451-9500


TMP2

SER1 ASSY

W SER1 ASSY (DWX4310)

Note:
The 1 and 2 Assys of SER Assy have the same circuitry, parts, and board shapes.
Only printed information is different, because their part numbers and wiring numbers are different.
They are handled similarly in their production management.
Therefore, either 1 or 2 Assy of the respective Assys is assembled in the respective place.

注意:
SER の 1 と 2 は回路そのもの、使用部品、基板形状は同じです。
生産上は 1 と 2 の ASSY を管理していません。
このためそれぞれの場所には 1 と 2 のどちらかの ASSY が配置されています。




SUBA	DWM2724 /J
SER1	DWX4310 /J
PCB	DNP2966

SER2 ASSY

X SER2 ASSY (DWX4314)

Note:
The 1 and 2 Assys of SER Assy have the same circuitry, parts, and board shapes.
Only printed information is different, because their part numbers and wiring numbers are different.
They are handled similarly in their production management.
Therefore, either 1 or 2 Assy of the respective Assys is assembled in the respective place.

注意:
SER の 1 と 2 は回路そのもの、使用部品、基板形状は同じです。
生産上は 1 と 2 の ASSY を管理していません。
このためそれぞれの場所には 1 と 2 のどちらかの ASSY が配置されています。




SUBA	DWM2724 /J
SER2	DWX4314 /J
PCB	DNP2966

10.57 PLAY1 ASSY

Y PLAY1 ASSY (DWX4307)

Note:
The 1 and 2 Assys of PLAY Assy have the same circuitry, parts, and board shapes.
Only printed information is different, because their part numbers and wiring numbers are different.
They are handled similarly in their production management.
Therefore, either 1 or 2 Assy of the respective Assys is assembled in the respective place.

注意:
PLAYの1と2は回路そのもの、使用部品、基板形状は同じです。
生産上は1と2のASSYを管理していません。
このためそれぞれの場所には1と2のどちらかのASSYが配置されています。



NOTES	
NM	means STANDBY
□	RS1/10SR***J
— —	CKSRYB***K

***CAPACITORS**
Indicated in Capacity/Voltage(V)
unless otherwise noted. u : μ F , p : pF

***RESISTORS**
Indicated in Ω , $\pm 5\%$ tolerance
unless otherwise noted. k : k Ω , M : M Ω .


SUBA	DWM2724 /J
PLAY1	DWX4307 /J
PCB	DNP2966

Z

PLAY2 ASSY (DWX4308)

Note:
The 1 and 2 Assys of PLAY Assy have the same circuitry, parts, and board shapes.
Only printed information is different, because their part numbers and wiring numbers are different.
They are handled similarly in their production management.
Therefore, either 1 or 2 Assy of the respective Assys is assembled in the respective place.

注意:
PLAYの1と2は回路そのもの、使用部品、基板形状は同じです。
生産上は1と2のASSYを管理していません。
このためそれぞれの場所には1と2のどちらかのASSYが配置されています。



NOTES

NM means STANDBY

RS1/10SR***J

CKSRBY***K

***CAPACITORS**
Indicated in Capacity/Voltage(V)
unless otherwise noted. u : μF , p : pF

***RESISTORS**
Indicated in Ω , $\pm 5\%$ tolerance
unless otherwise noted. k : k Ω , M : M Ω .

SUBA	DWM2724 /J
PLAY2	DWX4308 /J
PCB	DNP2966

AA 1/2



*CAPACITORS
Indicated in Capacity/Voltage (V)
unless otherwise noted. m = nF, p = pF

*RESISTORS
Indicated in Ω , $\text{k}\Omega$, $\text{M}\Omega$ tolerance
unless otherwise noted. h = h Ω , M = M Ω

- The  mark found on some component parts indicates the importance of the safety factor of the part.
Therefore, when replacing, be sure to use parts of identical designation.
- 印の部品は、安全上重要な部品です。
交換するときは、安全および性能維持のため必ず指定の部品をご使用ください。

JOGA	DWM2719 /J
JLCD1	DWX4288 /J
PCB	DNP2961

*CAPACITORS
Indicated in Capacity/Voltage (V)
unless otherwise noted. m = nF, p = pF

*RESISTORS
Indicated in Ω , $\text{k}\Omega$, $\text{M}\Omega$ tolerance
unless otherwise noted. h = h Ω , M = M Ω

- The  mark found on some component parts indicates the importance of the safety factor of the part.
Therefore, when replacing, be sure to use parts of identical designation.
- 印の部品は、安全上重要な部品です。
交換するときは、安全および性能維持のため必ず指定の部品をご使用ください。


JOGA	DWM2719 /J
JLCD1	DWX4288 /J
PCB	DNP2961

AA 2/2 JLCD1 ASSY (DWX4288)

Note:
The 1 and 2 Assys of JLCD Assy have the same circuitry, parts, and board shapes.
Only printed information is different, because their part numbers and wiring numbers are different.
They are handled similarly in their production management.
Therefore, either 1 or 2 Assy of the respective Assys is assembled in the respective place.

注意:
JLCDの1と2は回路そのもの、使用部品、基板形状は同じです。
生産上は1と2のASSYを管理していただきます。
このためそれぞれの場所には1と2のどちらかのASSYが配置されています。


JOG LED (WHITE)



to LCD MODULE
(3.5inch QVGA)


LCD IO/JOG ILM

LCD BACKLIGHT



AB 1/2 JLCD2 ASSY (DWX4289)

Note:
The 1 and 2 Assy of JLCD Assy have the same circuitry, parts, and board shape.
Only printed information is different, because their part numbers and wiring numbers are different.
They are handled similarly in their production management.
Therefore, either 1 or 2 Assy of the respective Assys is assembled in the respective place.
注意:
JLCD の 1 と 2 は回路そのもの、使用部品、基板形状は同じです。
生産上は 1 と 2 の ASSY を管理していません。
このためそれぞれの場所には 1 と 2 のどちらかの ASSY が配置されています。



G 2/3 CN4503 or
G 2/3 CN4515

5
7
19
CN3205

from SHRT SW
DSX1078-
1
1
CN3204
AC CN9601 or
AD CN9701

JOGA	DWM2719 / J
JLCD2	DWX4289 / J
PCB	DNP2961

• The Δ mark found on some component parts indicates the importance of the safety factor of the part.
Therefore, when replacing, be sure to use parts of identical designation.
• 凡目の部品は、安全上重要な部品です。
交換するときは、安全および性能維持のため必ず指定の部品をご使用ください。

※本図は、製品の仕様書に記載の図面を基に作成されたもので、製品の仕様書に記載の図面と異なる場合があります。
※本図は、製品の仕様書に記載の図面を基に作成されたもので、製品の仕様書に記載の図面と異なる場合があります。

IC3202
R5S72690W266FP
JOG LCD UCOM2

RSPi Slave Mode

AB22

AB22

AB22

SH7269/SDRAM

V+3R3D

1.25V LDO

V+1R2D

Y CN7951 or
Z CN8001

AB 1/2


AB 1/2

XDJ-XZ

AB 2/2 JLCD1 ASSY (DWX4289)

Note:
The 1 and 2 Assys of JLCD Assy have the same circuitry, parts, and board shapes.
Only printed information is different, because their part numbers and wiring numbers are different.
They are handled similarly in their production management.
Therefore, either 1 or 2 Assy of the respective Assys is assembled in the respective place.
注意:
JLCD の 1 と 2 は回路そのものの、使用部品、基板形状は同じです。
生産上は 1 と 2 の ASSY を管理していただきます。
このためそれぞれの場所には 1 と 2 のどちらかの ASSY が配置されています。


JOG LED (WHITE)



to LCD MODULE
(3.5inch QVGA)

LCD IO/JOG ILM

LCD BACKLIGHT



*CAPACITORS
Indicated in Capacity/Voltage (V)
unless otherwise noted. u: μ F, p: pF
*RESISTORS
Indicated in Ω , $\pm 5\%$ tolerance
unless otherwise noted. k: k Ω , M: M Ω

NOTES
NM means STANDBY
R1/165***J
R1/165***F
R1/165***J
R1/165***D
C1000***J
C1000***K
C1000***K

JOGA	DWM2719 /J
JLCD2	DWX4289 /J
PCB	DNP2961

The Δ mark found on some component parts indicates the importance of the safety factor of the part.
Therefore, when replacing, be sure to use parts of identical designation.
点印の部品は、安全上重要な部品です。
交換するときは、安全および性能維持のため必ず指定の部品をご使用ください。

LCD DCLK

XDU-XZ

10.63 JOG1 and JOG2 ASSYS

A

B

C

D


E

F

Note:
The 1 and 2 Assys of JOG Assy have the same circuitry, parts, and board shapes.
Only printed information is different, because their part numbers and wiring numbers are different.
They are handled similarly in their production management.
Therefore, either 1 or 2 Assy of the respective Assys is assembled in the respective place.
注意:
JOG の 1 と 2 は回路そのもの、使用部品、基板形状は同じです。
生産上は 1 と 2 の ASSY を管理していません。
このためそれぞれの場所には 1 と 2 のどちらかの ASSY が配置されています。


JOG1


AC JOG1 ASSY (DWX4317)




JOG2

AD JOG2 ASSY (DWX4318)



AE 1/4

NOTES		
NM is No Mount		
	RS1/16S****J	CKSSYB***K
	RS1/10SR***J	CKSRYB***K
	RS1/8SQ***J	CKSQYB***K
	RS1/4SA****J	
D	RS1/10SR****D, or RS1/16S****D	CCSSCH***J
F	RS1/10SR****F, or RS1/16S****F	CCSRCH***J
		N CEVW***M



*CAPACITORS
Indicated in Capacity/Voltage(V)
unless otherwise noted. u : μ F , p : pF

PADA	DWM2720 /J
	DWX4291 /J
PCB	DNP2962

AE 2/4

AE 4/4



*CAPACITORS
Indicated in Capacity/Voltage(V)
unless otherwise noted. u : μF , p : pF


PADA	DWM2720 /J
	DWX4291 /J
PCB	DNP2962

	DWX4291 /J
PCB	DNP2962

E10/12
CN6601

△印の部品は、指定部品(安全規格適合部品)を必ず使用すること。
The △ mark found on some component parts should be replaced
with same parts (safety regulation authorized) of identical
designation.

CAUTION - FOR CONTINUED PROTECTION AGAINST RISK OF FIRE, REPLACE WITH
SAME TYPE NO. S505-4A-R MFD. BY COOPER BUSSMANN INC. FOR F1.




10.69 VOLTAGES

A						
	Voltage name	Min	Typ.	Max	Associated Assy	Power Supply at standby (Power SW OFF)
	V+12E	11.40 V	12.00 V	12.60 V	AUDIO Assy	ON
	V+5E	4.90 V	5.00 V	5.10 V	AUDIO Assy, MAIN Assy, UCOM Assy	ON
	V+3R3E	3.20 V	3.30 V	3.40 V	UCOM Assy	ON
	V+12D V+12D_HP	11.40 V	12.00 V	12.60 V	AUDIO Assy, MAIN Assy	OFF
	V+12L V+12BL V+12BL_O V+12LED	11.40 V	12.00 V	12.60 V	AUDIO Assy, MAIN Assy, JLCD1 Assy, JLCD2 Assy, UCOM Assy	OFF
B	V+12A	11.40 V	12.00 V	12.60 V	AUDIO Assy	OFF
	V+9LED	8.58 V	9.00 V	9.43 V	AUDIO Assy, MAIN Assy, UCOM Assy, MIXER Assy, XPAD Assy, PAD1 Assy, PAD2 Assy, PLAY1 Assy, PLAY2 Assy, EFSW Assy, JLCD1 Assy, JLCD2 Assy	OFF
	V+5D V+5LED V+5LED_O V+5R2D	5.06 V	5.29 V	5.53 V	AUDIO Assy, MAIN Assy, LCDB Assy, UCOM Assy, MIXER Assy, DCK1 Assy, DCK2 Assy	OFF
	V+1R25D	1.20 V	1.26 V	1.32 V	MAIN Assy	OFF
	V+1R1 V+1R1_USBAHUB V+1R1_USBBHUB	1.09 V	1.15 V	1.21 V	MAIN Assy	OFF
C	V+1D	0.95 V	1.00 V	1.05 V	MAIN Assy	OFF
	V+4R2D	3.95 V	4.19 V	4.45 V	MAIN Assy	OFF
	V+1R375CORE	1.334 V	1.375 V	1.416 V	MAIN Assy	OFF
		1.261 V	1.300 V	1.339 V	MAIN Assy	
	V+3R0VSNVS	2.85 V	3.00 V	3.15 V	MAIN Assy	OFF
	V+1R5DDR	1.455 V	1.50 V	1.545 V	MAIN Assy	OFF
	V+1R375SOC	1.334 V	1.375 V	1.416 V	MAIN Assy	OFF
		1.261 V	1.300 V	1.339 V	MAIN Assy	
	V+2R8VHIGH	2.716 V	2.80 V	2.884 V	MAIN Assy	OFF
		2.910 V	3.00 V	3.090 V	MAIN Assy	
D	V+3R3D V+3R3D1 V+3R3D2 V+3R3D2_AD V+3R3D2_AD_MXR V+3R3D_AD_SH V+3R3D2_J V+3R3D2_AD_DCK	3.201 V	3.300 V	3.399 V	AUDIO Assy, MAIN Assy, UCOM Assy, LCDB Assy, JLCD1 Assy, JLCD2 Assy, PAD1 Assy, PAD2 Assy, EFSW Assy, MIXER Assy, CHF1 Assy, CHF2 Assy, CHF3 Assy, CHF4 Assy, DCK1 Assy, DCK2 Assy, JOG1 Assy, JOG2 Assy, TMP1 Assy, TMP2 Assy, CRF Assy	OFF
	V+5USBA1 V+5USBA2	4.92 V	5.14 V	5.36 V	MAIN Assy	OFF
	V+1R2D	1.24 V	1.26 V	1.27 V	JLCD1 Assy, JLCD2 Assy	OFF
	VGH	14.82 V	15.60 V	16.38 V	LCDB Assy	OFF
	VGL	-7.35 V	-7.00 V	-6.65 V	LCDB Assy	OFF
	VAVDD	9.50 V	10.00 V	10.50 V	LCDB Assy	OFF
	V+3R3D_CLK	3.20 V	3.30 V	3.40 V	AUDIO Assy	OFF
	V+18A	17.47 V	18.00 V	18.53 V	AUDIO Assy	OFF
E	V-18A	-18.86 V	-18.00 V	-17.16 V	AUDIO Assy	OFF
	V+15A	14.25 V	15.00 V	15.75 V	AUDIO Assy, MCIN Assy	OFF
	V-15A	-15.75 V	-15.00 V	-14.25 V	AUDIO Assy, MCIN Assy	OFF
	V+7R5HP	7.29 V	7.50 V	7.72 V	AUDIO Assy	OFF
	V-7R5HP	-7.88 V	-7.50 V	-7.11 V	AUDIO Assy	OFF
	V+9A	8.65 V	9.00 V	9.35 V	AUDIO Assy	OFF
	V+5A	4.80 V	5.00 V	5.20 V	AUDIO Assy	OFF
	V+3R3A	3.20 V	3.30 V	3.40 V	AUDIO Assy	OFF
	V+5AREF	4.80 V	5.00 V	5.20 V	AUDIO Assy	OFF
	BL_A	9.12 V	10.02 V	10.92 V	MAIN Assy, LCDB Assy	OFF

NOTE: The following waveforms were measured at the point of the corresponding balloon number in the schematic diagram and PCB diagram.

注意: ○で囲まれた数字は回路図及びPCB図の各測定ポイントの番号を示します.



AUDIO SECTION


Measurement Condition

IN or OUT	Measured CH	IN CH	IN Level	IN Frequency	RL	Remarks
OUT	MASTER1	CH2	0 dBfs	1kHz	10 kΩ	MASTER2: same conditions
OUT	BOOTH	CH2	0 dB	1kHz	10 kΩ	
OUT	HP	CH2	0 dB	1kHz	32 Ω	
IN	LINE	CH2	0 dB	1kHz		CH1: same conditions
IN	PHONO	CH2	-40 dB	1kHz		CH1: same conditions
IN	AUX	AUX	-30 dB	1kHz		
IN	MIC	MIC2	-40 dB	1kHz		MIC1: same conditions, TS JACK

Each SW/VR Position

Name	Position	Name	Position
TRIM	CENTER	TEMPO SLIDER	CENTER
EQ	CENTER	FX PARAMETER	CENTER
CH FADER	MAX	COLOR	CENTER
MIC SW	ON	MASTER LEVEL	CENTER
MIC LEVEL	CENTER	BOOTH MONITOR	CENTER
MIC EQ	CENTER	HP LEVEL	CENTER
CROSS FADER	CENTER	BALANCE	CENTER
CROSS FADER CURVE	CENTER	Master EQ	CENTER
CROSS FADER ASSIGN	THRU		

B AUDIO ASSY



4

SIDE B

SIDE B

A

B


C

D

F

F

A MAIN ASSY



CN105

CN103

CN104

(DNP2960-A)

A

5

6

7

8


XDJ-XZ

A

SIDE A

B AUDIO ASSY

SIDE A



C CN7602

(DNP2964-A)

XDJ-XZ

SIDE A

SIDE A

A



B

C

D

E


F



SIDE B


SIDE B

C MCIN ASSY



SIDE A


G UCOM ASSY



G

SIDE A

H MIXER ASSY



SIDE B

SIDE B

A

B


C

D

E

F

H MIXER ASSY





XDJ-XZ

H

11.8 EFSW ASSY


SIDE A

SIDE B



SIDE A

SIDE A




Note:
The 1 to 4 Assys of CHF Assys have the same circuitry, parts, and board shapes.
Only printed information is different, because their part numbers and wiring numbers are different.
They are handled similarly in their production management.
Therefore, either 1, 2, 3 or 4 Assy of the respective Assys is assembled in the respective place.

注意:
CHF の 1 から 4 は回路そのもの、使用部品、基板形状は同じです。
生産上は 1 から 4 の ASSY を管理していません。
このためそれぞれの場所には 1 から 4 のいずれかの ASSY が配置されています。

SIDE B

SIDE B




SIDE A


SIDE A

A

M CHF4 ASSY



N CRFD ASSY




Note:
The 1 to 4 Assys of CHF Assys have the same circuitry, parts, and board shapes.
Only printed information is different, because their part numbers and wiring numbers are different.
They are handled similarly in their production management.
Therefore, either 1, 2, 3 or 4 Assy of the respective Assys is assembled in the respective place.
注意:
CHFの1から4は回路そのもの、使用部品、基板形状は同じです。
生産上は1から4のASSYを管理していません。
このためそれぞれの場所には1から4のいずれかのASSYが配置されています。

SIDE B


SIDE B

D

M CHF4 ASSY



N CRFD ASSY



M N


M N

11.10 PAD1 ASSY

SIDE A

PAD1 ASSY


SIDE A



SIDE B

PAD1 ASSY

SIDE B




11.11 PAD2 ASSY

SIDE A

SIDE A

P PAD2 ASSY




(DNP2962-A)

SIDE B

SIDE B

P PAD2 ASSY




(DNP2962-A)

P

P

SIDE A


Q XPAD ASSY



(DNP2961-A)

SIDE B

Q XPAD ASSY



(DNP2961-A)

11.13 DCK1 and PWSW ASSYS

SIDE A

SIDE A

R DCK1 ASSY

S PWSW ASSY

(DNP2967-A)

(DNP2967-A)

G CN4518

U CN8351 or
V CN9451

W CN8302 or
X CN9402

XDJ-XZ

R S

R S

SIDE B

SIDE B

R DCK1 ASSY

S PWSW ASSY

(DNP2967-A)


R S

R S

4

SIDE A

T



G CN4520

SIDE B

SIDE B

T DCK2 ASSY

A


B

C

D

F


F



SIDE A

SIDE B

U TMP1 ASSY



Note:
The 1 and 2 Assys of TMP Assy have the same circuitry, parts, and board shapes.
Only printed information is different, because their part numbers and wiring numbers are different.
They are handled similarly in their production management.
Therefore, either 1 or 2 Assy of the respective Assys is assembled in the respective place.

注意:
TMP の 1 と 2 は回路そのもの、使用部品、基板形状は同じです。
生産上は 1 と 2 の ASSY を管理していません。
このためそれぞれの場所には 1 と 2 のどちらかの ASSY が配置されています。

SIDE A

SIDE B



Note:

The 1 and 2 Assys of TMP Assy have the same circuitry, parts, and board shapes.
Only printed information is different, because their part numbers and wiring numbers are different.
They are handled similarly in their production management.
Therefore, either 1 or 2 Assy of the respective Assys is assembled in the respective place.

注意：

注意：
TMP の 1 と 2 は回路そのもの、使用部品、基板形状は同じです。
生産上は 1 と 2 の ASSY を管理していません。
このためそれぞれの場所には 1 と 2 のどちらかの ASSY が配置されています。

V TMP2 ASSY

**V** TMP2 ASSY


V

V

11.16 SER1 and SER2 ASSYS


SIDE A W SER1 ASSY

Note:
The 1 and 2 Assys of SER Assy have the same circuitry, parts, and board shapes.
Only printed information is different, because their part numbers and wiring numbers are different.
They are handled similarly in their production management.
Therefore, either 1 or 2 Assy of the respective Assys is assembled in the respective place.
注意: SER の 1 と 2 は回路そのもの、使用部品、基板形状は同じです。
生産上は 1 と 2 の ASSY を管理していません。
このためそれぞれの場所には 1 と 2 のどちらかの ASSY が配置されています。




(DNP2966-A)

X SER2 ASSY




(DNP2966-A)

SIDE B W SER1 ASSY



(DNP2966-A)

X SER2 ASSY



(DNP2966-A)

5 6 7 8

11.17 PLAY1 anbd PLAY2 ASSYS

SIDE A



Note:
The 1 and 2 Assys of PLAY Assy have the same circuitry, parts, and board shapes.
Only printed information is different, because their part numbers and wiring numbers are different.
They are handled similarly in their production management.
Therefore, either 1 or 2 Assy of the respective Assys is assembled in the respective place.

注意:
PLAY の 1 と 2 は回路そのもの、使用部品、基板形状は同じです。
生産上は 1 と 2 の ASSY を管理していません。
このためそれぞれの場所には 1 と 2 のどちらかの ASSY が配置されています。

SIDE A

Y PLAY1 ASSY

Z PLAY2 ASSY





SIDE B

SIDE B

Y PLAY1 ASSY

Z PLAY2 ASSY



Y Z


Y Z

SIDE A

The diagram illustrates the DNP2961-A board layout. Key components and callouts include:


- Top Section:** Callouts for **Y** CN7951 or **Z** CN8001, and **CN3001**.
- Top Right:** **JLCD1** connector with options **DWX4288-** and **DWX**.
- Center:** **TFT LCD** connected to **CN3006**.
- Left Side:** **CN3003** connector, **MANUAL SOLDER** area, and callouts **19** and **21**.
- Bottom Left:** Callouts **AC** CN9601 or **AD** CN9701, and **CN3004**.
- Bottom Right:** Callouts **G** CN4503 or **G** CN4515, and **CN3005**.
- Right Side:** **CONTACT** label and various component labels like **CN3011**, **CN3012**, **CN3013**, **CN3014**, **CN3015**, **CN3016**, **CN3017**, **CN3018**, **CN3019**, **CN3020**, **CN3021**, **CN3022**, **CN3023**, **CN3024**, **CN3025**, **CN3026**, **CN3027**, **CN3028**, **CN3029**, **CN3030**, **CN3031**, **CN3032**, **CN3033**, **CN3034**, **CN3035**, **CN3036**, **CN3037**, **CN3038**, **CN3039**, **CN3040**, **CN3041**, **CN3042**, **CN3043**, **CN3044**, **CN3045**, **CN3046**, **CN3047**, **CN3048**, **CN3049**, **CN3050**, **CN3051**, **CN3052**, **CN3053**, **CN3054**, **CN3055**, **CN3056**, **CN3057**, **CN3058**, **CN3059**, **CN3060**, **CN3061**, **CN3062**, **CN3063**, **CN3064**, **CN3065**, **CN3066**, **CN3067**, **CN3068**, **CN3069**, **CN3070**, **CN3071**, **CN3072**, **CN3073**, **CN3074**, **CN3075**, **CN3076**, **CN3077**, **CN3078**, **CN3079**, **CN3080**, **CN3081**, **CN3082**, **CN3083**, **CN3084**, **CN3085**, **CN3086**, **CN3087**, **CN3088**, **CN3089**, **CN3090**, **CN3091**, **CN3092**, **CN3093**, **CN3094**, **CN3095**, **CN3096**, **CN3097**, **CN3098**, **CN3099**, **CN3100**, **CN3101**, **CN3102**, **CN3103**, **CN3104**, **CN3105**, **CN3106**, **CN3107**, **CN3108**, **CN3109**, **CN3110**, **CN3111**, **CN3112**, **CN3113**, **CN3114**, **CN3115**, **CN3116**, **CN3117**, **CN3118**, **CN3119**, **CN3120**, **CN3121**, **CN3122**, **CN3123**, **CN3124**, **CN3125**, **CN3126**, **CN3127**, **CN3128**, **CN3129**, **CN3130**, **CN3131**, **CN3132**, **CN3133**, **CN3134**, **CN3135**, **CN3136**, **CN3137**, **CN3138**, **CN3139**, **CN3140**, **CN3141**, **CN3142**, **CN3143**, **CN3144**, **CN3145**, **CN3146**, **CN3147**, **CN3148**, **CN3149**, **CN3150**, **CN3151**, **CN3152**, **CN3153**, **CN3154**, **CN3155**, **CN3156**, **CN3157**, **CN3158**, **CN3159**, **CN3160**, **CN3161**, **CN3162**, **CN3163**, **CN3164**, **CN3165**, **CN3166**, **CN3167**, **CN3168**, **CN3169**, **CN3170**, **CN3171**, **CN3172**, **CN3173**, **CN3174**, **CN3175**, **CN3176**, **CN3177**, **CN3178**, **CN3179**, **CN3180**, **CN3181**, **CN3182**, **CN3183**, **CN3184**, **CN3185**, **CN3186**, **CN3187**, **CN3188**, **CN3189**, **CN3190**, **CN3191**, **CN3192**, **CN3193**, **CN3194**, **CN3195**, **CN3196**, **CN3197**, **CN3198**, **CN3199**, **CN3200**, **CN3201**, **CN3202**, **CN3203**, **CN3204**, **CN3205**, **CN3206**, **CN3207**, **CN3208**, **CN3209**, **CN3210**, **CN3211**, **CN3212**, **CN3213**, **CN3214**, **CN3215**, **CN3216**, **CN3217**, **CN3218**, **CN3219**, **CN3220**, **CN3221**, **CN3222**, **CN3223**, **CN3224**, **CN3225**, **CN3226**, **CN3227**, **CN3228**, **CN3229**, **CN3230**, **CN3231**, **CN3232**, **CN3233**, **CN3234**, **CN3235**, **CN3236**, **CN3237**, **CN3238**, **CN3239**, **CN3240**, **CN3241**, **CN3242**, **CN3243**, **CN3244**, **CN3245**, **CN3246**, **CN3247**, **CN3248**, **CN3249**, **CN3250**, **CN3251**, **CN3252**, **CN3253**, **CN3254**, **CN3255**, **CN3256**, **CN3257**, **CN3258**, **CN3259**, **CN3260**, **CN3261**, **CN3262**, **CN3263**, **CN3264**, **CN3265**, **CN3266**, **CN3267**, **CN3268**, **CN3269**, **CN3270**, **CN3271**, **CN3272**, **CN3273**, **CN3274**, **CN3275**, **CN3276**, **CN3277**, **CN3278**, **CN3279**, **CN3280**, **CN3281**, **CN3282**, **CN3283**, **CN3284**, **CN3285**, **CN3286**, **CN3287**, **CN3288**, **CN3289**, **CN3290**, **CN3291**, **CN3292**, **CN3293**, **CN3294**, **CN3295**, **CN3296**, **CN3297**, **CN3298**, **CN3299**, **CN3300**, **CN3301**, **CN3302**, **CN3303**, **CN3304**, **CN3305**, **CN3306**, **CN3307**, **CN3308**, **CN3309**, **CN3310**, **CN3311**, **CN3312**, **CN3313**, **CN3314**, **CN3315**, **CN3316**, **CN3317**, **CN3318**, **CN3319**, **CN3320**, **CN3321**, **CN3322**, **CN3323**, **CN3324**, **CN3325**, **CN3326**, **CN3327**, **CN3328**, **CN3329**, **CN3330**, **CN3331**, **CN3332**, **CN3333**, **CN3334**, **CN3335**, **CN3336**, **CN3337**, **CN3338**, **CN3339**, **CN3340**, **CN3341**, **CN3342**, **C**

AC JOG1 ASSY




SIDE B

AC JOG1 ASSY




SIDE A

AB JLCD2 ASSY



SIDE B

AB JLCD2 ASSY



AB AD

XDJ-XZ

SIDE A


Note:

The 1 and 2 Assys of JOG Assy have the same circuitry, parts, and board shapes.
Only printed information is different, because their part numbers and wiring numbers are different.
They are handled similarly in their production management.
Therefore, either 1 or 2 Assy of the respective Assys is assembled in the respective place.

注意:


JOGの1と2は別物そのもの、使用部品、基板形状は同じです。
生産上は1と2のASSYを管理していません。
このためそれぞれの場所には1と2のどちらかのASSYが配置されています。

AD JOG2 ASSY



SIDE B

AD JOG2 ASSY



AB AD

103

SIDE A

SIDE A (SECOND)

A01 ICT

XDJ-XZ



11.20 SW POWER SUPPLY

SIDE A

SIDE B

AF SW POWER SUPPLY

AF SW POWER SUPPLY



12. PCB PARTS LIST

- NOTES: ● Parts marked by “NSP” are generally unavailable because they are not in our Master Spare Parts List.
 ● The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
 ● When ordering resistors, first convert resistance values into code form as shown in the following examples.

Ex.1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47 k ohm (tolerance is shown by J = 5%, and K = 10%).

560 Ω — 56×10^1 — 561 RD1/APU $\boxed{5}$ $\boxed{6}$ $\boxed{J}$ J
 47 k Ω — 47×10^3 — 473 RD1/APU $\boxed{4}$ $\boxed{7}$ $\boxed{J}$ J
 0.5 Ω — R50 RN2H $\boxed{R}$ $\boxed{5}$ $\boxed{0}$ K
 1 Ω — 1R0 RS1P $\boxed{1}$ $\boxed{R}$ $\boxed{0}$ K

Ex.2 When there are 3 effective digits (such as in high precision metal film resistors).

5.62 k Ω — 562×10^1 — 5621 RN1/4PC $\boxed{5}$ $\boxed{6}$ $\boxed{2}$ $\boxed{J}$ F

Mark	No.	Description	Part No.	Mark	No.	Description	Part No.
LIST OF ASSEMBLIES				A			
	1..	MAIN ASSY	DWX4287	MAIN ASSY			
	1..	AUDIO ASSY	DWX4298	SEMICONDUCTORS			
NSP	1..	SUBA ASSY	DWM2724	Δ	IC	301,501,1801,1802	BD9328EFJ
	2..	MCIN ASSY	DWX4300	Δ	IC	302	BD00ICOWEFJ
	2..	HPJK ASSY	DWX4301	Δ	IC	303	IS31BL3555-ZLS4
	2..	MCTR ASSY	DWX4302	Δ	IC	502	MMPF0100F0AEP
	2..	CHF1 ASSY	DWX4303		IC	701	MCIMX6Q6AVT10AD
	2..	CHF2 ASSY	DWX4304		IC	901,902	K4B4G1646E-BYMA
	2..	PLAY1 ASSY	DWX4307		IC	1101	H337S3959
	2..	PLAY2 ASSY	DWX4308	NSP	IC	1102	DYW2156*
	2..	SER1 ASSY	DWX4310		*Part number of the initial firmware equipped		
	2..	SER2 ASSY	DWX4314		IC	1301,2301	TC7SH04FUS2
NSP	1..	PADA ASSY	DWM2720	Δ	IC	1803,1804	TPS2557DRB
	2..	LCDB ASSY	DWX4291		IC	1805	TUSB4020BIPHP
	2..	PAD1 ASSY	DWX4292	NSP	IC	2001	RTL8152B-VB-CG
	2..	PAD2 ASSY	DWX4293		IC	2002	TUSB4041IPAP
	2..	USBA ASSY	DWX4294		IC	2003,2306-2308	TC7SH08FUS2
	2..	CRFD ASSY	DWX4295		IC	2151	RTL8309M-CG
NSP	1..	UCOMA ASSY	DWM2721	NSP	IC	2302	R5S72690W266FP
	2..	UCOM ASSY	DWX4296	NSP	IC	2303	DYW2157*
	2..	EFSW ASSY	DWX4297		*Part number of the initial firmware equipped		
	1..	MIXER ASSY	DWX4299		IC	2304	TC7SZU04FUS2
NSP	1..	PNL1 ASSY	DWM2725		IC	2305	TC7SHU04FUS2
	2..	DCK1 ASSY	DWX4309		IC	2501	D810K013DZKB400
	2..	TMP1 ASSY	DWX4311		IC	2502	W9812G6KH-6
	2..	PWSW ASSY	DWX4312		IC	2606	SN74AUC1G08DCK
	2..	CHF3 ASSY	DWX4305		Q	301	RT3T22M
	2..	STL1 ASSY	DWX4319		Q	302-305,2001	2SA1576A
	2..	STL2 ASSY	DWX4320		Q	306	LTC023JEB
	2..	STL3 ASSY	DWX4321		Q	1401	LTC014EEB
NSP	1..	PNL2 ASSY	DWM2726		Q	1801,1802,2303	RT3N22M
	2..	DCK2 ASSY	DWX4313		Q	1803	HN1C01FUS1
	2..	TMP2 ASSY	DWX4315		Q	2002,2302	LTC024EEB
	2..	CHF4 ASSY	DWX4306		D	301	RB060MM-30TF
	2..	JOG1 ASSY	DWX4317		D	302-305	1SS355VM
	2..	JOG2 ASSY	DWX4318		D	501	RB160M-60
	2..	STL4 ASSY	DWX4322		D	1801,1802	UDZV5R1
NSP	1..	JOGA ASSY	DWM2719	MISCELLANEOUS			
	2..	JLCD1 ASSY	DWX4288	L	105-108,110,111	INDUCTOR	CTF1545
	2..	JLCD2 ASSY	DWX4289	L	109	POWER INDUCTOR	ATH7053
	2..	XPAD ASSY	DWX4290	L	301	COIL (47 uH)	CTH1475
Δ	1..	SW POWER SUPPLY	DWR1548	L	302	SMD SPL INDUCTOR	CTH1527
				L	501	SMD SPL INDUCTOR	CTH1501
				L	502	SMD SPL INDUCTOR	CTH1531
				L	503-506	SMD SPL INDUCTOR	CTH1530
				L	1101	CHIP SOLID INDUCTOR	XTL3010
				L	1801,1802	INDUCTOR	CTH1253
				L	1803,1808,1809,2005	COIL	ATH7015
				L	2151-2156	CHOKE COIL	ATH7098
				L	2301-2303,2601	INDUCTOR	CTF1545
				L	2304	CHIP COIL (33 uH)	LCTAW330J2520

Mark	No.	Description	Part No.
A	L	2305,2306 CHIP SOLID INDUCTOR	QTL1013
	L	2307 CHIP BEADS	VTL1129
	L	2501 SMD FERRITE BEADS	CTF1823
	F	1801,1802,2001-2003 EMI FILTER	CCG1352
	F	2151,2152 EMI FILTER	CCG1352
	F	2501 EMI FILTER	DTL1106
	JA	2001 USB CONNECTOR	DKN1237
	JA	2151-2153 RJ45 CONNECTOR	AKN7115
	KN	2151,2152 SCREW PLATE	VNE1948
	X	1401 RESONATOR (32.768 kHz)	CSS1807
B	X	1402 CRYSTAL TRANSDUCER (24 MHz)	DSS1208
	X	1801,2002 RESONATOR (24 MHz)	CSS1773
	X	2001,2151 CRYSTAL (25.000 MHz)	DSS1205
	X	2301 RESONATOR (48.000 MHz)	CSS1760
	X	2302 CRYSTAL RESONATOR (13.333 3 MHz)	CSS1840
	CN	101,103 FFC/FPC CONNECTOR	CKS6543
	CN	102 19P RECEPTACLE	AKP7199
	CN	104,105 FFC/FPC CONNECTOR	CKS6645
	CN	1801,1802 CONNECTOR	AKM1277
	VA	2001-2003 SMD VARISTOR	EZJZ1V80010

RESISTORS

C	R	305	RS1/4SA1R0J
	R	308,317	RS1/10SR472J
	R	312	RS1/10SR151J
	R	313	RS1/16SS2701D
	R	314	RS1/16SS6201D
	R	319,505,506	RS1/16SS1502D
	R	321	RS1/16SS2202D
	R	322,2380	RS1/16SS5601D
	R	323,2206	RS1/16SS6800D
	R	324	RS1/16SS3301D
D	R	325,336,1808,1812	RS1/16SS1002D
	R	329	RS1/10SR3302F
	R	337	RS1/16SS1202D
	R	338,507	RS1/16SS8201D
	R	339	RS1/16SS3302D
	R	514,517,702,707	RS1/10SR0R0J
	R	515	RS1/10SR561J
	R	521	RS1/16SS1002F
	R	708,905,908	RS1/16SS2400F
	R	903,904	RS1/16SS1001D
E	R	1108,1109,1120,2501	RAB4CQ680J
	R	1127	RAB4CQ222J
	R	1139,1140	RAB4CQ220J
	R	1328,1333,1335	RAB4CQ470J
	R	1502,1505,1530-1533	RAB4CQ103J
	R	1507,1526-1529	RAB4CQ472J
	R	1803,1804	RS1/10SR220J
	R	1806,1810	RS1/10SR1100D
	R	1807,1811	RS1/16SS4702D
	R	1821,1822	RS1/10SR2702F
F	R	1823,1824	RS1/10SR5602F
	R	1839,2052	RS1/16SS4300D
	R	1840,2051	RS1/16SS9101D
	R	1847	RS1/16SS1201F
	R	1848	RS1/16SS6801D
	R	1872,1873	RS1/10SR102J
	R	2005	RS1/16SS91R0F
	R	2006	RS1/16SS2401D
	R	2044	RS1/16SS1002D
	R	2045	RS1/16SS9102F
	R	2047,2407,2408	RS1/10SR0R0J
	R	2172,2197	RS1/8SQ0R0J
	R	2205	RS1/16SS1801D
	R	2301-2304	RAB4CQ560J
	R	2355,2392	RAB4CQ103J
	R	2400,2401	RAB4CQ101J
	R	2405	RAB4CQ104J
	R	2413,2414	RS1/10SR105J
	R	2422	RAB4CQ223J

Mark	No.	Description	Part No.
R	2502		RAB4CQ680J
R	2509,2510,2516		RAB4CQ820J
R	2517,2518		RAB4CQ330J
R	2528-2531		RAB4CQ470J
	Other Resistors		RS1/16SS###J

CAPACITORS

C	101,303,316,320 (10 uF/10 V)	DCH1201
C	103-107,109,116	CKSSYB102K50
C	108,112,113,117	CKSSYB104K10
C	111,114,115,134	CKSSYB104K16
C	119-123,321,2303	CEVW101M16
C	124,130,136,140	CKSSYB104K10
C	129,135,137,139	CKSSYB102K50
C	138,142,304,331	CKSSYB104K16
C	141,144,153,306	CKSSYB102K50
C	143,155,305,309	CKSSYB104K10
C	160,1837,1838 (100 uF/16 V)	CCH1565
C	162,164,342,574 (0.1 uF/35 V)	ACE7100
C	301,302,334,335 (10 uF/16 V)	DCH1263
C	307,325,505,512	CCSSCH102J50
C	310,315,318,322	CKSSYB104K10
C	311,524,536,557	CKSRYB474K10
C	312	CCSRCH121J50
C	313	CKSSYB153K16
C	314,1809,1810,2151	CKSSYB102K50
C	317,328,523,526	CKSRYB105K10
C	319,513,1402,1405	CKSSYB103K16
C	324	CKSSYB472K25
C	326,329,339-341	CKSSYB104K10
C	330,515,516,529 (10 uF/10 V)	DCH1201
C	332,338,503,506	CKSSYB104K16
C	333	CEVW221M4
C	501,1803-1806 (10 uF/16 V)	DCH1263
C	507	CKSSYB682K25
C	511,514,525,528	CKSSYB104K10
C	517 (1000 pF/63 V)	ACE7099
C	518 (100 uF/6.3 V)	ACH7275
C	519,520,549 (22 uF/6.3 V)	DCH1256
C	527,701,703-710	CKSSYB224K6R3
C	530,545,909,910	CKSRYB105K10
C	532,535,538,540 (4.7 uF/10 V)	CCG1201
C	533,537,539,541	CKSSYB104K10
C	542,546,548,551	CKSSYB104K10
C	543,544,547,565 (4.7 uF/10 V)	CCG1201
C	550	CCSRCH102J50
C	552-555,558 (22 uF/6.3 V)	DCH1256
C	556,559,740,907	CKSSYB104K10
C	560-563,571-573 (22 uF/6.3 V)	DCH1256
C	564	CKSRYB474K10
C	570,1101,1106,1109	CCSSCH102J50
C	702,711,715,734 (22 uF/6.3 V)	DCH1256
C	712-714,716-718	CKSSYB224K6R3
C	719,722,728,908 (4.7 uF/10 V)	DCH1201
C	720,721,723-727	CKSSYB224K6R3
C	729-733,735-739	CKSSYB224K6R3
C	741,743,745-747	CKSSYB224K6R3
C	742,744,748,750 (22 uF/6.3 V)	DCH1256
C	749,751-755	CKSSYB224K6R3
C	901-906,913-924	CKSSYB224K6R3
C	911,912,925,1107	CKSSYB104K10
C	926,1817,1818,1826 (4.7 uF/10 V)	DCH1201
C	927-932,1105	CKSSYB224K6R3
C	1102,2001,2416	CCSSCH100D50
C	1108	CKSSYB222K50
C	1301,1304,1503	CCSSCH470J50
C	1309,1828,1829,1846	CKSSYB104K10
C	1401,1403	CCSSCH9R0D50
C	1807,1808,1811-1814	CKSSYB104K16
C	1815,1816,1823,1824	CKSSYB103K16
C	1821,1822	CEHVAW101M6R3

Mark	No.	Description	Part No.
C	1827,1833-1836,1843	(4.7 uF/10 V)	DCH1201
C	1831,1832,1845,1847		CKSSYB103K16
C	1839,1840,2024,2025		CCSSCH101J50
C	1844,1874-1876,2002	(4.7 uF/10 V)	DCH1201
C	1848,1849,1851		CKSSYB104K10
C	1850,1852,1854,1856		CKSSYB103K16
C	1853,1855,2003,2047		CCSSCH120J50
C	1857-1860,1863,1865		CKSSYB104K10
C	1861,1862,1864		CKSSYB103K16
C	1866-1869,2037,2040		CKSSYB103K16
C	1870-1872,1877,1878		CKSSYB104K10
C	1873,1883,1884,2026		CCSSCH102J50
C	1879,1880,2166		CKSSYB104K16
C	2004-2012,2014,2017		CKSSYB104K10
C	2015,2016,2019,2540		CKSRYP105K10
C	2018,2036,2039,2043		CKSSYB104K10
C	2028,2041,2152		CCSSCH102J50
C	2029,2032,2156,2159	(4.7 uF/10 V)	DCH1201
C	2042,2044,2048,2050		CKSSYB103K16
C	2045,2046,2049,2052		CKSSYB104K10
C	2051,2054-2056		CKSSYB103K16
C	2053,2165,2415,2417		CCSSCH120J50
C	2057-2059,2063,2065		CKSSYB104K10
C	2060	(2.2 uF/10 V)	CCG1218
C	2066,2368,2375,2378		CCSSCH471J50
C	2067,2154,2155,2157		CKSSYB104K10
C	2068	(22 uF/16 V)	CCG1254
C	2158,2160,2162-2164		CKSSYB104K10
C	2161,2414		CCSSCH150J50
C	2167-2177,2301,2302		CKSSYB104K10
C	2184-2186,2397,2538		CCSSCH102J50
C	2187,2314,2319,2320		CKSSYB102K50
C	2305,2307-2313		CKSSYB104K10
C	2306,2507		CKSSYB471K50
C	2315-2318,2321,2322		CKSSYB104K10
C	2324,2325,2328-2331		CKSSYB104K10
C	2326,2327,2332,2333		CKSSYB102K50
C	2334-2337,2340-2343		CKSSYB104K10
C	2338,2339,2344,2345		CKSSYB102K50
C	2346-2348,2351,2352		CKSSYB104K10
C	2349,2350,2353,2359		CKSSYB102K50
C	2354-2358,2361,2367		CKSSYB104K10
C	2360		CKSSYB221K50
C	2362,2370,2371,2386		CKSSYB102K50
C	2363-2366,2369,2372		CKSSYB103K16
C	2373,2385,2387,2398	(4.7 uF/10 V)	DCH1201
C	2374,2381-2383,2394		CKSSYB104K10
C	2376,2377,2379,2392		CKSSYB103K16
C	2380,2419		CCSSCH471J50
C	2384		CEVW101M16
C	2389,2390,2408,2409		CKSSYB102K50
C	2393,2400,2406,2407		CKSSYB103K16
C	2395,2401,2403-2405		CKSSYB104K10
C	2396,2411,2412,2537		CCSSCH101J50
C	2399,2402,2541	(4.7 uF/10 V)	DCH1201
C	2410,2418,2422,2423		CKSSYB104K10
C	2413,2420,2421,2503		CKSSYB102K50
C	2501,2505,2603,2610		CKSSYB104K10
C	2502		CEVW101M4
C	2504,2506,2508-2510		CKSSYB103K16
C	2511,2513,2515,2517		CKSSYB102K50
C	2512,2514,2516,2518		CKSSYB103K16
C	2519,2521,2523,2525		CKSSYB102K50
C	2520,2522,2524,2526		CKSSYB103K16
C	2527,2529,2531,2533		CKSSYB102K50
C	2528,2530,2532,2534		CKSSYB103K16
C	2535		CKSSYB102K50
C	2536,2539,2542-2548		CKSSYB103K16
C	2602,2609,2612		CCSSCH102J50
C	2608,2611		CKSSYB103K16

Mark	No. Description	Part No.
	C 2613	CKSSYB104K10
B AUDIO ASSY SEMICONDUCTORS		
	IC 5101,5102,5104-5107	TC7SH08FUS2
	IC 5103	TC7WHU04FKS1
	IC 5109	TC7SH08FUS2
	IC 5201,5401,6001-6003	NJM4580MD
	IC 5202,5203,5402,5403	NJM2121MD
	IC 5204,5404	AK5386VT
	IC 5601,5602	NJM2121MD
	IC 5603,5604	AK5358AET
	IC 5801	AK4384ET
	IC 5802	AK4458VN
	IC 6004,6005,6203,6204	NJM4580DD
	IC 6201,6202,6401	NJM4580MD
	IC 6402	NJM4565MD
⚠	IC 6601	MM1856A50N
⚠	IC 6602,6603	BD9328EFJ
⚠	IC 6604	NJM2831F33
⚠	IC 6605,6606	BD9851EFV
⚠	IC 6607	NJM78M09DL1A
⚠	IC 6608	NJM2872BF33
⚠	IC 6609,6610	NJM7805DL1A
⚠	IC 6611	NJM78M15DL1A
⚠	IC 6612	NJM79M15DL1A
	Q 5201,5203,5401,5403	2SK3320
	Q 5202,5402,5601	LTC114EUB
	Q 6001	RN2903
	Q 6002-6011,6014-6017	INC2002AC1
	Q 6201-6208,6401,6402	INC2002AC1
	Q 6405,6406	2SK209
	Q 6407,6408	INC2002AC1
	Q 6409,6411,6606,6808	2SC4081
	Q 6410,6412,6801-6806	2SA1576A
	Q 6413,6415	2SCR573D3
	Q 6414,6416	2SAR573D3
	Q 6601	LTC024EEB
⚠	Q 6602,6604	RSQ030P03
⚠	Q 6603	RSR020P05
⚠	Q 6605	RSQ045N03
⚠	Q 6607	RTQ040P02
	Q 6807	LTC014YEB
	Q 6809,6903	LSCR523UB
	Q 6901	RT3T22M
	Q 6902	RT3N22M
	Q 6904	HN1A01FUS1
	D 6201,6401-6404,6608	1SS355VM
	D 6602-6606	RB162MM-40TF
	D 6609,6610	RB501V-40
	D 6801-6806,6904	1SS355VM
	D 6901	UDZV7R5
	D 6902	RB160M-30
MISCELLANEOUS		
	L 5101 CHIP BEADS	VTL1126
	L 6601 POWER INDUCTOR (0.22 uH)	ATH7053
	L 6602,6603 CHOKE COIL (22 uH)	CTH1561
	L 6604-6607 POWER INDUCTOR (22 uH)	ATH7011
	JA 5201,5401 4P PIN JACK	DKB1090
	JA 5601,6001 RCA JACK	DKB1122
	JA 6002,6003 CANON CONNECTOR	DKB1093
	JA 6201,6202 6.5 DIA JACK	DKN1653
	JA 6401,6402 6.5 DIA JACK	DKN1652
	X 5101 CRYSTAL OSCILLATOR (22.579 2 MHz)	DSS1215
	CN 5001 19P PLUG	AKM7077
	CN 5002 FFC/FPC CONNECTOR	CKS6543
	CN 5601 9P CONNECTOR	09R-1.25FJ

Mark	No.	Description	Part No.
	CN 6401	CONNECTOR	AKM1277
	CN 6601	CONNECTOR	DKN1661
A	VA 5201-5206,5401-5406	VARISTORS	EZJZ1V270RM
	VA 5601-5603,6001-6009	VARISTORS	EZJZ1V270RM
	VA 6201-6205,6401-6403	VARISTORS	EZJZ1V270RM

RESISTORS

R 5130,6678,6679	RS1/10SR0R0J
R 5201,5203-5205,5401	RS1/16SS1000D
R 5202,5207,5209,5210	RS1/16SS2000D
R 5206,5211,5214,5216	RS1/16SS4702D
R 5212,5213,5222,5223	RN1/16SE1201D

R 5217,5224,5416,5424	RS1/10SR470J
R 5218,5227,5420,5427	RN1/16SE1001D
R 5220,5225,5228,5232	RN1/16SE1501D
R 5231,5235,5429,5435	RN1/16SE2703D
R 5234,5237,5434,5437	RN1/16SE2202D

R 5239,5240,5439,5440	RS1/16SS3001D
R 5241,5242,5441,5613	RS1/10SR2701D
R 5243,5244,5443,5444	RS1/16SS2701D
R 5245,5246,5445,5446	RS1/16SS6800D
R 5402,5407,5409,5410	RS1/16SS2000D

R 5403-5405,5601,5602	RS1/16SS1000D
R 5406,5411,5412,5415	RS1/16SS4702D
R 5413,5414,5422,5423	RN1/16SE1201D
R 5421,5425,5428,5430	RN1/16SE1501D
R 5442	RN1/16SE2701D

R 5603,5604	RS1/16SS2000D
R 5605,5606,6613	RS1/16SS4702D
R 5609-5612,6666	RS1/16SS3001D
R 5614,5616	RS1/10SR8201D
R 5615,6021-6028	RS1/10SR2701D

R 5617,5618,5621,5622	RS1/16SS3601D
R 5619,5620,5623,5624	RS1/16SS8200D
R 5829-5831	RS1/4SAOR0J
R 6001-6004	RS1/10SR513J
R 6005-6012	RS1/10SR3301D

R 6013-6020	RS1/10SR1202D
R 6029-6036	RS1/8SQ5600F
R 6037-6040,6049-6052	RS1/10SR223J
R 6041-6044	RS1/8SQ2700F
R 6053-6060	RS1/10SR1800F

R 6061,6062	RS1/10SR2202D
R 6063,6064,6405-6408	RS1/10SR1002D
R 6065-6072,6225-6232	RS1/10SR5601D
R 6073,6074,6413,6414	RS1/10SR6800D
R 6075-6082,6233-6240	RS1/10SR6801D

R 6083,6084,6427,6428	RS1/10SR104J
R 6085-6092	RS1/4SA471J
R 6093,6094,6107-6110	RS1/10SR183J
R 6095-6098,6245-6248	RS1/10SR2201D
R 6111,6112,6253-6256	RS1/10SR330J

R 6113,6114,6117,6120	RS1/16SS15R0D
R 6121-6124 (22 ohm)	DCN1198
R 6201-6208	RS1/10SR4701D
R 6209-6216	RS1/10SR1602D
R 6217-6224,6409-6412	RS1/10SR3601D

R 6241-6244 (330 ohm)	DCN1200
R 6249-6252,6257-6260	RS1/10SR183J
R 6261-6264,6641,6647	RS1/10SR330J
R 6401-6404	RS1/10SR5601D
R 6415,6416	RS1/10SR183J

R 6421,6422	RS1/16SS3300D
R 6425,6426	RS1/16SS3901D
R 6429,6430	RN1/16SE1502D
R 6431,6432	RS1/16SS3301D
R 6438,6440	RS1/8SQ680J

R 6441-6444	RN1/16SE3301D
R 6445-6448,6663	RS1/16SS1001D
R 6449-6452,6612,6615	RS1/16SS1801D
R 6453-6460	RS1/4SA220J

Mark	No.	Description	Part No.
R	6601,6682-6685		RS1/8SQ0R0J
R	6610,6623,6626,6655		RS1/16SS6802D
R	6611		RS1/16SS3302D
R	6614,6619,6621,6634		RS1/16SS1002D
R	6616		RS1/16SS1802D
R	6617		RS1/16SS2201D

R 6618,6620,6638	RS1/16SS1502D
R 6622,6625,6646,6651	RS1/16SS3002D
R 6628	RS1/16SS5102D
R 6629	RS1/16SS5601D
R 6631	RS1/16SS1803D

R 6633	RS1/16SS2200D
R 6635,6658,6659	RS1/16SS1002D
R 6639,6648	RS1/10SR220J
R 6649,6652	RS1/10SR105J
R 6654	RS1/16SS6201D

R 6656	RS1/16SS6802D
R 6662	RS1/16SS6202D
R 6664	RS1/16SS1503D
R 6665	RS1/16SS5101D
R 6669	RS1/16SS2002D

Other Resistors RS1/16SS###J

CAPACITORS

C 5001,5003,5004,5218	CKSSYB104K16
C 5007,5009,5014,5015	CKSSYB104K10
C 5101,5106,5109,5112	CKSSYB104K10
C 5102,5107,5111,5113	CCSSCH102J50
C 5103,5206,5210-5212	CCSSCH101J50

C 5104,5110,5632,5806	CKSSYB103K16
C 5116	CCSSCH180J50
C 5117,5119,5121,5123	CKSSYB104K10
C 5118,5120,5122,5124	CCSSCH102J50
C 5127,5240,5243,5247	CKSSYB104K10

C 5128,5223,5226,5241	CCSSCH102J50
C 5201,5204,5401,5404	CKSSYB102K50
C 5202,5205,5402,5405	CKSRBY104K25
C 5203,5207,5403,5407	CCSSCH221J50
C 5208,5209,5214,5219	CCSSCH471J50

C 5213,5217,5413,5417	CKSRBY123K50
C 5215,5220,5255,5415	CCSSCH331J50
C 5216,5221,5416,5421	CEVW101M16
C 5222,5225,5422,5425 (0.012 uF/63 V)	ACE7125
C 5224,5227,5424,5427 (3 300 pF/50 V)	DCG1049

C 5228,5230-5232,5263	CCSSCH101J50
C 5229,5233,5429,5433 (100 uF/25 V)	CCH2000
C 5234,5235,5408,5409	CCSSCH471J50
C 5236,5237,5249,5250 (220 uF/16 V)	CCH2090
C 5238,5242,5438,5442 (10 uF/16 V)	CCH1998

C 5239,5439,5809,5812 (1 uF/25 V)	ACE7129
C 5244,5423,5426,5441	CCSSCH102J50
C 5245,5445,5631,5634 (10 uF/10 V)	DCH1201
C 5248,5440,5443,5447	CKSSYB104K10
C 5251,5252,5449,5450 (0.1 uF/35 V)	ACE7100

C 5253,5826,6720,6784 (0.01 uF/50 V)	ACE7113
C 5254,6076,6083 (1 000 pF/50 V)	ACE7120
C 5264,6235-6238 (470 pF/50 V)	ACE7119
C 5265,5854,6618,6754	ACE7115
C 5406,5410-5412,5428	CCSSCH101J50

C 5414,5419,5434,5435	CCSSCH471J50
C 5418,6423,6601,6606	CKSSYB104K16
C 5420,6005-6008,6074	CCSSCH331J50
C 5430-5432,5605,5606	CCSSCH101J50
C 5436,5437,5811,5828 (220 uF/16 V)	CCH2090

C 5444,5608,5609,5637	CCSSCH102J50
C 5448,5633,5638,5641	CKSSYB104K10
C 5601,6064	CKSSYB102K50
C 5602,5607,5610,6428	CKSRBY104K25
C 5603,5604,6401,6402	CCSSCH221J50

C 5612,5620	CEVW101M25
-------------	------------

Mark	No.	Description	Part No.
C	5616-5619,5643,5645		CCSSCH101J50
C	5621,5622,5626,5627		CCSSCH471J50
C	5623,5628,6634,6636 (100 uF/16 V)		CCH1565
C	5624,5625,5810		CEVW101M16
C	5629,5630 (22 uF/6.3 V)		DCH1256
C	5635,5636		CEVW220M16
C	5639,5802,5818,5819		CCSSCH102J50
C	5640,5642,5646,5647 (10 uF/10 V)		DCH1201
C	5644,5648-5651,5801		CKSSYB104K10
C	5803		CEVW220M6R3
C	5804,5807,5817,5831		CKSSYB104K10
C	5808,6620-6622,6669		CKSSYB103K16
C	5813,5834,5841,5857 (1 uF/25 V)		ACE7129
C	5814,5827,5840,5853 (0.1 uF/35 V)		ACE7100
C	5815,5839,6077,6084 (0.01 uF/63 V)		ACE7097
C	5816,6625,6662,6681		CKSRYB105K10
C	5820,5821,5829,5835		CCSSCH101J50
C	5823,5830,5832,5836		CCSSCH102J50
C	5833,6623,6624,6652		CKSSYB104K10
C	5843,6035,6036,6053 (220 uF/16 V)		CCH2090
C	5855,6078,6085,6629 (0.1 uF/35 V)		ACE7100
C	5856,5868,5869		CCSSCH101J50
C	6001-6004,6743,6744 (100 uF/25 V)		CCH2000
C	6009-6016,6018,6021		CCSSCH101J50
C	6023,6024,6027,6030		CCSSCH101J50
C	6037,6040,6042,6043		CCSSCH101J50
C	6045-6052,6205-6228		CCSSCH101J50
C	6054,6056,6057,6434 (220 uF/16 V)		CCH2090
C	6058,6059,6066-6069 (1 000 pF/63 V)		ACE7099
C	6070,6072,6239,6432		CKSSYB103K25
C	6081		CCSSCH331J50
C	6201-6204,6714		CCSSCH271J50
C	6229-6234,6403,6407		CEVW101M16
C	6404,6406,6420,6421		CCSSCH121J50
C	6408,6409,6610-6612		CCSSCH101J50
C	6411,6412,6658,6684		CEVW101M16
C	6413,6414		CEVW470M16
C	6415,6416,6424,6426		CCSSCH102J50
C	6418,6419 (2 200 pF/63 V)		ACE7116
C	6422,6425		CCSSCH330J50
C	6427,6435-6438		CKSRYB104K16
C	6430,6715,6716,6748		CKSRYB104K25
C	6439,6641,6902,6904 (220 uF/16 V)		CCH2090
C	6442,6443		CCSSCH121J50
C	6602,6603		CKSRYB474K16
C	6604,6605,6630,6633 (10 uF/16 V)		DCH1263
C	6607,6619,6639,6640		CKSSYB104K16
C	6608,6609,6615-6617		CCSSCH102J50
C	6628 (0.01 uF/63 V)		ACE7097
C	6631,6689,6717,6761 (0.1 uF/35 V)		ACE7100
C	6635,6693,6757,6768 (1 uF/25 V)		ACE7129
C	6637 (3.3 uF/16 V)		DCE1029
C	6644		CKSSYB332K50
C	6645		CCSSCH821J50
C	6650,6651,6679,6700		CCSSCH102J50
C	6653,6671,6794,6796		CKSSYB104K16
C	6654,6656,6709,6710 (10 uF/10 V)		DCH1201
C	6655,6657,6670,6672 (10 uF/16 V)		DCH1263
C	6659,6765,6770,6773 (100 uF/16 V)		CCH1565
C	6660		CKSRYB474K10
C	6661		CKSRYB334K10
C	6664		CCSSCH221J50
C	6665		CKSSYB223K16
C	6666		CCSSCH680J50
C	6673,6676,6680,6686 (22 uF/16 V)		CCG1254
C	6674,6677		CCSSCH561J50
C	6675,6683,6690,6786 (10 uF/16 V)		DCH1263
C	6678,6747,6753,6755		CCSSCH101J50
C	6682,6687,6707,6708		CKSSYB104K10
C	6685,6691		CKSRYB105K16

Mark	No.	Description	Part No.
C	6688,6695,6697,6725		CKSRYB105K10
C	6696,6730		CKSQYB105K16
C	6698 (2.2 uF/10 V)		CCG1218
C	6702,6706		CKSSYB682K25
C	6703 (4.7 uF/10 V)		CCG1201
C	6713		CCSSCH471J50
C	6718,6719 (10 uF/35 V)		CCG1236
C	6721,6722,6728,6729		CCSSCH102J50
C	6724,6727,6731		CKSQYB105K25
C	6726		CKSRYB105K10
C	6734,6737,6745,6746		CKSQYB334K50
C	6738,6741,6742,6749		CCSSCH102J50
C	6739,6740 (10 uF/10 V)		DCH1201
C	6750		CKSSYB103K25
C	6751,6756,6760		CCSRCH102J50
C	6752,6762,6763,6777		CCSSCH102J50
C	6758,6759		CCSRCH101J50
C	6764		CKSRYB104K10
C	6766,6767		CKSRYB104K25
C	6769,6771,6772 (1 uF/25 V)		ACE7129
C	6776		CCSSCH101J50
C	6779,6780		CCSRCH331J50
C	6783 (0.1 uF/35 V)		ACE7100
C	6785 (4 700 pF/63 V)		ACE7115
C	6787 (10 uF/16 V)		DCH1263
C	6792 (100 uF/16 V)		CGH1565
C	6793,6795		CCSSCH102J50
C	6801,6903		CKSSYB103K16
SUBA ASSY			
Consists of			
MCIN ASSY			
HPJK ASSY			
MCTR ASSY			
CHF1 ASSY			
CHF2 ASSY			
PLAY1 ASSY			
PLAY2 ASSY			
SER1 ASSY			
SER2 ASSY			
C	D	F	J
K	W	X	Y
Z			
SUBA ASSY			
SEMICONDUCTORS			
IC	7601,7602		NJM4580MD
Q	7601-7604		2SK209
Q	7701,7702		INC2002AC1
Q	7951,7952,8001,8002		LTC114YUB
Q	8301,9401		LTC124EUB
D	7701-7704		DF2B18FU
D	7951,8001		LTL17KCGP4J
D	7952,8002		LTL17KSL5D-P
D	8301-8305,9401-9405		1SS355VM
MISCELLANEOUS			
L	7601,7602 CHIP SOLID INDUCTOR		XTL3010
JA	7601,7602 XLR SOCKET		DKB1124
JA	7701 STEREO MINI JACK		XKN3017
JA	7702 6.5 DIA JACK		DKN1669
KN	7701 SCREW PLATE		VNE1948
S	7951,7952,8001 TACTILE SWITCH		DSG1151
S	8002 TACTILE SWITCH		DSG1151
S	8301-8305,9401-9405 TACT SWITCH		DSG1089
CN	7601 CONNECTOR		CKS3561
CN	7602 9P CONNECTOR		09P-1.25FJ
CN	7701 L-PLUG(6P)		KM200NA6L
CN	7751 PLUG		CKS3533
CN	7901,7911 L-PLUG(3P)		KM200NA3L
CN	7951,8001 10P CONNECTOR		VKN1241
CN	7952,8002 4P JUMPER CONNECTOR		52147-0410

SUBA ASSY
Consists of
MCIN ASSY
HPJK ASSY
MCTR ASSY
CHF1 ASSY
CHF2 ASSY
PLAY1 ASSY
PLAY2 ASSY
SER1 ASSY
SER2 ASSY

C D F J K W X Y Z
SUBA ASSV

SEMICONDUCTORS

IC 7601,7602	NJM4580MD
Q 7601-7604	2SK209
Q 7701,7702	INC2002AC1
Q 7951,7952,8001,8002	LTC114YUB
Q 8301,9401	LTC124EUB
D 7701-7704	DF2B18FU
D 7951,8001	LTL17KCGP4J
D 7952,8002	LTL17KSL5D-P
D 8301-8305,9401-9405	1SS355VM

MISCELLANEOUS

L 7601,7602 CHIP SOLID INDUCTOR	XTL3010
JA 7601,7602 XLR SOCKET	DKB1124
JA 7701 STEREO MINI JACK	XKN3017
JA 7702 6.5 DIA JACK	DKN1669
KN7701 SCREW PLATE	VNE1948
S 7951,7952,8001 TACTILE SWITCH	DSG1151
S 8002 TACTILE SWITCH	DSG1151
S 8301-8305,9401-9405 TACT SWITCH	DSG1089
CN 7601 CONNECTOR	CKS3561
CN7602 9P CONNECTOR	09P-1.25FJ
CN7701 L-PLUG(6P)	KM200NA6L
CN7751 PLUG	CKS3533
CN7901,7911 L-PLUG(3P)	KM200NA3L
CN7951,8001 10P CONNECTOR	VKN1241
CN7952,8002 4P JUMPER CONNECTOR	52147-0410

Mark	No.	Description	Part No.
	CN 8301,9401	4P JUMPER CONNECTOR	52147-0410
	CN 8302,9402	12P CONNECTOR	VKN1243
	VA 7601-7606,7702,7703	VARISTORS	EZJZ1V270RM

RESISTORS

R 7601-7604	RN1/16SE1000D
R 7605-7608	RN1/16SE2200D
R 7609-7612	RN1/16SE3301D
R 7613,7614,7627,7628	RN1/16SE2701D
R 7615,7616,7624,7626	RN1/16SE4701D

R 7617,7618,7621,7622	RN1/16SE1501D
R 7619,7620	RN1/16SE8200D
R 7623,7625	RS1/10SR1500D
R 7631,7632	RN1/16SE1201D
R 7633,7634	RS1/10SR5102D

VR 7751,7752	ROTARY VR	DCS1123
VR 7901,7911	SLIDE VR	DCV1027
Other Resistors		RS1/10SR###J

CAPACITORS

C 7601,7603,7609-7616	CCSRCH102J50
C 7602,7604,7623,7624	CKSRYB103K50
C 7605-7608 (0.01 uF/50 V)	ACE7113
C 7617-7620,7627,7628	CCSRCH471J50
C 7621,7622	CCSRCH101J50

C 7625,7626	CCSRCH331J50
C 7635,7636	CEAT101M25
C 7638,7640,7642	CCSRCH102J50
C 7643,7644	CEANP101M16
C 7645,7646	CCSRCH471J50

C 7647,7648	CKSRYB102K50
C 7649,7650	CKSRYB104K25
C 7701,7702,7710,7711 (220 uF/6.3 V)	DCH1344
C 7703-7706	CKSRYB223K50
C 7707,7709	CKSRYB103K50

C 7951,7952,8001,8002	CKSRYB103K25
C 7954,8004 (10 uF/10 V)	DCH1201
C 7955,8005	CKSRYB104K10

PADA ASSY**Consists of****LCDB ASSY****PAD1 ASSY****PAD2 ASSY****USBA ASSY****CRFD ASSY****E N O P A E****PADA ASSY****SEMICONDUCTORS**

IC 3601	BU90R104
IC 3602-3604	74LCX541FT
IC 3605	R1290K103A
IC 3606	AK4187VN
IC 3901,3902,4101,4102	74VHC595FT

Q 3601	2SAR502UB
Q 3603-3614	LTC023JEB
Q 3901-3908,3929-3934	LTC123JUB
Q 3917,3919,3921,4117	LTC124EUB
Q 3918,3920,3922,4118	2SB1689

Q 3923-3928,3935-3940	LSCR523UB
Q 3941-3946,4101-4108	LTC123JUB
Q 4119,4121	LTC124EUB
Q 4120,4122	2SB1689
Q 4123-4128,4135-4140	LSCR523UB

Q 4129-4134,4141-4146	LTC123JUB
D 3602-3604	RB548W
D 3605	RB162MM-40TF
D 3606,3619-3622	NHSW146A-A21460
D 3607	FC-F1608BAK5

Mark	No.	Description	Part No.
D	3608,3609,3611-3618		SML-D12M8W(NP)
D	3610		SML-D12V8W
D	3909-3912,3921-3924		NSSM124F-A21107
D	3913-3920,3925-3932		1SS355VM
D	3933,3935,3937,3939		NSSM124F-A21107

D	3934,3936,3938	1SS355VM
D	3940-3960,4113-4120	1SS355VM
D	4109-4112,4121-4124	NSSM124F-A21107
D	4125-4132,4134,4136	1SS355VM
D	4133,4135,4137,4139	NSSM124F-A21107

D	4138,4140-4160	1SS355VM
---	----------------	----------

MISCELLANEOUS

L	3601,3623	CHIP BEEDS FILTER	BTX1042
L	3602	CHIP BEEDS FILTER	BTX1047
L	3603,3604	CHIP SOLID INDUCTOR	XTL3010
L	3605,3612-3621	CHIP BEADS	VTL1126
L	3607	SMD SPL INDUCTOR	CTH1531

L	3608,3622	CHIP INDUCTOR (10 uH)	DTL1105
L	3609	INDUCTOR (10 uH)	CTF1635
L	3624-3632	CHIP BEADS	VTL1126
JA	4301,4302	USB JACK	DKB1118
S	3601,3604-3610	TACT SWITCH	DSG1134

S	3602,3603,3611,3616	PUSH SWITCH	CSG1155
S	3612-3615	TACT SWITCH	DSG1134
S	3617	ENCODER SW	DSX1080
S	3901-3904,4101-4104	PUSH SWITCH	CSG1155
CN	3601	FFC/FPC CONNECTOR	CKS6543

CN	3602	CONNECTOR	CKS4428
CN	3603	FFC/FPC CONNECTOR	CKS6646
CN	3604	FFC/FPC CONNECTOR	CKS6625
CN	3901,4101	FFC/FPC CONNECTOR	DKP3953
CN	4301,4302	CONNECTOR	AKM1277

CN	4401	CONNECTOR	AKM1289
VA	4301-4306	SMD VARISTOR	EZJZ1V80010

RESISTORS

R	3606-3609,3655,3671	RS1/16SS1000D
R	3610,3680	RAB4CQ103J
R	3614,3616,3617,3620	RAB4CQ220J
R	3629-3632	RAB4CQ331J
R	3635	RS1/16SS3603D

R	3636	RS1/16SS5602D
R	3637	RS1/16SS5601D
R	3642	RS1/16SS1103D
R	3643	RS1/16SS1202D
R	3647	RS1/16SS1102D

R	3650	RS1/16SS3303D
R	3651	RS1/16SS2202D
R	3654	RS1/16SS3902D
R	3659	RS1/16SS15R0D
R	3660,3664	RS1/16SS22R0D

R	3662	RS1/16SS82R0D
R	3663,3668,3669	RS1/16SS39R0D
R	3665	RS1/16SS68R0D
R	3666	RS1/16SS1500D
R	3667	RS1/16SS27R0D

R	3670	RS1/16SS1200D
R	3672	RS1/16SS8200D
R	3673	RS1/16SS1000D
R	3674	RS1/16SS4700D
R	3917-3928,3948-3959	RS1/10SR681J

R	3929-3932,3960-3963	RS1/8SQ331J
R	3933-3936,3964-3967	RS1/8SQ391J
R	3938-3941,3969-3972	RS1/4SA271J
R	3944-3947,3975-3978	RS1/4SA331J
R	3979-3986,4179-4186	RS1/4SA561J

R	3987-3994,4187-4194	RS1/8SQ122J
R	3996-3999,4196-4199	RS1/4SA152J
R	4002-4005,4202-4205	RS1/4SA122J
R	4006,4010,4018,4025	RAB4CQ222J
R	4007,4011,4019,4022	RS1/10SR822J

Mark	No.	Description	Part No.
	R	4008,4012,4020,4023	RS1/10SR123J
	R	4009,4013,4021,4024	RS1/10SR103J
	R	4014-4017,4026-4030	RS1/10SR0R0J
	R	4117-4128,4148-4159	RS1/10SR681J
	R	4129-4132,4144-4147	RS1/8SQ331J
	R	4133-4136,4164-4167	RS1/8SQ391J
	R	4138-4141,4169-4172	RS1/8SQ271J
	R	4160-4163,4175-4178	RS1/8SQ331J
	R	4206,4207,4214,4217	RAB4CQ222J
	R	4208,4211,4220,4223	RS1/10SR822J
	R	4209,4212,4221,4224	RS1/10SR123J
	R	4210,4213,4222,4225	RS1/10SR103J
	R	4215,4216,4218,4219	RS1/10SR0R0J
	R	4226-4230,4401	RS1/10SR0R0J
	VR	4401 VARIABLE RESISTOR	CCW1024
	Other Resistors		RS1/16SS###J

CAPACITORS

C	3604,3615,3620,3623	CKSSYB104K10
C	3614,3617,3760,3763 (10 uF/10 V)	DCH1201
C	3616 (22 uF/16 V)	CCG1254
C	3619,3621,3622,3625	CKSSYB103K16
C	3624,3635,3637,3645	CKSSYB104K10
C	3628,3738 (2.2 uF/10 V)	CCG1218
C	3633,3639,3646,3697	CKSSYB103K16
C	3654-3656,3721-3723	CKSSYB104K10
C	3677	CKSRYB103K50
C	3678,3694,3701-3704	CKSSYB102K50
C	3679,3719,3720	CKSRYB105K10
C	3680,3690,3724,3751 (1 uF/10 V)	DCH1246
C	3682,3683	CKSQYB105K25
C	3684	CKSQYB475K6R3
C	3686,3689,3699	CKSSYB104K16
C	3687,3688	CKSQYB474K25
C	3692	CKSSYB224K6R3
C	3693,3715	CKSYB475K16
C	3695	CKSSYB561K50
C	3696	CKSSYB332K50
C	3698,3700,3728,3735 (10 uF/16 V)	DCH1263
C	3716-3718,3731	CKSSYB104K16
C	3727,3734,3736	CKSSYB102K50
C	3729 (10 uF/6.3 V)	CCG1234
C	3732,3743,3745,3761	CKSSYB104K10
C	3739	CKSSYB103K25
C	3741 (4.7 uF/10 V)	CCG1201
C	3742	CKSQYB334K50
C	3744	CKSRYB104K25
C	3748-3750,3752-3754	CCSSCH102J50
C	3756-3758,4305,4306	CCSSCH102J50
C	3762,3930,4130,4402	CKSSYB104K10
C	3901,3902,3920-3925	CKSSYB103K16
C	3903-3910,4103-4110	CCSSCH101J50
C	3913,4113 (10 uF/10 V)	DCH1201
C	3927,4127	CEVW101M16
C	3928,3929,4101,4102	CKSSYB103K16
C	4120-4125,4128,4129	CKSSYB103K16
C	4303,4304	CKSSYB103K16
C	4401	CKSSYB471K50

UCOMA ASSY

Consists of
UCOM ASSY
EFSW ASSY



UCOMA ASSY
SEMICONDUCTORS

NSP	IC 4501	74LCX244FT
	IC 4502	DYW2159*

Mark	No.	Description	Part No.
NSP	*Part number of the initial firmware equipped		PST8430N
	IC	4503	DYW2160*
	IC	4505	
*Part number of the initial firmware equipped			
⚠	IC	4508	NJM2872BF33
	IC	4509-4514	TC7SH08FUS2
	Q	4501	LTA024EEB
	Q	4503	LTC043EEB
	Q	4505,4507,4509	LSAR523UB
	Q	4506,4508,4510	LTC024EEB
	Q	4901-4908	LTC124EUB
	Q	4909-4914	2SC4081
	Q	4915	KTA1532U
	D	4501-4511,4901-4924	1SS355
	D	4925,4927,4929,4935	SLR343BD2T
	D	4931	LTL17KCGP4J
	D	4933	LTL17KRH5D-P

MISCELLANEOUS

L	4501,4502 CHIP COIL (33 uH)	LCTAW330J2520
S	4901,4902,4904,4908 TACT SWITCH	DSG1089
S	4903,4905,4906,4910 TACT SWITCH	DSG1079
S	4907 SLIDE SWITCH	DSH1058
S	4909 TACT SWITCH	DSG1089
S	4911,4912 ROTARY ENCODER	DSX1137
S	4913 ROTARY ENCODER	DSX1136
X	4501 CRYSTAL RESONATOR (16 MHz)	BSS1146
CN	4503,4515 27P CONNECTOR	VKN1287
CN	4504,4505 FFC/FPC CONNECTOR	CKS6645
CN	4506,4901 35P CONNECTOR	VKN2025
CN	4507 19P CONNECTOR	VKN1250
CN	4508 FFC/FPC CONNECTOR	CKS6645
CN	4509,4517,4519,4520 CONNECTOR	CKS3871
CN	4510-4514 PLUG(3P)	KM200NA3
CN	4516 FFC/FPC CONNECTOR	DKP3953
CN	4518 24P CONNECTOR	VKN1255

RESISTORS

R	4514-4517,4594,4595	RAB4CQ101J
R	4556,4566,4568	RAB4CQ560J
R	4567,4638	RAB4CQ103J
R	4583-4586,4626,4636	RAB4CQ560J
R	4646,4647,4654	RAB4CQ560J
R	4690,4693,4712,4740	RS1/8SQ0R0J
R	4697-4704,4750-4752	RS1/4SA2R0J
R	4716-4723	RS1/4SA3R3J
R	4741,4745	RS1/8SQ0R0J
R	4907-4912	RS1/10SR222J
R	4919-4924	RS1/10SR473J
R	4925	RS1/10SR681J
R	4926,4927	RS1/10SR223J
R	4928-4930,4934-4936	RS1/10SR122J
R	4931,4937,4940	RS1/10SR561J
R	4932,4933	RS1/10SR821J
R	4939	RS1/10SR102J
VR	4901 POTENTIONETER	DCS1065
Other Resistors		RS1/16SS###J

CAPACITORS

C	4502,4510,4528,4529	CKSSYB104K10
C	4503-4508,4540	CCSSCH100D50
C	4509,4563,4672,4698	CEVW101M16
C	4511-4527,4530-4533	CCSSCH471J50
C	4534,4535,4539,4544	CCSSCH102J50
C	4536,4537,4541,4542	CKSSYB103K16
C	4538,4543,4547,4548	CKSSYB104K10
C	4545	CCSSCH120J50
C	4546,4549-4551,4553	CCSSCH471J50
C	4552	CKSSYB473K10
C	4558,4577-4579,4581	CCSSCH101J50
C	4564,4576,4592,4593	CKSSYB104K10
C	4565,4588,4591,4594	CCSSCH471J50
C	4566-4570,4589,4598	CCSSCH102J50

Mark	No.	Description	Part No.
	C	4571-4575	CKSSYB103K16
A	C	4583-4585,4587	CCSSCH101J50
	C	4595,4614,4617,4620	CKSSYB104K10
	C	4596,4597,4599,4601	CCSSCH471J50
	C	4600,4659	CCSSCH102J50
	C	4602,4606	CCSSCH471J50
	C	4603-4605,4607	CCSSCH101J50
	C	4615,4616,4618,4621	CKSSYB104K16
	C	4635,4640,4644,4645	CKSSYB104K10
	C	4637,4683,4687,4699	CKSSYB104K16
	C	4642,4651,4695,4696 (10 uF/10 V)	DCH1201
B	C	4648	CKSSYB103K25
	C	4650 (2.2 uF/10 V)	CCG1218
	C	4655,4661,4663,4665	CKSSYB104K10
	C	4662,4664,4666,4690	CKSSYB102K50
	C	4667-4669,4678,4682	CKSSYB104K10
	C	4675-4677,4701-4703	CCSSCH101J50
	C	4686,4689,4691,4693	CKSSYB104K10
	C	4692,4694	CKSSYB102K50
	C	4697,4704,4705,4708	CKSSYB104K10
	C	4710,4715,4717,4718	CKSSYB104K10
	C	4720,4721,4737,4739	CKSSYB104K10
	C	4735,4736,4738,4740	CKSSYB104K16
	C	4741,4742,4747-4750	CKSSYB104K10
	C	4761,4762	CKSSYB104K10
	C	4901,4908,4909	CKSRYB104K16
C	C	4903,4906	CKSRYB104K10
	C	4905,4907	CEVW470M16

H MIXER ASSY SEMICONDUCTORS

	IC	7001-7003	TC74HC4051AF
	IC	7004	TC74VHC164F
	IC	7005,7006	TC74VHC595F
	Q	7001-7007,7010	LSCR523UB
	Q	7008,7009,7025,7027	LTC124EUB
D	Q	7011	2SB1694
	Q	7012-7024	LSCR523UB
	Q	7026,7028,7030,7032	KTA1532U
	Q	7029,7031,7033-7036	LTC124EUB
	D	7001,7002,7009-7014	LTL17KSL5D-P
	D	7003-7008	SLR343WBC7T
	D	7015,7016,7026,7027	LTL17KRH5D-P
	D	7017-7020,7028-7031	LTL17KSL5D-P
	D	7021-7025,7032-7036	LTL17KGH5D-P
	D	7037,7038,7048,7049	LTL17KRH5D-P
	D	7039-7042,7050-7053	LTL17KSL5D-P
	D	7043-7047,7054-7058	LTL17KGH5D-P
E	D	7059-7082	1SS355VM

MISCELLANEOUS

	S	7001,7003-7008 TACT SWITCH	DSG1079
	S	7002,7009 SLIDE SWITCH	DSH1058
	S	7010-7012 TACT SWITCH	DSG1079
	S	7013-7016 SLIDE SWITCH	DSH1058
	CN	7001,7003 35P CONNECTOR	VKN2025
	CN	7002 30P CONNECTOR	VKN1261

RESISTORS

	R	7023-7046	RS1/10SR5600D
	VR	7001,7002,7008,7014 ROTARY VR	DCS1104
	VR	7003-7007,7009-7013 ROTARY VR	DCS1078
	VR	7015-7018 ROTARY VR	DCS1078
	VR	7019,7020 ROTARY VR	DCS1104
F	VR	7021-7024 ROTARY VR	DCS1126
		Other Resistors	RS1/10SR###J

Mark	No.	Description	Part No.
CAPACITORS			
	C	7001-7006	CCSRCH681J50
	C	7007-7011,7076,7099	CKSRYB104K16
	C	7012-7023,7028-7039	CCSRCH471J50
	C	7024-7027,7040-7066	CKSRYB104K10
	C	7073,7080,7082,7086	CKSRYB104K10
	C	7074,7078,7084	CEJQ101M16
	C	7081,7083 (10 uF/10 V)	DCH1201
	C	7085,7088	CCSRCH471J50
	C	7087,7090	CKSRYB103K25
	C	7089,7092,7093,7100	CKSRYB104K10
	C	7101-7109	CCSRCH102J50

PNL1 ASSY

Consists of
DKK1 ASSY
TMP1 ASSY
PWSW ASSY
CHF3 ASSY
STL1 ASSY
STL2 ASSY
STL3 ASSY

L R S U

PNL1 ASSY

SEMICONDUCTORS

IC	8101	TC74HC4051AF
IC	8102	TC74VHC164F
Q	8101-8105,8109,8114	LTC124EUB
Q	8106,8110,8116,8120	2SAR502UB
Q	8107,8108,8111-8113	LTC123JUB
Q	8115,8117,8122,8126	HN1A01FUS1
Q	8118,8351	LTC124EUB
Q	8119,8123,8127,8128	LTC123JUB
Q	8121,8124,8125	LSCR523UB
D	8101-8111,8113,8115	1SS355VM
D	8112,8116,8117,8119	LTL17KRH5D-P
D	8118,8120,8122,8127	LTL17KSL5D-P
D	8121,8123,8126,8351	LTL17KRH5D-P
D	8124	LTL17KCBH5D
D	8125	SLR343WBC7T
D	8128,8130	LTL17KCGP4J
D	8129,8131,8353	LTL17KGH5D-P
D	8352,8354-8359	1SS355VM

MISCELLANEOUS

KN	8101,8351 EARTH TERMINAL	AKF7002
S	8101,8103,8104,8107 TACT SWITCH	DSG1089
S	8102,8105,8106,8109 TACT SWITCH	DSG1079
S	8108,8110,8112,8113 TACT SWITCH	DSG1089
S	8111 TACT SWITCH	DSG1079
S	8115,8117,8351-8353 TACT SWITCH	DSG1089
S	8116,8118,8119 SLIDE SWITCH	DSH1066
S	8401 PUSH SW	ASG1102
CN	7921 L-PLUG(3P)	KM200NA3L
CN	8101 30P CONNECTOR	VKN1261
CN	8102 24P CONNECTOR	VKN1255
CN	8103 12P CONNECTOR	VKN1243
CN	8104,8351 16P CONNECTOR	VKN1247
CN	8105,8401 4P JUMPER CONNECTOR	52147-0410

RESISTORS

VR	7921 SLIDE VR	DCV1027
VR	8101 ROTARY VR	DCS1104
VR	8102-8107 ROTARY VR	DCS1116
VR	8351 SLIDE VR	DCV1032
VR	8352 VARIABLE RESISTOR	DCP1107
	Other Resistors	RS1/10SR###J

CAPACITORS

C	8101,8107,8115-8120	CKSRYB104K10
---	---------------------	--------------

Mark	No. Description	Part No.
C	8102-8105,8108-8111	CCSRCH471J50
C	8112-8114,8352	CCSRCH102J50
C	8121,8122,8124,8128	CKSRYB103K25
C	8123,8126,8127,8131	CKSRYB104K10
C	8125,8129,8132	CEJQ101M16
C	8130	CKSRYB105K10
C	8134,8135	CCSRCH471J50
C	8136-8141,8353,8354	CKSRYB104K10
C	8355	CEJQ470M16
C	8356	CKSRYB104K10
C	8401	CKSRYB103K25

PNL2 ASSY

Consists of

DCK2 ASSY

TMP2 ASSY

CHF4 ASSY

JOG1 ASSY

JOG2 ASSY

STL4 ASSY

MTVACAD

PNL2 ASSY

SEMICONDUCTORS

IC 9001	TC74HC4051AF
IC 9002	NJM2903M
IC 9003,9004	TC74VHC595F
IC 9005	TC74VHC164F
Q 9001-9003,9005,9006	LTC124EUB
Q 9004	LTA143EUB
Q 9007,9011,9013,9018	2SA1577
Q 9008,9009,9014	LTC123JUB
Q 9010,9012,9015,9019	LTC124EUB
Q 9016,9017	HN1A01FUS1
Q 9020	2SAR502UB
Q 9021-9034	LSCR523UB
Q 9035,9037,9451	LTC124EUB
Q 9036,9038	2SB1689
D 9001-9016,9452	1SS355VM
D 9017,9018,9023,9024	LTL17KRH5D-P
D 9019-9022,9025,9029	LTL17KSL5D-P
D 9026,9030,9031	LTL17KRH5D-P
D 9027	LTL17KCBH5D
D 9028	SLR343WBC7T
D 9032-9035,9044-9047	LTL17KSL5D-P
D 9036-9040,9048-9052	LTL17KGH5D-P
D 9041-9043,9451	LTL17KRH5D-P
D 9453	LTL17KGH5D-P
D 9454-9459	1SS355VM

MISCELLANEOUS

KN 9001,9451 EARTH TERMINAL	AKF7002
S 9001,9003,9004,9007 TACT SWITCH	DSG1089
S 9002,9005,9006,9009 TACT SWITCH	DSG1079
S 9008,9010,9012-9017 TACT SWITCH	DSG1089
S 9011,9018 TACT SWITCH	DSG1079
S 9451-9453 TACT SWITCH	DSG1089
CN 7931 L-PLUG(3P)	KM200NA3L
CN 9001,9002 30P CONNECTOR	VKN1261
CN 9003 12P CONNECTOR	VKN1243
CN 9004,9451 16P CONNECTOR	VKN1247
CN 9601,9701 4P CONNECTOR	VKN1264
PC 9601,9701 PHOTO INTERRUPTER	KE-2N18-15

RESISTORS

R 9103-9113	RS1/4SA0R0J
R 9171-9177	RS1/8SQ101J
VR 7931 SLIDE VR	DCV1027
VR 9001 ROTARY VR	DCS1104
VR 9002,9006 ROTARY VR	DCS1117

Mark	No. Description	Part No.
	VR 9003-9005 ROTARY VR	DCS1116
	VR 9451 SLIDE VR	DCV1032
	VR 9452 VARIABLE RESISTOR	DCP1107
	Other Resistors	RS1/10SR###J

CAPACITORS

C 9001,9004,9005,9007	CKSRYB104K10
C 9002,9003,9008,9010	CCSRCH471J50
C 9009,9015-9021,9023	CKSRYB104K10
C 9011,9039,9043	CCSRCH471J50
C 9012-9014,9452	CCSRCH102J50
C 9022,9024,9032,9036	CKSRYB103K25
C 9029,9035,9038	CEJQ101M16
C 9030,9033,9037,9040	CKSRYB104K10
C 9031,9601,9701	CKSRYB105K10
C 9041,9042,9602,9603	CKSRYB103K25
C 9045-9047,9055,9453	CKSRYB104K10
C 9454	CEJQ470M16
C 9455,9456	CKSRYB104K10
C 9702,9703	CKSRYB103K25

JOGA ASSY

Consists of

JLCD1 ASSY

JLCD2 ASSY

XPAD ASSY

QAAAB

JOGA ASSY

SEMICONDUCTORS

IC 3001,3201	BD00IC0WEFJ
IC 3002,3202	R5S72690W266FP
IC 3003,3203	DYW2158*
*Part number of the initial firmware equipped	
IC 3007,3206	W9864G6KH-5
IC 3401	ATSAMD20E15A-MU
Q 3001,3014,3201,3202	LTC024EEB
Q 3002,3203	ISA1602AM1
Q 3005,3006,3206,3207	IMX25
Q 3007,3208	HN1A01FUS1
Q 3008,3011,3209,3212	LSCR523UB
Q 3401-3403	2SC4081
D 3001-3004,3201-3204	NHSW157B-A13072
D 3401-3403,3406-3408	SWBA05

MISCELLANEOUS

L 3001-3004,3011-3024 INDUCTOR	CTF1639
L 3005-3007,3205-3207 INDUCTOR	CTF1545
L 3008-3010,3208-3210 CHIP BEADS	VTL1126
L 3025,3225 CHIP BEADS	VTL1129
L 3026,3226 CHIP INDUCTOR (10 uH)	DTL1105
L 3201-3204,3211-3224 INDUCTOR	CTF1639
L 3401 CHIP SOLID INDUCTOR	XTL3010
X 3001,3201 CRYSTAL RESONATOR (13.333 3 MHz)	CSS1840
CN 3001,3201 10P CONNECTOR	VKN1414
CN 3003,3203 CONNECTOR	CKS1072
CN 3004,3204 FFC/FPC CONNECTOR	CKS6625
CN 3005,3205 27P CONNECTOR	VKN1431
CN 3006,3206 FFC/FPC CONNECTOR	CKS6646
CN 3401 CONNECTOR	CKS3860

RESISTORS

R 3001,3020,3081,3138	RS1/10SR0R0J
R 3002,3202	RS1/10SR9101D
R 3003,3203	RS1/10SR1602D
R 3013,3016,3017,3019	RAB4CQ121J
R 3018,3041,3043,3050	RAB4CQ102J
R 3033,3040,3048,3049	RAB4CQ560J
R 3063,3269	RAB4CQ472J
R 3075,3272	RS1/16SS2402F
R 3086,3279	RAB4CQ103J
R 3113,3304	RS1/10SR104J

Mark	No.	Description	Part No.
------	-----	-------------	----------

Mark	No.	Description	Part No.
------	-----	-------------	----------

AF

SW POWER SUPPLY

There is no service parts.

A

R	3114,3305	RS1/10SR332J
R	3115,3303	RAB4CQ222J
R	3118,3309	RAB4CQ473J
R	3126,3313	RS1/10SR5600D
R	3127,3314	RS1/10SR4300D

R	3128,3315	RS1/16SS1201D
R	3129,3316	RS1/16SS6800D
R	3130,3317	RS1/16SS2401D
R	3131,3318	RS1/16SS1801D
R	3132,3319	RS1/16SS91R0F

R	3133,3320	RS1/16SS5101D
R	3135,3322	RS1/16SS9101D
R	3136,3323	RS1/16SS8201D
R	3137,3324	RS1/16SS56R0D
R	3139,3147,3326,3334	RS1/10SR122J

B

R	3140,3148,3327,3335	RS1/10SR473J
R	3143,3146,3151,3154	RS1/10SR0R0J
R	3144,3152,3331,3339	RS1/10SR181J
R	3201,3220,3278,3325	RS1/10SR0R0J
R	3213,3216,3217,3219	RAB4CQ121J

R	3218,3242,3244,3251	RAB4CQ102J
R	3234,3241,3249,3250	RAB4CQ560J
R	3330,3333,3338,3341	RS1/10SR0R0J
R	3428-3436,3443-3451	RS1/10SR122J
Other Resistors		RS1/16SS###J

CAPACITORS

C

C	3002,3202	CKSRYB105K10
C	3003,3004,3009,3019 (10 uF/10 V)	DCH1201
C	3005,3020-3028,3031	CKSSYB104K10
C	3006,3017,3018,3029	CCSSCH471J50
C	3008,3208	CKSSYB104K16

C	3015,3215	CCSSCH470J50
C	3030,3032,3053-3055	CCSSCH101J50
C	3035,3036,3038-3041	CKSSYB104K10
C	3051,3052,3056-3059	CKSSYB104K10
C	3065-3068,3071-3074	CKSSYB104K10

D

C	3076,3078-3090,3092	CKSSYB104K10
C	3091,3097,3107-3113	CKSSYB103K16
C	3094,3230,3232	CCSSCH101J50
C	3095,3098,3102,3116	CKSSYB104K10
C	3096,3118,3124,3129	CCSSCH102J50

C	3099,3115,3122,3203 (10 uF/10 V)	DCH1201
C	3100,3101,3299,3300	CCSSCH120J50
C	3103,3302,3401,3402 (10 uF/6.3 V)	CCG1234
C	3114,3312 (47 uF/16 V)	CCH1961
C	3117,3290,3296	CKSSYB103K16

C	3119,3120,3317,3318	CKSRYB104K25
C	3123,3205,3220-3228	CKSSYB104K10
C	3132,3295,3316,3322	CCSSCH102J50
C	3204,3209,3219,3298 (10 uF/10 V)	DCH1201
C	3206,3217,3218,3229	CCSSCH471J50

E

C	3231,3235,3236	CKSSYB104K10
C	3238-3241,3251,3252	CKSSYB104K10
C	3253-3255,3293	CCSSCH101J50
C	3256-3259,3265-3268	CKSSYB104K10
C	3270-3273,3275	CKSSYB104K10

C	3277-3289,3291,3294	CKSSYB104K10
C	3297,3301,3314,3321	CKSSYB104K10
C	3305-3311,3315	CKSSYB103K16
C	3313,3320 (10 uF/10 V)	DCH1201
C	3324,3325	CCSSCH102J50

F

C	3403	CKSRYB104K10
C	3404 (10 uF/6.3 V)	CCG1234
C	3405,3407	CKSSYB104K10
C	3406 (1 uF/10 V)	DCH1266
C	3408-3410,3413-3415	CKSSYB102K50

C	3416 (10 uF/16 V)	DCH1263
---	-------------------	---------