

Pioneer

Service Manual

ORDER NO.
RRV2052

STEREO CD/VCD CASSETTE DECK RECEIVER

XR-VS77

XR-VS55

● Refer to the service manual RRV2035 for XR-VS77/DBDXJ.

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Type	Model		Power Requirement	The voltage can be converted by the following method.
	XR-VS77	XR-VS55		
DAMXJ	○	○	AC110–127V/220–230V/240V	With the voltage selector

1. CONTRAST OF MISCELLANEOUS PARTS

NOTES: ● Parts marked by "NSP" and ⊗ can not be supplied.

- The △ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- Screws adjacent to ▼ mark on the product are used for disassembly.
- Reference Nos. indicate the pages and Nos. in the service manual for the base model.

■ CONTRAST TABLE

XR-VS77/DAMXJ and XR-VS77/DBDXJ are constructed the same except for the following :

Ref. No.	Mark	Symbol and Description	Part No.		Remarks
			XR-VS77 /DBDXJ	XR-VS77 /DAMXJ	
P3-10	△ NSP	PACKING SECTION Packing Case	XHD3054	XHD3066	No.1
P3-13		Power Cord	ADG1158	ADG7018	
		Label	Not used	ARW7038	
		Warranty Card	Not used	ARY7028	
P7-26	NSP	EXTERIOR (2/2) SECTION Name Label	XAL3008	XAL3009	No.2
		Label	Not used	PRW1499	


XR-VS55/DAMXJ and XR-VS55/DBDXJ are constructed the same except for the following :

Ref. No.	Mark	Symbol and Description	Part No.		Remarks
			XR-VS55 /DBDXJ	XR-VS55 /DAMXJ	
P3-10	△ NSP	PACKING SECTION Packing Case	XHD3056	XHD3068	No.1
P3-13		Power Cord	ADG1158	ADG7018	
		Label	Not used	ARW7038	
		Warranty Card	Not used	ARY7028	
P7-26	NSP	EXTERIOR (2/2) SECTION Name Label	XAL3023	XAL3024	No.2
		Label	Not used	PRW1499	

Notes: ● The numbers in the remarks column correspond to the numbers on "EXPLODED VIEWS".

■ EXPLODED VIEWS

● PACKING SECTION



● EXTERIOR (2/2) SECTION

