



MICRO COMPONENT SYSTEM

MM-26

SERVICE Manual

MICRO COMPONENT SYSTEM




CONTENTS

1. Precautions
2. Specifications
3. Disassembly and Reassembly
4. Alignment and Adjustments
5. Special Circuit Descriptions
6. Troubleshooting
7. Exploded Views and Parts List
8. Electrical Parts List
9. Block Diagrams
10. PCB Diagrams
11. Wiring Diagram
12. Schematic Diagrams

12. Schematic Diagrams

12-1 Main



12-2 Front

