





Technics TAPE DECK MODEL RS-M12 SCHEMATIC DIAGRAM



- SWITCHES**
1. S₁-S₄ RECORD PLAYBACK SW
 2. S₁-S₄ EQUALIZER BIAS SELECT SW
 3. S₁-S₄ DOLBY SW
 4. S₁-S₄ IN PUT SELECT
 5. S₁ POWER SW
 6. S₁ MOTOR MUTING SW
 7. S₁ CUE REVIEW MUTING SW
 8. S₁ CUE REVIEW MUTING SW
 9. S₁-S₂ RECORD SELECT SW
 10. S₁ VOLTAGE SELECT SW



*Δ indicates that only parts specified manufacturer be used for replacement in critical components.

*This schematic diagram is subject to change.