






SANSUI 4000 SC




CONNECTION



- CAPACITOR
 △ CERAMIC
 ○ OIL
 ● MYLAR
 □ MICA
 ⊠ TANTALUM
 ⊞ STYROL
- ALL RESISTORS 1/4WATT
 UNLESS OTHERWISE NOTE





SANSUI 4000 SCHEMATIC DIAGRAM

SELECTOR $S_1(a-j)$

1. PHONO 1
2. PHONO 2
3. AM
4. FM MONO
5. FM AUTO
6. AUX

S_{2a} SPEAKER (R)

S_{2b} SPEAKER (L)

S_3 TAPE MONITOR

1. OFF 2. ON

S_4 REVERSE

1. OFF 2. ON

S_5 MON

1. OFF 2. ON

S_6 LOUDNESS

1. OFF 2. ON

S_7 HIGH FILTER

1. OFF 2. ON

S_8 LOW FILTER

1. OFF 2. ON

S_9 POWER

S_{10} ANTENNA

1. DIST 2. LOC

S_{11} MUTING

1. OFF 2. ON

S_{12} MPX NOISE

CANCER 1. OFF 2. ON

PHONO 1

PHONO 2

AUX

TAPE-REG

TAPE-MON

J002

TAPE RECORDER (DIN)

R001

R002

R003

R004

R005

R006

R007

R008

R009

R010

R011

R012

R013

R014

R015

R016

R017

R018

R019

R020

R021

R022

R023

R024

R025

R026

R027

R028

R029

R030

R031

R032

R033

R034

R035

R036

R037

R038

R039

R040

R041

R042

R043

R044

R045

R046

R047

R048

R049

R050

R051

R052

R053

R054

R055

R056

R057

R058

R059

R060

R061

R062

R063

R064

R065

R066

R067

R068

R069

R070

R071

R072

R073

R074

R075

R076

R077

R078

R079

R080

R081

R082

R083

R084

R085

R086

R087

R088

R089

R090

R091

R092

R093

R094

R095

R096

R097

R098

R099

R100

R101

R102

R103

R104

R105

R106

R107

R108

R109

R110

R111

R112

R113

R114

R115

R116

R117

R118

R119

R120

R121

R122

R123

R124

R125

R126

R127

R128

R129

R130

R131

R132

R133

R134

R135

R136

R137

R138

R139

R140

R141

R142

R143

R144

R145

R146

R147

R148

R149

R150

R151

R152

R153

R154

R155

R156

R157

R158

R159

R160

R161

R162

R163

R164

R165

R166

R167

R168

R169

R170

R171

R172

R173

R174

R175

R176

R177

R178

R179

R180

R181

R182

R183

R184

R185

R186

R187

R188

R189

R190

R191

R192

R193

R194

R195

R196

R197

R198

R199

R200

R201

R202

R203

R204

R205

R206

R207

R208

R209

R210

R211

R212

R213

R214

R215

R216

R217

R218

R219

R220

R221

R222

R223

R224

R225

R226

R227

R228

R229

R230

R231

R232

R233

R234

R235

R236

R237

R238

R239

R240

R241

R242

R243

R244

R245

R246

R247

R248

R249

R250

R251

R252

R253

R254

R255

R256



R257

R258


R259

R260

R261</



PROTECTOR IND.



- SELECTOR $S_1(a \sim j)$

1. PHONO 1
2. PHONO 2
3. AM
4. FM MONO
5. FM AUTO
6. AUX

- S_{2a} SPEAKER (R)
 S_{2b} SPEAKER (L)
 S₃ TAPE MONITOR
 1.0FF 2.0N
 S₄ REVERSE
 1.0FF 2.0N
 S₅ MON
 1.0FF 2.0N
 S₆ LOUDNESS
 1.0FF 2.0N
 S₇ HIGH FILTER
 1.0FF 2.0N
 S₈ LOW FILTER
 1.0FF 2.0N
 S₉ POWER

