










POWER SUPPLY SCHEMATIC DIAGRAM - SCHEMA DE L'ALIMENTATION - SCHALTBILD NETZTEIL - SCHEMA





	POWER ON	STAND BY	POWER OFF(ECO)
POWER LINE	HIGH	LOW	LOW
MUTE LINE	HIGH WHILE MUTE ELSE LOW	HIGH	LOW

MAIN SCHEMATIC DIAGRAM - SCHEMA DE LA PLATINE PRINCIPALE - SCHALTBIKD HAUPTPLATINE

Réf.	pin	FM	MW	LW
Q402	B	1,9	0	1,9
	C	0	1,4	0
	E	0	0	0

Réf.	pin	FM	MW	LW
Q403	B	0	1,4	0
	C	0	0	0
	E	0	0	0

TO CONTROL/DISPLAY BOARD

TO CONTROL/DISPLAY BOARD

TO CD BOARD

TO AUX INPUT BOARD


TO MAIN BOARD (S402)

MAIN


CRKD1282/CRKD1283

First issue 09/00


BILD HAUPTPLATINE - SCHEMA DELLA PIASTRA PRINCIPALE - ESQUEMA DE LA PLATINA PRINCIPAL




LD HAUPTPLATINE - SCHEMA DELLA PIASTRA PRINCIPALE - ESQUEMA DE LA PLATINA PRINCIPAL



**CONTROL / DISPLAY SCHEMATIC DIAGRAM - SCHEMA COMMANDES / AFFICHEUR - SCHALTBILD BEWAKTOER
ESQUEMA MANDOS / INDICADOR**





REMOVABLE CONTROL PCB - SCHEMA DE LA COMMANDE DÉTACHABLE - SCHALTBILD ABNEHMBARE STEUERPLATINE - PIASTRA CONTROLLO RIMOVIBILE - PLACA DE CONTROL EXTRAIBILE

