

Service Manual

Cassette Deck

RS-M270X

(Silver Face)
(Black Face)

dbx Equipped Direct Drive Cassette Deck
with Peak Hold FL Meters, Solenoid Controls
and Dolby Noise Reduction



This is the Service Manual for the following areas.

- For all European areas except United Kingdom.
- ▣ For United Kingdom.
- ▢ For Australia.

RS-M85 MECHANISM SERIES

Specifications

Track system:	4-track 2-channel stereo recording and playback	Inputs:	MIC; sensitivity 0.25 mV, input impedance 100 k Ω applicable microphone impedance 400 Ω —10 k Ω
Tape speed:	4.8 cm/s		LINE; sensitivity 60 mV, input impedance 47 k Ω
Wow and flutter:	0.035% (WRMS), $\pm 0.1\%$ (DIN)	Outputs:	LINE; output level 400 mV, output impedance 2.5 k Ω or less, load impedance 22 k Ω over
Frequency response:	Metal tape; 20—20,000 Hz 25—18,000 Hz (DIN) 30—17,000 Hz ± 3 dB		HEADPHONES; output level 125 mV, load impedance 8 Ω
	CrO ₂ tape; 20—19,000 Hz 25—18,000 Hz (DIN) 30—16,000 Hz ± 3 dB	Bias frequency:	85 kHz
	Normal tape; 20—17,000 Hz 25—16,000 Hz (DIN) 30—15,000 Hz ± 3 dB	Motor:	2-motor system 1-FG servo controlled direct-drive DC motor 1-DC motor for reel-table drive
Dynamic range:	110 dB (at 1 kHz)	Heads:	2-head system 1-SX (Sendust Extra) head for record/playback 1-sendust/ferrite double-gap head for erasure
Max. input level:	10 dB or more improved with dbx* in (at 1 kHz)	Power requirement:	AC; 110/125/220/240 V, 50-60 Hz Preset power voltage 240 V for Australia and United Kingdom
Signal-to-noise ratio:	dbx in; 92 dB Dolby* NR in; 68 dB (above 5 kHz) Dolby NR out; 58 dB (signal level=max. recording level, CrO ₂ type tape)	Power consumption:	30 W
Fast forward and rewind time:	Approx. 85 seconds with C-60 cassette tape	Dimensions:	43.0 cm(W) $\times$ 9.8 cm(H) $\times$ 35.0 cm(D)
		Weight:	6.2 kg

Specifications are subject to change without notice.

* The term dbx is a registered trademark of dbx Inc.

** 'Dolby' and the double-D symbol are trademarks of Dolby Laboratories.


Technics

Matsushita Electric Trading Co., Ltd.
P.O. Box 288, Central Osaka Japan

CONTENTS

ITEM	PAGE	ITEM	PAGE
LOCATION OF CONTROLS AND COMPONENTS.....	1	CIRCUIT BOARD	
DISASSEMBLY INSTRUCTIONS	2	MAIN AMP CIRCUIT BOARD	16
MEASUREMENT AND ADJUSTMENT METHODS		FL METER CIRCUIT BOARD	16
(WITHOUT dbx SYSTEM).....	3	SCHEMATIC DIAGRAM	
OUTLINE OF dbx SYSTEM	9	dbx SECTION	17
THE BLOCK DIAGRAM OF dbx SYSTEM	10	CIRCUIT BOARD	
MEASUREMENT AND ADJUSTMENT METHODS		dbx CIRCUIT BOARD	18
(FOR dbx SYSTEM)	11	SCHEMATIC DIAGRAM	
• TROUBLESHOOTING CHART FOR dbx SYSTEM	11	POWER SUPPLY & MAIN CONTROL SECTION	19
• ADJUSTMENT PARTS LOCATION OF dbx SYSTEM	12	CIRCUIT BOARD	
• SIGNAL WAVE FORMS AT INDIVIDUAL SECTIONS		POWER SUPPLY & MAIN CONTROL CIRCUIT BOARD....	20
OF THE RMS DETECTOR CIRCUIT & VCA CIRCUIT....	12	SCHEMATIC DIAGRAM	
• dbx SYSTEM CHECKING METHOD	12	CAPSTAN MOTOR SECTION	21
• ADJUSTMENT OF dbx SYSTEM	12	WIRING CONNECTION DIAGRAM	22
• CHECKING PROCEDURE FOR PROBLEMS.....	13	MECHANICAL PARTS LOCATION	23
ELECTRICAL PARTS LOCATION	14	CABINET PARTS LOCATION	23
SCHEMATIC DIAGRAM			
MAIN AMP SECTION	15		

LOCATION OF CONTROLS AND COMPONENTS



DISASSEMBLY INSTRUCTIONS




Fig. 1




Fig. 2




Fig. 3




Fig. 4



Fig. 5



Fig. 6




Fig. 7




Fig. 8




Fig. 9

Ref. No.	Procedure	To remove ———	Remove ———	Shown in fig. ———
1	1	Case cover	• 4 screws (A)	1
2	1 → 2	Front panel	• Cassette lid (B) • 2 volume knobs (C) • 3 red screws (D) • 3 black screws (E)	1 1 2 3
3	3	Bottom cover	• 7 red screws (F)	3
4	1 → 2 → 4	Mechanism	• 2 red screws (G) • 1 red screw (H) • 4 red screws (I)	2 2 3, 4
5	1 → 2 → 5	FL meter	• 1 meter holder (J)	4
6	1 → 6	dbx circuit board	• 4 screws (K)	2
7	1 → 2 → 5 → 7	Control key switch circuit board	• 2 screws (L)	4
8	1 → 2 → 3 → 6 → 8	Main amp. circuit board	• 2 knobs (M) • 2 push button (N) • 2 nuts (O) • 2 screws (P) • Rotary selector (Q) • 6 screws (R)	4 4 5 5 6 7
9	1 → 2 → 4 → 9	Capstan motor circuit board	• 3 screws (S) • 3 screws (T)	8 9

MEASUREMENT AND ADJUSTMENT METHODS

• CIRCUIT BOARDS AND ADJUSTMENT PARTS LOCATION (WITH OUT dbx SYSTEM)














Fig. 1




• MEASUREMENT AND ADJUSTMENT METHODS





NOTES: Keep good condition, set switches and controls in the following positions, unless otherwise specified.

- Make sure heads are clean.
- Make sure capstan and pressure roller are clean.
- Judgeable room temperature: $20 \pm 5^\circ\text{C}$ ($68 \pm 9^\circ\text{F}$)
- NR switch: OUT
- Tape selector: Normal
- Input selector: Line in
- Input level controls: Maximum
- Output level control: Maximum

ITEM	MEASUREMENT & ADJUSTMENT
A Takeup tension Condition: * Playback mode Equipment: * Cassette torque meter (QZZSRKCT)	1. Mount cassette torque meter on UNIT. 2. Place UNIT into playback mode and read takeup torque. 3. Measure several times and determine the mean value. Standard value: $35 \pm 5 \text{ g-cm}$ 4. If measured value is not within standard, adjust VR201 (Shown in fig. 1).
B Head azimuth adjustment Condition: * Playback mode Equipment: * VTVM * Oscilloscope * Test tape (azimuth) ... QZZCFM	L-CH/R-CH output balance adjustment 1. Make connections as shown in fig. 2. 2. Playback the 8kHz signal from the test tape (QZZCFM). Adjust screw (B) in fig. 3 for maximum output L-CH and R-CH levels. When the output levels of L-CH and R-CH are not at maximum at the same time, readjust as follows. 3. Turn the screw (B) shown in fig. 3 to find angles A and C (points where peak output levels for left and right channels are obtained). Then, locate the angle B between angles A and C, i.e., a point where L-CH and R-CH output levels come together at maximum (Refer to figs. 3 and 4). L-CH/R-CH phase adjustment 1. Make connections as shown in fig. 5. 2. Playback the 8kHz signal from the test tape (QZZCFM). Adjust screw (B) shown in fig. 3 so that pointers of the two VTVMs swing to maximum and a waveform as illustrated in fig. 6 is obtained on the oscilloscope.  Fig. 2  Fig. 3  Fig. 4  Fig. 5  Fig. 6
C Tape speed Condition: * Playback mode Equipment: * Digital electronic counter * Test tape ... QZZCWAT	Tape speed accuracy 1. Test equipment connection is shown in fig. 7. 2. Playback test tape (QZZCWAT 3,000 Hz), and supply playback signal to digital electronic counter. 3. Measure this frequency. 4. On the basis of 3,000Hz, determine value by following formula: $\text{Tape speed accuracy} = \frac{f - 3,000}{3,000} \times 100 (\%)$ where, f = measured value 5. Take measurement at middle section of tape. Standard value: $\pm 0.5\%$ 6. If measured value is not within standard, adjust VR301. Tape speed fluctuation Make measurements in same manner as above (beginning, middle and end of tape), and determine the difference between maximum and minimum values and calculate as follows: $\text{Tape speed fluctuation} = \frac{f_1 - f_2}{3,000} \times 100 (\%) \quad f_1 = \text{maximum value}, f_2 = \text{minimum value}$ Standard value: Less than 0.3%

ITEM	MEASUREMENT & ADJUSTMENT
㊦ Bias leakage Condition: * Record mode * Input level controls ... MAX * Tape selector ... Metal position Equipment: * VTVM * Oscilloscope	1. Test equipment connection is shown in fig. 12. 2. Press the record and playback buttons. 3. Adjust trap coils L1 (L-CH), L2 (R-CH), so that measured value becomes minimum. 4. Make adjustment for both channels.  Fig. 12
㊦ Erase current Condition: * Record mode * Tape selector ... Metal position Equipment: * VTVM * Oscilloscope	1. Test equipment connection is shown in fig. 13. 2. Press the record and playback button, then measure voltage at test point 9. 3. Determine erase current with the following formula: $\text{Erase current (A)} = \frac{\text{Voltage across both ends of R167}}{1 (\Omega)}$ Standard value: 95 ± 5 mA (Tape selector ... Metal)  Fig. 13 4. If measured value is not within standard, adjust VR11.
㊦ Overall frequency response Condition: * Record/playback mode * Tape selector ... Normal position ... CrO ₂ position ... Fe-Cr position ... Metal position * Input level controls ... MAX Equipment: * VTVM * AF oscillator * ATT * Oscilloscope * Resistor (600Ω) * Test tape (reference blank tape) ... QZZCRA for Normal ... QZZCRX for CrO ₂ ... QZZCRY for Fe-Cr ... QZZCRZ for Metal	Note 1: Before measuring and adjusting, make sure of the playback frequency response (For the method of measurement, please refer to the playback frequency response). Note 2: Test tape QZZCRA to be supplied after July 1980 has higher recording sensitivity in the middle and high frequency range.  Fig. 14 Refer to note 2  This chart indicates the standard values for the new type of QZZCRA when in use.  This chart indicates the standard values for the former type of QZZCRA when in use. The new type of QZZCRA is marked as shown in fig. 15. Former type  ➔ New type  Fig. 15 Overall frequency response adjustment by recording bias current Note 1: On RS-M270, overall frequency response is adjusted with tape selector set at Normal. Note 2: Recording equalizer is fixed. 1. Make connections as shown in fig. 16. 2. Input a 1kHz, -24 dB signal through LINE IN. Place the set in record mode. 3. Fine adjust the attenuator to obtain 0.4 V LINE OUT output. * Make sure that the input signal level is -24 ± 4 dB with 0.4 V output voltage.  Fig. 16

ITEM	MEASUREMENT & ADJUSTMENT
	4. Set the tape selector to Normal, and load the test tape (QZZCRA). 5. Adjust the attenuator to reduce the input signal level by 20 dB. 6. Adjust the AF oscillator to generate 30Hz, 40Hz, 100Hz, 200Hz, 500Hz, 1kHz, 4kHz, 8kHz, 10kHz and 13kHz signals, and record these signals on the test tape. 7. Playback the signals recorded in step 6, and check if the frequency response curve is within the limits shown in the overall frequency response chart for Normal tapes (fig. 14). (If the curve is within the charted specifications, proceed to steps 8, 9 and 10.) If the curve is not within the charted specifications, adjust as follows; Adjustment (A): When the curve exceeds the overall frequency response chart specifications (fig. 14) as shown in fig. 17.  Fig. 17 1) Increase bias current by turning VR9 (L-CH) and VR10 (R-CH). (See fig. 1 on page 3.) 2) Repeat steps 6 and 7 to confirm. (Proceed to steps 8, 9 and 10 if the curve is now within the charted specifications in fig. 14.) 3) If the curve still exceeds the specifications (fig. 14), increase bias current further and repeat steps 6 and 7. Adjustment (B): When the curve falls below the overall frequency response chart specifications (fig. 14) as shown in fig. 18.  Fig. 18 1) Reduce bias current by turning VR9 (L-CH) and VR10 (R-CH). 2) Repeat steps 6 and 7 to confirm. (Proceed to steps 8, 9 and 10 if the curve is now within the charted specifications in fig. 14.) 3) If the curve still falls below the charted specifications (fig. 14), reduce bias current further and repeat steps 6 and 7. 8. Switch the tape selector to CrO2, change test tape to QZZCRX, and record 30Hz, 40Hz, 100Hz, 200Hz, 500Hz, 1kHz, 4kHz, 8kHz, 10kHz and 14kHz signals. Then, playback the signals and check if the curve is within the limits shown in the overall frequency response chart for CrO2 tapes (fig. 19). Overall frequency response chart (CrO2, Fe-Cr, Metal)  Fig. 19 9. Switch the tape selector to Fe-Cr, change test tape to QZZCRY, and record 30Hz, 40Hz, 100Hz, 200Hz, 500Hz, 1kHz, 4kHz, 8kHz, 10kHz and 14kHz signals. Then, playback the signals and check if the curve is within the limits shown in the overall frequency response chart for Fe-Cr tapes (fig. 19). 10. Switch the tape selector to Metal, change test tape to QZZCRZ, and record 30Hz, 40Hz, 100Hz, 200Hz, 500Hz, 1kHz, 4kHz, 8kHz, 10kHz and 14kHz signals. Then, playback the signals and check if the curve is within the limits shown in the overall frequency response chart for Metal tapes (fig. 19). 11. Confirm that bias currents are approximately as follows when the tape selector is set at different positions. • Read voltage on VTVM and calculate bias current by following formula: Bias current (A) = Value read on VTVM (V) 10 (Ω) around 355μA (Normal position) around 360μA (Fe-Cr position) around 440μA (CrO2 position) around 700μA (Metal position) } : measured at TP1 (L-CH) and TP2 (R-CH) </

ITEM	MEASUREMENT & ADJUSTMENT
① Overall gain Condition: * Record/playback mode * Input level controls ... MAX * Standard input level; - MIC -72 ± 4 dB - LINE IN ... -24 ± 4 dB Equipment: * VTVM * AF oscillator * ATT * Oscilloscope * Resistor (600 Ω) * Test tape (reference blank tape) ... QZZCRA for Normal	1. Test equipment connection is shown in fig. 20. 2. Place UNIT into record mode, and tape selector to Normal position. 3. Supply 1 kHz signal (-24 dB) from AF oscillator, through ATT to LINE IN. 4. Adjust ATT until monitor level at LINE OUT becomes 0.4 V. 5. Using test tape, make recording. 6. Playback recorded tape, and make sure the value at LINE OUT on VTVM becomes 0.4 V. 7. If measured value is not 0.4 V, adjust VR5 (L-CH), VR6 (R-CH) (See fig. 1). 8. Repeat from step 2.  Fig. 20
② Fluorescent meter Condition: * Record mode * Input level controls ... MAX * Output level control ... MAX * Tape selector ... Normal position Equipment: * VTVM * AF oscillator * ATT * Oscilloscope * Resistor (600 Ω)	1. Test equipment connection is shown in fig. 20. 2. As shown in fig. 21, connecting the base of Q28 and ground stops the oscillation of the astable multivibrator comprising Q28 and Q29. 3. Supply 1 kHz signal (-24 dB) to the LINE IN jack, then press the record button. 4. Adjust the ATT so that the output level at LINE OUT jack becomes 0.4 V (The input level at this condition is termed the standard input level). 5. Adjustment at "-20 dB": A. Adjust the ATT so that input level is -20 dB below standard recording level. B. Adjust VR13 so that the -20 dB segment lights up in the -20 ± 0.8 dB range (L-CH ONLY) (See fig. 22). 6. Adjustment at "0 dB": A. Adjust the ATT so that the output level at LINE OUT jack becomes 0.4 V. (The input level at this condition is termed the standard input level.) B. Adjust VR12 so that the $+1$ dB segment lights up in the 0 ± 0.2 dB range of the standard input level (See fig. 23). 7. Repeat twice between steps 5 and 6 above. 8. Adjust ATT and check that all segments light up when an input signal level is increased to 10 dB higher than the standard input level (See fig. 24).  Fig. 21  Fig. 22  Fig. 23  Fig. 24
Ⓚ Dolby NR circuit Condition: * Record mode * NR switch ... Dolby IN/OUT * Input level controls ... MAX Equipment: * VTVM * AF oscillator * ATT * Oscilloscope * Resistor (600 Ω)	1. Test equipment connection is shown in fig. 25. 2. Place UNIT into record mode, set the NR switch to OUT position and supply to LINE IN to obtain -35 dB (17.5 mV) at TP5 (L-CH), TP6 (R-CH) (frequency 5 kHz). 3. Confirm that the value at Dolby IN position is 8.2 ± 2 dB greater than the value at Dolby OUT position of NR switch.  Fig. 25

OUTLINE OF dbx SYSTEM

In 1971, the dbx company of Massachusetts, U.S.A., succeeded in developing a logarithmic compression/expansion system for audio signals which extends across an extremely wide amplitude range and results in a very low distortion rate.

In this system, the dynamic range of the input signal is compressed to 1/2 its original level (measured in decibels), and then recorded. The recorded signal is then expanded (2x) prior to playback, in order to restore it to the original level. By this process, a dynamic range exceeding 100dB can be easily obtained by using an ordinary tape recorder.

This system is referred to as a decilinear noise reduction system, but is generally called the "dbx system", the name being derived from the dbx company.


• The features of the dbx system

1. A significant noise reduction (approximately 30dB or more) is obtained over the entire audible frequency range.

Noise reduction mode	S/N ratio RS-M270X	Remarks
Noise reduction "OUT"	58dB	CrO ₂ tape, peak level
Dolby NR "IN"	66dB	CrO ₂ tape, peak level
dbx "IN"	92dB	CrO ₂ tape, peak level

2. A great improvement in the dynamic range makes it possible to extend the range to 110dB (at 1kHz, CrO₂ tape).
3. The direct logarithmic method of compression and expansion protects against problems caused by level mismatching.
4. Even if phase distortion occurs in the signal transmission system, precise operation is maintained by means of the RMS level detector.
5. A low distortion rate is maintained throughout the frequency range.
 - Improvement of high frequency response. The dbx system solves the problem of deteriorated high frequency at higher input levels which is an inherent fault of cassette tape equipment. The response at approx. 8,000Hz at 10dB input is improved as much as 14dB. As a result, flatter response is obtained at both low and high input levels.

Overall frequency response (RS-M270X)




• Remarkable dynamic range of 110dB

About dynamic range:

The dynamic range refers to the output range of an audio transmission system, extending from the lowest recognizable level to the highest possible level produced. Dynamic range is one of the values used to express the degree of fidelity of an audio transmission system.

Dynamic range: 1kHz (RS-M270X)



- **Compressing the dynamic range to 1/2 before recording, and then expanding it (by 2x) before playback produces the remarkable dynamic range of the dbx system.**

- The dynamic range of cassette tape with a saturation level of +10dB and a noise level of -45dB (such as Technics CrO₂ position tape) is 55dB. Any sounds with a level greater than +10dB will result in considerable distortion, and any sounds less than -45dB will be inaudible due to the effect of noise, making high-fidelity reproduction impossible.


The dbx system, however, linearly compresses the input level by a ratio of 1/2 in decibels prior to recording it onto the tape. A +20dB sound is thus compressed to +10dB, a -20dB sound is compressed to -10dB, and a -90dB sound is compressed to -45dB.

As a result, a signal with a dynamic range extending from -90dB to $+20\text{dB}$ (a 110dB dynamic range) can be contained within a range which extends from -45dB to $+10\text{dB}$ (a 55dB dynamic range). Recording onto a cassette tape with a 55dB dynamic range is then possible.


Prior to playback, the exact opposite process occurs and the sound levels are expanded. The +10dB sound is restored to its original level of +20dB, the -10dB sound is restored to -20dB, and the -45dB sound is restored to -90dB.

Therefore, the basic principle of the dbx system, as described above, is to compress the 110dB dynamic range by 1/2 to 55dB prior to recording, and then the expand it (by 2x) prior to playback.


dbx system function diagram



Level compression/expansion diagram



THE BLOCK DIAGRAM OF dbx SYSTEM



(Block configuration change for dbx circuit Encode/Decode is electrically performed by switching transistors between blocks.)

ENCODER

- The portion of the dbx system with compresses the volume level of the input signal by 1/2 (measured in decibels), before sending it to the recording system, is called the encoder.

① INPUT BANDPASS FILTER (27 Hz—20 kHz)

To prevent pulse noise or other types of interference from causing erroneous operation of the dbx system, all signals outside the 27 Hz—20 kHz audio band range are eliminated here.

② PRE-EMPHASIS

The high frequency range, where hiss noise is prominent, is emphasized here during recording. The end result is that, although the dbx system is effective in reducing noise across entire frequency band, noise in the high frequency range is reduced still more by this pre-emphasis circuitry.

③ **VCA (voltage-controlled amplifier/attenuator)**

This is an extremely important circuitry in the construction of the dbx system. In response to the incoming DC control voltage, the VCA varies the degree of amplification logarithmically in the same manner as the direct current, resulting in compression and expansion of the input signal's dynamic range.

④ RMS DETECTOR (RMS: root mean square)

This is an important element in the composition of the dbx system, because its circuitry generates a DC voltage (the voltage that controls the degree of amplification in the VCA) in proportion to the size of the input signal.

It does this by detecting the root mean square value of the input signal, and then converting it to a DC voltage in proportion to the logarithm of the detected level.

Erroneous operation due to phase shift is prevented by monitoring of the voltage level derived from the root mean square value.

⑤ WEIGHTING

To prevent the saturation level of the tape deck in high frequencies, this increases the RMS DETECTOR high frequency sensitivity and decreases the VCA high frequency gain. As a result, the linearity of the tape deck is enhanced in the high frequency range.

⑥ RMS FILTER (27 Hz to 10kHz)

This filter cuts any signal other than 27Hz to 10kHz that mixes in input signals to prevent the RMS DETECTOR from malfunctioning. Those to be cut include an FM tuner STEREO PILOT signal, tape deck bias leakage and record player motor rotational noise. In addition, the signal in the frequency range (27Hz to 10kHz) passing through the BAND PASS FILTER is comparatively small in level variations when handled by the tape deck.

This ensures correct complementarity in the operation of the RMS DETECTOR and VCA during Encoding and Decoding.

DECODER

As shown in the diagram on the previous page, for playback output, the decoder expands the constantly changing level to double the decibel range.

For example, -30dB signal is expanded to -60dB , and a level of -45dB becomes -90dB . On the other hand, a playback output $+10\text{dB}$ is expanded to $+20\text{dB}$, and a saturation level signal is also correspondingly increased.

In terms of the system's operation, the decoder's function is the exact opposite of the function of the previously mentioned encoder.

MEASUREMENT AND ADJUSTMENT METHODS (FOR dbx SYSTEM)




Fig. 1

• ADJUSTMENT PARTS LOCATION OF dbx SYSTEM





Fig. 2

• SIGNAL WAVE FORMS AT INDIVIDUAL SECTIONS OF THE RMS DETECTOR CIRCUIT & VCA CIRCUIT (FOR OPERATION CHECK OF dbx SYSTEM)

Figures 4 and 5 show the signal waveforms at pins of the major ICs when an input signal (1kHz, 300mV) shown in Fig. 3 is applied to the input terminals TP603 (L-CH) and TP604 (R-CH) of the dbx system.



Measurement Method and condition

1. Make the connections as shown in fig. 6, and apply 1kHz -27dB signal from LINE IN, and set the noise reduction selector to dbx tape position.
2. Set the unit to record mode, adjust ATT so that the signal level at TP603 (L-CH) and TP604 (R-CH) is 300mV.




Fig. 6

• dbx SYSTEM CHECKING METHOD

NOTES: Keep good condition, set switches and controls in the following positions, unless otherwise specified.

- Input selector: Line in
- Input level controls: Maximum
- Output level control: Maximum

ITEM	CHECKING METHOD
A Check for expansion/compression Condition: * Stop/record mode * Input level controls ... MAX * Output level control ... MAX * Noise reduction selector ... disc/dbx tape Equipment: * VTVM * AF oscillator * ATT * Oscilloscope * Resistor (600Ω)	A-1 Check for expansion 1. Make the connections as shown in fig. 7 and apply 1kHz -27dB signal from LINE IN, and set the noise reduction selector to disc position. 2. Adjust ATT, increase input signal level by 10dB, and make sure that the reading for VTVM increases by $20dB \pm 1dB$. 3. Adjust ATT, decrease the input signal level, and make sure that the reading for VTVM decreases by $20dB \pm 1dB$. A-2 Check for compression 1. Make the connections as shown in fig. 8 and apply 1kHz -27dB signal from LINE IN, and set the noise reduction selector to dbx tape position. 2. Set the unit to record mode. 3. Adjust ATT, increase input signal level by 10dB, and make sure that the reading for VTVM at TP605 (L-CH) and TP606 (R-CH) increases by $5dB \pm 1dB$. 4. Adjust ATT, decrease the input signal level by 10dB, and make sure that the reading for VTVM at TP605 (L-CH) and TP606 (R-CH) decreases by $5dB \pm 1dB$.
B Check for standard level of dbx Condition: * Stop/record mode * Input level controls ... MAX * Noise reduction selector ... disc/dbx tape Equipment: * VTVM * AF oscillator * ATT * Oscilloscope * Resistor (600Ω)	B-1 Check for standard level of dbx in dbx Encode mode 1. Make the connections as shown in fig. 8 and apply 1kHz -27dB signal from LINE IN, and set the noise reduction selector to dbx tape position. 2. Set the unit to record mode, adjust ATT so that the signal level at TP603 (L-CH) and TP604 (R-CH) is 300mV. 3. Make sure that the signal level at TP605 (L-CH) and TP606 (R-CH) is $300mV \pm 0.5dB$. B-2 Check for standard level of dbx in dbx Decode mode 1. Make the connections as shown in fig. 8 and apply 1kHz -27dB signal from LINE IN, and check as follows: 2. Set the noise reduction selector to disc position and adjust ATT so that the signal level at TP603 (L-CH) and TP604 (R-CH) becomes 300mV. 3. Make sure that the signal level at TP605 (L-CH) and TP606 (R-CH) is $300mV \pm 0.5dB$.
C Check for output signal distortion factor (Check for distortion factor of VCA) Condition: * Stop/record mode * Input level controls ... MAX * Noise reduction selector ... disc/dbx tape Equipment: * VTVM * AF oscillator * ATT * Oscilloscope * Resistor (600Ω) * Distortion meter	C-1 Check for output signal distortion factor in dbx Decode mode 1. Make the connections as shown in fig. 9 and apply 1kHz -27dB signal from LINE IN, and check as follows: 2. Set the noise reduction selector to disc position, and adjust ATT so that the signal level at TP603 (L-CH) and TP604 (R-CH) becomes 300mV. 3. Measure the distortion factor of output signal at TP605 (L-CH) and TP606 (R-CH), and make sure that the distortion factor is less than 0.2%. 4. Next, adjust ATT to raise the output signal level by 5dB and measure the distortion of output factor at TP605 (L-CH) and TP606 (R-CH). Make sure that the distortion is less than 0.8%. 5. Adjust ATT to set the output signal at a level 5dB lower than the dbx reference level (300mV), and measure the output signal distortion at TP605 (L-CH) and TP606 (R-CH) to check that it is less than 0.3%. C-2 Check for output signal distortion factor in dbx Encode mode 1. The connection is the same as above, as is the input signal. 2. Set the noise reduction selector to dbx tape position, and the unit to record mode. 3. Adjust ATT so that the signal level at TP603 (L-CH) and TP604 (R-CH) is 300mV. 4. Measure the distortion factor of output signal at TP605 (L-CH) and TP606 (R-CH), and make sure that the distortion factor is less than 0.25%.




Fig. 7




Fig. 8




Fig. 9

① Check response circuit

Condition:
 * Stop/record mode
 * Input level controls ... MAX
 * Noise reduction selector ... disc/dbx tape

Equipment:
 * VTVM
 * ATT
 * Resistor

② Check for standard level of dbx

Condition:
 * Stop/record mode
 * Input level controls ... MAX
 * Noise reduction selector ... disc/dbx tape

• ADJUSTMENT

NOTES: W

K

① Adjust detector

Condition:
 * Stop mode
 * Input level controls ... MAX
 * Noise reduction selector ... disc/dbx tape

Equipment:
 * VTVM
 * ATT
 * Resistor

② Adjust standard

• dbx SYSTEM CHECKING METHOD

NOTES: Keep good condition, set switches and controls in the following positions, unless otherwise specified.

- Input selector: Line in • Input level controls: Maximum • Output level control: Maximum

ITEM	CHECKING METHOD
A Check for expansion/compression Condition: * Stop/record mode * Input level controls ... MAX * Output level control ... MAX * Noise reduction selector ... disc/dbx tape Equipment: * VTVM * AF oscillator * ATT * Oscilloscope * Resistor (600Ω)	A-1 Check for expansion 1. Make the connections as shown in fig. 7 and apply 1kHz -27dB signal from LINE IN, and set the noise reduction selector to disc position. 2. Adjust ATT, increase input signal level by 10dB, and make sure that the reading for VTVM increases by 20dB ± 1dB. 3. Adjust ATT, decrease the input signal level, and make sure that the reading for VTVM decreases by 20dB ± 1dB. A-2 Check for compression 1. Make the connections as shown in fig. 8 and apply 1kHz -27dB signal from LINE IN, and set the noise reduction selector to dbx tape position. 2. Set the unit to record mode. 3. Adjust ATT, increase input signal level by 10dB, and make sure that the reading for VTVM at TP605 (L-CH) and TP606 (R-CH) increases by 5dB ± 1dB. 4. Adjust ATT, decrease the input signal level by 10dB, and make sure that the reading for VTVM at TP605 (L-CH) and TP606 (R-CH) decreases by 5dB ± 1dB.
B Check for standard level of dbx Condition: * Stop/record mode * Input level controls ... MAX * Noise reduction selector ... disc/dbx tape Equipment: * VTVM * AF oscillator * ATT * Oscilloscope * Resistor (600Ω)	B-1 Check for standard level of dbx in dbx Encode mode 1. Make the connections as shown in fig. 8 and apply 1kHz -27dB signal from LINE IN, and set the noise reduction selector to dbx tape position. 2. Set the unit to record mode, adjust ATT so that the signal level at TP603 (L-CH) and TP604 (R-CH) is 300mV. 3. Make sure that the signal level at TP605 (L-CH) and TP606 (R-CH) is 300mV ± 0.5dB. B-2 Check for standard level of dbx in dbx Decode mode 1. Make the connections as shown in fig. 8 and apply 1kHz -27dB signal from LINE IN, and check as follows: 2. Set the noise reduction selector to disc position and adjust ATT so that the signal level at TP603 (L-CH) and TP604 (R-CH) becomes 300mV. 3. Make sure that the signal level at TP605 (L-CH) and TP606 (R-CH) is 300mV ± 0.5dB.
C Check for output signal distortion factor (Check for distortion factor of VCA) Condition: * Stop/record mode * Input level controls ... MAX * Noise reduction selector ... disc/dbx tape Equipment: * VTVM * AF oscillator * ATT * Oscilloscope * Resistor (600Ω) * Distortion meter	C-1 Check for output signal distortion factor in dbx Decode mode 1. Make the connections as shown in fig. 9 and apply 1kHz -27dB signal from LINE IN, and check as follows: 2. Set the noise reduction selector to disc position, and adjust ATT so that the signal level at TP603 (L-CH) and TP604 (R-CH) becomes 300mV. 3. Measure the distortion factor of output signal at TP605 (L-CH) and TP606 (R-CH), and make sure that the distortion factor is less than 0.2%. 4. Next, adjust ATT to raise the output signal level by 5dB and measure the distortion of output factor at TP605 (L-CH) and TP606 (R-CH). Make sure that the distortion is less than 0.8%. 5. Adjust ATT to set the output signal at a level 5dB lower than the dbx reference level (300mV), and measure the output signal distortion at TP605 (L-CH) and TP606 (R-CH) to check that it is less than 0.3%. C-2 Check for output signal distortion factor in dbx Encode mode 1. The connection is the same as above, as is the input signal. 2. Set the noise reduction selector to dbx tape position, and the unit to record mode. 3. Adjust ATT so that the signal level at TP603 (L-CH) and TP604 (R-CH) is 300mV. 4. Measure the distortion factor of output signal at TP605 (L-CH) and TP606 (R-CH), and make sure that the distortion factor is less than 0.25%.

CUIT &









Fig. 7




Fig. 8




Fig. 9

Specifications-1

Frequency	Signal levels at TP605 and TP606
1kHz	0dB (300mV)
100Hz	-0.5dB ± 1dB
20Hz	-28dB ± 5dB
7kHz	+7dB ± 1dB

Specifications-2

Frequency	Signal levels at TP605 and TP606
1kHz	0dB (300mV)
100Hz	+0.5dB ± 1dB
7kHz	-3.5dB ± 1dB

NOTES:

- If the results of the above checks A, B, C and D do not satisfy the specifications, perform the following adjustments.
- If the specifications are not satisfied even after the adjustments, follow the checking procedure for problems.
- If the output signal is not produced or is extremely distorted, follow the checking procedure for problems.

• ADJUSTMENT OF dbx SYSTEM

NOTES: When adjusting the circuit of the dbx system, be sure to perform the adjustments in the following order:

- Adjustment of RMS detector,
- Adjustment of dbx standard level
- Adjustment of output signal distortion factor.

Keep good condition, set switches and controls in the following positions, unless otherwise specified.

- Input selector: Line in • Input level controls: Maximum

ITEM	ADJUSTMENT
1 Adjustment of RMS detector Condition: * Stop mode * Input level controls ... MAX * Noise reduction selector ... disc Equipment: * VTVM * AF oscillator * ATT * Oscilloscope * Resistor (600Ω)	1. Make the connections as shown in fig. 10, and set the noise reduction selector to disc position. 2. Apply 50Hz -27dB signal from LINE IN. 3. Adjust ATT so that the signal level at TP603 (L-CH) and TP604 (R-CH) becomes 300mV. 4. Make sure that the output signal at R739 (L-CH) and R740 (R-CH) (Shown in fig. 2) is at 100Hz sine wave. If the output signal is not sinusoidal as shown in fig. 11, adjust VR605 (L-CH) and VR606 (R-CH) to make it sinusoidal. NOTE: The voltage of the output signal after adjustment is about 0.8 to 1.1mVrms.
2 Adjustment of dbx standard level	NOTE: Be sure to perform the standard level adjustment in dbx Encode, followed by the standard level adjustment in dbx Decode.




Fig. 10




Fig. 11

Fig. 6

ITEM	ADJUSTMENT
Condition: * Record/stop mode * Input level controls ... MAX * Noise reduction selector ... disc/dbx tape Equipment: * VTVM * AF oscillator * ATT * Oscilloscope * Resistor (600Ω)	②-1 Standard level adjustment in dbx Encode mode 1. Make the connection as shown in fig. 12 and apply 1kHz -27 dB signal from LINE IN, and set the noise reduction selector to dbx tape position. 2. Set unit to record mode, adjust ATT so that the signal level at TP603 (L-CH) and TP604 (R-CH) is 300 mV. 3. Adjust VR607 (L-CH) and VR608 (R-CH) so that the output signal level at TP605 (L-CH) and TP606 (R-CH) becomes 300 mV ± 0.5 dB. ②-2 Standard level adjustment in dbx Decode mode 1. Make the connection as shown in fig. 12 and apply 1kHz -27 dB signal from LINE IN, and perform the following adjustments. 2. Set the noise reduction selector to disc position, and adjust ATT so that the signal level at TP603 (L-CH) and TP604 (R-CH) becomes 300 mV. 3. Adjust VR609 (L-CH) and VR610 (R-CH) so that the output signal level at TP605 (L-CH) and TP606 (R-CH) becomes 300 mV ± 0.5 dB. ③ Adjustment of output signal distortion factor Condition: * Stop mode * Input level controls ... MAX * Noise reduction selector ... disc Equipment: * VTVM * AF oscilloscope * ATT * Oscilloscope * Resistor (600Ω) * Distortion meter NOTE: After adjustments ①, ② and ③, re-check according to "dbx SYSTEM CHECKING METHOD". If the specifications are not satisfied, perform the adjustments again.

• CHECKING PROCEDURE FOR PROBLEMS

NOTES: Find defective parts according to the circuit operation checking method given below, and use the results for your reference during repair. Remember to adjust after repair.

Keep good condition, set switches and controls in the following positions, unless otherwise specified.

- Input selector: Line in
- Input level controls: Maximum

ITEM	CHECKING METHOD
① Operation check of regulated power supply circuit in dbx circuit Equipment: * DC volt meter * Oscilloscope	①-1 Check of 19V voltage Make the connection as shown in fig. 14 and make sure that the emitter voltage of Q645 is +19V ± 0.5V. (If the voltage is deflected slightly from +19V ± 0.5V, it can be adjusted by VR611.) ①-2 Check of 9.5V voltage Make the connection as shown in fig. 14 and make sure that the emitter voltage of Q647 is around 9.5V.




Fig. 14

ITEM	CHECKING METHOD																																																																																																																						
2 Check of control circuit in dbx circuit Equipment: • DC volt meter	E.C.B (G.S.D) voltage check of each switching transistor for Encode/Decode The terminal voltage of each switching transistor in Encode/Decode mode are shown in the table below. <table><tr><th rowspan="2">Transistor Ref. No.</th><th colspan="3">Encode</th><th colspan="3">Decode</th></tr><tr><th>E (G)</th><th>C (S)</th><th>B (D)</th><th>E (G)</th><th>C (S)</th><th>B (D)</th></tr><tr><td>Q7, 8</td><td>0V</td><td>0V</td><td>0V</td><td>0V</td><td>0V</td><td>0.7V</td></tr><tr><td>Q9, 10, 11, 12</td><td>0V</td><td>9.5V</td><td>9.5V</td><td>0V</td><td>9.5V</td><td>9.5V</td></tr><tr><td>Q601, 602</td><td>0V</td><td>9.43V</td><td>9.43V</td><td>0V</td><td>9.54V</td><td>9.52V</td></tr><tr><td>Q605, 606</td><td>10.7V</td><td>9.7V</td><td>0V</td><td>10.7V</td><td>10.7V</td><td>11.3V</td></tr><tr><td>Q607, 608</td><td>10.7V</td><td>10.7V</td><td>11.3V</td><td>0.3V</td><td>10.7V</td><td>0V</td></tr><tr><td>Q615, 616</td><td>0V</td><td>9.61V</td><td>0V</td><td>9.61V</td><td>9.61V</td><td>10.2V</td></tr><tr><td>Q617, 618</td><td>9.61V</td><td>9.61V</td><td>10.1V</td><td>10.6V</td><td>9.61V</td><td>0V</td></tr><tr><td>Q627, 628</td><td>0V</td><td>9.61V</td><td>9.47V</td><td>0V</td><td>9.59V</td><td>9.58V</td></tr><tr><td>Q637</td><td>0V</td><td>0.2V</td><td>0V</td><td>0V</td><td>0.6V</td><td>0V</td></tr><tr><td>Q638</td><td>0V</td><td>0V</td><td>0.7V</td><td>0V</td><td>0V</td><td>0V</td></tr><tr><td>Q640</td><td>0V</td><td>12.8V</td><td>0V</td><td>0V</td><td>9.15V</td><td>0V</td></tr><tr><td>Q641</td><td>0V</td><td>0V</td><td>0.7V</td><td>0V</td><td>14.2V</td><td>0V</td></tr><tr><td>Q642</td><td>19.1V</td><td>19.1V</td><td>18.4V</td><td>19.1V</td><td>0V</td><td>19.0V</td></tr><tr><td>Q643</td><td>0V</td><td>19.1V</td><td>0.7V</td><td>0V</td><td>0V</td><td>0V</td></tr><tr><td>Q644</td><td>0V</td><td>0.7V</td><td>0V</td><td>0V</td><td>0.1V</td><td>0V</td></tr></table>	Transistor Ref. No.	Encode			Decode			E (G)	C (S)	B (D)	E (G)	C (S)	B (D)	Q7, 8	0V	0V	0V	0V	0V	0.7V	Q9, 10, 11, 12	0V	9.5V	9.5V	0V	9.5V	9.5V	Q601, 602	0V	9.43V	9.43V	0V	9.54V	9.52V	Q605, 606	10.7V	9.7V	0V	10.7V	10.7V	11.3V	Q607, 608	10.7V	10.7V	11.3V	0.3V	10.7V	0V	Q615, 616	0V	9.61V	0V	9.61V	9.61V	10.2V	Q617, 618	9.61V	9.61V	10.1V	10.6V	9.61V	0V	Q627, 628	0V	9.61V	9.47V	0V	9.59V	9.58V	Q637	0V	0.2V	0V	0V	0.6V	0V	Q638	0V	0V	0.7V	0V	0V	0V	Q640	0V	12.8V	0V	0V	9.15V	0V	Q641	0V	0V	0.7V	0V	14.2V	0V	Q642	19.1V	19.1V	18.4V	19.1V	0V	19.0V	Q643	0V	19.1V	0.7V	0V	0V	0V	Q644	0V	0.7V	0V	0V	0.1V	0V
Transistor Ref. No.	Encode			Decode																																																																																																																			
	E (G)	C (S)	B (D)	E (G)	C (S)	B (D)																																																																																																																	
Q7, 8	0V	0V	0V	0V	0V	0.7V																																																																																																																	
Q9, 10, 11, 12	0V	9.5V	9.5V	0V	9.5V	9.5V																																																																																																																	
Q601, 602	0V	9.43V	9.43V	0V	9.54V	9.52V																																																																																																																	
Q605, 606	10.7V	9.7V	0V	10.7V	10.7V	11.3V																																																																																																																	
Q607, 608	10.7V	10.7V	11.3V	0.3V	10.7V	0V																																																																																																																	
Q615, 616	0V	9.61V	0V	9.61V	9.61V	10.2V																																																																																																																	
Q617, 618	9.61V	9.61V	10.1V	10.6V	9.61V	0V																																																																																																																	
Q627, 628	0V	9.61V	9.47V	0V	9.59V	9.58V																																																																																																																	
Q637	0V	0.2V	0V	0V	0.6V	0V																																																																																																																	
Q638	0V	0V	0.7V	0V	0V	0V																																																																																																																	
Q640	0V	12.8V	0V	0V	9.15V	0V																																																																																																																	
Q641	0V	0V	0.7V	0V	14.2V	0V																																																																																																																	
Q642	19.1V	19.1V	18.4V	19.1V	0V	19.0V																																																																																																																	
Q643	0V	19.1V	0.7V	0V	0V	0V																																																																																																																	
Q644	0V	0.7V	0V	0V	0.1V	0V																																																																																																																	
NOTE: If no abnormality is found in steps 1 and 2, check the operation for each part as follows:																																																																																																																							
3 Operation check of INPUT BAND PASS FILTER circuit (27 Hz—20 kHz) Condition: • Record mode • Input level controls ... MAX • Noise reduction selector ... dbx tape Equipment: • VTVM • AF oscillator • ATT • Oscilloscope • Resistor (600Ω)	TP603 (L-CH) TP604 (R-CH) dbx circuit board Q603 (L-CH) Q604 (R-CH) VTVM Oscilloscope AF oscillator ATT 600Ω Resistor LINE IN TP609 VTVM Oscilloscope dbx circuit board Fig. 15 1. Make the connections as shown in fig. 15, and apply 100Hz —27 dB signal from LINE IN, and set the noise reduction selector to dbx tape position. 2. Set the unit to record mode. 3. Adjust ATT so that the signal level at TP603 (L-CH) and TP604 (R-CH) is 300 mV. 4. Make sure that the emitter signal level of Q603 (L-CH) and Q604 (R-CH) is 300 mV. 5. Set the input signal frequency to 5 kHz and make sure that the emitter signal of Q603 (L-CH) and Q604 (R-CH) remains at the same level (300 mV).																																																																																																																						
4 Operation check of VCA circuit and Pre-emphasis/De-emphasis circuit Condition: • Stop/record mode • Input level controls ... MAX • Noise reduction selector ... disc/dbx tape Equipment: • VTVM • AF oscillator • ATT • Oscilloscope • Resistor (600Ω)	4-1 Operation check of VCA circuit and Pre-emphasis circuit 1. Make the connections as shown in fig. 16, and apply 100Hz —27 dB signal from LINE IN. 2. Short-circuit both terminals of VR603 (L-CH) and VR604 (R-CH) as shown in fig. 17 to make the VCA control voltage 1/2 Vcc (9.5 V), so that the gain of VCA does not change. 3. Set the unit to record mode, and set the noise reduction selector to dbx tape position. 4. Adjust ATT so that the signal level at TP603 (L-CH) and TP604 (R-CH) is 300 mV. 5. Make sure that the output signals at TP605 (L-CH) and TP606 (R-CH) are sinusoidal. (The operation of VCA can then be checked.) TP603 (L-CH) TP604 (R-CH) LINE IN TP605 (L-CH) TP606 (R-CH) AF oscillator ATT 600Ω Resistor dbx circuit board VTVM Oscilloscope Fig. 16 dbx circuit board Connection wire Connection wire Fig. 17																																																																																																																						




Fig. 15




Fig. 16







Fig. 17


ITEM
⑤ Operation check of RMS FILTER (27 Hz—10 kHz) Condition: * Stop mode * Input level controls ... MAX * Noise reduction selector ... disc Equipment: * VTVM * AF oscillator * ATT * Oscilloscope * Resistor (600Ω)

ITEM	CHECKING METHOD																																																																																																																						
2 Check of control circuit in dbx circuit Equipment: • DC volt meter	E.C.B (G.S.D) voltage check of each switching transistor for Encode/Decode The terminal voltage of each switching transistor in Encode/Decode mode are shown in the table below. <table><tr><th rowspan="2">Transistor Ref. No.</th><th colspan="3">Encode</th><th colspan="3">Decode</th></tr><tr><th>E (G)</th><th>C (S)</th><th>B (D)</th><th>E (G)</th><th>C (S)</th><th>B (D)</th></tr><tr><td>Q7, 8</td><td>0V</td><td>0V</td><td>0V</td><td>0V</td><td>0V</td><td>0.7V</td></tr><tr><td>Q9, 10, 11, 12</td><td>0V</td><td>9.5V</td><td>9.5V</td><td>0V</td><td>9.5V</td><td>9.5V</td></tr><tr><td>Q601, 602</td><td>0V</td><td>9.43V</td><td>9.43V</td><td>0V</td><td>9.54V</td><td>9.52V</td></tr><tr><td>Q605, 606</td><td>10.7V</td><td>9.7V</td><td>0V</td><td>10.7V</td><td>10.7V</td><td>11.3V</td></tr><tr><td>Q607, 608</td><td>10.7V</td><td>10.7V</td><td>11.3V</td><td>0.3V</td><td>10.7V</td><td>0V</td></tr><tr><td>Q615, 616</td><td>0V</td><td>9.61V</td><td>0V</td><td>9.61V</td><td>9.61V</td><td>10.2V</td></tr><tr><td>Q617, 618</td><td>9.61V</td><td>9.61V</td><td>10.1V</td><td>10.6V</td><td>9.61V</td><td>0V</td></tr><tr><td>Q627, 628</td><td>0V</td><td>9.61V</td><td>9.47V</td><td>0V</td><td>9.59V</td><td>9.58V</td></tr><tr><td>Q637</td><td>0V</td><td>0.2V</td><td>0V</td><td>0V</td><td>0.6V</td><td>0V</td></tr><tr><td>Q638</td><td>0V</td><td>0V</td><td>0.7V</td><td>0V</td><td>0V</td><td>0V</td></tr><tr><td>Q640</td><td>0V</td><td>12.8V</td><td>0V</td><td>0V</td><td>9.15V</td><td>0V</td></tr><tr><td>Q641</td><td>0V</td><td>0V</td><td>0.7V</td><td>0V</td><td>14.2V</td><td>0V</td></tr><tr><td>Q642</td><td>19.1V</td><td>19.1V</td><td>18.4V</td><td>19.1V</td><td>0V</td><td>19.0V</td></tr><tr><td>Q643</td><td>0V</td><td>19.1V</td><td>0.7V</td><td>0V</td><td>0V</td><td>0V</td></tr><tr><td>Q644</td><td>0V</td><td>0.7V</td><td>0V</td><td>0V</td><td>0.1V</td><td>0V</td></tr></table>	Transistor Ref. No.	Encode			Decode			E (G)	C (S)	B (D)	E (G)	C (S)	B (D)	Q7, 8	0V	0V	0V	0V	0V	0.7V	Q9, 10, 11, 12	0V	9.5V	9.5V	0V	9.5V	9.5V	Q601, 602	0V	9.43V	9.43V	0V	9.54V	9.52V	Q605, 606	10.7V	9.7V	0V	10.7V	10.7V	11.3V	Q607, 608	10.7V	10.7V	11.3V	0.3V	10.7V	0V	Q615, 616	0V	9.61V	0V	9.61V	9.61V	10.2V	Q617, 618	9.61V	9.61V	10.1V	10.6V	9.61V	0V	Q627, 628	0V	9.61V	9.47V	0V	9.59V	9.58V	Q637	0V	0.2V	0V	0V	0.6V	0V	Q638	0V	0V	0.7V	0V	0V	0V	Q640	0V	12.8V	0V	0V	9.15V	0V	Q641	0V	0V	0.7V	0V	14.2V	0V	Q642	19.1V	19.1V	18.4V	19.1V	0V	19.0V	Q643	0V	19.1V	0.7V	0V	0V	0V	Q644	0V	0.7V	0V	0V	0.1V	0V
Transistor Ref. No.	Encode			Decode																																																																																																																			
	E (G)	C (S)	B (D)	E (G)	C (S)	B (D)																																																																																																																	
Q7, 8	0V	0V	0V	0V	0V	0.7V																																																																																																																	
Q9, 10, 11, 12	0V	9.5V	9.5V	0V	9.5V	9.5V																																																																																																																	
Q601, 602	0V	9.43V	9.43V	0V	9.54V	9.52V																																																																																																																	
Q605, 606	10.7V	9.7V	0V	10.7V	10.7V	11.3V																																																																																																																	
Q607, 608	10.7V	10.7V	11.3V	0.3V	10.7V	0V																																																																																																																	
Q615, 616	0V	9.61V	0V	9.61V	9.61V	10.2V																																																																																																																	
Q617, 618	9.61V	9.61V	10.1V	10.6V	9.61V	0V																																																																																																																	
Q627, 628	0V	9.61V	9.47V	0V	9.59V	9.58V																																																																																																																	
Q637	0V	0.2V	0V	0V	0.6V	0V																																																																																																																	
Q638	0V	0V	0.7V	0V	0V	0V																																																																																																																	
Q640	0V	12.8V	0V	0V	9.15V	0V																																																																																																																	
Q641	0V	0V	0.7V	0V	14.2V	0V																																																																																																																	
Q642	19.1V	19.1V	18.4V	19.1V	0V	19.0V																																																																																																																	
Q643	0V	19.1V	0.7V	0V	0V	0V																																																																																																																	
Q644	0V	0.7V	0V	0V	0.1V	0V																																																																																																																	









NOTE:
 If no abnormality is found in steps 1 and 2, check the operation for each part as follows:

3 Operation check of INPUT BAND PASS FILTER circuit (27 Hz—20 kHz) Condition: • Record mode • Input level controls ... MAX • Noise reduction selector ... dbx tape Equipment: • VTVM • AF oscillator • ATT • Oscilloscope • Resistor (600Ω)	- Make the connections as shown in fig. 15, and apply 100Hz —27 dB signal from LINE IN, and set the noise reduction selector to dbx tape position. - Set the unit to record mode. - Adjust ATT so that the signal level at TP603 (L-CH) and TP604 (R-CH) is 300mV. - Make sure that the emitter signal level of Q603 (L-CH) and Q604 (R-CH) is 300mV. - Set the input signal frequency to 5kHz and make sure that the emitter signal of Q603 (L-CH) and Q604 (R-CH) remains at the same level (300mV).  Fig. 15
--	--

4 Operation check of VCA circuit and Pre-emphasis/De-emphasis circuit Condition: • Stop/record mode • Input level controls ... MAX • Noise reduction selector ... disc/dbx tape Equipment: • VTVM • AF oscillator • ATT • Oscilloscope • Resistor (600Ω)	4-1 Operation check of VCA circuit and Pre-emphasis circuit - Make the connections as shown in fig. 16, and apply 100Hz —27 dB signal from LINE IN. - Short-circuit both terminals of VR603 (L-CH) and VR604 (R-CH) as shown in fig. 17 to make the VCA control voltage 1/2 Vcc (9.5V), so that the gain of VCA does not change. - Set the unit to record mode, and set the noise reduction selector to dbx tape position. - Adjust ATT so that the signal level at TP603 (L-CH) and TP604 (R-CH) is 300mV. - Make sure that the output signals at TP605 (L-CH) and TP606 (R-CH) are sinusoidal. (The operation of VCA can then be checked.)  Fig. 16  Fig. 17
---	---

ITEM	CHECKING METHOD
	- Shift the frequency of input signal to 5kHz, and make sure that the output signal levels at TP605 (L-CH) and TP606 (R-CH) are increased by about 12 dB. (The operation of the Pre-emphasis circuit can then be checked.) 4-2 Operation check of VCA circuit and De-emphasis circuit - The procedure is the same as 1—2 for the above VCA circuit and Pre-emphasis circuit. - Set the noise reduction selector to disc position. - Adjust ATT so that the signal level at TP603 (L-CH) and TP604 (R-CH) is 300mV. - Make sure that the output signals at TP605 (L-CH) and TP606 (R-CH) are sinusoidal. (The operation of VCA can then be checked.) - Change the frequency of input signal to 5kHz and make sure that the output signal level at TP605 (L-CH) and TP606 (R-CH) is decreased by about 12 dB. (The operation of the De-emphasis circuit can then be checked.) NOTE: After check, disconnect the short-circuited terminals of VR603 (L-CH) and VR604 (R-CH).
5 Operation check of RMS FILTER circuit (27 Hz—10 kHz) Condition: • Stop mode • Input level controls ... MAX • Noise reduction selector ... disc Equipment: • VTVM • AF oscillator • ATT • Oscilloscope • Resistor (600Ω)	- Make the connections as shown in fig. 18, and apply 100Hz —27 dB signal from LINE IN. - Set the noise reduction selector to disc position. - Adjust ATT so that the signal level at TP603 (L-CH) and TP604 (R-CH) is 300mV. - Make sure that the emitter signal level of Q619 (L-CH) and Q620 (R-CH) is around 300mV. - Change the frequency of input signal to 5kHz and make sure that the emitter signal of Q619 (L-CH) and Q620 (R-CH) remains at the same level (300mV).  Fig. 18

ELECTRICAL PARTS LOCATION




REPLACEMENT PARTS LIST

Important safety notice
Components identified by Δ mark have special characteristics important for safety.
When replacing any of these components, use only manufacturer's specified parts.

Ref. No.	Part No.	Part Name & Description
ELECTRICAL PARTS		
E1	QWY4123Z	Record/Playback Head
E2	QWY2133Z	Erase Head
E3	QMA3578	Power Switch Angle
E4	EMR201	Plunger
E5	XTN3+6B	Screw $\phi 3 \times 6$
E6	Δ SJA88	AC Power Cord
*For all European areas except United Kingdom.		
Δ QFC1205M		
*For United Kingdom.		
Δ QFC1208M		
*For Australia.		
E7	QTS00054	Shield Plate
E8	QTD1164	Cord Clamper
E9	QMA3577	Transformer Angle
E10	QTS00050	Shield Plate
E11	Δ QMA3944	Fuse Angle
*For all European areas.		
E12	Δ QTF1039	Fuse Holder
*For all European areas.		
E13	QJP1921TN	3 Pin Post
E14	QJP1923TN	9 Pin Post
E15	QTHM0010	Heat Sink
E16	QSL5006RF	Fluorescent Level Meter
E17	QJP1922TN	6 Pin Post
E18	QTS1494	Shield Plate (for Input Level Control VR)
E19	QMAM0131	Push Switch Angle (for S2 and S5)
E20	QJT1067	Check Pin
E21	QKJ0388	LED Holder (for D225, D226 and D227)
E22	QTH1088	Heat Sink
E23	QMA3866	Hall IC Angle
E25	QTH1151	Heat Sink (for IC301)
E26	QGO00041	Push Button (for S210)
E27	QMA3867	Angle
E28	QMA3872	Jack Holder
E29	QJC0021	Earth Plate
E30	QJC0020	"
E31	QBG1366	Rubber Cushion
E32	QKJM0051	Pilot Lamp Cover
E33	XTN3+10B	Screw $\phi 3 \times 10$
E34	XSN3+10BVS	"
E35	QBG1228	Rubber Bush
E36	XSN3+8S	Screw $\phi 3 \times 8$
E37	XWA3B	Washer
E38	XWG3	"
E39	XTS3+10B	Screw $\phi 3 \times 10$
E40	XSN3+6S	Screw $\phi 3 \times 6$
E41	QJT1054	Contact
E42	QMR1825	Switch Rod
E43	XNS8	Nut
E44	XWS8AW	Washer
E45	XNS9	Nut
E46	XNG3ES	"
E47	QNG1070	"
E48	XSS3+6S	Screw $\phi 3 \times 6$
E49	QTTM011	Spacer
E50	XSN4+10	Screw $\phi 4 \times 10$
E51	XWA4B	Washer
E52	QJS1921TN	3 Pin Housing
E53	QJS1922TN	6 Pin Housing
E54	QJS1923TN	9 Pin Housing
E55	XNG4ES	Nut
E56	QSR0401	Rotary Selector (for Switching S3)
E57	QBJ1425	Cord Bushing
E58	QJT4017	4 Pin Terminal
E59	QMA3945	Terminal Angle
E60	XSB3+20BNS	Screw $\phi 3 \times 20$
E61	QTW1195	Spark Killer Cover
E62	Δ QZE0003	Porcelain Tube
*For all European areas.		

SCHEMATIC DIAGRAM MAIN AMP SECTION



NOTES:

- (2%) presents allowable resistance range of resistor used.
e.g. R665 220 (2%) → 220±4.4(Ω)
- Mark represents switching transistor for changing connections of blocks in the dbx circuit.
- Circuit constructions for encoding, decoding and disc are different as shown in page 10.

e.g. "E.ON" shows ON condition during Encode mode. →

"De.ON" shows ON condition during Decode mode. →

"Di.ON" shows ON condition during Disc mode. →

"Di.OFF" shows OFF condition during Disc mode. →

E.ON

De.ON

Di.ON

Di.OFF

SPECIFICATIONS

- Input level controls ... MAX
- Output level control ... MAX

Playback S/N ratio Test tape ... QZZCFM	Greater than 47 dB
Overall distortion Test tape ... QZZCRA for Normal ... QZZCRX for CrO ₂ ... QZZCRY for Fe-Cr ... QZZCRZ for Metal	Less than 3% (Normal) Less than 3.5% (CrO ₂ , Fe-Cr, Metal)
Overall S/N ratio Test tape ... QZZCRA	Greater than 45 dB (without NAB filter)

NOTES: RESISTORS

ERD...Carbon
ERG...Metal-oxide
ERS...Metal-oxide
ERO...Metal-film
ERX...Metal-film
ERQ...Fuse type metallic
ERC...Solid
ERF...Cement


CAPACITORS

ECBA...Ceramic
ECG...Ceramic
ECK...Ceramic
ECC...Ceramic
ECFO...Ceramic
ECQM...Polyester film
ECQE...Polyester film


ECQF...Polypropylene
ECE...Electrolytic
ECEN...Non polar electrolytic
ECQS...Polystyrene
ECS...Tantalum
QCS...Tantalum

EQUIVALENT CIRCUIT


IC1, 2 NE645B



IC4 AN6870



IC5 AN6552




REPLACEMENT PARTS LIST

Important safety notice

Components identified by Δ mark have special characteristics important for safety. When replacing any of these components, use only manufacturer's specified parts.

Ref. No.	Part No.	Ref. No.	Part No.	Ref. No.	Part No.
RESISTORS					
R1, 2, 3, 4	ERD25FJ100	R157, 158	ERD25TJ683	R227	ERD25FJ561
R5, 6	ERD25TJ223	R159	ERD25FJ102	R228	ERD25FJ562
R7, 8	ERD25TJ101	R160	ERD25FJ562	R229	ERD25FJ562
R9, 10	ERD25FJ560	R161, 162	ERD25FJ103	R230	ERD25FJ101
R11, 12	ERD25CKF1003	R163	ERD25FJ682	R231	ERG12ANJ220
R13, 14	ERD25FJ822	R166	ERD25FJ332	R232	ERD25FJ282
R15, 16	ERD25TJ124	R167	ERD25FJ180	R233, 234	ERD25FJ102
R17, 18	ERD25FJ682	R168, 169	ERD25TJ683	R235	ERD25FJ282
R19, 20	ERD25TJ104	R170, 171	ERD25TJ683	R236	ERD25FJ222
R21, 22	ERD25FJ472				
R23, 24	ERD25TJ473				
R25, 26	ERD25FJ472				
R27, 28	ERD25FJ221				
R29, 30	ERD25FJ472				
R31, 32	ERD25FJ562				
R33, 34	ERD25TJ224				
R35, 36	ERD25FJ103				
R37, 38, 39, 40	ERD25TJ823				
R41, 42	ERD25TJ104				
R43, 44	ERD25TJ274				
R45, 46	ERD25TJ473				
R47, 48	ERD25TJ684				
R49, 50	ERD25FJ332				
R51, 52	ERD25FJ101				
R53, 54, 55, 56	ERD25FJ102				
R57, 58	ERD25TJ184				
R59, 60	ERD25TJ274				
R61, 62	ERD25FJ181				
R63, 64, 65, 66	ERD25TJ223				
R67, 68	ERD25TJ104				
R69, 70	ERD25TKG2702				
R71, 72	ERD25TKG1003				
R73, 74	ERD25FJ102				
R75, 76	ERD25TJ224				
R77, 78	ERD25FJ332				
R79, 80, 81, 82	ERD25FJ682				
R83, 84	ERD25FJ392				
R85, 86	ERD25TJ473				
R87, 88	ERD25TJ684				
R89, 90	ERD25FJ272				
R91, 92	ERD25FJ681				
R93, 94	ERD25FJ680				
R95, 96	ERD25FJ271				
R97, 98	ERD25FJ102				
R99, 100	ERD25FJ472				
R101, 102	ERD25FJ332				
R103, 104, 105, 106, 107, 108	ERD25FJ330				
R109, 110	ERD25FJ152				
R111, 112	ERD25TJ183				
R115, 116	ERD25TJ104				
R117, 118, 119, 120	ERD25FJ102				
R121, 122	ERD25FJ121				
R123, 124, 125, 126	ERD25TJ473				
R150	ERD25FJ102				
R151	ERG12ANJ151				
R152	ERD25TJ153				
R153	ERD25FJ220				
R154	ERD25FJ681				
R155	ERG12ANJ221				
R156	ERG12ANJ151				
R157	ERG12ANJ151				
R158	ERG12ANJ151				
R159	ERG12ANJ151				
R160	ERG12ANJ151				
R161	ERG12ANJ151				
R162	ERG12ANJ151				
R163	ERG12ANJ151				
R164	ERG12ANJ151				
R165	ERG12ANJ151				
R166	ERG12ANJ151				
R167	ERG12ANJ151				
R168	ERG12ANJ151				
R169	ERG12ANJ151				
R170	ERG12ANJ151				
R171	ERG12ANJ151				
R172	ERG12ANJ151				
R173	ERG12ANJ151				
R174	ERG12ANJ151				
R175	ERG12ANJ151				
R176	ERG12ANJ151				
R177	ERG12ANJ151				
R178	ERG12ANJ151				
R179	ERG12ANJ151				
R180	ERG12ANJ151				
R181	ERG12ANJ151				
R182	ERG12ANJ151				
R183	ERG12ANJ151				
R184	ERG12ANJ151				
R185	ERG12ANJ151				
R186	ERG12ANJ151				
R187	ERG12ANJ151				
R188	ERG12ANJ151				
R189	ERG12ANJ151				
R190	ERG12ANJ151				
R191	ERG12ANJ151				
R192	ERG12ANJ151				
R193	ERG12ANJ151				
R194	ERG12ANJ151				
R195	ERG12ANJ151				
R196	ERG12ANJ151				
R197	ERG12ANJ151				
R198	ERG12ANJ151				
R199	ERG12ANJ151				
R200	ERG12ANJ151				
R201	ERG12ANJ151				
R202	ERG12ANJ151				
R203	ERG12ANJ151				
R204	ERG12ANJ151				
R205	ERG12ANJ151				
R206	ERG12ANJ151				
R207	ERG12ANJ151				
R208	ERG12ANJ151				
R209	ERG12ANJ151				
R210	ERG12ANJ151				
R211	ERG12ANJ151				
R212	ERG12ANJ151				
R213	ERG12ANJ151				
R214	ERG12ANJ151				
R215	ERG12ANJ151				
R216	ERG12ANJ151				
R217	ERG12ANJ151				
R218	ERG12ANJ151				
R219	ERG12ANJ151				
R220	ERG12ANJ151				
R221	ERG12ANJ151				
R222	ERG12ANJ151				
R223	ERG12ANJ151				
R224	ERG12ANJ151				
R225	ERG12ANJ151				
R226	ERG12ANJ151				

Ref. No.	Part No.	Ref. No.	Part No.	Ref. No.	Part No.
R320	ERD25FJ391	R778	ERD25FJ392	C99, 100	ECEA1ES101
R321	ERD25FJ391	R779, 780	ERD25FJ393	C101, 102	ECCD1H181K
R322	ERD25FJ391	R781	ERD25FJ332	C130, 131, 132	ECEA1ES101
R323	ERD25TJ123	R782	ERD25FJ122	C133	ECEA1ES471
R324	ERD25VKG1203	R783	ERD25FJ221	C134	ECEA5021
R601, 602	ERD25FJ390	R785, 786	ERD25FJ103	C135	ECKD1H223ZF
R607, 608	ERD25FJ101	R787, 788	ERD25TJ473	C136	ECEA5021
R611, 612, 613, 614	ERD25FJ101	R789, 790	ERD25FJ221	C137	ECEA502R33
R615, 616	ERD25TJ224	R791, 792	ERD25FJ390	C138	ECFQ4333KZ
R617, 618	ERD25FJ472	R793	ERD25FJ392	C139	ECFDD104KXY
R619, 620	ERD25TJ333	R797, 798, 799	ERD25TJ223	C140, 141	ECQM1H822KZ
R621, 622	ERD25FJ103				
R623, 624	ERD25TJ824				
R625, 626	ERD25FJ822				
R627, 628	ERD25TJ393				
R629, 630	ERD25TJ683				
R631, 632	ERD25TJ333				
R633, 634, 635, 636	ERD25FJ103				
R637, 638	ERD25FJ221				
R639, 640	ERD25FJ332				
R641, 642	ERD25FJ391				
R643, 644	ERD25FJ102				
R645, 646	ERD25FJ103				
R647, 648	ERD25TKG3302				
R649, 650, 651, 652	ERD25TJ473				
R653, 654	ERD25FJ391				
R655, 656	ERD25FJ102				
R657, 658	ERD25TKG2200				
R659, 660	ERD25TJ224				
R661, 662	ERD25FJ472				
R663, 664	ERD25FJ390				
R665, 666, 667, 668, 669, 670	ERD25TKG2200				
R671, 672	ERD25TJ473				
R673, 674	ERD25TJ333				
R675, 676	ERD25TJ224				
R677, 678	ERD25FJ472				
R679, 680	ERD25TJ184				
R681, 682	ERD25TJ333				
R683, 684	ERD25FJ682				
R685, 686	ERD25FJ822				
R687, 688	ERD25FJ332				
R689, 690	ERD25TJ333				
R691, 692	ERD25FJ391				
R693, 694	ERD25FJ181				
R695, 696	ERD25FJ103				
R697, 698	ERD25FJ221				
R699, 700	ERD25FJ332				
R701, 702	ERD25FJ391				
R703, 704	ERD25FJ392				
R705, 706	ERD25TJ473				
R707, 708	ERD25TKG1002				
R709, 710	ERD25TJ225				
R711, 712	ERD25TKG2002				
R713, 714	ERD25TJ105				
R715, 716	ERD25FJ392				
R717, 718	ERD25FJ332				
R719, 720	ERD25FJ393				
R721, 722	ERD25TJ564				
R723, 724	ERD25FJ103				
R725, 726	ERD25TJ224				
R727, 728, 729, 730	ERD25FJ103				
R731, 732	ERD25TJ104				
R733, 734	ERD25TJ105				
R735, 736, 737, 738	ERD25TJ473				
R739, 740	ERD25TKG3901				
R741, 742	ERD25TKG4701				
R743, 744	ERD25TKG5100				
R745, 746	ERD25TKG4701				
R747, 748	ERD25TJ122				
R761	ERD25TJ153				
R762	ERD25TJ104				
R763, 764	ERD25TJ473				
R766, 767	ERD25TJ473				
R768	ERD25FJ682				
R770, 771	ERD25TJ104				
R772, 773, 774	ERD25TJ473				
R775	ERD25TJ333				
R776	ERD25FJ222				
R777	ERD25TJ473				

CIRCUIT BOARD
MAIN AMP
CIRCUIT BOARD

ene
c
electrolytic
eat for safety.
ified parts.

Part No.

RD25FJ561

RD25FJ562

RD25FJ222

RD25FJ101

RG12ANJ220

RD25FJ2R2

RD25FJ102

RD25FJ2R2

RD25FJ222

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102


RD25FJ102

RD25FJ102

RD25FJ102

RD25FJ102





RD25FJ102

CIRCUIT BOARD
MAIN AMP
CIRCUIT BOARD


* For all European areas

Ref. No.	Part No.	Ref. No.	Part No.	Ref. No.	Part No.	Ref. No.	Part No.	Ref. No.	Part No.	Ref. No.	Part No.	Ref. No.	Part No.	Part Name & Description
C637, 638	ECEA1HS100	Q3, 4	2SC1400E	Q219	2SC2021SF	Q609, 610	2SK30A0	D201, 202, 203, 204	D622	RD24EB4	T1 QLPD44EME AC Power Transformer	QLPD44EME AC Power Transformer	QLPD44EME AC Power Transformer	
C639, 640, 641, 642	ECEA1HS100	Q5, 6, 7, 8	2SC945-Q	Q221	2SB744R	Q611, 612	2SD661U	MA1056	D623	MA1056				
C643, 644	ECQV05104JZ	Q9, 10, 11, 12		*For all European areas.		Q613, 614	2SB641R	MA1056	D624	RVDRD12FB				
C645, 646	ECKD1H331KB			Q222	2SD638S	Q615, 616, 617, 618	2SD1010R	MA161						
C647, 648	ECQV05104JZ	Q13, 14	2SD592NCS	Q223	2SB744R	Q619, 620	2SC2021SF	D205	MA1056	INTEGRATED CIRCUITS				
C649, 650	ECEA1CS221	Q15, 16	2SC945-Q	Q224	2SC1383Q	Q621, 622	2SK30A0	D206, 207	SM112	IC1, 2	NE645B	QLMX1032W Bias Trap Coil	QLMX1032W Bias Trap Coil	
C651, 652	ECQV05104JZ	Q19, 20	2SC1400E	Q225	2SD638R	Q623, 624	2SD661U	D208, 209, 210	MA161	IC3	AN6552			
C653, 654	ECQV05104JZ	Q21, 22	2SD592NCS	Q226	2SC1383Q	Q625, 626	2SB641R	D215	SM112	IC4	AN6870			
C655, 656	ECCD1H221KD	Q23	2SC945-Q	Q227	2SD638S	Q627, 628	2SK68AM	D216	MA161	IC5	NJM4556			
C657, 658	ECEA16M2RRK	Q24, 25	2SD592NCS	Q228	2SC1383Q	Q637, 638, 639, 640, 641	2SC2021SF	D217	RVDRD12FB	IC201	AN6251	L3, 4	QLQX0332K	Peaking Coil
C663	ECEA50ZR22	Q26	2SC1384NCS	Q229	2SD638R	Q642	2SB641R	D218	MA161	IC202	M53200P	L5	QLB0194K	Bias Oscillation Coil
C664	ECEA50ZR1	Q27	2SC945-Q	Q230	2SD638R	Q643, 644	2SC2021SF	D219	MA1100	IC203	M53204P	L8	QZE0013	FG Coil
C665	ECEA1HS470	Q28, 29	2SC2021SF	Q231	2SC2021SF	Q645	2SD794R	D220	MA161	IC204	DN6838	L201	QLQZ1014D	Choke Coil
C666	ECEA1ES101	Q201	2SD836Q	Q232	2SA786RF	Q646	2SB644R	D221	MA1056	IC301	AN6633	L.P.F. 1, 2	SLM219	MPX Filter Coil
C667, 668	ECEA1HS100	Q202	2SC945-Q	Q233	2SC2021SF	Q647	2SD638S	D222	MA161	IC601, 602	BA651	ESA29238 Slide Switch	QSWY204 Push Switch	QSS8403 Slide Switch
C669	ECEA2524R7	*For all European areas.		Q234	2SC2021SF	Q648, 649, 650	2SC2021SF	D223, 224	MA161	IC603, 604	BA652			
C670	ECEA1ES470	*For Australia.		Q235	2SA786RF			D225	TLR206	IC605, 606	NJM4558D			
C671	ECKD1H103ZF	*For Australia.		Q236	2SA786RF			D227	TLG206	IC607, 608	NJM4558DF			
COMBINATION PARTS		Q203, 204	2SD638R	Q237	2SC2021SF	DIODES & RECTIFIERS		D601, 602, 603, 604, 605, 606, 607, 608, 611, 612, 613, 614, 615, 616, 617	D609, 610, 611, 612, 613, 614, 615, 616, 617	HALL ELEMENTS		S3	QSS8403	Slide Switch (Noise Reduction Selector)
R1, 2	EXRP102K562	Q205, 206	2SD946AR	Q238	2SA786RF	D1, 2, 3, 4, 5, 6, 7, 8	MA161			H1, 2	QVZVHE610D3	S4	QSR6402	Rotary Switch (Tape Selector)
X-1	RM6562K	Q207, 208, 209, 210, 211, 212	2SC2021SF	Q239	2SC2021SF	D9	MV121					S201, 202, 203, 204, 205, 206, 207	QSW1111	Push Switch (Control Key Switch)
1, 2	QCR0011	Q215	2SD638R	Q240	2SB744R	D10	MA161					S208	QSB0238	Leaf Switch (Cassette Detection Switch)
TRANSISTORS		Q216	2SB744R	Q241	2SK68AM	D11	RVDRD6R8EB					S209	QSM0067	Micro Switch (Accidental Erase Prevention Switch)
		Q217	2SD638R	Q242	2SC2021SF	D12	MV121							
		Q218	2SC1846R	Q243	2SD1010R	D13, 14, 15, 16, 17	MA161							


7, 608 Q609, 610 D605 Q611, 612 Q613, 614 Q615-618
 (S) 2SK30AO 1S2473T77 2SD661(U,T) 2SB641(R,S) 2SD1010(R,S)
 [MA161] [2SD661U] [2SB641R] [2SD1010R]




IC605, 606, 607, 608, 609



IC601, 602



IC603, 604



NOTES:

- VR601, VR602 VCA distortion adjustment VR.
- VR603, VR604 VCA distortion adjustment VR.
- VR605, VR606 RMS distortion adjustment VR.
- VR607, VR608 dbx standard input level adjustment VR (Encode).
- VR609, VR610 dbx standard level adjustment VR (Decode).
- VR611 DC voltage adjustment VR.
- Resistance are in ohms (Ω), 1/4 watt unless specified otherwise.
 1K = 1,000(Ω), 1M = 1,000k(Ω).
- Capacity are in microfarads (μ F) unless specified otherwise.
 P = Pico-farads.
- The mark (▼) shows test point. e.g. ▼ = Test point 1.
- All voltage values shown in circuitry are under no signal condition and record mode with volume control at minimum position.
 However, the voltage in playback mode is indicated in () when it differs from that in record mode.

For measurement, use VTVM.

- () this arrow indicates the flow of the playback signal.
- () this arrow indicates the flow of the recording signal.
- () this arrow indicates the flow of V.C.A. control signal.
- Described in the schematic diagram are two types of numbers; the supply parts number and production parts number for transistors and diodes.
 One type of number is used for supply parts number and production parts number when they are identical.

e.g. Q619, 620

[2SC2021(SF,RF)] ← Production parts number

[2SC2021SF] ← Supply parts number

D602, 604

1S2473T77 ← Production parts number

[MA161] ← Supply parts number

- The supply parts number is described alone in the replacement parts list.

- (2%) presents allowable resistance range of resistor used.
 e.g. R665 220 (2%) → 220 $\pm$ 4.4(Ω)

- Mark represents switching transistor for changing connections of blocks in the dbx circuit.

- Circuit constructions for encoding, decoding and disc are different as shown in page 10.

e.g. "E.ON" shows ON condition during Encode mode. →

"De.ON" shows ON condition during Decode mode. →


"Di.ON" shows ON condition during Disc mode. →

"Di.OFF" shows OFF condition during Disc mode. →


D B 1K
 For all European areas.
 A 220
 For Australia.

D624
 D B MA1120
 [RVDRD12FB]


D B For all European areas.
 A For Australia.
 D B Only for European areas.




Q646 2SB644(R,S) [2SB644R]
 D611, 612 1S2473T77 [MA161]
 D622 RD24EB4T [RD24EB4]
 D623 MA1056TA [MA1056]

CIRCUIT BOARD
dbx CIRCUIT BOARD

SCHEMATIC DIAGRAM POWER SUPPLY & MAIN CONTROL SECTION



EQUIVALENT CIRCUIT



- NOTES:**
- S201 Rewind button switch.
 - S202 Fast forward button switch.
 - S203 Playback button switch.
 - S204 Pause button switch.
 - S205 Record button switch.
 - S206 Stop button switch.
 - S207 Record mute button switch.
 - S208 Cassette detection switch.
 - S209 Accidental erase prevention switch.
 - S210 Power ON/OFF switch.
 - S211 AC power voltage select switch.
 - VR201 Takeup torque adjustment VR.
 - Resistance are in ohms (Ω), 1/4 watt unless specified otherwise.
 - 1K = 1,000 Ω , 1M = 1,000k(Ω).
 - Capacity are in microfarads (μ F) unless specified otherwise.
 - P = Pico-farads.
 - All voltage values shown in circuitry are under no signal condition and stop mode with volume control at minimum position. However, the voltage in playback mode is indicated in () when it differs from that in record mode. For measurement, use VTVM.

- Important safety notice
Components identified by Δ mark have special characteristics important for safety.
When replacing any of these components, use only manufacturer's specified parts.

- Described in the schematic diagram are two types of numbers; the supply parts number and production parts number for transistors and diodes. One type of number is used for supply parts number and production parts number when they are identical.

- e.g. Q213
(2SA786(RF,QF)) $\leftarrow$ Production parts number
(2SA786RF) $\leftarrow$ Supply parts number

1S2473T77 $\leftarrow$ Production parts number
(MA161) $\leftarrow$ Supply parts number


- The supply parts number is described alone in the replacement parts list.

- Δ For all European areas
 Δ For Australia.

CIRCUIT BOARD

POWER SUPPLY & MAIN CONTROL CIRCUIT BOARD


IC201 (AN6251) equivalent circuit



Relationship of each operation mode with input/output


Operation mode	Input terminal	IC (AN6251)							
		(12) PAUSE OUT	(13) PLAY OUT	(14) REC OUT	(17) D-PLAY OUT	(18) BRK OUT	(20) TMS OUT	(22) FF OUT	(23) REW OUT
REW	(2) REW IN	H	H	H	H	L	H	H	L
FF	(3) FF IN	H	H	H	H	L	H	L	H
PLAY	(8) FWD IN	H	L	H	L	L	H	H	H
PAUSE	(9) PAS IN	L	H	H	H	H	H	H	H
REC	(10) REC IN	H	H	L	H	H	H	H	H
STOP	(6) STOP IN	H	H	H	H	H	H	H	H

* Doesn't become "L" immediately even if playback button pushed; becoming "L" after a slight delay.



CIRCUIT BOARD

POWER SUPPLY & MAIN CONTROL CIRCUIT BOARD




NOTES:


- The circuit shown in on the conductor is + B (bias) circuit.
- The circuit shown in on the conductor indicates printed circuit on the back side of the printed circuit board.
- Values indicated in are under no signal condition and record mode with volume control at minimum position. However, the voltage in playback mode is indicated in () when it differs from that in record mode. For measurement, use VTVM and oscilloscope.
- Described in the circuit board diagram are two types of numbers; the supply parts number and production parts number for transistors. One type of number is used for supply parts number and production parts number when they are identical.
- e.g. Q207
2SC2021(SF,RF) — Production parts number
[2SC2021SF] — Supply parts number
- The supply parts number is described alone in the replacement parts list.

- For all European areas.
- For Australia

SCHEMATIC DIAGRAM CAPSTAN MOTOR SECTION



CIRCUIT BOARD CAPSTAN MOTOR




NOTES:

- VR301.....Tape speed adjustment VR.
- Resistance are in ohms (Ω), 1/4 watt unless specified otherwise.
1K = 1,000 Ω , 1M = 1,000k(Ω).
- Capacity are in microfarads (μ F) unless specified otherwise.
P = Pico-farads.
- ($\Rightarrow$) this arrow indicates the flow of position detection signal.
- ($\Rightarrow$) this arrow indicates the flow of armature coil driving signal.
- All voltage values shown in circuitry are under no signal condition and record mode with volume control at minimum position.
- For measurement, use VTVM and oscilloscope.
- Described in the schematic diagram are two types of numbers; the supply parts number and production parts number for transistors and diodes. One type of number is used for supply parts number and production parts number when they are identical.


e.g. Q305
2SB744Q(R,S) ← Production parts number
[2SB744Q] ← Supply parts number

1S2473T77 ← Production parts number
[MA161] ← Supply parts number



- The supply parts number is described alone in the replacement parts list.



CIRCUIT BOARD CAPSTAN MOTOR CIRCUIT BOARD




WIRING CONNECTION DIAGRAM



* For all Euro

MECHANICAL PARTS LOCATION




REPLACEMENT PARTS LIST

Ref. No.	Part No.	Part Name & Description	Ref. No.	Part No.	Part Name & Description	Ref. No.	Part No.	Part Name & Description	Ref. No.	Part No.	Part Name & Description	Ref. No.	Part No.	Part Name & Description
MECHANICAL PARTS			M22	XSN3+6S	Screw $\pm 3 \times 6$	M45	QH1182	Step Screw	M68	QML3575	Connector Lever	M91	XSN26+6	Screw $\pm 2.6 \times 6$
M1	QXK2203	Head Base Plate	M23	QDG1128	FG Plate-1	M46	MDN7R	Reel Motor	M69	QBP1872	Steel Ball Holder	M92	XSN3+5S	Screw $\pm 3 \times 5$
M2	QMZ1238	Head Holder	M24	QMF2096	FG Plate-2	M47	QXL1188	Eject Lever Assembly	M70	QTS1491	Shield Plate	M93	XWA3B	Spring Washer
M3	QBCA0008	Head Spring	M25	QSF0013	FG Magnet	M48	QDP1758	Roller				M94	XSN2+6	Screw $\pm 2 \times 6$
M4	QMC0104	Collar	M26	QML3273	Brake	M49	QXA0714	Detection Angle Assembly				M95	XWA2B	Spring Washer
M5	QH1296	Head Adjustment Screw	M27	QBG1132	Stopper Rubber	M50	QML3284	Release Lever	M71	QBN1750	Head Base Plate Spring	M96	XSS3+8S	Screw $\pm 3 \times 8$
M6	XSN2+14	Screw $\pm 2 \times 14$	M28	QXL1335	Pressure Roller Assembly				M72	QML3577	Connection Lever	M97	XXE26D3FZ	Screw with Hexagon Hole
M7	QXL1191	Link Lever-A Assembly	M29	QMA3591	Plunger Angle-L				M73	QMH2009	Steel Ball Holder	M98	QBJ3224	Washer
M8	QXL1190	Link Lever-B Assembly	M30	QME0147BG	Plunger				M74	QML1213	Spacer	M99	QBW2012	Poly Washer
M9	QXA0703	Angle-L Assembly				M51	QXA0713	Angle Assembly	M75	QDB0215	Counter Belt	M100	XUC3FT	Stop Ring 3 ϕ
M10	QXA0704	Angle-R Assembly				M52	QML3285	Detection Lever	M76	QBC1272	Back Tension Spring			
			M31	QXR0540	Connection Rod Assembly	M53	QBN1573	Detection Lever Spring	M77	QBT1713	Record Spring			
M11	QXA1006	Holder Angle-L Assembly	M32	QMA3588	Counter Angle	M54	QXA0702	Connector-R Angle Assembly	M78	QBT1405	Lever Spring	M101	XWA26B	Spring Washer
M12	QXA1005	Holder Angle-R Assembly	M33	QXL1337	Idler Lever Assembly	M55	QXL1173	Lock Lever Assembly	M79	QBT1773	Eject Lever Spring	M102	QXC0069	Tape Counter
M13	QMH2027	Cassette Holder-L	M34	QBF1260	Idler Felt	M56	QXD0087	Reel Table Assembly	M80	QBT1441	Pressure Roller Spring	M103	XSS2+4	Screw $\pm 2 \times 4$
M14	QMH2028	Cassette Holder-R	M35	QXi0101	Idler Assembly	M57	QXH0277	Mechanism Cover				M104	XQS26+3FZ	Screw $\pm 2.6 \times 3$
M15	QKJ0384	Cover	M36	QBW2015	Poly Washer	M58	QXA3312	Plunger Angle-R	M81	QBT1369	Playback Rod Spring	M105	QMA3850	Connector Lever Angle-L
M16	QBP1135	Spring Washer	M37	QBC1308	Idler Spring	M59	QBG1593	Cushion Rubber	M82	QBT1642	Record Lever Spring	M106	XSN3+6S	Screw $\pm 3 \times 6$
M17	QBN1734	Cassette Holder Spring	M38	XUC2FT	Stop Ring 2 ϕ	M60	QXF0160	Flywheel Assembly	M83	QH11775	Step Screw	M107	XWA3B	Spring Washer
M18	QMF2200	Cassette Holder Plate	M39	QML3578	Brake Lever				M84	QHQ1297	"	M108	XWG3B	Washer
M19	XSS3+6S	Screw $\pm 3 \times 6$	M40	XUC25FT	Stop Ring 2.5 ϕ	M61	QMA3851	Cord Clamper	M85	QDK1006	Steel Ball 3 ϕ	M109	QBW2008	"
M20	XSN26+4	Screw $\pm 2.6 \times 4$				M62	QMA3321	Lamp Angle	M86	QH1185	Step Screw	M110	QMG0054	Cassette Guide
M21	XSN2+8	Screw $\pm 2 \times 8$				M63	QMA3852	Mechanism Angle	M87	QTD1001	Lug Terminal			
			M41	QXP0599	Magnet Pulley Assembly	M64	QX3571	Pressure Roller Lever Assembly	M88	XWC3B	Washer			
			M42	QXP0600	Friction Pulley	M65	QML3269	Lever-B Assembly	M89	QBW2019	Poly Washer			
			M43	QXH0321	Cassette Holding Cushion	M66	QML3572	Lever-A Assembly	M90	QBW2013	Poly Washer			
			M44	QMA3849	Motor Angle	M67	QML3574	Plunger Lever						


SPECIFICATION

Pressure of pressure roller	400 $\pm$ 50 g
Wow and flutter (JIS)	Less than 0.05%
Test tape ... QZCZCAT	(WRMS)



400 ± 50 g
Less than 0.05%
(WRMS)

CABINET PARTS LOCATION



REPLACEMENT PARTS LIST

Ref. No.	Part No.	Part Name & Description	Ref. No.	Part No.	Part Name & Description	Ref. No.	Part No.	Part Name & Description
CABINET PARTS								
G1	QGC1179S	Case Cover	G5	QYT0590	Volume Knob-A	G17	QGOM0043	Push Button
	"Silver Type"	"	G6	QYT0591	Volume Knob-B	G18	QGSM0147	Main Name Plate
	QGC1179K	"	G7	QYT0617	Volume Knob-C	*For all European areas except United Kingdom.		
	"Black Type"	"	G8	QYT0618	Volume Knob-D	[UK] QGSM0139		
G2	QYPM0047	Front Panel Assembly	G9	XYA4+BJ10FN	Screw $\varnothing 4 \times 10$	*For United Kingdom and Australia.		
	"Silver Type"	"				ACCESSORIES		
	QYPM0044K	"				A1	RP023A	Connection Cord
	"Black Type"	"				A2	QQT3049	Instruction Book
G2-1	QGOM0044	Push Button (rec-mute)	G10	XTN3+10B	Screw $\varnothing 3 \times 10$	*For all European areas except United Kingdom.		
G2-2	QGOM0045	Push Button (stop, play)	G11	QYCM0022	Bottom Cover Assembly	[UK] QQT3097		
G2-3	QGOM0046	Push Button (rec, rew, ff, pause)	G12	QYMM0077K	Main Case	*For United Kingdom.		
G3	QYKM0010	Meter Cover Assembly	G12-1	QMA3865	Control Key Switch Circuit Board	[UK] QQT3011		
G3-1	QYKM0010K	"	G12-2	QXBM0022	Eject Button	*For Australia.		
	"Silver Type"	"	G12-3	QBC1189	Eject Button Spring	PACKINGS		
	"Black Type"	"	G12-4	XUC25FT	Stop Ring	P1	QPNM0167	Inside Carton
	QKJ0387	Meter Cover	G12-5	XTN3+10B	Tapping Screw $\varnothing 3 \times 10$	P2	QPA0450	Cushion-L
G3-2	QBW2008	Washer	G12-6	QJC0025	Earth Plate	P3	QPA0451	Cushion-R
G4	QYFM0050	Cassette Lid	G13	QBH2043	Spacer	P4	XZB50X65A02	Poly Bag
	"Silver Type"	"	G14	QBH0115	"	P5	QPG1985	Pad
	QYFM0050K	"	G15	XTN3+8B	Tapping Screw $\varnothing 3 \times 8$	P6	QPA0461	Spacer
	"Black Type"	"	G16	XTS3+10B	Tapping Screw $\varnothing 3 \times 10$	P7	QPSM0008	Spacer (for Volume Knob)

Service Manual

Cassette Deck

RS-M270X

(Silver Face)
(Black Face)
Supplement-1

dbx* Equipped Direct Drive Cassette Deck with Peak Hold FL Meters, Solenoid Controls, and Dolby Noise Reduction

**



RS-M85 MECHANISM SERIES

- For **D** **B** **A** mark areas, use this manual together with the service manual for model No. RS-M270X (Original) order No. ARD81030031C8-24.
- For **N** **F** **J** mark areas, use this manual together with the service manual for model No. RS-M270X (Original) order No. ARD81020019C7-24.

PARTS COMPARISON TABLE:

Please revise the original parts list in the Service Manual (RS-M270X) to conform to the changes shown herein.

If new part numbers are shown, be sure to use them when ordering parts.


Ref. No.	Part Name & Description	Part Numbers	
		Former Type	New Type
M35	Idler Assembly	QXi0101	QXi0118
M77	Record Spring	QBT1713	QBT1273
M90	Poly Washer	QBW2013	QBW2049
M112	Cushion (Added)	—	QBW2026

This is the Service Manual for the following areas.


- D** ...For all European areas except United Kingdom.
- B** ...For United Kingdom.
- N** ...For Asia, Latin America, Middle East and Africa areas.
- A** ...For Australia.
- F** ...For Asian PX.
- J** ...For European PX.

MECHANICAL PARTS LOCATION

(ADDITION)



Former Type



New Type

*The term dbx is a registered trademark of dbx Inc.

** 'Dolby' and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation.

Technics

Matsushita Electric Trading Co., Ltd.
P.O. Box 288, Central Osaka Japan