



Service Bulletin

No. : MZ08-056

Date: October 3, 2008

Model: CD5003

Subject: Power PWB Modification

Symptom: Should the Power Supply fail replace the Power Supply Board and the Power Supply Relay with the improved parts outlined below.

Solution:

1. Power PWB "PWB No.CUP12097Z-3" has been replaced with "CUP12097Y-3".
2. After replacing the board replace relay "POS.NO. RY01".
3. POS.NO. IC95 (IC) is to be additionally mounted.

Note: Please DO NOT apply this modification to the old PWB (CUP12097Z-3). It is not applicable to the old PWB.

CONFIDENTIALITY NOTICE:

The information contained in this document is intended for the exclusive use by MARANTZ Authorized Service Centers and their employees. This document may contain information that is privileged, confidential and may be protected from disclosure under applicable laws and terms of the MARANTZ Service Agreement. Any distribution, disclosure, dissemination or copying of this document and the information it contains is prohibited. No responsibility will be accepted by MARANTZ for any damage, injury or loss resulting from the misuse of the information contained in this document.


Parts:

Old New	POS. NO.	PART NO. (MZ)	PART NAME	DESCRIPTION
Old	31	nsp	PWB ASSY	POWER PWB ASSY CUP12097Z-3
New	31	nsp	PWB ASSY	POWER PWB ASSY CUP12097Y-3
Old	RY91	90M-LY000340R	RELAY	SDT-S-112DMR Factory code no. HSL1A008ZE
New	RY91	943682004660S	RELAY	G5PA-1 DV6V Factory code no. CSL1E002ZE
Add	IC95	00MHC3890699F	IC	KIA7806API Factory code no. VIKIA7806API

CONFIDENTIALITY NOTICE:

The information contained in this document is intended for the exclusive use by MARANTZ Authorized Service Centers and their employees. This document may contain information that is privileged, confidential and may be protected from disclosure under applicable laws and terms of the MARANTZ Service Agreement. Any distribution, disclosure, dissemination or copying of this document and the information it contains is prohibited. No responsibility will be accepted by MARANTZ for any damage, injury or loss resulting from the misuse of the information contained in this document.


POWER PWB ASSY



Old: POWER PWB No. CUP12097Z-3
New: POWER PWB No. CUP12097Y-3

IC95
to be additionally mounted

RY91
changed



CONFIDENTIALITY NOTICE:

The information contained in this document is intended for the exclusive use by MARANTZ Authorized Service Centers and their employees. This document may contain information that is privileged, confidential and may be protected from disclosure under applicable laws and terms of the MARANTZ Service Agreement. Any distribution, disclosure, dissemination or copying of this document and the information it contains is prohibited. No responsibility will be accepted by MARANTZ for any damage, injury or loss resulting from the misuse of the information contained in this document.

