



Service Bulletin

No. : MZ07-098

Date: October 29, 2007

Model: SR7002, SR8002

Subject: Software Update* Information.

* This update is for only following a minor problem, and is not required for all units.

Symptom: 1. In the MENU setting the set may loose function control when set to 7.1CH INPUT.

2. When the analog audio and HDMI signals are being input simultaneously with DIG = "-" selected from "FUNC INPUT SETUP", the unit is not switched to the analog audio output mode even when out of connection via HDMI.

Solution: The MAIN and HDMI microprocessor software must be updated. First, please check the version of the current firmware in reference to SERVICE MODE of the Service Manual. After performing the update, check the indicated firmware version again.

For information on how to rewrite the firmware, refer to "7. UPDATE FIRMWARE" in the Service Manual.

Firmware version

Ref No.	DATE	MAIN	HDMI	DSP	HDR	
					CPU	ID
MZ07-098	2007.10.29	V070919 2	h33	pa17_c78_070823_1.upd	07082701	07082701

Parts:

Ref#	Description	Part Number
NA	sr8002_Main070919_2.mot	00M36CW499A02
NA	HDMI_REPV3x070913h33.mot	00M36CW499B02

CONFIDENTIALITY NOTICE:

The information contained in this document is intended for the exclusive use by MARANTZ Authorized Service Centers and their employees. This document may contain information that is privileged, confidential and may be protected from disclosure under applicable laws and terms of the MARANTZ Service Agreement. Any distribution, disclosure, dissemination or copying of this document and the information it contains is prohibited. No responsibility will be accepted by MARANTZ for any damage, injury or loss resulting from the misuse of the information contained in this document.

Serial Number Range:

Model	To be serviced	Corrected on production line
SR7002/U1B	MZ000737000001~000650 MZ000739000651~001800	MZ0107**001801~
SR8002/U1B	MZ000737000001~000300 MZ000739000301~000780	MZ0107**000781~

CONFIDENTIALITY NOTICE:

The information contained in this document is intended for the exclusive use by MARANTZ Authorized Service Centers and their employees. This document may contain information that is privileged, confidential and may be protected from disclosure under applicable laws and terms of the MARANTZ Service Agreement. Any distribution, disclosure, dissemination or copying of this document and the information it contains is prohibited. No responsibility will be accepted by MARANTZ for any damage, injury or loss resulting from the misuse of the information contained in this document.